

User Manual

English



Data Acquisition Software

Perception

Version 7.40



Note: When you are using Perception Version 8, some of the information in this manual may be outdated. Especially the acquisition modes described in chapter **"5 Acquisition Control and Status"** on page 113 and appendix **"A Acquisition and Storage"** on page 483 have been updated in Perception Version 8. For more information on new acquisition modes, please visit the Perception product page for the document "Perception V8 Acquisition Modes Quick Start".

Document version 9.0 - October 2021

For HBK's Terms and Conditions visit www.hbm.com/terms

Hottinger Brüel & Kjaer GmbH
Im Tiefen See 45
64293 Darmstadt
Germany
Tel: +49 6151 80 30
Fax: +49 6151 8039100
Email: info@hbm.com
www.hbm.com/highspeed

Copyright © 2021

All rights reserved. No part of the contents of this document may be reproduced or transmitted in any form or by any means without the written permission of the publisher.

LICENSE AGREEMENT AND WARRANTY

For information about LICENSE AGREEMENT AND WARRANTY refer to www.hbm.com/terms.

Table of Contents		Page
1	Getting Started	26
1.1	Introduction	26
1.2	Requirements	29
1.2.1	Supported acquisition hardware	29
1.2.2	System performance tests	30
1.3	Installing the software	31
1.3.1	Install Perception	31
1.3.2	Conventions	32
1.4	Starting Perception	33
1.4.1	Start Perception	33
1.4.2	Perception user modes	33
1.5	What's new in Perception	34
2	Perception Concepts	35
2.1	Introduction	35
2.2	Virtual Workbench	36
2.2.1	Active display	36
2.2.2	User sheet	36
2.3	Individual storage of settings	38
2.3.1	Hardware settings	38
2.3.2	Formulas	38
2.3.3	Report layouts	38
2.3.4	Information	39
2.3.5	Other optional software components	39
2.4	Experiment	40
2.5	User interface modes	41
2.5.1	User modes	41
2.5.2	Perception Start-up	42
2.5.2.1	Quick Start	44
2.5.2.2	Start Perception in a specific mode	45
2.5.3	Switch to Instrument Panel	45
2.5.4	Settings sheet layout modes	46
2.6	Data sources	47
2.6.1	Data source types	48
2.6.2	Where are data sources used	49
2.6.3	Data source naming	51

2.6.4	Restricted characters	53
3	The Work Area and Generic Procedures	55
3.1	Introduction	55
3.1.1	Start dialog options	55
3.1.1.1	Start dialog options summary	57
3.2	Getting familiar with your work environment	58
3.2.1	About the work area	58
3.2.2	Notifications	59
3.2.3	Choosing commands	61
3.2.4	Modifying color	62
3.2.5	Insert and format a data source	64
3.3	Using palettes	66
3.3.1	Showing and hiding palettes	66
3.3.2	Moving, docking and sizing palettes	67
3.3.3	Tabbed grouping	69
3.4	Using toolbars	70
3.5	Working with sheets	72
3.5.1	Introduction	72
3.5.2	Sheet management feature	72
3.5.3	Sheet commands and options	75
3.5.4	Active and user sheets	75
3.5.4.1	Layout and splitters	76
3.5.5	Sheets and workbooks	77
4	Navigator Panels	79
4.1	Introduction	79
4.2	Hardware navigation	80
4.2.1	Add and remove a data acquisition system	82
4.2.1.1	To add a data acquisition system:	82
4.2.1.2	Network conflict	84
4.2.1.3	To remove a data acquisition system:	86
4.2.1.4	When you are not sure:	86
4.2.1.5	Password protect a system	86
4.2.1.6	Add an unlisted system	87
4.2.1.7	Enable and disable individual recorders	88
4.2.2	Firmware upgrade	89
4.2.3	Arranging recorders and viewing options	91
4.2.4	Data source selection for display	92

4.3	Recordings navigation	94
4.3.1	Working with archives	95
4.3.1.1	Current acquisition folder	96
4.3.1.2	Open Recordings	97
4.3.1.3	File types	97
4.3.2	Remote access	98
4.3.3	Externally stored recordings	101
4.3.3.1	Mainframes	101
4.3.3.2	Visions	103
4.3.4	Data source selection for display	104
4.3.4.1	Review or Redo and experiment	105
4.3.4.2	Load as Active	106
4.3.4.3	Load as Reference	106
4.3.4.4	Load Using Filename	106
4.3.4.5	Open in new User Sheet	106
4.3.4.6	Close an open recording	107
4.4	Data Sources navigation	108
4.4.1	Data source selection for display and meters	109
4.4.1.1	Search Similar	110
4.5	Properties window	112
5	Acquisition Control and Status	113
5.1	Introduction	113
5.2	Acquisition control	114
5.2.1	Name	117
5.2.2	Acquisition	118
5.2.2.1	More acquisition	119
5.2.3	Status	120
5.2.4	Groups	121
5.2.4.1	Slow Sweep	121
5.2.4.2	Fast Sweeps	122
5.2.4.3	Continuous	123
5.3	Status	125
6	Data Visualization	129
6.1	Introduction	129
6.2	Waveform display fundamentals	130
6.2.1	The Y-annotation area	135
6.2.2	Y-annotation per tick	138

6.2.3	The X-annotation area	139
6.2.4	Control area	142
6.2.4.1	Page control	143
6.2.4.2	Time control	144
6.2.4.3	Replay control	144
6.2.4.4	Cursor values	144
6.2.5	Event/digital traces	145
6.2.6	The waveform display event bar	147
6.3	Waveform display operation	149
6.3.1	Adding traces to a display	149
6.3.1.1	Using the Hardware Navigator	149
6.3.1.2	Using the Recordings Navigator	149
6.3.1.3	Using the Data Source Navigator	149
6.3.1.4	Using Display Setup	150
6.3.2	Drag and drop traces	150
6.3.2.1	Separate combined traces	151
6.3.2.2	Move a trace to a different or new page	153
6.3.3	Modifying the display layout	153
6.3.3.1	Modifying the view arrangement and view type	154
6.3.3.2	Modifying the pane size	156
6.3.4	Zooming and panning	157
6.3.4.1	Using the keyboard and time control to zoom	159
6.3.4.2	Scrolling waveforms on the X-axis	160
6.3.4.3	Mouse wheel support	160
6.3.5	Replay data	161
6.3.5.1	Replay continuous data	161
6.3.5.2	Replay sweep data	162
6.4	Cursors and basic measurements	163
6.4.1	Vertical cursors	165
6.4.1.1	Sample snap	166
6.4.1.2	Auto placement	167
6.4.1.3	Miscellaneous functions	167
6.4.2	Horizontal cursors	169
6.4.3	Slope cursors	170
6.4.4	Cursor measurements	171
6.4.5	Cursor navigation	178
6.4.5.1	Cursor navigation properties	182

6.4.6	Statistical calculations	183
6.5	Waveform display miscellaneous context commands	186
6.5.1	Trace commands	186
6.5.1.1	New Trace	186
6.5.1.2	Insert Trace	186
6.5.1.3	Delete Trace	186
6.5.1.4	Trace Setup	187
6.5.2	Pane commands	187
6.5.2.1	New Pane	187
6.5.2.2	Insert Pane	187
6.5.2.3	Delete Pane	187
6.5.2.4	Pane Setup	188
6.5.3	Page commands	188
6.5.3.1	New Page	188
6.5.3.2	Insert Page	188
6.5.3.3	Delete Page	189
6.5.3.4	Rename Page	189
6.5.3.5	Copy Page as Picture	189
6.5.3.6	Page Setup	189
6.5.3.7	Print Display	190
6.6	Display Setup dialog	191
6.6.1	Display Setup	191
6.6.2	Annotation & Grid	196
6.6.3	Panes Setup	199
6.6.4	Traces Setup	201
6.7	Display markers	207
6.7.1	Trace marker	211
6.7.2	X-range marker	212
6.7.3	Y-range marker	212
6.7.4	Slope marker	213
6.7.5	Time marker	213
6.7.6	Full display marker	214
6.7.7	Slope cursor marker	214
6.7.8	Free float marker	215
6.7.9	Marker properties	215
6.7.10	Automatic markers	217
6.8	External clock support	221

7	Sheet Objects	225
7.1	Introduction	225
7.1.1	Adding and deleting objects	225
7.2	Waveform display	228
7.3	Meters	229
7.3.1	Meter flavors	230
7.3.2	Data sources for meters	230
7.3.2.1	Real-time parameters	230
7.3.2.2	System variables	231
7.3.3	Adding meters to a sheet	231
7.3.3.1	Replacing meters	233
7.3.4	Modifying the layout of a meter array	234
7.3.5	Inserting, deleting and moving individual meters	234
7.3.6	Meter properties	235
7.3.6.1	General	237
7.3.6.2	Value	238
7.3.6.3	Styles & Colors	242
7.3.6.4	Auto Setup	244
7.3.7	Meter miscellaneous features and functions	245
7.3.7.1	Meters and the clipboard	245
7.3.7.2	Page commands	246
7.3.7.3	Using the page control	247
7.4	Images	249
7.5	User tables	252
7.5.1	Creating a user table	253
7.5.2	Inserting data into the user table	253
7.5.2.1	Typing into a cell	253
7.5.2.2	Using the Data Sources Navigator	254
7.5.2.3	Inserting multiple data sources	255
7.5.2.4	Properties and cell distribution	255
7.5.2.5	Dropping an item on a row header	256
7.5.2.6	Overwriting existing data using drag and drop	256
7.5.2.7	Using the Insert Data Source dialog	257
7.5.3	Editing data in the user table	257
7.5.3.1	Typing into a cell	258
7.5.3.2	Using the Data Source Properties dialog	258
7.5.3.3	Modifying the layout of the user table	258

7.5.3.4	Adding rows	258
7.5.3.5	Adding columns	259
7.5.3.6	Deleting rows	259
7.5.3.7	Deleting columns	260
7.5.3.8	Deleting the table	260
7.5.3.9	Clearing cells	261
7.5.3.10	Cell alignment	261
7.5.3.11	Font and font style	261
7.5.4	User table properties	262
7.5.5	User table toolbar	263
7.5.5.1	Posting to Excel	263
7.5.5.2	Posting to Word	264
7.6	XY-display	266
7.6.1	XY-display concepts and components	267
7.6.1.1	Concept	267
7.6.1.2	Pages	267
7.6.1.3	Traces	267
7.6.1.4	Views	267
7.6.1.5	The XY-display view area in detail	269
7.6.1.6	The Y-annotation area	272
7.6.1.7	The X-annotation area	273
7.6.1.8	Control area	273
7.6.1.9	Frame cursor control	274
7.6.2	XY-display operations	274
7.6.2.1	General	274
7.6.2.2	Linked display	275
7.6.2.3	Add or remove traces to or from an XY-display	276
7.6.2.4	Modifying the display layout	276
7.6.2.5	Zooming and panning in the XY-display	277
7.6.2.6	To zoom in:	278
7.6.2.7	To resize a zoom area:	278
7.6.2.8	To move the zoom area:	278
7.6.2.9	To unzoom:	279
7.6.2.10	Replay data	279
7.6.2.11	Interaction between the XY-display and the time display	279
7.6.2.12	Frame cursor	279
7.6.2.13	Linking	281

7.6.3	Cursors and basic measurements	282
7.6.3.1	Cursor measurements	283
7.6.4	XY-display properties	287
7.6.4.1	XY-display settings	288
7.6.5	XY-display shortcut menu	290
7.6.5.1	Link With submenu	291
7.6.5.2	Split submenu	291
7.6.6	Dynamic menu	291
7.6.7	Dynamic toolbar	292
8	More Sheets	293
8.1	Introduction	293
8.2	Information sheet	294
8.2.1	Default information	294
8.2.2	Comment	294
8.2.3	Additional commands	295
8.2.3.1	Load Information	296
8.2.3.2	Save Information	297
8.2.3.3	Refresh comment	297
8.2.3.4	Print Information	298
8.3	Settings sheet	299
8.3.1	Settings sheet layout	299
8.3.2	Modifying settings	303
8.3.2.1	Mixed values	304
8.3.2.2	Modify multiple cells	304
8.3.3	Using the block diagram	305
8.3.4	Additional commands	307
8.3.4.1	Load Default Settings	308
8.3.4.2	Load Settings	308
8.3.4.3	Save Settings	308
8.3.4.4	Resolve All Conflicts	309
8.3.4.5	Bridge Wizard	309
8.3.5	Print Report	313
8.3.6	Network and External storage setup	315
8.3.6.1	Network setup	315
8.3.6.2	To review/update the mainframe network settings:	316
8.3.6.3	Setup external storage	316
8.3.6.4	To setup connection to an external storage device:	317

8.3.7	Power on Setup	317
8.4	Fiber Status sheet	320
8.4.1	Status information	320
8.4.2	Additional commands	326
8.4.2.1	Show Battery Summary	326
8.4.2.2	Show battery details	326
8.4.2.3	Temperature unit	326
8.5	Diagnostic Viewer sheet	327
8.5.1	Operation	327
8.5.2	Commands	328
9	Menus Walkthrough	331
9.1	Introduction	331
9.2	File menu	332
9.2.1	New...	332
9.2.1.1	Start a new work environment	333
9.2.1.2	Set up new blank experiment (1)	334
9.2.1.3	Set up an auto-configured Experiment (2)	334
9.2.1.4	Redo an existing Experiment (3)	335
9.2.1.5	Review a stored experiment (4)	336
9.2.1.6	Hardware not found	336
9.2.1.7	Open an existing workbench	339
9.2.2	Open...	339
9.2.3	Save	339
9.2.4	Save a Copy As...	340
9.2.5	Close	344
9.2.6	Open Virtual Workbench...	344
9.2.7	Save Virtual Workbench	344
9.2.8	Save Virtual Workbench As...	345
9.2.9	Revert to Last Opened Setup	345
9.2.10	Save Configuration for Offline Use...	346
9.2.11	New Sheet	346
9.2.12	Workbook	347
9.2.12.1	New	347
9.2.12.2	Duplicate	347
9.2.12.3	Delete	347
9.2.13	Archives	347
9.2.13.1	Add new folder ...	348

9.2.14	Set and Test current storage location	348
9.2.14.1	Continuous data rate feature	348
9.2.15	Continuous data rate gauge	351
9.2.16	Load Recording...	354
9.2.16.1	Load Recording	355
9.2.16.2	Action	355
9.2.16.3	File Formats	355
9.2.17	Export Recording...	356
9.2.18	Print	363
9.2.19	Preferences...	365
9.2.19.1	User Interface Mode startup options	366
9.2.20	Exit	366
9.2.21	Definer Mode menu	366
9.2.21.1	Introduction to the Definer Mode concept	366
9.2.21.2	How to create a restricted Workbench	368
9.2.21.3	How to change a restricted Workbench	368
9.2.21.4	Detailed description of Definer Mode functionality	369
9.2.21.5	Some details of the effect of restrictions on toolbars and docking panes	385
9.2.21.6	What to do if the Restrictions Password is not known	389
9.2.21.7	Definer Mode use case examples	390
9.3	Edit menu	392
9.3.1	Transfer an object	392
9.3.2	Delete an object	392
9.4	Control menu	393
9.4.1	Basic acquisition control	393
9.4.1.1	Start	393
9.4.1.2	Stop	393
9.4.1.3	Single Shot	393
9.4.1.4	Pause	393
9.4.2	Manual Trigger	394
9.4.3	Voicemark	394
9.4.3.1	How to use the Perception Voicemark feature	395
9.4.4	Zero Balancing	398
9.4.5	Timer for Conditional Start Stop	400
9.4.6	Reboot System(s)	401
9.4.6.1	To reboot a mainframe/system:	402
9.5	Automation menu	404

9.5.1	Logfile	404
9.5.1.1	Manual logging	405
9.5.1.2	Configure Logfile	405
9.5.1.3	Add to Logfile	407
9.5.1.4	Clear Logfile	407
9.5.1.5	Open Logfile in Excel	407
9.5.1.6	Options	408
9.5.2	Process Display	409
9.5.3	Setup Process Display	409
9.5.3.1	Interval selection	410
9.5.3.2	Data source	411
9.5.3.3	Automation actions	411
9.5.4	Recordings Batch Processing	412
9.5.4.1	Interval selection	413
9.5.4.2	Recordings	414
9.5.4.3	Data source	414
9.5.4.4	Automation Actions	414
9.5.5	Automated Recording Processing	414
9.5.5.1	Interval selection	415
9.5.5.2	Data source	416
9.5.5.3	Automation Actions	416
9.5.6	Actions configuration dialogs	416
9.5.6.1	Print Options	419
9.5.6.2	Time base	419
9.5.6.3	Location	419
9.5.7	Automation Progress dialog	423
9.5.8	Merge Files	424
9.5.9	Quick Report to Word	426
9.5.9.1	How it works	428
9.5.9.2	Operation	429
9.6	Window menu	430
9.6.1	Hardware	430
9.6.2	Recording	430
9.6.3	Data Sources	431
9.6.4	Properties	431
9.6.5	Automation Progress	432
9.6.6	Acquisition Controls	432

9.6.7	Battery Status	433
9.6.8	Status	433
9.6.9	Cursor Navigation	434
9.6.10	Toolbars	434
9.7	Help menu	436
9.7.1	Check for Software Updates	436
9.7.2	Update Key...	436
9.7.3	Open Perception Diagnostics Folder	437
9.7.4	Performance Tests...	437
9.7.5	Network Load	438
9.7.6	About Perception	443
10	QuantumX in Perception	445
10.1	Introduction	445
10.2	Supported QuantumX modules	446
10.3	References	448
10.4	Concepts and terminology	449
10.5	How to use a QuantumX module in Perception	454
10.6	Connection basics	456
10.7	Configuring a QuantumX module	460
10.8	First time connecting	461
10.9	Configuring the hardware via the Settings Sheet	466
10.9.1	MX471B specific settings	471
10.9.1.1	Recorder (General group)	471
10.9.1.2	Can-Bus (Input group)	472
10.10	Combining QuantumX and GEN series	474
10.11	Perception with a QuantumX via a CX27B	480
10.11.1	Hardware setup	480
10.11.1.1	Direct connection to an integrated GEN series mainframe	480
10.11.1.2	CX27B combined with a tethered GEN series mainframe and/or other QuantumX modules	481
10.11.2	Synchronization and network setup	481
10.11.3	Miscellaneous information	482
A	Acquisition and Storage	483
A.1	Introduction	483
A.2	Acquisition	485
A.3	Storage	487
A.3.1	More on sweeps	488
A.3.2	Pre-trigger sweeps	490

A.3.3	Fast sweep stretch storage	492
A.3.4	More on continuous data storage	493
A.4	Time base	495
A.4.1	Real-time sampling and time base	495
A.4.2	Time base settings for FFT's	496
A.4.2.1	Additional information	498
B	Digital Trigger Modes	499
B.1	Introduction	499
B.2	Understanding digital triggering	501
B.2.1	Digital trigger detector	501
B.2.2	Valid trigger conditions	503
B.3	Trigger modes	505
B.3.1	Basic trigger mode	505
B.3.2	Dual trigger mode	506
B.3.3	Window trigger mode	507
B.3.4	Dual-window trigger mode	508
B.3.5	Sequential trigger mode	509
B.3.6	Trigger qualifier	510
B.4	Trigger add-ons	511
B.4.1	Slope detector	511
B.4.2	Pulse detector	512
B.4.3	Holdoff	513
B.4.4	Interval timer	514
B.4.4.1	Interval timer - Less	514
B.4.4.2	Interval timer - More	515
B.4.4.3	Interval timer - Between	516
B.4.4.4	Interval timer - NotBetween	517
B.4.5	Event counter	518
B.5	Recorder and system trigger	519
B.6	Channel alarm	521
C	Offline Setup & Configuration Manager	522
C.1	Introduction	522
C.2	Creating offline configuration information	524
C.3	Configuration Manager	525
C.3.1	Moving mainframes	527
C.3.2	Using mainframes	528
C.3.3	Miscellaneous configuration commands	529

C.4	Perception offline setup mode	530
C.4.1	Using the offline setup mode	530
C.5	Hints, tips and techniques	532
C.5.1	Limitations	532
C.5.2	Perception without a key	533
D	Settings Sheet Reference	534
D.1	Settings Sheet – Introduction	534
D.1.1	Conventions	535
D.2	General group	536
D.2.1	Introduction	536
D.2.2	Mainframe	536
D.2.2.1	Introduction	536
D.2.2.2	Basic settings	536
D.2.2.3	Advanced settings	540
D.2.3	Recorder	552
D.2.3.1	Introduction	552
D.2.3.2	Basic settings	552
D.2.3.3	Advanced settings	552
D.2.4	Analog channel	557
D.2.4.1	Introduction	557
D.2.4.2	Basic settings	557
D.2.4.3	Advanced settings	561
D.2.4.4	Advanced settings	561
D.2.5	Marker (Events)	563
D.2.5.1	Introduction	563
D.2.6	Timer/Counter	567
D.2.6.1	Introduction	567
D.2.6.2	Basic settings	568
D.2.6.3	Advanced settings	569
D.2.7	CAN-Bus	570
D.2.7.1	Introduction	570
D.2.7.2	Basic settings	571
D.2.7.3	Advanced settings	573
D.3	Memory and Time base group	574
D.3.1	Introduction	574
D.3.2	Mainframe	574
D.3.2.1	Introduction	574

D.3.2.2	Basic settings	575
D.3.2.3	Advanced settings	575
D.3.3	Time base groups	581
D.3.3.1	Introduction	581
D.3.3.2	Basic settings	581
D.3.3.3	Advanced settings	587
D.4	Input group	589
D.4.1	Introduction	589
D.4.2	Basic-voltage	589
D.4.2.1	Introduction	589
D.4.2.2	Basic settings	590
D.4.2.3	Advanced settings	596
D.4.3	Basic-sensor	599
D.4.3.1	Introduction	599
D.4.3.2	Basic settings	599
D.4.3.3	Advanced settings	607
D.4.4	Bridge	608
D.4.4.1	Introduction	608
D.4.4.2	Basic settings	609
D.4.4.3	Advanced settings	617
D.4.5	Charge	618
D.4.5.1	Introduction	618
D.4.5.2	Basic settings	619
D.4.5.3	Advanced settings	624
D.4.6	CAN-Bus	625
D.4.6.1	Introduction	625
D.4.6.2	Basic settings	625
D.4.7	IEPE	629
D.4.7.1	Introduction	629
D.4.7.2	Basic settings	629
D.4.7.3	Advanced settings	636
D.4.8	Current loop	637
D.4.8.1	Introduction	637
D.4.8.2	Basic settings	638
D.4.8.3	Advanced settings	644
D.4.9	Marker (Events)	645
D.4.9.1	Introduction	645

D.4.9.2	Basic settings	646
D.4.10	Thermocouple	647
D.4.10.1	Introduction	647
D.4.10.2	Basic settings	647
D.4.11	Resistance thermometers	650
D.4.11.1	Introduction	650
D.4.11.2	Basic settings	651
D.4.11.3	Advanced settings	654
D.4.12	Timer/Counter	654
D.4.12.1	Introduction	654
D.4.12.2	Basic settings	655
D.4.12.3	Advanced settings	664
D.4.13	Resistor	665
D.4.13.1	Basic settings	665
D.5	Sensors group	672
D.5.1	Introduction	672
D.5.2	Shunt verification	672
D.5.2.1	Introduction	672
D.5.2.2	Task pane	673
D.5.2.3	Control	673
D.5.2.4	Warnings	673
D.5.2.5	Basic settings	674
D.5.3	Zero Balance and Calibration	678
D.5.3.1	Introduction	678
D.5.3.2	Task pane	679
D.5.3.3	Warnings	680
D.5.3.4	Calibration	680
D.5.3.5	Control	681
D.5.3.6	Amplifier	681
D.5.3.7	Basic settings	681
D.6	Real-time calculators group	687
D.6.1	Introduction	687
D.6.2	Cycle based calculator	687
D.6.2.1	Introduction	687
D.6.2.2	Basic settings	688
D.6.2.3	Advanced settings	692
D.6.3	Cycle Source	693

D.6.3.1	Introduction	693
D.6.3.2	Basic settings	694
D.6.4	Formula Database	697
D.6.4.1	Introduction to RT-FDB Boolean formulas	699
D.6.4.2	Basic arithmetic operations	702
D.6.4.3	Data storage	703
D.6.4.4	Basic settings	704
D.6.4.5	Real-time calculators - Functions	706
D.6.5	RT-FDB Publishing	781
D.6.5.1	Basic settings for RT-FDB - Publishing	783
D.7	Trigger group	786
D.7.1	Introduction	786
D.7.2	Recorder	786
D.7.2.1	Introduction	786
D.7.2.2	Basic settings	786
D.7.2.3	Advanced settings	788
D.7.3	Analog channel	790
D.7.3.1	Introduction	790
D.7.3.2	Basic settings	790
D.7.3.3	Advanced settings	793
D.7.4	Marker channel	797
D.7.4.1	Introduction	797
D.7.4.2	Basic settings	797
D.7.5	CAN-Bus channel	797
D.7.5.1	Introduction	797
D.7.5.2	Basic settings	798
D.7.6	Calculated Channel	800
D.7.6.1	Introduction	800
D.8	Alarm group	803
D.8.1	Introduction	803
D.8.2	Channel	803
D.8.2.1	Introduction	803
D.8.2.2	Basic settings	803
D.8.3	Marker	805
D.8.3.1	Introduction	805
D.8.3.2	Basic settings	805
D.8.4	Timer/Counter	806

D.8.4.1	Introduction	806
E	Real-Time Calculations Explained	807
E.1	Introduction	807
E.2	Cycle source	810
E.2.1	Timer	810
E.2.2	Cycle detector	810
E.2.2.1	2.2.1 Level crossing detector operation	810
E.2.2.2	Input signal slew rate limitation	812
E.2.2.3	State change limitation	816
E.2.2.4	Counter/filter operation	818
E.2.2.5	Cycle detector time out	818
E.2.2.6	Rate limitation	820
E.3	Calculated channels	822
E.3.1	Processing	822
E.3.2	Trigger detector	822
E.4	Analog calculated channels	825
E.4.1	Area	825
E.4.2	Energy	825
E.4.3	Maximum	825
E.4.4	Mean	826
E.4.5	Minimum	826
E.4.6	Peak to peak	826
E.4.6.1	Peak to peak	826
E.4.7	RMS	826
E.5	Cycle source calculated channels	828
E.5.1	Cycles	828
E.5.2	Cycle Frequency	830
E.6	Timer/Counter calculated channels	833
E.6.1	Frequency	833
E.6.2	Frequency (gated)	833
E.6.3	RPM of Angle	834
E.7	Settings and conflicts	835
F	Wake-on-LAN	836
F.1	Overview	836
F.1.1	Technology background	836
F.1.1.1	Purpose	836
F.1.1.2	Magic packet	836

F.1.2	Wake-on-LAN in Perception	837
F.1.2.1	Managing Wake-on-LAN mainframes	839
F.1.2.2	Hardware navigator	841
F.1.2.3	Wake-on-LAN in the hardware navigator context menus	842
F.2	Trouble-shooting (Wake-on-LAN)	843
F.2.1	Connection fails after Wake-on-LAN message	843
F.2.2	Perception try to connect to a not used mainframe	843
G	QuantumX – Unsupported features	844
G.1	Unsupported features	844
G.1.1	General limitations/remarks	844
G.1.2	Perception features	845
G.1.3	QuantumX features	845
H	Configuring MX471B – MX Assistant	847
H.1	Introduction	847
H.2	Configuring the MX471B using the MX Assistant	848
H.2.1	Ethernet network setting MX471	848
H.2.2	Configuring the CAN bus settings	853
H.2.3	Configuring the CAN signal settings	854
H.2.4	Configuring CAN signal settings using a CAN database file	855
H.2.5	Configuring CAN signal settings manually	859
H.2.6	Configuring CAN signal repetition time	861
H.2.7	Configuring CAN signal minimum/maximum value	863
I	Creating a synchronized recording using Perception and PTP	864
I.1	Using PTP	864
I.1.1	Why use a synchronization method	864
I.1.2	Why choose PTP	864
I.2	Hardware setup	865
I.3	Software setup	866
I.3.1	PTP Synchronization status monitoring	866
I.3.2	Advanced setup 1: Accurate master	872
I.3.3	Advanced setup 2: PTP tolerance	873
I.3.4	Advanced setup 3: Using separate network for data and synchronization	874
I.3.4.1	Tethered systems	874
I.3.4.2	Integrated systems	875
I.3.5	PTP synchronization lost during recording	876
I.3.5.1	Synchronization lost during recording	877
I.3.5.2	New clock introduced in PTP network	878

I.4	Using Perception to troubleshoot PTP synchronization	879
I.4.1	Unable to synchronize to PTP at all	879
I.4.2	Synchronization keeps getting lost	879
I.4.3	Unexpected master is found or not all mainframes synchronize to the same master	879
I.4.4	32 second offset	880
I.4.5	19 second offset	880
I.4.6	13 second offset	881
I.4.7	Accuracy not as expected	881
J	Recordings	882
J.1	Merge Recordings explained	882
J.1.1	Basic recording (PNRF) structure	882
J.1.2	Basic recording merge process	882
J.2	ASCII Recording Loader	885
J.2.1	Opening an ASCII file with the Perception ASCII file loader	885
J.2.1.1	Opening an ASCII file with the Recordings Navigator	885
J.2.1.2	Opening an ASCII file with the File menu	886
J.2.2	Supported ASCII file formats	888
J.2.2.1	ASCII file format I	888
J.2.2.2	Header:	889
J.2.2.3	Data:	890
J.2.2.4	ASCII file format II	891
J.2.2.5	Header:	891
J.2.2.6	Data:	892
J.2.2.7	ASCII file format III and IV	893
J.2.2.8	ASCII file format III (Short header)	894
J.2.2.9	ASCII file format IV (Long header)	894
J.2.2.10	Data	895
J.2.2.11	ASCII file format V	896
J.2.2.12	Data:	896
J.3	CSV Recording Loader	898
J.3.1	Opening a CSV file with the Perception CSV file loader	898
J.3.1.1	Opening a CSV file with the Recordings Navigator	898
J.3.1.2	Opening a CSV file with the File menu	899
J.3.2	Supported CSV file format	900
J.3.2.1	Header:	901
J.3.2.2	Data:	901

K	File Information	903
K.1	UFF58 File Format	903
K.1.1	Configuration of UFF58 and UFF58b files	903
K.2	File extensions in Perception 6.0 or later	905
L	Product Cycle	906
L.1	End-of-life products	906
M	Glossary	908
M.1	Abbreviations	908

1 Getting Started

1.1 Introduction

Welcome to Perception, the latest addition in a range of sophisticated software for data acquisition control, display, analysis and reporting. This software platform which capitalizes on more than 30 years design experience was designed from the ground up using state-of-the-art tools that leave competitors standing.

Designed as the software platform of the future, Perception software will support most current and future HBM Genesis HighSpeed hardware as well as selected legacy data acquisition systems. Secure your future... the most complete range of data acquisition systems all supported by a single software suite and a team of engineers committed to continuous improvement and expansion.

Perception allows control of a variety of hardware, ranging from straightforward, continuous data streaming of a few channels to multi-rack based DAQ instruments providing millions of data points per second. Perception software is equally comfortable with fast update scope type displays, streaming strip chart displays and transient recording.

To support this range of instruments, each offering different acquisition capabilities and their corresponding signal conditioners, Perception uses a spreadsheet-style setup. This setup offers ease of use and enables instant overview of all relevant parameters. An additional acquisition control dialog gives you interactive control of one or multiple acquisition units. In the case of the GEN2i, a unique platform called the Instrument Panel was developed. Powered by the Perception engine, made specifically for the touch screen environment and tailored toward simplicity and ease of use.

The unique displays let you visualize real-time waveforms instantly. Review historical data while acquiring and displaying current data. Compare with reference curves or zoom in to see the finest details with our free-style zooming and panning. The alternate zoom feature gives you two zoom areas simultaneously within the same waveform.

Dedicated hardware support allows for live and accurate display updates even when working on multiple channels through an Ethernet interface. StatStream® display technology enables even high resolution files to be viewed instantly regardless of acquisition size or network speed.

In addition the Perception software includes a variety of numerical displays and “VU-meters” with alarm levels that are configurable and scalable to suit various requirements and conditions.

With true multi-monitor support you can create a work space that goes beyond conventional software capabilities. View different sets of data on multiple high-resolution monitors for real power and control of your application.

Perception provides the measurement functionality you need to work with ease and efficiency. The cursor measurements with horizontal, vertical and slope cursors with a swiftly updated result table allows for fast and easy access to points of interest.

A variety of built-in meters can be connected directly to parameters like max, min and mean value as well as Peak-to-Peak, RMS, etc. These values are generated by the acquisition hardware and displayed in real-time on your computer screen.

The data navigator lets you easily find your way between the various data sources such as live waveforms, files, strings, numerical values or calculated results. These data sources can be located anywhere: on your data acquisition system, on your hard disk or somewhere on the intranet. Configure the information structure to your preferred viewing options. All detailed properties of a selected source are instantly available making searching through a myriad of data sources a breeze.

When you find an event of interest you can print your traces with a single menu command on high-resolution printers in full-color. Or simply copy the display of interest and paste it into any document for more advanced reporting. In addition you can create quick or advanced (option) reports using Microsoft® Word.

For off-line analysis using third-party software packages, Perception can offer a variety of export formats for many popular programs. Extensive set-up options let you export the data of interest the way you want, and nothing more.

Perception’s thoughtful workbench concept allows for arrangement of a variety of graphical objects into logical groups for easy reference. You can freely customize the work space to suit your control and analysis needs: create an environment by selecting the required windows, displays and components, size and position them and save this as a Virtual WorkBench (*.pvwb) file for later use. You can easily switch between saved work spaces for different requirements, and at start-up you can choose between auto-configuration and a saved work space.

A variety of options is available to tailor the Perception application to your needs including, but not limited to:

- **Multiple workbooks** that allow you to create multiple ‘instances’ of your work environment and effectively use multi-monitor systems.
- **Export plus** for additional export formats.
- **Control plus for** acquisition control of multiple mainframes.
- **Remote control** with SOAP and RPC.
- **Video playback** that enables synchronized playback of video and time domain data with tracking cursors.
- **Analysis** that allows entry of formulas to calculate math channels and channel parameters.
- **Advanced reporting:** a DTP-alike tool for the creation of stunning reports with displays, tables, results, etc.
- **Information:** a tool to include a variety of information in your experiment.
- **Spectral display:** provides basic FFT and Spectral Analysis functionality".

Other options include **Custom Software Interface** programming CSI, **STL formulas**, **BE256/Multipro Control**, and **HPHV Automated Analysis**.

Each option is described in it's own separate manual.

Note *Not all features and functions mentioned in this manual are included as standard.*

1.2 Requirements

The following section lists the hardware requirements.

- Intel® Core™ Duo (or compatible)
- For Perception
Windows Vista™ Business or Ultimate (32-bit and 64-bit, Service pack 2 or higher) Window 7 Professional (32-bit or 64-bit, Service Pack 1 or higher) Windows 8 Pro, Windows 8.1 Pro
- For Perception Enterprise 64-bit
Windows Vista™ Business or Ultimate (64-bit, Service pack 2 or higher) Window 7 Professional or Ultimate (64-bit, Service Pack 1 or higher) Windows 8 Pro, Windows 8.1 Pro
- Microsoft DirectX® 9 or higher (included on media)
- Microsoft®.NET 4.0 (Included in Perception install)
- 512 MB of RAM memory - 2 GB recommended, and required when working with more than one data acquisition mainframe.
- 1 GB of available hard-disk space for installation
- At least 1% of free hard-disk capacity for storage of acquired data
- TrueColor (24-bit) video display adapter with 64 MB on-board video memory and hardware DirectX 9 and Microsoft Direct3D® support using a screen size of at least 1024 x 768 pixels
- CD-ROM drive for installation of the software (DVD-drive required for supplemental content)
- A free USB port for the HASP®HL USB Token
- 100 Mbit Ethernet interface (1 Gbit recommended) when combined with GEN DAQ products

Note *Please refer to Perception release notes for detailed information on specific versions of Perception.*

Note *The Perception software is tested on video displays with a screen resolution of 96 dpi. Other resolutions may work, but are currently not advised.*

1.2.1 Supported acquisition hardware

- GEN series Modular Data Acquisition System
- Vision XP (review and analysis)
- BE256 / MultiPro (requires BE256/MP Control option)
- ISOBE5600m
- QuantumX MX1609KB
- QuantumX MX1609TB
- QuantumX MX471B
- BE3200

1.2.2 System performance tests

After a new (clean) installation of the software, Perception will run a system performance test at the first run of the software. This test verifies part of the above mentioned system requirements and also advises on configurations for best performance. Tests include:

- Available internal memory
- Operating system
- Processor type
- Swap file usage
- Continuous Data Rate

You can run this test any time from the menu: **Help ► Performance Tests**

In addition there is a test for the video display. You can access this test from the menu: **File ► Preferences... ► Perception ► Video.**

There is also a test for Storage Speeds which is done at first launch of Perception. You can access this from the menu: **Window ► Continuous Data Rate.** This will show the Continuous Date Rate palette.




Figure 1.1: Continuous Data Rate dialog

Click on **Details**, when available, to show the details of this test. For more info please see section "Set and Test current storage location" on page 348.

1.3 Installing the software

When you install the Perception program files from the CD, note that you cannot run Perception from the CD; you must install the components onto your hard drive and run the software from that drive.

1.3.1 Install Perception

To install Perception in Microsoft® Windows®

- 1 Insert the Perception CD into your CD-ROM drive.
- 2 Click **Next** in the Perception AutoPlay dialog box. If the AutoPlay dialog box doesn't appear, choose **Start ► Run**, enter **d:\setup.exe** (where "d" is the letter of your CD-ROM drive), and click **OK**.
- 3 Click **Perception**, read the information in the Setup dialog box, and click **Next**.
- 4 Read the end user license agreement, select **I accept...** and click **Next**.
- 5 Enter the *User Name* and *Organization*. Click **Next**.
- 6 Choose which type of Perception installation you would like, there are three choices:
 - Full install** This installs a full version of perception with no limited functionality. Also installs Offline and Freeview mode.
 - Offline install** This installs Perception for offline use; prepare all measurements as normal without connected hardware, you cannot record when offline.
 - Free viewer install** The Free viewer enables you to open, view, measure, export and print Perception recordings.
- 7 Specify the type of installation you want:
 - To use the standard installation, choose **Typical**.
 - To use the complete installation, choose **Complete**.
 - To install only particular components, or when you want to modify the default installation location, choose **Custom Install** and select the *components* and */ or modify the installation location*.

Note *For a description of any component - and disk space required - that can be installed, choose **Custom Install** to see a list of the components, and select the component you want in the list. A description of the component appears in the dialog box. In the Custom Install you can also verify the installation location. To change the installation location, click **Change**, and specify a destination folder.*

- 8 Click **Next**, and follow the on-screen instructions to complete the installation. When the process is complete, a message tells you that Perception is installed. Click **Finish**.

1.3.2 Conventions

Throughout this manual the software is described and depicted using Windows 7. When required for Windows XP or Windows Vista, differences will be explicitly stated.

When the wording “click **Start**....” is used, this refers to the Windows XP Start button. In Windows Vista and Windows 7, the Start Menu has undergone some significant changes, with the taskbar icon no longer labeled "Start" but simply the pearl icon (of the window-frame in an orb).

1.4 Starting Perception

To start Perception proceed as described in the following section.

1.4.1 Start Perception

The Perception software requires a HASP key. HASP (Hardware Against Software Piracy) is a hardware-based (hardware key) software copy protection system that prevents unauthorized use of software applications. You must have the HASP@4 USB Token installed in a USB port before you can run the software.



Figure 1.2: HASP USB Key example

To start Perception

- Choose **Start** ► **All Programs** ► **HBM** ► **Perception** ► **Perception**

When Perception is installed on a Dimension 4i or GEN5i, no external HASP key is required. These instruments are equipped with a built-in HASP key.

1.4.2 Perception user modes

Perception allows for a number of different user modes. These user modes pre-configure the Perception user interface to a layout that best suits the selected situation.

When Perception has fully started you can navigate to the **File** menu then **Select User Mode**, this is described in more detail in the chapter "Switch to Instrument Panel" on page 45. From this menu you can select between all Perception modes.

Commonly selected User modes are Single Sweep for transient applications and Continuous for recorder applications.

1.5 What's new in Perception

For detailed information of the new features of Perception please refer to:
www.hbm.com/perception

Note *When you are using Perception Version 8, some of the information in this manual may be outdated. Especially the acquisition modes described in chapter "5 Acquisition Control and Status" on page 113 and appendix "A Acquisition and Storage" on page 483 have been updated in Perception Version 8. For more information on new acquisition modes, please visit the Perception product page for the document "Perception V8 Acquisition Modes Quick Start".*

2 Perception Concepts

2.1 Introduction

Within the Perception application some concepts and terms are used that may need an introduction. Knowledge of these concepts and terms is vital when you want to gain maximum profit from Perception. It will also ease the operation of the software.

When you do measurements, analysis and reporting there are a number of procedures that you want to use more than once. Within these procedures there are also a number of settings that you might want to save and recall.

Typical procedures / settings that you can save and recall in Perception are:

- Recorded data
- Hardware settings
- When options are installed:
 - Report layout
 - Formulas
 - Settings from custom CSI projects
 - And any other

These are the settings that you can store individually as well as combined. Other settings can only be stored as part of a larger concept. In the following sections we will describe the various possibilities.

Note *Various file formats for storage are expanded over the years to include more information. HBM, however, always strives for backwards compatibility as much as possible. Therefore reading older files should always be possible although they may not contain all the latest settings. In these situations warnings are generated, but you can always use these older files and save them for upwards compatibility.*

2.2 Virtual Workbench

A "workbench" is a way to save the way you arrange your tools and components in a configuration that best suits your requirements.

- The Virtual WorkBench can be recalled whenever you like.
- Multiple workbenches can be created for various tasks.

The **Virtual Workbench** comprises the following components:

- Active display settings
- Hardware settings
- Information
- Formulas (option)
- Reports (option)
- User sheets
- As an option sheets can be organized in workbooks

The workbench defines your complete test environment without recorded data. Some of the components can be saved individually.

2.2.1 Active display

The active display holds recorded or loaded data.

- The data can be referenced by display as well as by data source.

This allows you to perform operations on the currently active recording as well as a fixed named recording. *For example you can create a formula in the formula database that references the "active" recording, regardless of the physical location or file name. When new data flows in the active display, the formula result is updated automatically.*

The active display settings can not be stored independently, but are stored when a virtual workbench is saved or with a recording.

When a virtual workbench is loaded, the active display settings are loaded as well. *For example when you connect the active display to a recorder and save the workbench, reloading the workbench will recreate the active display with the traces connected to that recorder.*

2.2.2 User sheet

When you load the saved data into a new user sheet, the active display settings are used to create the settings for the display in the new user sheet.

User sheets are sheets created by the user in addition to the predefined sheets as explained later on in this document. User sheets are not saved independently, but are part of a virtual workbench.

2.3 Individual storage of settings

Various settings can be stored individually in a separate file. These files can easily be transferred between various uses of the application and/or computers. For example when you have created a “standard” report for your company you can save this and load it later on as a template for a specific test.

2.3.1 Hardware settings

The settings that define the hardware setup can be saved / loaded independently from other settings. For example you might want to load a workbench with the same test environment but alternative hardware settings for a different test.

The hardware settings:

- define the complete hardware setup as specified in the settings sheet,
- can be stored in a separate file with the file extension .pset,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.

2.3.2 Formulas

When the formula database is available (as part of the Advanced Analysis option), the complete formula database with all functions can be saved and reloaded.

The formula database settings:

- comprises all formulas/functions as specified in the formulas sheet,
- can be stored in a separate file with the file extension .pFormulas,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.

2.3.3 Report layouts

When the Reporter is available (as part of the Report option), complete report layouts can be saved and reloaded. This is the layout without the actual data that might be in there.

The report layout settings:

- comprise all settings of a multi-page report as specified in the report sheet,
- can be stored in a separate file with the file extension .pReportLayout,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.

2.3.4 Information

By default a standard two-line information sheet is available. This can be expanded by the Information option to create a freely configured information tool.

The information settings:

- comprise all settings, fields and field values as set in the information sheet,
- can be stored in a separate file with the file extension .pInfo,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.

2.3.5 Other optional software components

For details on settings of other optional software components refer to their respective manuals.

2.4 Experiment

As from version 4.0 the complete test environment including the recorded data is stored in an experiment database file. The highest amount of data storage space is used by the experiment.

Before version 4.0 recorded data and the test environment were two separate files: a data file and a virtual workbench file.

- **Data file** The data file contains the actual data (or 'waveforms' or 'traces'). This data is automatically stored when a recording has been made. The data files had an extension like **.nrf** or **.dnrf** or **.pnrf**.
- **Virtual workbench** The workbench defines your complete test environment without recorded data.

As from version 4.0 the experiment concept is introduced: save and load the recorded data complete with the test environment, i.e. the data file and the workbench are combined into one file.

This file has the extension **.pnrf** like the classic data files. As from version 6.0 the file extension is **.pnrf**.

The load experiment command is the default operation to load data using the **Open...** command.

To load the data only use the **Load Recording...** command with the 'classic' options *As active*, *As reference* or *Using filename*.

Note *Various file formats for storage are expanded over the years to include more information. HBM, however, always strives for backwards compatibility as much as possible. Therefore reading older files should always be possible although they may not contain all the latest settings. In these situations warnings are generated, but you can always use these older files. Save them for upwards compatibility.*

2.5 User interface modes

The Perception software is very sophisticated, has a variety of functions and features and supports multiple hardware platforms with almost unlimited capabilities.

To support all this the user interface is very extensive and may provide information that you will never use or want to see.

To add a basic form of customization, Perception provides options to tailor the user interface to your specific requirements: user modes for the complete Perception application and a basic / advanced option for the settings sheet.

2.5.1 User modes

User modes are related to the type of application. You may be a typical transient recorder user or a data logger user or somewhere in between or beyond. Depending on the selection, sheets, functions or options may be not available.

In the application the following user/usage profiles are identified:

- **Review** The software is used to review data, maybe in combination with analysis and reporting. No acquisition control or hardware settings are required.
- **Single sweep** Typical transient recording usage. By definition each recording comprises a single sweep (shot). No multi sweep settings or multi-time base settings are required.
- **Multi sweep** Equals single sweep usage. Only now a recording can comprise of multiple - triggered - sweeps.
- **Slow-Fast sweeps** Equals the multi sweep usage. Within a sweep time base changes are possible (slow-fast-slow, also known as A-B-A).
- **Continuous** Typical recorder or data logger usage. The acquisition is a single continuous recording on a single time base.
- **Dual** Continuous acquisition combined with one or more sweeps within a single recording.

When Perception has been started, navigate to the **File** menu and to **Select User Mode**.




Figure 2.1: File menu with Select User Mode option

A Select User Mode

You will be presented with a submenu of options. Select one of these options to change user mode in Perception without the need to exit the application.

2.5.2 Perception Start-up

You may turn on the user mode selection dialog, which is now off by default, during Perception start-up.

Navigate to **File ► Preferences: Perception ► Start up** and select **Show User Mode selection dialog**, which appears at start-up. When Perception starts, you will be presented with the following dialog:




Figure 2.2: Perception User Mode dialog

Select your user mode in this dialog. Use the question mark buttons to get more information about a specific mode. When you've made your selection, click **OK**.

By default, the dialog above (Figure 2.2) does not appear at start-up. Select the *Remember my selection* if you want your selection to be the default at start-up. If you want to omit this dialog at start-up, select the *Don't show this dialog again* option.

Offline mode start-up has now moved to a separate application. Please see chapter "Offline Setup & Configuration Manager" on page 522 for further details.

To change the default start-up behaviour, you can define a Quick Start: each time you start up Perception, your personal configuration will be loaded immediately.

Quick Start

Use **Quick Start** to initialize the software without the User Mode and Start selection dialogs.

Use the Create command to use the current work environment as the preferred start-up state.

To set up your Quick Start:

- 1 Start the software
- 2 Set up your work environment
- 3 On the **File** menu and click **Preferences**
- 4 In the Preferences dialog, select **Start up**
- 5 Under Quick Start, select the **Use Quick Start** check box
- 6 To create a new Quick Start configuration, click **Create**
- 7 Click **Apply** or **OK** to confirm




Figure 2.3: Preferences dialog with Quick Start area

- A Quick start area**
- B Start-up:** Click **Start up** in the tree view to open the **Quick Start** area.
- C Use Quick Start:** Select the **Use Quick Start** check box to enable the **Create** button.
- D Create:** Click the **Create** button to create a new Quick Start file using your current configuration.
- E Information** on the quickstart file currently being used.

To disable Quick Start:

- 1 On the **File** menu, click **Preferences**
- 2 In the Preferences dialog, select **Start up**
- 3 Under **Quick Start**, click to clear the **Use Quick Start** check box
- 4 Click **Apply** or **OK** to confirm

Start Perception in a specific mode

Perception can also be started in other modes. To start Perception in a specific mode:

- 1 On the **File** menu, click **Preferences**
- 2 In the Preferences dialog, select **Start up**
- 3 Under **User Mode**, select your preferred **Default User Mode**
- 4 Click **Apply** or **OK** to confirm

2.5.3 Switch to Instrument Panel

To switch to the Instrument Panel, navigate to the **File** menu and then select **Switch to Instrument Panel**.

Note *Switching to Instrument Panel mode menu item is only visible if Instrument Panel mode is available.*




Figure 2.4: Switch to Instrument Panel option

A Switch to the Instrument Panel

To start Perception in the Instrument Panel mode:

- 1 Click **Preferences...** in the File menu.
- 2 Select **Start up** in the tree view of the **Preferences** dialog.
- 3 In the **User Interface Mode**, drop down list box select the **Instrument Panel** mode.



A Instrument Panel mode

2.5.4 Settings sheet layout modes


The hardware controlled by Perception can have numerous settings. Already the settings are grouped into logical units to allow for a better overview of related settings.

Apart from this logical grouping it is also possible to show or hide settings within a group that are not relevant for basic operation of the instruments.

When the settings sheet is visible you can switch between the basic and advanced mode.

To set or switch the settings sheet layout modes:

- 1 In the main menu select **Settings**.
- 2 In the Settings menu select **Show Settings ▶**.
- 3 In the submenu select:
 - **Basic:** this will show only the relevant settings
 - **Advanced:** this will show all settings
- 4 Or, when visible, use the toolbar icon to set the mode:



2.6 Data sources

Introduction

One of the central concepts of Perception is the data source. Data sources are the generic mechanism that allows data visualization components to access data and all kinds of different hardware to deliver it.



Figure 2.5: Data sources

2.6.1 Data source types

In general there are four different kinds of data can be supplied by a data sources:

- **Waveform data:**
A collection of values in which each value on the Y-axis can be projected against one specific value on the X-axis.
 - If the values on the X-axis are placed at equal distances (equidistant), this is typically synchronous data.
 - If the values on the X-axis are not placed at equal distance, this is asynchronous data.
- **Digital waveform data:**
Same as standard waveform data. Values are restricted to High or Low.
- **Numerical data:**
Single numerical value. The source of the data may represent a single point in time but may also be the result of an operation that combines multiple values into a single result, for example formulas and user variables.

Note *May be integer or floating point data.*

- **String data:**
Textual information

2.6.2 Where are data sources used

Data sources can be used as input for further operations, or can be visualized. See the tables below how different types of datasources can be visualized in Perception.

	Waveform data synchronous	Waveform data A-synchronous ⁽¹⁾	Digital waveform synchronous	Digital waveform A-synchronous ⁽¹⁾	Numerical	String
Time display ⁽²⁾	YES	YES	YES	YES	NO	NO
XY-display ⁽²⁾	YES	YES	YES	YES	NO	NO
Spectral display ⁽²⁾	YES	YES	YES	YES	NO	NO
User table	NO	NO	NO	NO	YES	YES
Meter	NO	NO	NO	NO	YES	YES
Report ⁽³⁾	YES	YES	YES	YES	YES	YES
Image	NO	NO	NO	NO	NO	NO

- (1) A-synchronous data may be synchronized in case an operation only supports synchronous data. In this case the operation may take more time as expected.
- (2) These components have both live and review operational modes. Not all mainframes support live data, or live data for spectral/XY displays.
- (3) The report allows visual representation of all data types. However special containers are required to show specific data source types. For more information, refer to the report option manual.

Data source can also be used as input for further processing, the following table shows which data sources can be used for which operations.

	Waveform data synchronous	Waveform data A-synchronous ⁽¹⁾	Digital waveform synchronous	Digital waveform A-synchronous ⁽¹⁾	Numerical	String
Export	YES	YES	YES	YES	YES ⁽²⁾	YES ⁽²⁾
Automation ⁽²⁾	YES	YES	YES	YES	YES	YES
Formula database ⁽²⁾	YES	YES	YES	YES	YES	YES
User actions ⁽²⁾	YES	YES	YES	YES	YES	YES
Display markers	NO	NO	NO	NO	YES	YES
Logging	NO	NO	NO	NO	YES	YES
Applications	YES	YES	YES	YES	YES	YES

- (1) A-synchronous data may be synchronized in case an operation only supports synchronous data. In this case the operation may take more time as expected.
- (2) Depending on which specific part of the feature that is used these certain data sources may or may not be available.

2.6.3 Data source naming

Data sources are uniquely identified in the system by their path. This path typically also indicates where the data from the data source originates from. Some examples of this are:

Raw samples:

Active.<GroupName>.<RecorderName>.<ChannelName>

Live parameters:

Active.<GroupName>.<RecorderName>.<ChannelName>.
<ParameterName>

Formula database:

Formula.<FormulaName>

Information sheet:

Active.Information.<PartOfInformationSheet>

Display related:

Display.<DisplayName>.<PartOfDisplay>.<IndividualValue>

System:

System.<SystemConstantName>

Hardware diagnostics:

Hardware.<MainframeName>.<HardwareComponentPath>

Application sheet:

<ApplicationPrefix>.<DatasourceName>

User defined:

<Any>

By using fixed prefixes for different types of data sources, duplicate names are less likely; however there are still a number of operations that may cause duplicate names:

- Renaming a channel.
- Renaming a recorder.
- Renaming a mainframe in case of multiple mainframes.
- Adding a recorder to a group
(happens automatically upon connecting to a mainframe).

In these cases Perception will not deny a renaming request, but will ensure that no duplicate names exist. As the rename request is always accepted, the existing duplicate name is always renamed. Typically this is achieved by adding an "\$1" or other sequence number at part of the path that was duplicated. For example:

Consider a recorder (Recorder A) in group 1 with two channels:

- Channel A with user name: **Current**
- Channel B with user name: **Channel A2**

These two channels will have the following data sources exposing their data:

- Datasource 1: **Active.Group1.Recorder A.Current**
- Datasource 2: **Active.Group1.Recorder A.Channel A2**

Now if the second channel is renamed into Current as well, this will be the end result:

- Channel A with user name: **Current\$1**
- Channel B with user name: **Current**

With the following datasources:

- Datasource 1: **Active.Group1.Recorder A.Current\$1**
- Datasource 2: **Active.Group1.Recorder A.Current**

Within the formula database another mechanism is used to prevent datasources with duplicate names. The formula database will deny a formula from being created if another formula with that name already exists, instead it will automatically create a new name that does not exist yet and show the new name.




Figure 2.6: Automatically renaming

Note *In case a custom application is running inside Perception, that application is responsible for not introducing duplicate names. A recommended way of working is to introduce a unique prefix for the application.*

2.6.4 Restricted characters

When (re)naming channels and other elements that publish data through data sources most characters are allowed. There are a number of characters that are not allowed because they are reserved for specific operations within the application.

Restricted characters:

!	Exclamation point
.	Full stop
	Space
,	Comma
+	Plus sign
-	Minus sign
*	Asterisk
/	Slash mark
<	Less than sign
>	Greater than sign
@	At sign
;	Semicolon
[Left square bracket
]	Right square bracket

Restricted characters:

{	Left curly bracket
}	Right curly bracket
(Left parenthesis
)	Right parenthesis
"	Quotation mark

In case any of these characters is used in a name, it will typically be replaced by an underscore character ('_').

3 The Work Area and Generic Procedures

3.1 Introduction

The Perception work area can be arranged to help you focus on your measurement task. It uses the concept of a "workbench" where you arrange your tools and components in a configuration that best suits your requirements. This Virtual WorkBench can then be saved and recalled whenever you like. Multiple workbenches can be created for various tasks. For more details on virtual workbenches refer to "Virtual Workbench" on page 36.

3.1.1 Start dialog options

- 1 Connect the GEN series system to the Perception PC and start Perception.

Note *Perception can be adapted to meet personal wishes. The Getting started sequence is described using the default installed selections.*

- 2 The user mode selection dialog appears (see Figure 3.1):




Figure 3.1: Perception User Mode dialog

User modes are explained in the Perception Data Acquisition Software manual. For this section about getting started, the system defaults are used.

Click **OK** to continue.

- 3 Perception will continue to start. To continue, Perception will ask which job it should perform (see Figure 3.2):




Figure 3.2: Perception job dialog

A Set up an auto-configured Experiment

In the dialog select:

Set up an auto-configured Experiment Let Perception search for connected acquisition hardware and create a default layout. Optionally you can select **and reset hardware**. When this option is selected, Perception resets the hardware and restores the factory default settings in the mainframe.

Click **Continue**. This will show a selection of mainframes (see Figure 3.3) or automatically make a selection if only one mainframe is available.




Figure 3.3: Mainframe selection

From the list of available mainframes, select the mainframe(s) required for the experiment. Click **OK** to continue.

When using the mainframe for the first time, the IP address should have been dynamically assigned. This ensures that the IP address matches the PC if the PC network settings are also configured dynamically. However, if the mainframe or PC is configured to a static IP-address, the two networks may not match. The list of available mainframes shows every HBM mainframe supported by Perception, even if network settings do not match.

Start dialog options summary

Summarized the Start dialog provides the following experiment options:

	Load VWB environment	Load hardware and connect	Load data
New	blank		
Auto	default	search and select	
Auto + reset	default	search, select and reset	
Redo	√	√	
Redo + data	√	√	√
Review	√		√

3.2 Getting familiar with your work environment

3.2.1 About the work area

The Perception work area is arranged to help you focus on your work. The work area consists of the following components:




Figure 3.4: The Perception work area


- A Menu bar
- B Toolbar
- C Palette
- D Hidden palettes
- E Status bar
- F Sheet area
- G Tabbed sheet
- H Dynamic toolbar
- I Dynamic menu

- A Menus** The menus in the menu bar contain commands for performing tasks.
- B Toolbar** The icons in the toolbar provide quick access to commonly used commands.
- C - D Palette** A number of palettes are available. Palettes are auto-hide and pinnable floating windows that can be docked on various positions. These windows provide access to commands and operations that constitute your typical work environment.
- E Status bar** The status bar is used to provide additional information.
- F- G Sheet area** The main part of the work area is occupied by sheets. Sheets provide an interface to a variety of functions, for example display of data, modification of settings, analysis, reporting, etc.
 - Sheets are now managed with the Sheet Menu item **Sheet Manager**. Sheet Manager gives you complete flexibility on what sheets are loaded on start-up and what sheets you want to be active or not. For more information please see "Sheet management feature" on page 72.
- H Dynamic menu** Each sheet has its own proprietary menu that contains commands related to the visible sheet.
- I Dynamic toolbar** Each sheet has its proprietary toolbar that contains commands that are applicable to the visible sheet.

3.2.2 Notifications

A notification informs you of system events that are not related to the current user activity. It can also provide you with useful and relevant but typically not critical information. The notification could result from a user action or significant system event, or could offer potentially useful information from the Perception application.

The notification is made through a window briefly displayed from the notification icon in the status bar. Notifications are displayed for a fixed duration of 9 seconds. After that they disappear.

 The notification icon is highlighted when a notification has occurred. When the icon is dimmed there is no notification active.

When using sheets and automation it is increasingly common for tasks to run in the background. Using notifications for such tasks (for example analysis) leaves you, the user, in control.




Figure 3.5: Notification warning

In this example, Perception notifies the user that the connection to fiber channel Ch F1 is present.

When you click on the notification icon, a dialog comes up with the latest (unread) notifications. This will also clear the notification icon.

When you close the dialog, this list of latest notifications is cleared.




Figure 3.6: Recent Notifications

A history of all notifications are available through an xml file called "Notifications.xml". You can open and read this file with an xml viewer or use the Perception Diagnostics Viewer.

To read the history of notifications using the Perception Diagnostics Viewer:

- 1 If not already available, add the Diagnostics Viewer sheet: In the **Sheets** menu point to **Diagnostics Viewer**, if the sheet isn't available click **Manage Sheets** and **Load** the Diagnostics viewer.
- 2 On the **Diagnostics Viewer** menu click **Open Diagnostics**.

- 3 In the **Open** dialog box select **Notifications.xml** and click **Open**.
Now you see the notification history.
- 4 Use the chevrons (arrows) to slide open a surface to show remaining items in hidden content.

To read the history of notifications using an external application:

- 1 On the **Help** menu click **Open Perception Diagnostics Folder**.
- 2 In **Windows® Explorer** double-click the **Notifications.xml** file.
- 3 Your xml viewer will open the xml file.

3.2.3 Choosing commands

Commands let you perform a wide variety of tasks. Perception provides several ways to choose commands:

- The menus at the top of the work area provide access to commands. If a command is dimmed in a menu, it isn't applicable to the current operation. For instance, a command may only work on a selected object, or a particular kind of object.
- Shortcut menus drop-down when you right-click on an object or window region that supports a shortcut menu. They display a small set of commands and options related to the current context. Therefore they are also referred to as context menus.
- Keyboard access keys also provide access to commands. However, don't confuse access keys with shortcut keys. While both access keys and shortcut keys provide keyboard access to user interface, they are different. Access keys have the following main characteristics:
 - They use the Alt key plus an alphanumeric key.
 - They are assigned to all menus and most dialog box controls.
 - They aren't intended to be memorized, so they are documented directly in the user interface by underlining the corresponding control label character.
 - They have effect only in the current window, and navigate to the corresponding menu item or control.
- Keyboard shortcuts let you quickly execute commands without using a menu. When available, the keyboard shortcut appears to the right of the command name in the menu.
- A toolbar is a graphical presentation of commands optimized for efficient access. When available they let you quickly execute commands without using a menu.

3.2.4 Modifying color

In various locations you can modify the color of objects. The following diagram shows the various controls used to modify a color.




Figure 3.7: Color selection

- A Color drop-down box
- B Summary of available colors
- C Color dialog box
- D Color pointer
- E Color matrix
- F Luminosity slider

To modify a color:

The following procedure describes the general line for modifying colors:

- 1 Click on the color drop-down box **A**.
- 2 In the summary of available colors **B**:
 - Click on a color to select it, or
 - Click on **More...** to select another color


- 3 When you want to select another color in the **Color** dialog box **C**, click on a color from the list of *Basic colors*, or click anywhere in the color matrix **E** on the right and:
 - Drag the color pointer **D** in the color matrix to the right or left to change the hue.
 - Drag the color pointer in the color matrix up or down to change the color saturation.
 - Drag the slider **F** at the right of the matrix to change the luminosity.
 - Once you have defined the color you want, click **Add to Custom Colors**.
- 4 Click **OK**.

3.2.5 Insert and format a data source

In various locations of Perception, for example the **User Tables**, you can insert and format a data source in a single operation. This option is available if the data source that you want to insert is a numerical value or a text string, not a waveform. These data sources are also referred to as variables. You can enter variables in various text areas. Variables can be combined with plain text.

To insert and format a data source/variable

- 1 If applicable, position the text cursor on the insertion point in the text area where you want to enter the variable, for example an empty cell in the **User Table**.
- 2 Click **Insert Data Source**. The Insert Data Source dialog box will come up.
- 3 Make your selections and click **OK** when ready.



- A Data source selection area
- B Insert parameter
- C Value properties
- D Output string and sample

A Data source Select the data source in the tree view that you want to insert.

B Insert You can choose which information of the data source you want to insert.

- **Value** Actual value of the data source.
- **Name** Name of the data source as it is shown in the tree view.
- **Units** Units in which the data source is measured.

If you do not select any of the three options the value will be used as default.

C Value properties Select from multiple output formats:

- **Integer:** Number with no decimals.
- **Floating Point:** Number with decimals, without fixed "layout".
- **Fixed Point:** Number with decimals, fixed number of places before and after the decimal separator.
- **Scientific Notation:** Shorthand way of writing very large or very small numbers. A number expressed in scientific notation is expressed as a decimal number between 1 and 10 multiplied by a power of 10.
- **Engineering Notation:** Scientific notation in which the power of ten is a multiple of three. The power of ten is represented by SI prefixes such as Mega (M), Kilo (k) or Milli (m).

D Output In this area you see an example of the actual output as well as the internal format string of the placeholder.

For each selection you make in the Insert Data Source dialog an example of the output and the corresponding placeholder is given, using the selected data source.

When you close the dialog, the text area will be updated with the information provided. Depending on the situation you may also need to close a properties dialog of the selected text area. If no actual data is available, for example because a recording has not been made yet, the placeholder will be shown. After the recording, the actual data will be filled in.

3.3 Using palettes

Palettes are floating windows that can be docked (pinned) in various positions and provide auto-hide functionality. These windows provide access to commands and operations that constitute your typical work environment. Examples of palettes are:

- Control All - Acquisition Control
- Battery Status
- Recordings
- Hardware

Palettes can be shown, hidden, moved, docked, etc.

3.3.1 Showing and hiding palettes

You can display and hide palettes as you work.

To show or hide a palette:

Do one of the following:

- In the menu bar choose **Window ► [palette name]**. A check mark appears next to the palette that is currently visible - either open or auto-hidden.
- When open click the top right button to close it.



- To auto-hide a palette it must be open and docked. Click the **auto-hide** button. The palette will auto-hide when the mouse pointer leaves the palette area.
- Click on a tab of the 'hidden' palette to let the palette slide open.



3.3.2 Moving, docking and sizing palettes

You can move palettes to any position on the screen where they can stay as floating windows, or you can dock a palette to a fixed location.

To move a palette:

- 1 Make sure the palette can be moved: clear the auto-hide feature.
- 2 Click on the title bar of the palette and drag the palette to a new location.

To dock a palette:

- 1 Make sure the palette can be moved: clear the auto-hide feature.
- 2 Click on the title bar of the palette and drag the palette. While dragging a transparent docking context (B) will shade the area that the docking palette can occupy. Docking stickers (A) will visually display where the docking palette can be docked by displaying stickers that point to the appropriate locations.




Figure 3.8: Palette position main area

- 3 Position the mouse pointer on one of the stickers and release the mouse button to dock the palette. You can either dock in the main area (see Figure 3.8 on page 67) or relative (see Figure 3.9) to an already docked palette.




Figure 3.9: Palette position relative

The inner arrowed docking icons will place the palette on the inside of the main window/selected area and the outer arrowed docking icons place the palette on the outside of the main window/selected area.

When a palette is floating you can control the size of a palette as well as how many options appear in it.

To change the palette size:

- To change the size of the palette, drag the lower right corner of the palette, or one of the sides.


3.3.3 Tabbed grouping

You can group palettes in a tab style arrangement and display them in any arrangement docked to any side of the work area. The docking palettes can be grouped together or docked inside one another to make the best use of the work space.

When grouped, the group behaves as a single palette.

To group palettes:

- 1 Click on the title bar of a palette and drag it to another palette.
- 2 A tabbed icon sticker will be displayed in the center of the docking stickers. A transparent docking context (**B**) will change into a tabbed style palette when you can group it.



- 3 Release the mouse button on the central icon (**A**) and the palettes will be grouped together with tabs (**C**) on the bottom.

To switch between palettes in a group:

- Click on the tabs to switch between the palettes.

To remove a palette from a group:

- Grab a palettes tab and drag the palette outside the group.

3.4 Using toolbars

A toolbar contains (buttons with) images that provide quick access to commonly used commands and operations. Perception includes various built-in toolbars that you can show and hide as needed. By default, all built-in toolbars are docked side by side below the menu bar.

Some information (buttons) in the toolbar depends on the selected sheet. This is the dynamic toolbar.



Figure 3.10: Perception toolbar (example)

- A** Toolbar grip (handle)
- B** Toolbar area
- C** File toolbar
- D** Acquisition control toolbar
- E** Zero Balance toolbar
- F** Logfile toolbar
- G** Dynamic toolbar/Information sheet including:
 - H** Display/setup
 - I** Cursor control
 - J** Marker control

Toolbars can be repositioned:

- Below or above the menu bar.
- In a multi-line arrangement to save horizontal space.

To show or hide a specific toolbar:

To show or hide a specific toolbar do one of the following:

- Using the toolbar area:
 - 1 Right-click the toolbar area.
 - 2 In the context menu that comes up click the toolbar that you want to show or hide.

- Using the Window menu:
 - In the menu bar choose **Window ► Toolbars ► [toolbar]**. A check mark appears before a toolbar that is currently visible.

To move a toolbar to another position:

- Click on the grip (handle) of the toolbar, and then drag the toolbar to a different location.

3.5 Working with sheets

The main part of the work area is occupied by sheets. Sheets provide an interface to a variety of functions, for example display of data, modification of settings, analysis, reporting, etc.

3.5.1 Introduction

Sheets can be divided into the following categories:

- **System sheets** These sheets provide specific user interfacing for Perception standard and optional features.
- **User Sheets** You can add as many user sheets as you want. These sheets can be deleted.
- **CSI Sheets** With the Custom Software Interface (CSI) option you can create your own plug-in for the Perception software. The graphical user interface of this plug-in is based on sheets. In your application you define the behaviour of the sheet.

3.5.2 Sheet management feature

The following feature is a management tool that allows the user complete freedom to organize and display the sheets in Perception.

For improved management of the Perception work space, the Sheet management feature will help personalize Perception quickly and easily.

A menu bar Item “Sheets” is now available; it contains all of the functions and commands related to sheet selection and also the **Sheet Manager**.

The Sheet menu provides the ability to:

- Load and Unload sheets from the Perception Engine at any time
- Set the default value for all sheets on start-up
- Show or hide loaded sheets

Sheets that have a check-mark beside them are loaded and showing in Perception, sheets that do not have a check-mark are loaded but hidden. The **New User Sheet** command is now also available in this menu.




Figure 3.11: Sheets menu

- 1 In the menu bar click **Sheets**
- 2 Select **Manage sheets** to open the Sheet manager interface.





Figure 3.12: Sheet manager

- 1 Click to highlight the sheet to be changed
- 2 On the left you will see a short description of the sheet, and above are two buttons:



Loads a sheet into the Perception engine. When a sheet is loaded, you can select whether or not it shows as an active sheet.



Remove will unload the sheet from the Perception engine immediately. It will not be visible until reloaded with **Load**.

Startup default includes a drop down selection box in which you can select the Startup default of the selected sheet.

When Perception starts a sheet can be started in either of the following modes: **Hidden, shown or unloaded**.

3.5.3 Sheet commands and options

Sheets by themselves can have various commands and options. These can be generic or pertinent to a specific sheet.

To access the sheet commands and options do one of the following:

- Select a command from the dynamic menu or a sub menu.
- The toolbar provides a selection of commonly used commands. Click the command to execute.
- Right-click the sheet tab. In the context menu that comes up select your command or option.

3.5.4 Active and user sheets

For display of data the active and user sheets are used.

The **active sheet** is always available and cannot be deleted. It is a special sheet that by default has a single display that shows the active recording. The active recording is usually the recording that is being acquired or reviewed. If new data comes in (from the hardware), it shows up in the display that is on the active sheet automatically. You can re-arrange the layout of the active sheet when required.





Figure 3.13: Active sheet default layout (example)

For additional flexibility **user sheets** are provided. On a user sheet you place various objects like waveform displays, meters, images, etc. You can add multiple sheets, each with their own layout and content. This allows you to define various layouts for various parts of a measurement task and quickly switch between them.

To add a user sheet:

To add a user sheet do one of the following:


- In the menu bar choose **Sheets ▶ New User Sheet**.
- When visible, in the file **toolbar** click the **New Sheet** button . In the drop down list select **User Sheet**.
- Right-click a sheet tab or in the sheet tab area. In the context menu that comes up select **New Sheet ▶ User Sheet**

Layout and splitters

By default a user/active sheet is a single area in which you can place a single object: display, meter array, picture or video. To add more objects to a single sheet you can modify the layout of a sheet to include up to 4 sections. Each section can contain one object. Sections are separated by splitters. The splitters can be moved to resize the sections.

To modify the layout of a sheet:

To divide a sheet into two or more sections do one of the following:

- In the menu bar choose **[dynamic menu] ▶ Sheet Layout** and select one of the presented options in the submenu.
- When visible, in the dynamic **toolbar** click the **Sheet Layout** button . In the drop down list select one of the presented options in the submenu.
- Right-click in an empty sheet area. In the context menu that comes up select **Sheet Layout** and select one of the presented options in the submenu.

Note *When you modify the number of sections within a sheet, layout options may be lost.*







Figure 3.14: Sheet layout select example

Once a layout is selected for a sheet, splitters appear that divide the sheet into sections. These splitters can be freely moved. When you hover the mouse over a splitter, the mouse pointer will change into a pointer with arrows. The arrows point in the direction that you can move the splitter. Click and drag the splitter in the required direction.

The following cursor icons are used:

 When this cursor shape is visible you can move the splitter that divides the sheet area horizontally.

 When this cursor shape is visible you can move the splitter that divides the sheet area vertically.

 Four way splitter icon: this icon appears when you are in the vicinity of an intersection of a horizontal and vertical splitter. You can now freely move both splitters at the same time.

3.5.5 Sheets and workbooks

As standard Perception has one workbook that contains all the sheets that are available. As an option Perception allows you to create multiple workbooks. When this option is installed you can create new workbooks, delete, copy and paste workbooks. Workbooks can be placed anywhere on your screen or secondary monitor(s). You can move sheets from one workbook to another workbook.

To move a sheet:

To move a sheet to another workbook do one of the following:

- In the menu bar choose **[dynamic menu] ► Move sheet [sheet name] to ►** and select one of the presented options in the submenu.
- Right-click the sheet tab. In the context menu that comes up select **Move sheet [sheet name] to ►** and select one of the presented options in the submenu.

4 Navigator Panels

4.1 Introduction

Navigators within Perception are used to easily find your way through the various data originators. A navigator resembles Windows® Explorer with paths and folders to the various data sources. While Windows® Explorer only deals with files, the Perception navigators allow you to browse files, hardware, variables, etc. Navigators are organized as palettes. For details on palettes refer to "Using palettes" on page 66.

For ease of use the Navigators are split into three classes:

- **Hardware** The hardware navigator lists all available hardware within a network. This includes all mainframes that you use, that are in use by somebody else or are not in use at all. This is also the place where you can select (connect to) the hardware that you want to use for a specific experiment. A tree structure provides the possibility to go down to the channel level for detailed information.
- **Recordings** The recordings navigator lists all available recordings. Recordings can be physically stored in archives on your PC or network, cached in acquisition hardware, or referenced by Perception.
- **Data Sources** The data sources navigator allows you to browse and access all data that is available within Perception. This can be referenced/opened recordings, (system) variables, formula results, etc.
- **Sensors** The sensors navigator lists all available HBM sensors and User sensors (optional). You can browse and access all sensors within the Perception Sensor Database.




Figure 4.1: Perception navigators

In addition a Properties window is available that shows details - when available - of the selected item within a navigator.

4.2 Hardware navigation

Data acquisition hardware within Perception is based on the concept of a recorder. A recorder consists of a number of acquisition channels that share the same basic recording parameters sample rate, sweep length and pre- and posttrigger length. Usually a single recorder is physically identical to a single acquisition card.

Multiple recorders can be placed in a single mainframe. The mainframe is the housing for the recorders, provides the power and includes the interface for the local area network. A mainframe has its own network address (IP address).

Within the Perception software recorders can be combined into logical groups for easy reference. Recorders within a group are not bound by physical mainframes.

The navigator uses a Tree View to display the various items as an indented outline based on their logical hierarchical relationship. The Hardware section displays the acquisition unit(s) currently visible to Perception. All recognized systems on your network are automatically displayed. The list is divided into two categories: **Used Hardware** and **Unused Hardware**.

The **Used Hardware** entry displays the acquisition units currently connected to Perception for data acquisition.

The **Unused Hardware** entry shows mainframes that are available on the local area network to be connected to the Perception software. Mainframes that are found on the network but are already in use are greyed out.




Figure 4.2: Hardware tree with mainframes (detail)

- A Unused hardware
- B Used hardware
- C Wake-on-LAN hardware
- D Manually added hardware
- E Detected hardware with a potential problem

- A Unused hardware** available for connection.
- B Used hardware** used by another user (user name in brackets). It is not possible to connect to this hardware until the other user has disconnected from it. Perception will be automatically updated when this occurs.
- C Wake-on-LAN hardware;** this hardware was previously detected with Wake-on-LAN, but is now no longer detected on the network. Connecting to this device will first attempt to power it on via Wake-on-LAN. If successful it will connect normally, if the device does not startup the connection will fail. Connecting to this type of mainframe will typically take longer than connecting to hardware that is already running.

- D Manually added hardware**, it is possible to add manual GEN series mainframe configurations. Mainframes added manually will be shown like this. For more information, please refer to "Add an unlisted system" on page 87
- E Detected hardware** with a potential connection and/or configuration problem. When connecting to the hardware you will be shown a dialog to resolve the detected issue. For more information, please refer to "Network conflict" on page 84.

You can select to show or hide the unused hardware section.

To show or hide the unused hardware:

- 1 Right-click anywhere in the hardware navigator.
- 2 In the context menu that comes up select **Show Unused Hardware**.




Figure 4.3: Hardware navigator menu

4.2.1 Add and remove a data acquisition system

When the Unused Hardware section is visible you can add data acquisition systems to be used with your test. When you add a system you will also automatically connect to that system and communication is started.

To add a data acquisition system:

To add a data acquisition system do one of the following:

- Click on a mainframe listed in the Unused Hardware section and drag it onto the Used Hardware section.
- Select a mainframe listed in the Unused Hardware section. Double-click on this selected mainframe.
- Select a mainframe listed in the Unused Hardware section. With a right mouse click call up the context menu. In this menu select the Connect command.

- The mainframe will be added to the Used Hardware section. Recorders will be grouped together, based on their time-base settings. So all 1 MS/s boards will be placed into a single group, and all 250 kS/s boards will be placed in another group. If a group with the same time-base setting already exists, the recorder will be added to it, even if it contains recorders from another mainframe.

Note *When using multiple mainframes, recorders may be automatically renamed when placed in the same group to avoid naming conflicts.*

To see individual recorders expand the mainframe tree by clicking on the + sign to the left of the mainframe or group entry.

When the mainframe is transferred to the Used Hardware section, a connection dialog will come up, showing the progress in establishing the connection.





Figure 4.4: Hardware connection status dialog

In the Connecting Hardware dialog:

- Click **Close** when connection has finished successfully.
- Click **Show Diagnostics** when you want to see an overview of the connection procedure. This may be useful when connection failed. Selecting this command will open the Diagnostics Viewer sheet.
- Select **Automatically close this dialog when connection has finished successfully** when you want this dialog to close automatically when connection has finished successfully.



Category	Description	Date
(i) sim_VGEMU-LT010	Connection finished successfully.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Mainframe configuration completed.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Recorders assigned to group.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Assigning recorders to group.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Using group 'Group1'	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Creating a new group.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Finished checking for existing groups.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Checking for existing groups.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Connection finished	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Connection successful	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Finished connecting to mainframe.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Mainframe storage 2 available.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Mainframe storage 1 available.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Updating storage possibilities.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Starting basic mainframe configuration.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Successfully connected to the mainframe.	2012-03-05 16:02:30
(i) sim_VGEMU-LT010	Starting mainframe connection.	2012-03-05 16:02:29
(i) sim_VGEMU-LT010	Starting actual mainframe connect	2012-03-05 16:02:29
(i) sim_VGEMU-LT010	Doing type check	2012-03-05 16:02:29
(i) sim_VGEMU-LT010	Verifying input parameters	2012-03-05 16:02:29

Figure 4.5: Diagnostics Viewer sheet (example)

Network conflict

If a network setting conflict is detected, this conflict must be resolved before the connection can continue. The Perception Connect dialog appears (see Figure 4.6).

Initially, the dialog appears with the settings currently used by this mainframe, i.e. the ones containing the conflict. Make the changes required to resolve the conflict and click **Continue** to complete the connection process.

Note *If the conflict has not been properly resolved, this is indicated in the diagnostics overview. The hardware is still shown in **Unused Hardware** in this case. By connecting to the hardware again, the Perception Connect dialog will appear again.*




Figure 4.6: Perception Connect dialog

- A Description** of the connection and/or configuration problem encountered by Perception.
- B Mainframe name** The name of the mainframe on which the problem was encountered.
- C DHCP** To configure for dynamic addressing (recommended default), click for the mainframe to obtain an IP address automatically, and then click **Continue**.
- D Fixed IP address** To configure for static addressing, click **Use the following IP address**, and in **IP address** and **Subnet mask** type the IP address and subnet mask to match the settings of the network adapter installed in the PC running Perception
- E Network adapter information** List of available network connections of the PC running Perception. In Windows®, check the detailed settings of the network adapter. Make sure that the network adapter settings in the mainframe match the settings in the PC.
- F** Click **Cancel** to stop the connection process for this mainframe.
- G** Click **Continue** to apply the changes and to continue the connection.

If a reboot of the system is required to apply the new network settings, this will be done automatically. The progress window (see Figure 4.7) will close automatically when the mainframe has been rebooted.




Figure 4.7: Perception progress indicator for mainframe reboot

To remove a data acquisition system:

To remove a data acquisition system from the list of used hardware do one of the following:

- Click on a mainframe or group listed in the Used Hardware section and drag it onto the Unused Hardware section.
- Select a mainframe or group listed in the Used Hardware section. With a right mouse click call up the context menu. In this menu select **Disconnect** (for mainframes) or **Remove** (for groups). The mainframe will be moved to the Unused Hardware section.

When you are not sure:

When you are not sure if all systems are listed do the following:

- 1 Make sure the Unused Hardware entry is available.
- 2 Right-click the Unused Hardware entry.
- 3 In the context menu that comes up click **Scan for Mainframes**.

Password protect a system

Control access to a mainframe can be password protected. Refer to the user manual that came with your acquisition system for more information on this topic. From Perception you can modify this password.

To modify a mainframe password:

- 1 Make sure you are in mainframe mode - right click in the **Hardware** palette and select **Mainframe** view - and that your hardware is listed in the used hardware section.
- 2 Right-click the mainframe that you want to modify.
- 3 In the context menu that comes up click **Change Password...**

- 4 In the dialog that comes up enter the old password and the new password. Type the new password also in the **Retype password** field.




Figure 4.8: Change Password dialog

- 5 Click **OK** to effectuate the changes or **Cancel** to close this dialog without modifications.

Add an unlisted system

The Perception software can locate known acquisition systems that are on the same network. When a system is located behind a network firewall it cannot be found by automatic detection.

To add an unlisted system:

To connect to a system that is not shown in the Unused Hardware section proceed as follows:

- 1 Make sure the Unused Hardware entry is available.
- 2 Right-click the Unused Hardware entry.
- 3 In the context menu that comes up click **Add Configuration ...**
- 4 In the dialog that comes up enter a name for the mainframe and the correct IP-address.




Figure 4.9: Add Configuration dialog

- 5 Click **OK** when done or **Cancel** to quit without modifications.

Enable and disable individual recorders


You can re-arrange the configuration of recorders within the Used Hardware section as described later. You cannot move individual recorders from the Used Hardware to the Unused Hardware. When you do not want to use a specific recorder you can disable this recorder and enable it again when you want to use it.

You can also access this setting through the Settings sheet.

Enabling and disabling individual recorders:

To enable and disable individual recorders proceed as follows:

- 1 Make sure you can see the individual recorder(s). If not so, expand the group or mainframe tree by clicking on the + sign on the left side of the group or mainframe entry.



- 2 When enabled select **Disable** to disable the recorder. The recorder will be disabled and automatically removed from its current group and moved to the disabled group. Another way to disable recorders is to drag and drop them into the disabled group.

When disabled select **Enable** to enable the individual recorder. The recorder will be added to a newly created group. Another way to enable a recorder is to drag and drop it to an enabled group. The recorder icon will reflect the state of the recorder.

Note

A recorder can only be added to a group that is set to a sampling rate it also supports. E.g. it is not possible to add a 1 MS/s recorder to a group that is set to 100 MS/s. When adding a recorder to a group, its sampling rate is automatically adjusted to the sampling rate of that group, also its sweep/continuous settings are automatically adjusted.

4.2.2 Firmware upgrade

If a new version of Perception has been installed, the Firmware will be upgraded. See the following steps with an example of a GEN series mainframe for further information.

- 1 Perception has detected that an update is required.




Figure 4.10: Firmware upgrade (Step 1)

Click **OK** to continue with the next step.



WARNING

**DO NOT POWER OFF OR UNPLUG YOUR SYSTEM WHILE IT IS UPDATING.
THE MAINFRAME CAN BE DAMAGED.**

- The update is in progress. Please wait for the next step.




Figure 4.11: Firmware upgrade (Step 2)



WARNING

**DO NOT POWER OFF OR UNPLUG YOUR SYSTEM WHILE IT IS UPDATING.
THE MAINFRAME CAN BE DAMAGED.**

- The system is rebooting. Please wait until this process is finished.




Figure 4.12: Firmware upgrade (Step 3)



WARNING

**DO NOT POWER OFF OR UNPLUG YOUR SYSTEM WHILE IT IS UPDATING.
THE MAINFRAME CAN BE DAMAGED.**

4.2.3 Arranging recorders and viewing options

Depending on your requirements you can select one of three viewing options for the hardware navigator: group view, mainframe view or recorder view.

- **Group View** In group view recorders are arranged in the used hardware section as being part of a group. A group is a “logical” arrangement of recorders and has no relation to the physical hardware location of the recorders. Recorders can be moved from one group to another.
- **Mainframe View** In mainframe view the recorders are listed as they are located in the physical mainframes. You cannot move recorders around.
- **Recorder View** In recorder view the recorders are listed in a single branch without any reference to groups or mainframes.

To select a view mode:

- Use a right mouse click anywhere in the Hardware navigator. In the context menu that comes up select the view mode.

To add a group:

To add a group proceed as follows:

- 1 Select Group View.
- 2 Right-click the Used Hardware entry.
- 3 In the context menu that comes up select **Add Group**.

To delete a group:

- 1 Select Group View
- 2 Select the group you want to delete.
- 3 With a right mouse click access the context menu and choose **Remove**. The recorders that are in this group will be disabled and moved to the disabled group.

Note *When removing the last recorder from a group, the group will automatically be deleted.*

To rename a group:

- 1 Select Group View
- 2 Select the group you want to rename.
- 3 With a right mouse click access the context menu and choose **Rename**. You can now rename the group. Other options are: click the group name twice or press F2.

Note *Groups should be uniquely named. If a duplicate name is used, the group that previously had that name will be automatically renamed.*

To move a recorder:

To move a recorder from one group to another group:

- In group view select the recorder and drag it to another group.

Note *A recorder can only be added to a group that is set to a sampling rate it also supports. E.g. it is not possible to add a 1 MS/s recorder to a group that is set to 100 MS/s. When adding a recorder to a group, its sampling rate is automatically adjusted to the sampling rate of that group, also its sweep/continuous settings are automatically adjusted.*

Note *If a recorder with the same name already exists in the group, that recorder will be automatically renamed to a unique name. Two recorders with the same name cannot exist in the same group.*


4.2.4 Data source selection for display

You can use the hardware navigator to directly select a data source for display of data. Basically you connect a display to acquisition hardware as data source.

To select a data source:

To select data sources using the hardware navigator do one of the following:

- Select a recorder or a number of channels and drag them onto an empty sheet or sheet section. A new display will be created that fills the complete sheet (section) with the selected channels displayed. When data is available this will be shown.



Note *The selected channels will be added as overlaid traces to the targeted pane.*



HINT/TIP

Hold down the Shift-key while dragging the channels. This will create/add meters instead of waveforms.

4.3 Recordings navigation

Previously recorded data files are accessible through the Recordings Navigator. This navigator uses a Tree View to display the various items as an indented outline based on their hierarchical relationship. The Navigator enables you to open data files into Perception for review, or to use selected waveforms as a reference. In addition the navigator allows you to organize files by moving and deleting files and the creation, deletion and assignment of storage folders.

Data files are divided into four groups, defining their fundamental origin.




Figure 4.13: Recordings Navigator panel

- A Archives: data stored on PC or network
- B Default archive for storage of streamed data
- C Open Recordings: references to recordings open in Perception
- D On-line storage devices of connected hardware
- E Data files stored on a Vision data acquisition system

- A Archives** The archives section contains all recorded data that is stored on the control PC's local disk(s) accessible network locations. In this section you can add and remove additional storage locations to organize the data. Here you also define where streamed data from the acquisition hardware must be stored. Predefined storage locations cannot be deleted.
- B Default archive** for storage This is the location where streamed data from the acquisition hardware is stored.
- C Open Recordings** This folder does not hold actual data. It holds references to recordings that are open in Perception .
- D Mainframes** Depending on the type of acquisition hardware and installed options local storage on the connected hardware can be available. For example an iSCSI storage location connected to a GEN series mainframe. These storage locations are shown in this folder.
- E Visions** Data stored on a connected Vision data acquisition system is shown here. As opposed to "mainframes", Visions cannot be controlled from within the Perception software.

4.3.1 Working with archives

The archives section holds all stored recordings that are available through your PC's environment. By default it has two folders that cannot be deleted:

- **My Recordings** Your personal folder: this folder contains recordings that are available only to the current user of the PC. This is the person that is logged in as user within the Windows® environment.
- **Shared Recordings** Perception also provides a Shared recordings folder for files you want to share with other users.

You can add more folders to the Archives directory.

To add an archive folder:

To create a new archive folder proceed as follows:

- 1 Right-click the Archives entry and click **Add Archive...**
or
- 1a Navigate to the File menu and then to **Archives ► Add New Folder...**
- 2 In the **Browse for Folder** dialog that comes up do one of the following:
 - Browse to and select an existing folder. Click **OK**.
 - Click **Make New Folder**. A new folder is displayed with the default name New Folder selected. Type a name for the new folder, and then click **OK**.

The folder will be added to the tree view of Archives. You can add and manipulate subfolders through Windows® Explorer.

To gain access to Windows® Explorer:

- Right-click a folder in Archives and click **Open in Windows Explorer**.

Note *You can also assign removable storage devices as archive folders. When you remove such a device, for example a memory stick, the folder will still be assigned as an archive folder. An exclamation mark on the folder icon indicates that this folder is not valid. When you insert the device again it will be recognized automatically and used as defined.*

You can delete folders that you have created. The default folders cannot be deleted.

To delete an archive folder:





To delete a created archive folder from the Archive list proceed as follows:

- 1 Select the folder that you want to delete.
- 2 Use a right mouse click to access the context menu.
- 3 In the context menu click **Delete**.

Current acquisition folder

Within Perception you designate a folder that is used for data capture: when an acquisition system is acquiring data in a continuous mode and has no local storage capability, the data will be spooled to the PC and stored in this designated folder.

The following icons are used to identify the various folder options:

- The  icon is used to identify the “current” acquisition folder.
- The  icon indicates that the “current” acquisition folder is within the selected folder.
- The  icon is for standard recording folders.
- The  icon is for temporarily unavailable folders.

By default the **My Recordings** folder is set as current acquisition folder. You can select any other folder within Archives as current acquisition folder.

To set a folder as current acquisition folder:

- 1 Select the folder that you want to assign as current acquisition folder.
- 2 Use a right mouse click to access the context menu.
- 3 In the context menu click **Make Current**.

Open Recordings








The Open Recordings section of the recordings navigator lists all recordings that are open in Perception . This list provides quick access to open recordings without going through file lists in folders and subfolders in the archives section.

An open recording is identified with the  file open icon.

File types

Within Perception you can encounter various recording/waveform file types. Most of these file types have a distinct icon. Below is a list of file types and the corresponding (large) icons.

Table 4.1: File types

ICON	FILE TYPE
	LRF file type. This is the standard file type for Dimension data acquisition systems. Color coded with a magenta waveform and header.
	NRF file type. This is the standard file type for Odyssey and Vision data acquisition systems. Color coded with a red waveform and header.
	PNRF file type. This is the standard file type for data acquisition systems that are controlled by Perception. Color coded with a blue waveform and header.
	TEAM file type. This is the standard file type for data acquisition systems controlled by the TEAM256/TeamPro/ProView software. Color coded with a golden waveform and header.
	WFT file type. This is the standard file type for data acquisition systems controlled by the “Nicolet Windows” software. Color coded with a purple waveform and header.
	ASCII file type. ASCII* files having the extension *.txt or *.asc are accessible through the Recordings Navigator.
	Catman binary DAQ file. These files, with the .bin extension, are accessible through the Recordings Navigator and the File menu.

* For more information about ASCII files please refer to appendix “ASCII Recording Loader” on page 885.

4.3.2 Remote access

The GEN DAQ series mainframes can be used in combination with Perception and in unattended mode. If the GEN DAQ series mainframes are setup to store recordings on the internal disk, these recordings can be accessed using Perception or by using regular network file sharing (SMB/CIFS).

The **Remote Access** option is accessible via the Perception **Mainframe Settings** dialog. Once connected you can select the menu item “Mainframe Setup..” in the “Settings” menu.

Note *The Remote access option is only available when Perception is connected to a GEN DAQ system.*




Figure 4.14: Remote access controlled by Mainframe Settings dialog

A GenDAQ API

Enable access to the mainframe using GenDAQ API

By granting access to the GenDAQ API, the mainframe can be controlled from any device in the network which runs a client application that supports the GenDAQ API.

B The file sharing option can be enabled by checking the **Enable access to the internal storage of the mainframe checkbox.**

C/D Set up the **Username** and **Password**. Click **Apply** to confirm this action, than the GEN DAQ series mainframe can be accessed through the network share.

E **Access mainframe storage using Windows® Explorer** In order to access the mainframe storage, click the link or enter the displayed path in the adress bar of the Windows® Explorer.

Accessing the mainframe using Windows® Explorer:

- 1 Open Windows® Explorer and type the network share in one of the following formats.
 - IP address based: \\<IP address>\Recordings (see Figure 4.15)
 - Name based: \\<Mainframe name>\Recordings

Note *When using mainframe names which exceed 16 characters the mainframe IP address should be used to access the network share.*




Figure 4.15: Windows® Explorer IP adress

- 2 Connecting to a network share is only possible with the right credentials (username + password). When a new network connection is setup Windows® security asks for the **Username** and **Password**, once these are provided Windows® can setup the connection (see Figure 4.16).




Figure 4.16: Windows Security dialog

A Prefix: GHS\

Once the connection is established successfully Windows® caches the credentials.

Note *The username must be prefixed with **GHS** to specify the correct domain/workgroup (see Figure 4.16).*

Note *When the password is changed after Windows® cached the credentials, the PC should be rebooted before the network connection to the GEN DAQ can be made using the changed password.*

3 After the connection to the network share has been set up successfully the recordings can be accessed directly using Windows® Explorer (see Figure 4.17). The recordings of the internal disk can be copied and deleted.




Figure 4.17: Access to recordings via Windows® Explorer

Note *Do not delete the active recording.*

4.3.3 Externally stored recordings

Apart from the stored recordings that are available through your PC's environment, there can also be data available that is stored directly onto a storage device in a data acquisition system:

- iSCSI storage locations connected to a GEN DAQ product.
- External SCSI disk(s) connected to a GEN DAQ product.
- Hard Disk Drive in a Vision data acquisition system.

Recordings that are located on a GEN series data acquisition system need to be transferred to the PC first before you can display them. Recordings located on a Vision can be viewed directly; that is, you can connect to a recording on a Vision without the need to copy that recording to the PC local storage.

Mainframes

The mainframes section lists connected mainframes that have on-board storage for recordings. Currently the GEN series data acquisition systems are supported. Recording files in a mainframe can be copied, moved and deleted from within the recordings navigator. They can not be directly opened for viewing.

To delete a recording in a mainframe:

- 1 Right-click the file you want to delete to access the context menu.
- 2 In the context menu click **Delete**.
- 3 In the Confirmation dialog that comes up click **OK** to delete the file.

To move or copy a recording from a mainframe:

To move or copy one or more recordings from a mainframe to the control PC proceed as follows:

- 1 Select the file(s) you want to move or copy.
- 2 Right-click the selected file(s) to access the context menu.
- 3 In the context menu click **Move to Archive [archive name]** or **Copy to Archive [archive name]**.
- 4 A dialog comes up that shows the progress. The current folder is used to create a subfolder to store the transferred data.

The move/copy progress dialog provides feedback on the transfer progress and can also be used to interrupt the transfer of either a single recording or the complete transfer process.




Figure 4.18: Copy / Move progress dialog

- A File in transfer: number, name and source
- B Target location
- C File in transfer status and control
- D Total transfer status and control
- E List of files with current status

- A File in transfer** In the **Transfer** section of the dialog information is available on the current file in transfer. This includes the running number, file name and source location. The **Source Location** identifies the name of the mainframe.
- B Target Location** The **Target Location** identifies the storage folder on the controlling computer. By default this is a subfolder of the current acquisition folder. The name of the subfolder is the name of the mainframe. To modify the location of the current acquisition folder refer to "Current acquisition folder" on page 96.
- C - D Progress** The **Progress** section includes progress indicators for the current file in transfer and the total transfer. When you click the **Skip** button the current file transfer will be aborted and the next file transfer will be started. Click the **Stop** button to abort the complete transfer process.

E File list The file list area shows all files included in the copy or move process. In front of the file name an icon displays the current status of the file.

Options are:



Indicates a file that has to be transferred.



Indicates the file currently in transfer.



Indicates a file that has been transferred successfully.



Indicates a file that has not been transferred correctly or has been aborted.

In the progress dialog click **OK** when done. Select **Close this dialog when finished** if you want to close the dialog automatically after data transfer.

Visions

Although you can open a recording directly from a Vision disk, you cannot delete, move or copy a recording from the Vision disk to the control PC. For file transfer capabilities of a Vision refer to the User Manual that came with the Vision.

When you are not sure:

When you are not sure if all Visions are listed do the following:

- 1 Right-click the **Visions** entry.
- 2 In the context menu that comes up click **Scan for Visions**.

Add an unlisted system

The Perception software can locate known Vision systems that are on the same network. When a system is located behind a network firewall it cannot be found by automatic detection.

To add an unlisted system:

To connect to a Vision that is not shown in the Visions section proceed as follows:

- 1 Right-click the **Visions** entry.
- 2 In the context menu that comes up click **Add a Vision ...**
- 3 In the dialog that comes up enter a name for the Vision and the correct IP-address.
- 4 Click **OK** when done or Cancel to quit without modifications.



HINT/TIP

Please note Perception also offers file copy / move functionality through user keys, these can also be used in combination with recording automation. For details on how to use user keys, please refer to manual User keys and Macros (A05025).

4.3.4 Data source selection for display

You can use the Recordings Navigator to select a recording as data source for display. Perception provides various options to load/open a recording.




Figure 4.19: Recordings Navigator with shortcut menu

To load / open a recording:

To load or open a recording do one of the following:

- Double-click on a recording. This will open that recording as experiment.
- Select a recording and drag it onto an empty sheet or sheet area. A new display will be automatically created that fills the entire sheet (area) with the selected recording displayed with channels as stacked (separated) traces.
- Select a recording and drag it onto an existing display. The selected recording will be added as overlaid traces to the targeted pane.
- Select a recording and use a right mouse click to access the context menu shown in Figure 4.19.




Figure 4.20: Load/open recording options



HINT/TIP

You can also load recordings through the **File ► Load Recording...** menu command. The dialog used for this operation offers also a variety of options that are almost identical to the ones described in this section. Refer to "Load Recording..." on page 354 for more information.

Review or Redo and experiment

As from version 4.0 the experiment concept is introduced in the Perception software: save and load the recorded data complete with the test environment, i.e. the data file and the workbench are combined into one file. This file has the extension .pnrf like the classic data files.

For more information on the experiment concept refer to "Experiment" on page 40.

See also the section "Start dialog options" on page 55.

Load as Active

By default the active display on the active sheet is connected to the actual hardware. The last made recording is on this display by definition. You can load any other recording as active. This will load the selected recording into the active display on the active sheet, and therefore becomes the active recording. When a new recording is made in hardware, this will again replace the currently connected recording in the active display.

For more information refer to "Active display" on page 36.

Load as Reference

While there can only be one active recording there can be multiple reference recordings. When you click **Load as Reference...** a dialog comes up that allows you to give the recording a meaningful name.

The reference recording entry now is not an actual recording, but a pointer (reference) to a recording. You can assign a reference recording to a display. You can also modify the actual recording that is referenced by the reference recording. By doing so the display that shows the reference recording will be updated to reflect the new recording.

To modify the source a reference recording:

To modify the source of an existing reference recording proceed as follows:

- 1 Select a recording and use a right mouse click to access the context menu.
- 2 In the context menu click **Load as Reference...**
- 3 In the dialog that comes up enter the name of the existing reference to replace the source.

Load Using Filename

This option makes the recording available in the system without creating a display or replacing any other data. The recording is available with its own file name through the *Open Recordings* section in the Recordings Navigator and in the Data Sources Navigator.

Open in new User Sheet

This option creates a new user sheet. A new display will be automatically created that fills the entire sheet with the selected recording displayed with channels as stacked (separated) traces.

Close an open recording

To close an open recording:

- 1** Select an open recording and use a right mouse click to access the context menu.
- 2** In the context menu that comes up click **Close**.

4.4 Data Sources navigation

The Data Sources Navigator provides a comprehensive list of all available data sources within the Perception environment. These data sources are connected hardware, opened files, system generated constants and variables, formula results, etc.




Figure 4.21: Data Sources Navigator and expanded Active branch

- A Active: active recording in active display/sheet
- B Display: information and parameters of displays
- C Formula: results of formulas
- D Hardware: various information about connected hardware
- E Loaded/opened recordings
- F System: a variety of system information

- A Active** The Active section provides data from the current active recorder/recording. For a recorder this will be the data of all channels and extracted parameters like maximum, minimum, etc. Depending on the originating system more or less parameters are available. You can drag data from this location into a display.
- B Display** The display section provides information and data of the available displays. information includes relevant values of all cursors, markers, active sweep and active trace; and start and end time.
- C Formula** The formula section holds the results of the formulas as defined in the formula database. These results can be numbers, strings and waveforms. You can drag data from this location into a display.
- D Hardware** The hardware section list information and status of the connected hardware. Depending on the connected hardware this may include battery and system power status, fan speeds, and temperatures of amplifiers and processors. Note that the actual data channels are not listed here. To add data from the acquisition channels use the Hardware Navigator.
- E Loaded and opened recordings** Each open recording is listed. For each recording the actual recorded data is available as well as information like company and user name as well as recording times and title.
- F System** The system section provides a variety of information ranging from numerical constants, to acquisition status and data/time information.

You can use any of these data sources. Depending on the type of data source you can use them in formulas, displays or meters.

4.4.1 Data source selection for display and meters

From the Data Sources Navigator you can select a data source to show data in a meter or display, depending on the type of data.

To use data:

To use data from one or more of the listed data sources do one of the following:

- Select a recorder (recording) or a (number of) channels and drag them onto an empty sheet or sheet area. A new display will be automatically created that fills the entire sheet (area) with the selected data displayed with channels as stacked (separated) traces.
- Select a recorder (recording) or a (number of) channels and drag them onto an existing display. The selected data will be added as overlaid traces to the targeted pane.
- Select a parameter/value or a number of parameters/values and drag them on an empty sheet or sheet area. New meters will be automatically created that fill the entire sheet (area) displaying the selected parameters/values.

- Select a parameter/value or a number of parameters/values and drag them on an existing meter array. New meters will be added to the existing array displaying the selected parameters/values.



HINT/TIP

You can also drag data sources directly into a formula in the formula database. This allows you to quickly insert constants and variables into a function without the need to know the complete path of that variable. E.g simply drag a cursor X-position into your formula without typing the complete path like: `Display.Display1.Cursor1.XPosition`.

Search Similar

When you right-click a data source, the context menu has a single entry: Search Similar.

You can search within the Data Sources Navigator for sources that are similar to the selected one. For example when you select a maximum of a channel, Search Similar... will search for all maximum values within the data sources and list them. This list can then be dragged onto a sheet.

To use Search Similar:

- 1 Select a data source and use a right mouse click to access the context menu. Click **Search Similar...**
- 2 In the Search Results window that comes up:
 - select the required data sources and drag them onto the applicable location. Click **Close** when done.
 - select a data source and click **Goto**. The indicator in the Data Sources Navigator will jump to the selected data source. When required the tree will be expanded to show the selected data source.




Figure 4.22: Search Similar

4.5 Properties window

The Properties window displays the properties of a selected item in one of the navigators. Therefore it will be generally used in combination with one or more of the navigators.




Figure 4.23: Various Properties windows

Depending on the type of object you have selected various properties will be shown.

5 Acquisition Control and Status

5.1 Introduction

Note *When you are using Perception Version 8, some of the information in this manual may be outdated. Especially the acquisition modes described in chapter "5 Acquisition Control and Status" on page 113 and appendix "A Acquisition and Storage" on page 483 have been updated in Perception Version 8. For more information on new acquisition modes, please visit the Perception product page for the document "Perception V8 Acquisition Modes Quick Start".*

Within Perception all hardware related settings are accessible through the Settings sheet, with the exception of the acquisition control commands Start, Stop, Single Shot, Pause and (manual) Trigger. These commands are accessible through the Control menu, the control toolbar and the Acquisition Control palette.

The Settings sheet gives access to all hardware settings and may thus not be preferable for day-to-day operation.

Therefore Perception provides three additional palettes for acquisition control and status feedback:

- **Acquisition Control** The Acquisition Control palette has a user interface tailored towards daily operation. The palette can be docked and resized for optimal usage. It provides acquisition control as well as quick setup of the main acquisition parameters like recording length/time, sample rate, etc.
- **Status** The Status palette can be used to provide feedback on the acquisition, automation and battery status at a glance. Full-size indicators are used for easy readout even at a larger distance.

More detailed and background information on acquisition modes and storage can be found in appendix "Acquisition and Storage" on page 483.


5.2 Acquisition control

The Acquisition Control palette is used for quick access to the main parameters of an acquisition. It is also used to control the actual acquisition and to give feedback on the acquisition status of the controlled system(s).

To show or hide the Acquisition Control palette:

Do one of the following:

- In the menu bar choose **Window ► Acquisition Control**. If an acquisition control palette is currently visible it will have a check mark on its left hand side.



- When open click the top right button to close it.



- To auto-hide a control palette it must be open and docked. Click the **auto-hide** button. The palette will auto-hide when the mouse pointer leaves the palette area.



- Click on a tab of the 'hidden' control palette to let the palette slide open.

In general you will select **Control All** to control all groups at the same time. To control individual groups select a group. By default groups will be combined into one palette.

For more information on palette grouping refer to "Tabbed grouping" on page 69.

For more information on acquisition groups refer to "Arranging recorders and viewing options" on page 91.

For more information on the usage of palettes in general refer to "Using palettes" on page 66.

Before you can actually use an Acquisition Control palette you must be connected to acquisition hardware. Refer to "Add and remove a data acquisition system" on page 82 for details on how to connect to a data acquisition system.




Figure 5.1: Full blown Acquisition Control palette

- A** Recording name: See chapter "Name" on page 117.
- B** Acquisition control: See chapter "Acquisition" on page 118.
- C** Acquisition status, including storage capacity / usage: See chapter "Status" on page 120.
- D** User Mode (Slow sweep settings): See chapter "Slow Sweep" on page 121.
- E** User Mode (Fast sweep settings): See chapter "Fast Sweeps" on page 122.
- F** User Mode (Continuous recording settings): See chapter "Continuous" on page 123.

The actual layout/options that are available in the Acquisition Control palette depend on the connected hardware and the selected User Mode. See "Switch to Instrument Panel" on page 45 for more information.

You can show or hide various blocks of information and control in the palette.

To show or hide options in the Acquisition Control palette:

- Click the triangle in front of the group name. Example:



The Acquisition Control palette provides the functions as described in the following sections.

5.2.1 Name

The experiment name defines the name of the recording in progress. The experiment name uses autonumbering. When a recording starts, the experiment number is incremented.




Figure 5.2: Recording name

- 1 Experiment name: the name of the experiment in progress. When a recording starts, the recording number is incremented.
- 2 Click the **Set** button to change the name and/or number of the experiment.

To change the name of an experiment:

To change the name and/or number of the experiments proceed as follows:

- 1 Click **Set** (...) in the Name section of the Acquisition Control palette.

- 2 In the dialog that comes up:




Figure 5.3: Set Experiment Name dialog

- Enter a name in the **Name** field. This will be the 'prefix' of the recording name.
 - Enter a number in the **Serial number start** field. The serial number is the 'suffix' of the recording name (the part that is added to the end of the name). Here you define where to start.
- 3 Click **OK** when done.

5.2.2 Acquisition

This section provides the fundamental acquisition control.




Figure 5.4: Acquisition control

- 1 **Status display** Shows the current status of the acquisition.
- 2 **Acquisition control** The following controls are available:
 - **Preview** This button serves two purposes:
 - When no acquisition is active it will place the recorder in the pause or stand-by mode. Although the recorder is digitizing, no data is stored in memory or disk. This is useful for monitoring purposes.

- When an acquisition is active, the button will update to **Pause** once **Record** is selected (see Figure 5.5). Using the control now it will place the recorder in a hold mode: although the recorder is digitizing, no data is stored in memory or disk. At this point the **Record** button will change into **Resume** (see Figure 5.6), when **Resume** is selected, the current recording continues, when **Stop** is selected, the recording is finished.




Figure 5.5: Acquisition control - Record selected




Figure 5.6: Acquisition control - no data in memory or disk

- **Record**
The Record command starts acquisition of data.
- **Stop**
To stop an acquisition, select this button. This stops the current recording. When in a sweep acquisition mode, the current sweep will be aborted immediately.
- **Trigger**
The button is used to send a “manual” trigger command to the recorder(s) under control.

More acquisition

Apart from the basic acquisition controls as provided in this palette, the same controls are also available on other places:

- Control menu: refer to "Control menu" on page 393 for details.
- Accelerator (shortcut) keys: function keys F4 through F8

- Toolbar: see Figure 5.7 below.



Figure 5.7: Acquisition control toolbar

- 1 Start F4
- 2 Stop F5
- 3 Single Shot F6
- 4 Pause F7
- 5 Manual Trigger F8
- 6 Voicemark F9

Note *Voicemark is only enabled when making a recording with PC storage.*

5.2.3 Status

While the acquisition section is used to control - and return information about - the selected acquisition mode, the Status section is used to control - and return information about - the state or progress of the actual storage: armed, triggered or archiving.




Figure 5.8: Acquisition control - status

- 1 **Elapsed time** The elapsed time from start of recording. Format is days - hours : minutes : seconds.
- 2 **Memory gauge** The memory gauge gives visual feedback on the amount of local volatile memory of the acquisition system.
- 3 **Disk gauge** The disk gauge gives visual feedback on the amount of disk space used on the PC.

- 4 Data rate gauge** The data rate gauge gives visual feedback on the amount of data that will be stored to disk per second, the maximum amount is determined by the device the data is stored to. For more information please refer to "Continuous data rate gauge" on page 351.

Note *When you hover with the mouse pointer over a gauge, the amount of storage in use is displayed. A red indicator on the right hand side of the gauges is lit when storage requirements exceeded the available space.*

5.2.4 Groups

When data is stored, this data is organized in recordings. A recording (noun) is defined as all the data that has been stored between the start of acquisition (START command) and the end of acquisition. The end can be defined in various ways. A recording can have one or multiple sweeps, a continuous data stream or a combination of both.

These settings can be applied to each group of recorders independently. Recorders within a group will always have the same storage settings. If a subset of these recorders should be configured differently, they should be moved to their own group.

Note *The storage mode defines how data that is digitized and acquired is saved. Perception offers a variety of storage modes, each with various options. Each storage mode is related to a user mode, refer to section "User modes" on page 41 for more information on the available user modes.*

Slow Sweep

When in Slow-Fast Sweep mode, the slow sweep parameters are set here.




Figure 5.9: Slow Sweep parameters

- 1 Sample rate** Here you set the slow-time base or sample rate of the group: the rate at which the analog signals are sampled and digitized. Depending on the connected hardware and the User Mode, this option is available.

You can set the sample rate by selecting the desired value from the list of available sample rates, only values that are supported by all recorders in the group are listed.

Note *The maximum selectable sample rate of a group is determined by the slowest card in the group. E.g. a group containing a 1 MS/s recorder and a 100 MS/s recorder will have a maximum selectable sample rate of 1 MS/s. Moving the 100 MS/s to a new group will allow a selection up to 100 MS/s.*

Values may be shown using standard characters as technical multiplier prefixes. For example selecting a value as “10 k” will set the the time base to 10000.

Valid multipliers are: u (micro = 10^{-6}), m (milli = 10^{-3}), k (kilo = 10^{+3}) and M (mega = 10^{+6}).

- 2 **Length** Defines the total length of the slow sweep.
- 3 **Trig. Pos** the trigger position defines the location of the trigger point within the slow sweep: the part before the trigger (t=0) is negative time (history) and termed pre-trigger. The part after the trigger is posttrigger. Set this value as follows:
 - $0\% \leq \text{position} \leq 100\%$: trigger position is within the sweep
 - $\text{position} < 0\%$: trigger position is in front of the sweep (delayed trigger)
- 4 **Units** Select between samples, seconds or percentage (position only).

Fast Sweeps

These settings are used when storage mode is sweeps, dual or slow-fast.




Figure 5.10: Fast Sweeps parameters

- 1 **Sample rate** Here you set the fast-time base or sample rate of the group: the rate at which the analog signals are sampled and digitized. Depending on the connected hardware and the User Mode, this option is available.

You can set the sample rate by selecting the desired value from the list of available sample rates, only values that are supported by all recorders in the group are listed.

Note *The maximum selectable sample rate of a group is determined by the slowest card in the group. E.g. a group containing a 1 MS/s recorder and a 100 MS/s recorder will have a maximum selectable sample rate of 1 MS/s. Moving the 100 MS/s to a new group will allow a selection up to 100 MS/s.*

Values may be shown using standard characters as technical multiplier prefixes. For example selecting a value as “10 k” will set the the time base to 10000.

Valid multipliers are: u (micro = 10^{-6}), m (milli = 10^{-3}), k (kilo = 10^{+3}) and M (mega = 10^{+6}).

- 2 **Count** Defines the number of sweeps you want to acquire. This setting is disabled when infinite is selected.
- 3 **Length** Defines the total length of the fast sweeps.
- 4 **Trig. Pos** the trigger position defines the location of the trigger point within a fast sweep: the part before the trigger (t=0) is negative time (history) and termed pre-trigger. The part after the trigger is posttrigger. Set this value as follows:
 - $0\% \leq \text{position} \leq 100\%$: trigger position is within the sweep
 - $\text{position} < 0\%$: trigger position is in front of the sweep (delayed trigger)
- 5 **Infinite** Select this option for unlimited sweeps.
- 6 **Units** Select between samples, seconds or percentage (position only).

Continuous

Use this section to set the parameters of the continuous mode.




Figure 5.11: Continuous parameters

- 1 **Sample rate** Here you set the continuous-time base or sample rate of the group: the rate at which the analog signals are sampled and digitized. Depending on the connected hardware and the User Mode, this option is available.

You can set the sample rate by selecting the desired value from the list of available sample rates, only values that are supported by all recorders in the group are listed.

Note *The maximum selectable sample rate of a group is determined by the slowest card in the group. E.g. a group containing a 1 MS/s recorder and a 100 MS/s recorder will have a maximum selectable sample rate of 1 MS/s. Moving the 100 MS/s to a new group will allow a selection up to 100 MS/s.*

Values may be shown using standard characters as technical multiplier prefixes. For example selecting a value as “10 k” will set the the time base to 10000.

Valid multipliers are: u (micro = 10^{-6}), m (milli = 10^{-3}), k (kilo = 10^{+3}) and M (mega = 10^{+6}).

- 2 **Acq. mode** Defines the acquisition mode: when to stop this continuous acquisition. Possibilities are:
 - **Standard** Continuous acquisition without a specific stop condition. Click the **Stop** button to stop recording.
 - **Circular** Data is acquired in a circular buffer of specified length. Click the **Stop** button to stop recording
 - **Stop on trigger** Stop when a trigger occurs. Basically this is a sweep with pre- and posttrigger: pre-trigger = Total time - Posttrigger.
 - **Specified time** Stop after specified total time is acquired. The Total time field is now also available when the acquisition mode is Specified time.
- 3 **Total time** Defines the total time in seconds of the acquisition when the acquisition mode is circular or stop-on-trigger.
- 4 **Posttrigger** the trigger position defines the location of the trigger point within a fast sweep: the part before the trigger ($t=0$) is negative time (history) and termed pre-trigger. The part after the trigger is posttrigger. Here you set the posttrigger value in seconds.

5.3 Status

The Status palette is used for a quick overview of vital system parameters. A large font is used to allow visibility at larger distances.


To show or hide the Status palette:

Do one of the following:

- In the menu bar choose **Window ► Status**. A check mark appears in front of the status palette entry when it is visible.
- When open click the top right button to close it.



- To auto-hide a control palette it must be open and docked. Click the **auto-hide** button. The palette will auto-hide when the mouse pointer leaves the palette area.



- Click on a tab of the 'hidden' control palette to let the palette slide open.

For more information on the usage of palettes in general refer to "Using palettes" on page 66.

Depending on the connected hardware not all parameters listed below may be available.




Figure 5.12: Status palette example

- A** Fiber: refers to the status of Fiber Optic isolated Digitizer front-ends
- B** RTC: Real-Time Clock
- C** Acquisition: acquisition status as in acquisition control palette
- D** Trigger status: trigger status as in acquisition control palette
- E** Automation: automation as defined in the automation menu
- F** Timer: status of the Timer for Conditional Start Stop (Control menu)
- G** Sensor: status of connected sensors
- H** RT Formulas: displays RT-FDB deployment case status

Note that various status notifications are a combination of individual systems, recorders or channels. When no information is available the message “---” is displayed.

- A Fiber** The GEN series data acquisition system can be equipped with Fiber Optic Isolated Digitizers. These front-ends are sometimes battery operated. This field can display one of the following messages:
 - Power OK: system is ready
 - Power Off: system is not ready
 - Low Battery: low on battery
 - No Signal: cannot communicate with front-end
 - Warming Up: amplifier is warming up
 - Thermal Shutdown: internal temperature high

- B RTC (Real-Time Clock)** The real-time clock can be internal, synchronized to an IRIG or GPS receiver, synchronized to a PTP master or a Master within a Master/Slave configuration. This field shows the status as follows:
- Synchronized: all is OK
 - Synchronizing: almost OK
 - Out of Sync: the RTC lost synchronization with the synchronization source
 - No Signal: the RTC has no signal from the synchronization source

When you hover with the mouse over this field a tooltip displays the synchronization source.

- C Acquisition** Displays the acquisition status as shown also in the acquisition control palette. For details refer to "Acquisition control" on page 114. Messages are:
- Idle: waiting for a start command
 - Running: acquisition is active
 - Pause: the acquisition is temporarily suspended
 - Single Shot: the acquisition is in single shot mode
- D Trigger** Displays the trigger status. Messages are:
- Idle: no trigger detection active
 - Armed: ready and waiting for a trigger
 - Triggered: triggered and recording is still active. Otherwise stated: the recording is in the posttrigger segment
- E Automation** Informs about the status of one of the automation options. Messages are:
- Off: no automation is active
 - Busy: automation is active
 - Waiting: automation is active and waiting for new data to process
- F Timer** Returns the status of the timer for conditional start-stop. Messages are:
- Idle: no timer active
 - Off: timer is off
 - Wait for start: timer is waiting for a start of acquisition
 - Wait for automatic start: timer is waiting for an automatic start of acquisition (tooltip text only)
 - Wait for stop: timer is waiting for a stop of an acquisition
 - Wait for automatic stop: timer is waiting for an automatic stop of acquisition (tooltip text only)
 - Wait for automatic restart <time>: automatic restart after time (tooltip text only)
 - Wait for automatic restart <n> out of <m>: counted restart (tooltip text only)
 - Time to next Start: <time>: time to next start (tooltip text only)
 - Time to next Stop: <time>: time to next stop (tooltip text only)

- G Sensor** Shows the status of sensors connected to acquisition cards that support this feature. In case none of the channels support sensor status it will be displayed as None. Messages are:
- None: none of the channels in the acquisition system support sensor information retrieval. In case of a problem, the tooltip for this status field will identify the first channel this issue was found for.
 - No Sensor: no sensor is attached to one of the channels
 - Connected: a sensor is connected to all channels
 - Short circuit: one of the sensors connected has a short circuit
 - TEDS connected: a TEDS able sensor was detected
 - Overflow: a value exceeding the sensor range was detected on one of the connected sensors
- H RT Formulas** GEN DAQ mainframes can include real-time formulas. This field displays the worst case status of deployment of real-time formulas to any connected mainframe. Messages are:
- Error: one or more of the mainframes contain an RT-FDB setup that cannot be deployed
 - OK: no problems with deployment of RT-FDB formulas

6 Data Visualization

6.1 Introduction

One of the most important tasks within data acquisition is the visualization of data. The Perception software provides a variety of features for fast and accurate display of waveforms. The unique displays let you visualize real-time waveforms instantly. Review historical data while acquiring and displaying current data. Compare with reference curves or zoom in to see the finest details with free-style zooming and panning. The alternate zoom feature gives you two zoom areas simultaneously within the same waveform.

Two vertical cursors are used for interactive measurements. Combined with a cursor values table and sample snap you can have accurate results up to the sample level. In addition horizontal cursors and slope cursors are available for even more interactive interpretation of recorded data. Extensive replay facilities let you jog/shuttle through the data with ease.

For documentation purposes you can annotate points of interest on the display with a variety of display markers. These markers can be set manually or automatic at the end of an acquisition.

6.2 Waveform display fundamentals

On the active sheet and user sheets one or more waveform displays can be positioned. Each waveform display can have multiple pages. Each page of the display can then have multiple panes and each pane in the display can have any number of overlapped traces.

Pages

A page is a part of a display, just like a page that is part of a book. Each display has at least one page, but can have multiple pages. Multiple pages are used to display a large number of traces with the same X-axis parameters like start- and stop time, cursor position, etc.

Only one page per display can be shown at a time. The other pages are positioned virtually 'behind each other'. You can switch to other pages easily using the page control. Within a page one or more panes can be displayed.

Panes

A pane is a part of a page: the page is divided into panes. Panes are used to display data in separated - individual - areas. Panes can have individual heights and might contain one or more traces. By definition traces can be overlapped in a single pane. Overlapping can range from full (100%) to none (0%). Also the position of individual traces within a pane can be set freely.

Traces

A trace is the fundamental graphical representation of a digitized real-world analog signal, or the result of a formula/calculation on such a signal.

Views

In addition to the standard arrangement possibilities a display page can be divided furthermore into views. A view is a display-in-a-display and is used to represent the same data in a different way, for example as a zoomed part of the original trace(s).




Figure 6.1: Display components - part 1

- A Display
- B Pane @ 25% height with single trace. No scaling.
- C Pane @ 44% height with two traces, partially overlapped. Scaled.
- D Pane @ 17% height with one trace. No scaling.
- E Pane @ 14% height with two traces, fully overlapped. No scaling.
- F Pages 1 through 4
- G A trace

View types

Within a display page there can be a maximum of 4 (four) views. Depending on the settings these are:

- **Main view:** review in either sweep or recording mode.
- **Zoom:** a detail of the review view.
- **Alternate zoom:** another detail of the review view.

- **Live:** live streaming data



Figure 6.2: Display components - part 2

- A Review
- B Zoom
- C Alternate zoom
- D Live

Each view is laid out as an individual display. However, due to the nature of views, they are 'connected' to each other.

The display view area in detail

Note *In the display view area the cursor values in the Y-annotation area are the values of the primary vertical measurement cursors. There are also horizontal and slope cursors that are discussed in "Horizontal cursors" on page 169 and "Slope cursors" on page 170.*

The display view area provides a wealth of functions and information.




Figure 6.3: Display components - part 3

The display view area can be divided into four main regions:

- 1 Y-annotation area
- 2 X-annotation area
- 3 Control area
- 4 Trace area

Other items include:

- A View type
- B Upper display limit
- C Cursor values
- D Lower display limit
- E Range indicator
- F Trace name (active trace)
- G Sweep index

- H Page control
- I Time control
- J Replay control
- K Cursor values
- L Time scale
- M Active cursor
- N Trigger symbol
- O Passive cursor
- P Event bar

A View type Here you see and select the type of this view. The following basic types are available:

- Review
- Zoom
- Alternate zoom
- Live

Depending on the selected basic type various options are available. The view type indicator is highlighted when the view is selected. When selected it is the “active view”.

B, D Upper and lower display limits These values indicate the display range. By default this range is equal to the analog input range.

C Cursor values You can select if you want to see cursor values here:

- Active cursor value.
- Both cursor values.
- Difference between the two cursor values.

E Range indicator When the upper and lower limit are not equal to the input range, the range indicator shows the display range relative to the actual input range.

F Trace name The trace name is highlighted when selected. When selected it is the “active trace”.

G Sweep index This index is available when the review is in sweep mode. It shows the number of the sweep that is reviewed.

H Page control Use this control to go to other pages.

I Time control You can use this control to jog/shuttle through time and to set the X-axis zoom factor.

J Replay control You can use this control to replay the data. When in sweep review mode you can use this control to step through the sweeps

K Cursor values X- and Y-value of the active cursor and the difference of these values with the passive cursor.

L Time scale X-annotation area

- M Active cursor** The active cursor is the cursor that is currently selected. It is color-coded red.
- N Trigger marker** This marker indicates where a trigger occurred.
- O Passive cursor** The other cursor, color-coded blue.
- P Event bar** There are various events. Their markers are placed here, for example the trigger marker.

6.2.1 The Y-annotation area

On the left-hand side of the display there is the Y-annotation area. A view within a display and its Y-annotation area are divided into panes. Each pane can support one or more traces.




Figure 6.4: Y-annotation area of a pane

- A Upper display limit
- B Trace name
- C Display range indicator
- D Cursor values
- E Lower display limit

Traces and annotation are color coded. Depending on the available space the Y-annotation area of a single pane can comprise one or more of the following options. The width of the Y-annotation area can be set in the Display Setup dialog.

To set the width of the Y-annotation area:

You can set the width of the Y-annotation area as follows:

- 1 Using a right mouse click in the display area access the context menu.
- 2 In the context menu select **Display Setup...**

- 3 In the Display Setup dialog select the **Annotation & Grid** page.
- 4 In the Y-Annotation section set the **Width** of the area.
- 5 Click **OK** when done.

A, E Upper and lower display limits These values indicate the display range. By default this range is equal to the analog input range. The values are in technical units. Depending on the zoom range the display area can be either equal to, larger than or smaller than the actual input range of the signal.

B Trace name The trace name is the name given to the channel at recording time. The trace name is highlighted when selected. When selected it is the “active trace”.

C Display range indicator When the upper and lower limit are not equal to the input range, the range indicator shows the display range relative to the actual input range.




Figure 6.5: Display range indicator

- A** The display range is smaller than the input range
- B** The display range is larger than the input range

- D Cursor values** Depending on the selected option, one or more cursor values are shown here. A blue square indicates the value at the passive cursor position, a red square indicates the value at the active cursor position.

To select the cursor values readout:

You can select which value(s) to show in the Y-annotation area. To do so:

- 1 Using a right mouse click in the display area access the context menu.
- 2 In the context menu select **Display Setup...**
- 3 In the Display Setup dialog select the **Annotation & Grid** page.
- 4 Make sure that in the **Show** area the **Y-Annotation** check box is selected and select in the **Y-annotation** area under **Show values** one of the following options:
 - **Display Y-range only** Do not show cursor values.
 - **Active cursor value** Show the Y-value of the active cursor.
 - **Values of both measurement cursors** Show the Y-values of both cursors.
 - **Difference between Y-values of cursors** Show the difference between the Y-values of both cursors.
- 5 Click **OK** when done.




Figure 6.6: Y-annotation options

- A Display Y-range only
- B Active cursor value
- C Values of both measurement cursors
- D Difference between Y-values of cursors

6.2.2 Y-annotation per tick

To show the Y-annotation:

- 1 Use a right mouse click in the display area to access the context menu.
- 2 In the context menu select **Display Setup...**
- 3 In the Display Setup dialog select the **Annotation & Grid** page.
- 4 In the **Y-annotation** area select the check box **Show annotation per tick**.




Figure 6.7: Y-annotation per tick

A Show annotation per tick

Figure 6.8 shows the Y-annotation in detail:




Figure 6.8: Y-annotation area of a pane

A Enabled Y-annotation

6.2.3 The X-annotation area

The X-annotation area is used to display a time or position scale. The scale supports internal (time-based) and external (position-based) acquisition time bases. When time is used, the x-axis scale can be relative or absolute. When position is used the position can be translated to linear or rotational displacement. For ease of reference the X-annotation scale will be named time scale although it can also refer to a position.

When the time scale is **relative time**, the time is referenced to the start of the recording. With relative time the start of the recording is considered the start of the time line, i.e. $t=0$.

When the time scale is **absolute time**, the actual time of day at the start of recording is used as reference without correction.

To select the time scale:

- 1 Right-click anywhere in the display area
- 2 On the context menu click **Display Setup...**

- 3 In the Display Setup dialog box select the **Annotation & Grid** page
- 4 Make sure that in the **Show** area the **X-Annotation** check box is selected and select in the **X-annotation** area under **Scaling** one of the following options:
 - In time: **Relative to start of recording** Use the relative time scale
 - In time: **Absolute local time** Use the absolute time scale with respect to local time
 - In time: **Absolute UTC** Use the absolute time scale with respect to Coordinated Universal Time (UTC)
 - In position: **Linear** The time scale displays external “clocks”
 - In position: **Rotational, 360 degrees per cycle** The time scale displays cycles, each cycle represents 360 external “clocks”
 - In position: **Rotational, 720 degrees per cycle** The time scale displays cycles, each cycle represents 720 external “clocks”
- 5 Click **OK** when ready



HINT/TIP

Coordinated Universal Time (UTC) - is a high-precision atomic time standard. UTC has uniform seconds with leap seconds announced at irregular intervals to compensate for the earth's slowing rotation, and other discrepancies. The leap seconds allow UTC to closely track Universal Time (UT), which is a time standard based on the earth's angular rotation, rather than a uniform passage of seconds.

The complete absolute time format is **date HH:MM:SS.T-T**, the relative time format is **DD HH:MM:SS:T-T** with:

- **date** Actual date
- **DD** Number of days
- **HH** Hours in range 0 through 23
- **MM** Minutes in range 0 through 59
- **SS** Seconds in range 0 through 59
- **T-T** Depending on available resolution a number of decimals in range 0 through 9

Example: the absolute time **20-09-2006 21:53:16.879** reflects September 20, 2006 at 9:53:16 pm and 879 milliseconds.

The relative time **01 11:23:16.2365** reflects 1 day, 11 hours, 23 minutes, 16 seconds and 236500 microseconds.

Time annotation in the display by default shows three values: the *start time (or position)* and the *end time (or position)* of the data as shown in the display as well as the *time (or clocks, cycles) per division*. You can set this to show a time value at every division: **annotation per tick**.

To set the time annotation:

To set the number of time values displayed in the X-annotation area proceed as follows:

- 1 Using a right mouse click in the display area access the context menu.
- 2 In the context menu select **Display Setup...**
- 3 In the Display Setup dialog select the **Annotation & Grid** page.
- 4 Make sure that in the **Show** area the **X-Annotation** check box is selected and select in the **X-annotation** area **Show annotation per tick**.
- 5 In the **Grid** area set the number of **Horizontal divisions** you want to use.
- 6 Click **OK** when done.





Figure 6.9: X-axis annotation

- A Default annotation: begin, end and time/division
- B Annotation per tick

You can set the time interval that you see on the display. Use the various Time Scale options to fit (a part of) the waveform in the display area.

To set the Time Scale proceed as follows:

- 1 Using a right mouse click in the display area access the context menu.
- 2 In the context menu point to **Time Scale** ►



- 3 In the sub menu that comes up select one of the following options:
 - **Auto** The complete recording (all available data) from start to end is shown in the display area. This function can also be accessed through the auto scale button in the time control as explained in Figure 6.19 "Time control" on page 159.
 - **Time per Division** ► In the sub menu that comes up select a value. The displayed data will be the number of divisions times the time per division.
 - **Select...** In the dialog that comes up use the Start and End fields to define a segment of the complete waveform to be shown in the display.

6.2.4 Control area

The control area is a part of the display that contains one or more controls. The control area can be hidden as well as individual controls. The control area can hold the following controls:

- **Page control** Manage pages
- **Time control** Scroll through the waveform data
- **Replay control** Replay waveform data
- **Cursor values** Show the values of the active and passive cursor

To show or hide control items:

You can select to show or hide individual control items as well as the complete control area. To do so proceed as follows:

- 1 On the dynamic menu, click **Setup Display**, or right-click in the display area to see the shortcut menu and select **Display Setup**.
- 2 In the Display Setup dialog select the **Display Setup** page.
- 3 In the **Control** area select the items you want to include in the control area.
- 4 Under **Icon size** sub section select an icon size.
- 5 Click **OK** when done.

Page control

You use the page control primarily to step through the available pages. In addition the page control allows you to modify a page name directly in the control.

To step through the pages click the **Next Page** button and **Previous Page** button. In addition you can use the following keyboard accelerators:

- **Ctrl+Page Up** to go to the previous page
- **Ctrl+Page Down** to go to the next page
- **Ctrl+1 ... 9** to go directly to the indexed page
- **Ctrl+Home** to go to the first page
- **Ctrl+End** to go to the last page




Figure 6.10: Page control functionality

- A Default view
- B Rename page
- C List view
- D Previous page
- E Next page

In the text field of the page control you can do:

- **Click:** A drop down list shows all available pages. The currently active page is marked. Click on a page name in the list to jump directly to that page. Note that numbering used by the default naming continues to increase even if previous pages have been deleted. The number is not an index
- **Double-click:** When you double-click the text field, the name of the page is highlighted. Now you can modify the name. Press Enter to accept or Escape to cancel.
- **Right-click:** A context menu will come up. Refer to "Page commands" on page 188 for details.

Time control

The time control is explained in full detail in "Using the keyboard and time control to zoom" on page 159.

Replay control

The replay control is explained in full detail in "Replay data" on page 161.

Cursor values

In the control area you can select to show the cursor values. Depending on the available screen area not all of the information may be visible. A tooltip provides the same information.




Figure 6.11: Cursor values in display control area

- A X-value of active cursor
- B X-difference of active and passive cursor
- C Y-value of active cursor
- D Y-difference of active and passive cursor
- E Tooltip

6.2.5 Event/digital traces

Event (or digital) traces are different from 'normal' waveforms with respect of their possible values. Possible values are binary: either one (1) or zero (0) or low/high, on/off, open/close, etc.

These traces are displayed differently as shown in the following diagram.




Figure 6.12: Event traces

- A Low
- B Low + High
- C High

- A** A **low** value is displayed as a one-pixel line.
- B** When within a certain time interval the values are **low and high**, but these values cannot be displayed separately due to time scaling constraints, a full height bar is displayed.
- C** A **high** value is indicated by a half-height bar from the top

You can set the size of the event traces.

To set the size of the event traces:

- 1 Using a right mouse click in the display area access the context menu.
- 2 In the context menu select **Display Setup...**
- 3 In the Display Setup dialog select the **Annotation & Grid** page.
- 4 In the **Sizes** area under **Event traces** select the size you want.
- 5 Click **OK** when done.

6.2.6 The waveform display event bar

The event bar in the waveform display is used to hold the vertical measurement cursor handles and to hold markers that reflect a specific event. The markers are placed on the event bar at the time position on which the event took place. When you hover over an event marker a tooltip gives additional information when available.



Figure 6.13: Event bar markers

- A** Active cursor handle (red). In addition each cursor handle has a fixed number (1 or 2) for static reference.
- B** Passive cursor handle (blue). In addition each cursor handle has a fixed number (1 or 2) for static reference.
- C** Video marker: a video stream is available, starting at this point. Double-click the marker to start the video.
- D** Bookmark: a text is available at this point. Double-click the marker to read it.
- E** Audio marker: an audio stream is available, starting at this point. Double-click the marker to start the audio.
- F** Alarm: an alarm event occurred at this point.
- G** Trigger: a trigger occurred at this point.
- H** Start of recording. Multiple start-of-recording markers can be present in a display.
- I** End of recording. Multiple end-of-recording markers can be present in a display.
- J** Cold trigger: a trigger condition has been met. However it did not trigger the acquisition, i.e. it did not start the posttrigger segment.
- K** Communication restored (OK): the communication with a remote front-end has been restored (is OK). This typically happens after a communication failure.
- L** Communication failure: there is no communication possible anymore with a remote front-end. A typical cause is cabling malfunction.
- M** Poor quality communication: there is communication possible with the remote front-end, but communication is poor. Loss of data and misinterpretation of commands is possible.
- N** Clock synchronized: the internal clock of a mainframe is now synchronized with the selected synchronization source. This can be in Master/Sync mode, PTP, or using an IRIG/GPS synchronization source. This situation also occurs when you switch from one source to another.
- O** Clock not synchronized: the internal clock of a mainframe has lost the synchronization with the selected clock source. Typical causes are cabling malfunction or no GPS signal.

- P** Recording paused: the recording was paused. No data will be recorded from this point until the recording is resumed. A tooltip displays details, as shown in Figure 6.14.




Figure 6.14: Event marker - tooltip

- Q** Recording suspended: the internal memory of the mainframe is full. The recording will first be stored in the experiment and then it will resume automatically. A tooltip shows details.
- R** Frequency too high: the cycle source input signal frequency is too high; multiple cycles will be used to calculate results.
- S** Frequency too low: the cycle source input signal stayed between the two hysteresis levels longer than the can be handled through the available computation memory. This typically occurs if the frequency is too low, but there are other possibilities. Please refer to the cycle detection description for more information.
- T** Cycle detect normal: cycle detection on the input signal is operating normally again after detecting an earlier problem.
- U** Invalid calculation result: no cycles have been detected on the input signal for a prolonged period. Possible causes:
- No cycle source input signal.
 - The cycle source input signal range is outside the cycle source hysteresis/levels settings, for example because of a DC offset.
 - The input signal stays between the two hysteresis levels too long (also indicated by the frequency too low marker, but now for such a long period that no more calculations can be done based on the cycle source).
- V** Calculated trigger: a calculated channel generated a trigger at this position, but the hardware has triggered at a later point in time.
- W** Cycle detector overload: the cycle detector has lost track of its input signal due to high frequency components in the signal.
- X** PTP master information: When using a PTP sync source this marker is present at start of a recording and upon each move to a different PTP master. The tooltip of this marker contains more information about which mainframe is using which PTP master. If this happens during a recording it is always preceded by a “Sync Lost”.

6.3 Waveform display operation

This section describes how to use a waveform display and how to benefit as much as possible from its capabilities

6.3.1 Adding traces to a display

There are various ways to add traces to a display. Most of them are based on drag-drop from one of the navigators.

Using the Hardware Navigator

For more details on how to use the Hardware Navigator for data source selection refer to the Hardware Navigator section: "Data source selection for display" on page 92.

To select a data source:

To select data sources using the hardware navigator do one of the following:

- Select a recorder or a (number of) channels and drag them onto an empty sheet or sheet section. A new display will be created that fills the complete sheet (section) with the selected channels displayed. When data is available this will be shown.
- Select a recorder or a (number of) channels and drag them onto an existing display. The selected channels will be added as overlaid traces to the targeted pane.

Using the Recordings Navigator

For more details on how to use the Recordings Navigator for data source selection refer to the Recordings Navigator section: "Data source selection for display" on page 104.

To select a data source:

To select a data source for a display do one of the following:

- Select a recording and drag it onto an empty sheet or sheet area. A new display will be automatically created that fills the entire sheet (area) with the selected recording displayed with channels as stacked (separated) traces.
- Select a recording and drag it onto an existing display. The selected recording will be added as overlaid traces to the targeted pane.

Using the Data Source Navigator

For more details on how to use the Data Source Navigator for data source selection refer to the Data Source Navigator section: "Data source selection for display and meters" on page 109.

To select a data source:

To select data sources using the data sources navigator do one of the following:

- Select a recorder or a (number of) channels and drag them onto an empty sheet or sheet section. A new display will be created that fills the complete sheet (section) with the selected channels displayed. When data is available this will be shown.
- Select a recorder or a (number of) channels and drag them onto an existing display. The selected channels will be added as overlaid traces to the targeted pane.

Using Display Setup

You can create a complete display with panes and traces from scratch using the Display Setup dialog.

To create a display setup from scratch:

Once a display is on a sheet proceed as follows:

- 1 Using a right mouse click in the display area access the context menu. You can also access this dialog for the active display through the **Setup Display ...** command on the dynamic menu.
- 2 In the context menu select **Display Setup...**
- 3 In the Display Setup dialog select the **Display Setup** page. In this page do one of the following:
 - Add or remove pages.
 - Rename page(s).
 - Configure the display and zoom behaviour.
 - Configure the control area.
- 4 In the Display Setup dialog select the **Annotation & Grid** page. In this page you define:
 - The type and layout of X and Y-annotation.
 - The various colors used in the display.
 - The grid and separator settings.
- 5 In the Display Setup dialog select the **Panes Setup** page. In this page do:
 - a Add or remove panes as required.
 - b Select a pane and select the data sources that should go in it.
 - c Re-arrange traces when required.
- 6 In the Display Setup dialog select the **Traces Setup** page and modify the trace properties as required.
- 7 Click **OK** when done.

6.3.2 Drag and drop traces

A summary of how to move and select traces.

- To select a trace you must click on a trace in the Y-annotation area.

If there are more than one trace in a pane:

- Cycle through traces with a single click in the panes Y-annotation area.
- Click on a trace name to specifically select that trace.

Drag and drop a selected trace to compare traces:

- Select a trace.
- Drag it over another trace and drop.

The two traces are now combined and overlapped. More traces can be added this way.

Separate combined traces

You can separate combined traces by opening another trace from the context menu or with drag and drop.

To separate combined traces by opening another trace from the context menu:

- Open another trace from the context menu (for more information see "Waveform display miscellaneous context commands" on page 186).
- Drag the required trace back into an empty trace.

To separate combined traces with drag and drop:

- 1 Select a trace.
- 2 Drag it over a pane separator as shown in Figure 6.15.
- 3 The pane separator will be highlighted and the cursor icon will change into a “drag to new pane” icon.




Figure 6.15: Drag trace over pane separator

A Drag icon

- 4 Drop the drag icon to create a new pane between the existing panes or at the top or bottom of the display area.

For more information on organizing traces refer to "Traces Setup" on page 201.

Move a trace to a different or new page

To move a trace to a different or new page:

- 1 Select a trace.
- 2 Drag it to the page selection area.




Figure 6.16: Drag trace to different or new page

A Page selection area

- 3 The page selection area shows all existing pages and a new page.
- 4 Drop the drag icon in the desired page.

6.3.3 Modifying the display layout

Various options are available to adapt the layout of any individual waveform display to suit your requirements. These options include, but are not limited to, general layout, number of pages, numbers of panes and pane size, colors, grid, etc.


Modifying the view arrangement and view type

The arrangement of views in a display as well as their size is controlled by split modes and splitters. For details on the usage of these controls refer to "Layout and splitters" on page 76. You can modify the current layout. You cannot add or delete views using the Split settings.

To gain access to the split settings:

To gain access to the split settings within the display proceed as follows:

- 1 With a right mouse click in the display area call up the context menu.
- 2 In the context menu point to **Split** ▶



- 3 In the sub lists make your choice.

What you see in a view is defined by the sources that are connected to a view and the view **type**. There are four basic types:

- **Review** in either sweep or recording mode.
- **Zoom**: a detail of the review view.
- **Alternate zoom**: another detail of the review view.
- **Live**: live streaming data.

Review A view is in review mode when stored data is shown. This can be either from a recording on disk, data stored locally in the data acquisition system, or a partially stored recording that is still active. This last option is the so-called “review while recording” feature.

When in review mode you can select between Recording and Sweep:

- **Recording:** what you see is the complete recording, or the recording as far as it has been stored when recording is still active.
- **Sweep:** what you see is a selected sweep or the last recorded sweep when recording is still active.

Zoom A zoomed area of a review view is displayed.

Alternate zoom Another zoomed area of a review view is displayed.


Live The view is in live mode when you are looking to live data coming from an acquisition system. Within a display there can only be one Live view. When you switch a view from review to live while another view is already in live mode, this view will be switched automatically to review mode.

Live mode is only available when an acquisition system is connected to the display and the system is in Pause or Acquire mode.

To switch between view types:


To switch between the various view types proceed as follows:

- 1 Right-click the **view** mode indicator of a view.



- 2 In the context menu that comes up click the **view** mode and **option(s)**.

When you apply the above procedure to the live view a modified list of possibilities comes up:



- **Sweep Triggered** Each sweep is displayed as-is.
- **Display Triggered** Each sweep is displayed with a display trigger as reference point.
- **Scoping** Provides a stable picture like an oscilloscope.
- **Scrolling** Provides a scrolling display.
- **Display Trigger** Sets the position of the trigger point as percentage of the sweep length.

Modifying the pane size

You can modify the (vertical) size of a pane in a Review view at any time. When you hover the mouse over a pane separator in the Y-annotation area, the mouse pointer will change into a pointer with arrows. The arrows point in the direction that you can move the separator. While dragging the affected pane separators are displayed as dotted lines. You can also modify the pane size through the Display Setup dialog.

To modify pane size(s) do one of the following:

- Click and **drag** the splitter in the required direction. This will modify the height of the pane above, and the height of the pane below the selected pane separator.
- **Shift+drag** the splitter in the required direction. This will modify the height of all panes below the selected pane separator. You must press and hold down the SHIFT key before pressing the mouse button.
- **Ctrl+drag** the splitter in the required direction. This will modify the height of all panes above the selected pane separator. You must press and hold down the CTRL key before pressing the mouse button.

- Using a right mouse click in the display area access the context menu, and proceed as follows:
 - In the context menu select **Display Setup...**
 - In the Display Setup dialog select the **Panes Setup** page. In this page select a pane and set its height.
 - Click **OK** when done.

6.3.4 Zooming and panning

A powerful feature of the display is the ability to zoom in on a segment of interest of the waveform. Perception supports fully free-style zooming and panning in two areas of the waveform data. The second zoom area is called the alternate zoom. All zoom functions on the alternate zoom are performed exactly the same as on a normal zoom but with the ALT key pressed.




Figure 6.17: Zoom areas

To zoom in:

- Click and drag the mouse. A bounding box with a semi-transparent fill will appear indicating the zoom area. When you release the mouse, a zoom view will be created filled with the zoomed portion of the original view. The zoom area is shown as a raised semitransparent bounding box in the review view. The alternate zoom area is shown as a sunken semi-transparent bounding box in the review view. When zooming you can press the CTRL or SHIFT key to constrain the zoom area in the X or Y direction respectively.




Figure 6.18: Zoom area indicator and cursor shapes

- A Resize vertically
- B Resize horizontally
- C Move entire zoom area
- D Resize both horizontally and vertically

To resize a zoom area:

You can resize a zoom area by dragging a side or a corner of the bounding box to another location as follows:

- With the mouse hover over a border or corner. When an arrow cursor appears click and drag in the required direction.

To move the zoom area:

You can move the zoom area by dragging it to another location as follows:

- With the mouse hover over the zoom area. When the four-way cursor shape appears click and drag the zoom area to another location.

To unzoom:

- Right-click a view. In the context menu that comes up click **Unzoom**. The zoom area will disappear.

Using the keyboard and time control to zoom

You can also zoom with keys on the keyboard. This allows you to zoom without creating a zoom display. You can also use the time control.

To zoom using the keyboard do one of the following:

- To compress and expand in the x-direction (time scale) press the - (minus), + (plus), * (asterisk) or / (slash) on the numeric key pad.
- To compress and expand in the y-direction (trace scale) press the - (minus), + (plus), * (asterisk) or / (slash) on the numeric key pad while pressing at the same time the CTRL-key.

These options are also accessible through the display context menu: right-click the display area. In the context menu that comes up point to **Time Scale** or **Trace Scale** to access these commands.



HINT/TIP

Right-click in the display area, go to **Time Scale**, then click **Select...** To see the shortcut menu, right-click on the actual time scale and then click **Select...**

To zoom using the display time control:

- Make sure the time control is visible. If not:
 - 1 Right-click in the display area to see the shortcut menu. In the shortcut menu that comes up click **Display Setup...**
 - 2 In the Display Setup page select **Show timescale indicator** in the Control Area section.
- Click the Compress, Expand or Autoscale button.




Figure 6.19: Time control

- A** Compress time scale
- B** Scroll arrows
- C** Scroll box, a.k.a. thumb, slider or elevator
- D** Scroll bar shaft

- E Expand time scale
- F Autoscale time scale

Scrolling waveforms on the X-axis

Once you have zoomed in the review area, i.e. you can only see part of the recording in the review area, you can move this area along the x-axis (time scale) only. This is called scrolling. Scrolling is supported in various ways as described below.

Keyboard You can use the **Page Up** and **Page Down** keys to scroll one screen to the left and right respectively. Use the Home key to jump immediately to the beginning of the waveform and the **End** key to jump to the end of the waveform.

Mouse wheel When you are using a mouse with integrated wheel button, you can use the wheel (plus optional Shift key) to scroll the waveform to the left and to the right.

Time control scroll bar You can use the display time control scroll bar to scroll through the waveform. When you click a scroll arrow, the data in the display moves, revealing data in the direction of the arrow. The scroll box moves along the scroll bar to indicate how far the visible portion of the waveform is from the edge. The size of the scroll box reflects the difference between what is visible in the display and the entire contents of the waveform (file). Refer to Figure 6.19 "Time control" on page 159 for graphical details.

To scroll using the display time control:

- Make sure the time control is visible. If not:
 - 1 Right-click the display area. In the context menu that comes up click **Display Setup...**
 - 2 In the Display Setup page select **Show timescale indicator** in the Control Area section.
- Click on the scroll arrows and drag the scroll box.

Mouse wheel support

The waveform displays include support for computer mice that have a wheel button.

- Use the wheel to scroll the waveform to the left and to the right.
- Hold down the **SHIFT** key and use the wheel to scroll the waveform to the left and to the right in larger steps.
- Hold down the **CTRL** key and use the wheel to zoom in and out on the X-axis.

- Hold down the **CTRL+ALT** key combination and use the wheel to move the selected trace up and down.
- Hold down the **CTRL+SHIFT** key combination and use the wheel to zoom in and out on the Yaxis of the selected trace.

6.3.5 Replay data

Recorded data can be replayed within a Review view of the waveform display. The data can be either from a stored recording, or it can be part of the current acquisition. When the data to replay is part of the current recording then the feature is called “review while recording”.

The replay functionality is controlled by the **replay control** that is located in the control bar of the display. The layout and functions of the replay control depend on the review mode: continuous or sweep.

Replay continuous data




Figure 6.20: Replay control for continuous data

- A** Jump to begin of data
- B** Play backward
- C** Stop
- D** Play forward
- E** Jump to end of data

To replay continuous data:

To replay continuous data proceed as follows:

- 1 Make sure the view is in continuous mode. If not:
 - a Right-click the view mode indicator of a view.
 - b In the context menu that comes up select the **Review** and **Continuous** option.
- 2 Make sure the replay control is visible. If not:
 - a Right-click the display area. In the context menu that comes up click **Display Setup...**
 - b In the Display Setup page select **Show replay control** in the Control Area section.

- 3 Do one of the following:
 - Click one of the **jump** buttons to go quickly to the start or the end of the recording.
 - Click one of the **play** buttons to start replay of data.
 - To **increase** the replay speed click the **play** button again.
 - When the replay speed is increased you can **decrease** the replay speed by clicking the opposite **play** button.
 - To **stop** replay click the Stop button.

Replay sweep data




Figure 6.21: Replay control for sweep data

- A Jump to begin of data
- B Previous sweep
- C Next sweep
- D Jump to end of data

To replay sweep data:

To replay sweep data proceed as follows:

- 1 Make sure the view is in sweep mode. If not:
 - a Right-click the view mode indicator of a view.
 - b In the context menu that comes up select the **Review** and **Sweep** option.
- 2 Make sure the replay control is visible. If not:
 - a Right-click the display area. In the context menu that comes up click **Display Setup...**
 - b In the Display Setup page select **Show replay control** in the Control Area section.
- 3 Do one of the following:
 - Click one of the **jump** buttons to go quickly to the start or the end of the recording, first and last sweep respectively.
 - Click the **previous** button to show the previous sweep.
 - Click the **next** button to show the next sweep.

You can see the sweep index in the lower left hand corner of the display. The sweep index is labelled item **G** in Figure 6-3 .

6.4 Cursors and basic measurements

Within the Review or Zoom view of a Perception display there are three types of cursors:

- The **vertical** measurement cursors. These are the primary cursors for a variety of measurements. They also serve as boundaries for calculations.
- The **horizontal** cursors. These are additional cursors that provide amplitude information.
- The **slope** cursors. These are free moveable cursors (line segments) that provide slope/angle information.




Figure 6.22: Cursor types

A Vertical cursors

B Horizontal cursors

C Slope cursors

All three cursor types can be visible or hidden on a per display basis. They can also be 'locked': when cursors of a specific type are locked or grouped, they move simultaneously.

The various cursor commands are accessible through the toolbar, the dynamic sheet menu and the display context menu.



Figure 6.23: Cursor toolbar

- A** Vertical cursors visibility
- B** Vertical cursors grouping
- C** Horizontal cursors visibility
- D** Horizontal cursors grouping
- E** Slope cursors visibility
- F** Slope cursors grouping
- G** Slope cursors select

To show or hide cursors:

To show or hide specific cursors do one of the following:

- Click on the corresponding visibility button in the toolbar.
- Using the dynamic sheet menu:
 - 1 Point to **Cursors** ►.
 - 2 Point to the required cursor type.
 - 3 Click **Visible**.
- Using the context menu:
 - 1 Right-click the display area.
 - 2 In the context menu that comes up, point to the required cursor type.
 - 3 Click **Visible**.

When cursor visibility is switched to visible, the cursors may come up 'docked', i.e. the cursors themselves are not visible, but the handles are displayed. These handles can appear in a corner or on a side of the waveform display area. Click and drag these handles to reveal the complete cursors.

Cursors are moved by clicking on the handle or on the cursor line using the mouse and dragging the cursor to the new location. When you hover the mouse pointer over the cursor the mouse pointer changes to indicate that you can drag the cursor or the cursor handle.

You can also drag corresponding cursors as a group, i.e. moving one cursor automatically moves the other cursor while they maintain their distance.

To group or ungroup cursors:

To group or ungroup specific cursors do one of the following:

- Click on the corresponding group button in the toolbar.
- Using the dynamic sheet menu:
 - 1 Point to **Cursors** ▶.
 - 2 Point to the required cursor type.
 - 3 Click **Group**.
- Using the context menu:
 - 1 Right-click the display area.
 - 2 In the context menu that comes up, point to the required cursor type.
 - 3 Click **Group**.




Figure 6.24: Grouped cursors maintain distance when moved

6.4.1 Vertical cursors

The event bar at the top of the display is used to place event markers and also contains cursor “handles” used for moving the vertical cursors. By definition the red cursor is the active cursor and the blue cursor is the passive (inactive) cursor. A cursor becomes active when you click on it. Cursors are moved by clicking on the handle or on the cursor line using the mouse and dragging it to a new location. When you move the pointer over the cursor the mouse pointer changes to indicate that you can drag the cursor.




Figure 6.25: Vertical cursors

- A Active cursor (red)
- B Trigger event indicator
- C Passive cursor (blue)
- D Event bar
- E Ready-to-drag mouse pointer
- F Drag mouse pointer

The values of the vertical cursors can be displayed in the control area (refer to Figure 6.9 "X-axis annotation" on page 141) and in the Y-annotation area (refer to Figure 6.6 "Y-annotation options" on page 137).

In addition the cursors also have a number. This number is fixed for that specific cursor, i.e. it does not change. This makes it easy to reference the cursors without knowing which one is the active one.

Sample snap

When you are zoomed in far enough to see the individual samples of a trace (denoted by dots and connected by a linear interpolated line) you can easily measure the exact value of each individual sample. To do so drag the vertical cursor while holding down the CTRL-key. The cursor will snap to each individual sample while dragging. When you position the cursor between two consecutive samples, the displayed value is a linear interpolation between the two samples.




Figure 6.26: Individual samples and sample snap

Auto placement

You can quickly position the active cursor on a trigger point:

- The keyboard combination **Ctrl+T** moves the active cursor to the next available trigger to the right of the original position and re-centres the display around the trigger.
- The keyboard combination **Ctrl+Shift+T** moves the active cursor to the next available trigger to the left of the original position and re-centres the display around the trigger.

Miscellaneous functions

More vertical cursor functions are available through the display context menu.

Set Cursor at Position

You can set the active cursor at the position where you clicked with the mouse in the display. To do so proceed as follows:

- 1 Right-click the display area.
- 2 In the context menu that comes up, point to **Vertical Cursors ▶**.
- 3 Click **Set Cursor at Position**

Change Active

You can swap the active and passive cursor: the active cursor becomes the passive cursor and vice versa. Their position remains intact. To do so proceed as follows:

- 1 Right-click the display area.
- 2 In the context menu that comes up, point to **Vertical Cursors ▶**.
- 3 Click **Change Active**.

Find and Go To

You can search for specific events in a waveform and jump to that location with the active cursor. To search for a specific event and jump to it proceed as follows:

- 1 Make sure that the waveform you want to inspect is active.
- 2 Right-click the trace area of the waveform you want to inspect.
- 3 In the context menu that comes up, point to **Vertical Cursors** ►.
- 4 Click **Find and Go To....** The following dialog will come up:





Figure 6.27: Find and Go To dialog

- A Display name
- B Trace name
- C Search parameters
- D Go to next event
- E Go to previous event
- F Close dialog
- G Center display around event
- H List of search criteria

- A Display name** The dialog header shows the name of the display that is selected.
- B Trace name** The name of the selected trace is shown. Make sure this is the correct one.

- C Search parameters** Depending on the selected search criterion one or more parameters may be required to define the exact condition. Enter values and/or make the correct selections here.
- D-E Command and Buttons** Select **Next** or **Previous** to jump between successive events.
- F Close** Select when done.
- G Center Display** Select this option if you want to center the display around the event.
- H Search criteria** List of criteria that you can use.

You can also gain access to this dialog as follows:

- Select **[dynamic menu] ► Find and Go To...**
- When available in the **toolbar** click the **Find and Go To** button 

6.4.2 Horizontal cursors

Horizontal cursors are additional cursors that you can use for amplitude measurements. By definition the red cursor is the active cursor and the blue cursor is the passive (inactive) cursor. A cursor becomes active when you click on it. Cursors are moved by clicking on the handle or on the cursor line using the mouse and dragging it to a new location. When you move the pointer over the cursor the mouse pointer changes to indicate that you can drag the cursor.

In addition the cursors also have a number. This number is fixed for that specific cursor, i.e. it does not change. This makes it easy to reference the cursors without knowing which one is the active one.




Figure 6.28: Horizontal cursors

- A** Active cursor (red)
- B** Passive cursor (blue)
- C** Ready-to-drag mouse pointer
- D** Drag mouse pointer

Set Cursor at Position

You can set the active cursor at the position where you clicked with the mouse in the display. To do so proceed as follows:

- 1 Right-click the display area.
- 2 In the context menu that comes up, point to **Horizontal Cursors** ►.
- 3 Click **Set Cursor at Position**.

6.4.3 Slope cursors

While horizontal and vertical cursors can be moved only along a single axis, the slope cursors offer you complete freedom of size and position.

Three slope cursors are provided. You can select to use one, two or all three slope cursors. Each cursor can be freely positioned, and the end points can be dragged to any location. This freedom allows you to create a tangent and measure the slope of a curve

There is no active slope cursor. Each cursor is color coded and has a fixed number.




Figure 6.29: Slope cursors

- A Blue slope cursor (2)
- B Red slope cursor (1)
- C Green slope cursor (3)
- D Ready to move mouse pointer
- E Move mouse pointer

F Ready to rotate mouse pointer

G Rotate mouse pointer


Set Cursor at Position

You can set the last activated slope cursor at the position where you clicked with the mouse in the display. To do so proceed as follows:

- 1 Right-click the display area.
- 2 In the context menu that comes up, point to **Slope Cursors ▶**.
- 3 Click **Set Cursor at Position**.

Select number of slope cursors

You can select the number of slope cursors you want to use in your display. To select the number of slope cursors do one of the following:

- When available in the **toolbar** you can select the **Number of Slope Cursors**  drop down list and select one, two or three cursors
- Using the dynamic sheet menu:
 - 1 Point to **Cursors ▶**.
 - 2 Point to **Slope Cursors ▶**.
 - 3 In the sub menu that comes up, select one, two or three cursors.
- Using the context menu:
 - 1 Right-click the display area.
 - 2 In the context menu that comes up, point to **Slope Cursors ▶**.
 - 3 In the sub menu that comes up select one, two or three cursors.

6.4.4 Cursor measurements

The values of the vertical cursors can be displayed in the control area (refer to Figure 6-9 "Cursor values" on page 144) and in the Y-annotation area (refer to Figure 6-6 "The Y-annotation area" on page 135).

In addition a window can be displayed with all cursor values, including horizontal and slope cursors. The Cursor Table shows the cursor values of the active display.

This window also provides functionality to copy values to clipboard and post values to Excel.

To show or hide the Cursor Table make sure a display is active and do one of the following:

- When available in the **toolbar** you can click the **Cursor Table** button
- With the display selected: press the space bar.
- Using the dynamic sheet menu:
 - 1 Point to **Cursors** ▶.
 - 2 Click **Cursor Table**
- Through the context menu:
 - 1 Right-click the display area.
 - 2 In the context menu that comes up, click **Cursor Table**.
- In addition you can close the Cursor Table as follows:
 - Click **Close** in the title bar of the window.
 - Click **Close** in the **Settings** menu of the window.




Figure 6.30: Cursor Table

- A Menu bar
- B Vertical cursors area
- C Horizontal cursors area
- D Slope cursors area
- E Crossing parameters cursor 1 / cursor 2
- F Crossing parameters cursor 1 / cursor 3
- G Crossing parameters cursor 2 / cursor 3
- H Toolbar

- A** **Menu bar** The menu bar has one menu: Settings. The settings menu provides access to all additional features of the Cursor Table.
- B** **Vertical cursors** The vertical cursors area has rows for each trace and a bottom row to display the time information.
- C** **Horizontal cursors** The horizontal cursors area has a single row. This row displays the active trace.
- D** **Slope cursors** The slope cursors area has two sections: one for the slope of each cursor and one for the crossing of each cursor with another cursor.
- E, F, G** Refer to Figure 6.30 "Cursor Table" on page 172, for the location of the following details:
 - E** The crossing of cursor 1 and cursor 2
 - F** The crossing of cursor 1 and cursor 3
 - G** The crossing of cursor 2 and cursor 3

Note

The crossing of the cursors is not visible by definition. The crossing is calculated by the position and slope of the visible cursors. When the crossing is outside the visible area, extrapolation is used to calculate the virtual crossing of the two cursors.




Figure 6.31: Slope cursors crossing

- a** Actual crossing
- b** Virtual crossing

- H** **Toolbar** The toolbar provides quick access to the most commonly used commands.

A Menu bar in Detail:




Figure 6.32: Cursor table settings menu

Active Trace Values

Show only the values of the vertical cursors and the active trace. When information on horizontal and/or slope cursors is available these will be shown also.

All Traces Values

Show the values of the vertical cursors and all traces. When information on horizontal and/or slope cursors is available these will be shown also.

Values are displayed in technical units. For event traces technical units typical are 1/0, high/ low, on/off, etc.

Engineering Format

Select this option when you want the displayed values to be in engineering format. This format is a scientific notation in which the power of ten is a multiple of three. The power of ten is represented by prefixes like *kilo* or *milli*.

Scientific Format

Select this option when you want the displayed values to be in scientific format. This format is a shorthand way of writing very large or very small numbers. A number expressed in scientific notation is expressed as a decimal number between 1 and 10 multiplied by a power of 10.

X-axis Format

Select this command to set the format used to display time.




Figure 6.33: X-Axis Format dialog

By default the time is displayed as short as possible: only the available information is displayed without leading zeros. In the x-axis format dialog you can set the number of **decimal places** used behind the seconds.

Select **Use full notation** when you always want the complete format. The number of days is only displayed above 24 hours.

Static Cursor Table

Select this option when you want to use the fixed numbers of the horizontal and vertical cursors as reference instead of the relative 'left/right' and 'top/bottom' naming. Use this option if you want the values in the columns related to a cursor remain in the same column. For example when you move one cursor to the other side of the other cursor, the indication remains in the same column: values from one cursor are always in the same column, regardless of the position of the cursor.




Figure 6.34: Static and non-static cursor table

In the figure above situation A and B depict the operation when the table is non-static.

- a Start situation: the red cursor (active) is on the left-hand side of the blue (passive) cursor. You can verify this by looking at the Time positions (750 ms vs 1.2 s). When we move the active cursor to the other side of the passive cursor we get situation **b**.
- b End situation: the active cursor is on the right-hand side of the passive cursor. You can verify this by looking at the Time positions (1.2 s vs 1.6 s). The values that correspond to the passive cursor have moved from the right-hand column to the left-hand column, i.e. the columns are swapped.
In Figure 6.34 situation **c** and **d** depict the operation when the table is static.
- c Start situation: the red cursor (#1) is on the left-hand side of the blue (#2) cursor. You can verify this by looking at the Time positions (677 ms vs 1.3 s). When we move the active cursor #1 to the other side of the passive cursor #2 we get situation **d**.
- d End situation: the red cursor (#1) is on the left-hand side of the blue (#2) cursor. You can verify this by looking at the Time positions (1.9 ms vs 1.3 s). The values that correspond to the cursors remained in their respective columns however, i.e. the columns are not swapped.

Copy to Clipboard

You can copy values to clipboard and paste these values in another application. You can select to copy only the values of the horizontal, vertical or slope cursors. The copy includes the column headers.

Copy to Excel

You can copy the values directly to Microsoft® Excel with the following options:

- **Post To** This will place the complete table into Excel on a sheet called " Perception - <display name>". When Excel is not active it will be launched. When the sheet already exists data will be overwritten.
- **Append To** The data will be appended to the data that is already in the sheet called " Perception - <display name>".
- **Copy to Current Cell** Data will be placed in the currently active sheet with the upper lefthand cell of the cursor table in the currently active cell of the sheet.

Close

Close the Cursor Table.

- B Horizontal Cursors in Detail** The columns provide the following information:
- **Name** The name of the active trace.
 - **Left/Cursor 1** The Y-value of a trace at the named cursor position. The cursor position in time is shown in the Time row. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
 - **Right/Cursor 2** The Y-value of a trace at the named cursor position. The cursor position in time is shown in the Time row. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
 - **Delta** The difference between the cursor values.
 - **Units** The technical units.
- C Vertical Cursors in Detail** The columns provide the following information:
- **Name** The name of the trace.
 - **Top/Cursor 1** The level of this cursor with respect to the active trace. Depending on the location of the cursor this level may be well above or below the actual levels of the active trace. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
 - **Bottom/Cursor 2** The level of this cursor with respect to the active trace. Depending on the location of the cursor this level may be well above or below the actual levels of the active trace. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
 - **Delta** The difference between the cursor values.
 - **Units** The technical units of each trace and the time.
- D Slope Cursors in Detail**
- The **slope** section has a single row. This row displays the name of the active trace. The slope values are related to the X- and Y-axis of that trace. The columns provide the following information:
- **Name** The name of the active trace (reference trace)
 - **Cursor 1, 2, 3** The slope value of each cursor
 - **Units** The slope in the units of the reference trace.

The crossing section provides information about the crossing of each cursor with any other cursor. Units are with respect to the reference trace.

6.4.5 Cursor navigation

The cursor navigation keys are used to easily navigate the display cursors through your displayed waveforms. The cursor navigation keys are available via a Perception **Cursor Navigation** panel.



Figure 6.35: Cursor Navigation

The panel can be enabled or disabled via the Perception Window menu item (see Figure 6.36): **Cursor Navigation**




Figure 6.36: Window menu with cursor navigation enabled

- A** Show/hide cursor navigation
- B** Cursor Navigation Properties

The Cursor Navigation panel is always linked to the active display and operates on the active trace in this display. The name of the active display and active trace are shown at the top of the dialog. When there is no active display and/or no active trace the keys are disabled.


The panel contains the following cursor navigation buttons:

 Previous Relative Maximum

The active cursor steps to the previous relative (or local) maximum on the active trace.

 Next Relative Maximum


The active cursor steps to the next relative (or local) maximum on the active trace.

 Previous Relative Minimum


The active cursor steps to the previous relative (or local) minimum on the active trace.

 Next Relative Minimum


The active cursor steps to the next relative (or local) minimum on the active trace.

 Go to absolute Maximum


Set the active cursor at the absolute maximum of the active trace.

 Go to absolute Minimum

Set the active cursor at the absolute minimum of the active trace.

 Previous Level Crossing

The active cursor steps to the previous level crossing on the active trace. The level can be specified via the **Cursor Navigation Properties** dialog. This dialog can be opened by a right button click on this key or via the Windows main menu item **Cursor Navigation Properties...**

 Next Level Crossing

The active cursor steps to the next level crossing on the active trace. The level can be specified via the **Cursor Navigation Properties** dialog. This dialog can be opened by a right button click on this key or via the Windows main menu item **Cursor Navigation Properties...**

 Previous Step

The active cursor steps back by the specified step value. The step value can be specified via the **Cursor Navigation Properties** dialog. This dialog can be opened by a right button click on this key or via the Windows main menu item **Cursor Navigation Properties...**

 Next Step


The active cursor steps ahead by the specified step value. The step value can be specified via the **Cursor Navigation Properties** dialog. This dialog can be opened by a right button click on this key or via the Windows main menu item **Cursor Navigation Properties...**

 Previous Trigger


The active cursor goes to the previous trigger position.

 Next Trigger


The active cursor goes to the next trigger position.

 Previous Voicemark


The active cursor goes to the previous voicemark position.

 Next Voicemark


The active cursor goes to the next voicemark position.

 Previous Marker

The active cursor goes to the previous marker mark position.


 Next Marker

The active cursor goes to the next marker mark position.




Swap Cursors

Exchange the positions of the two cursors. This has the effect of making the inactive cursor the active one.




Set Cursor at Other Cursor

Set the inactive cursor at the position of the active cursor.



Slope between Cursors

Set a slope cursor on the active trace between the two vertical cursors.



Specific X-Position

Shows a dialog box (see Figure 6.37) to specify the new X-value for the active cursor, requesting you to enter the new X-value for the active cursor.




Figure 6.37: Go to Specific X-position dialog

A Numerical value or selected data source

B Select data source

The x value can either be a fixed numerical value (**A**), but can also be a data source (**B**). A data source entry can be very useful in case you are interested to set the cursor at a calculated position, for example set the cursor to the time where the trace has the steepest tangent. The formulas can look like:

Num	Name	Formula	Units
1	SignalDf	@Abs(@Diff(Formula.Signal))	
2	XSteepest	@MaxPos(Formula.SignalDf)	

Figure 6.38: Formula example

Now you can use the calculated position to set your cursor there.




Figure 6.39: Example of specifying the new X-value with a formula

A X-value specified by a formula

Cursor navigation properties

The Cursor Navigation Properties dialog (see Figure 6.36) can be shown via the Window menu or via a right mouse click on the level crossing or step keys.

The Cursor Navigation Properties dialog looks like:





Figure 6.40: Cursor Navigation Properties dialog

- A Level** Define the level used to find the correct level crossings.
- B Direction** Define the direction used to find the correct level crossings.
- C Step(s)** Define the stepsize expressed in the same units as the X-axis, this will be mostly seconds.

6.4.6 Statistical calculations

Within Perception a variety of statistical calculations and parameter extraction can be performed easily on the waveform data shown as active trace in the active display.

To show or hide the Calculations window make sure a display is active and do one of the following:

- When available in the **toolbar** you can click the **Calculator** button .
- Using the dynamic sheet menu:
 - 1 Click **Calculator**.
- Through the context menu:
 - 1 Right-click the display area.
 - 2 In the context menu that comes up, point to **Calculate**.
 - 3 Select one of the calculation options.

- In addition you can close the Cursor Table as follows:
 - Click the **Close** button in the title bar of the window.
 - Click **Close**.




Figure 6.41: Calculations window

- A** Calculation selection
- B** Result area
- C** Progress bar

- A Calculations** The Calculation window provides four categories of calculations that you can use:
 - **Statistics** This category includes calculations for statistical values such as mean value, standard deviation, signal root-mean-square (RMS) value, maximum and minimum value.
 - **Cycle** Various parameters related to repetitive signals is calculated in this category. Included are frequency, period, number of cycles and standard deviation.
 - **Pulse** This category comprises an extensive range of (single) pulse parameters like: rise time, fall time, pulse width, top, base, duty cycle, pre-shoot and overshoot.
 - **Area** Energy and area under curve are calculated here.
- B Results** The results of the calculations are shown in the result area. The following generic information is always displayed: channel name, begin and end time of the calculation interval, i.e. the vertical cursor positions, duration and the actual number of samples used for the calculations.
- C Progress bar** The progress bar shows the progress for calculations on large data sets. You can click the **Abort** button to abort a calculation.

To perform calculations:

To perform calculations make sure the window is open and proceed as follows:

- 1 Select the waveform display that you want to use. The name of the selected waveform display is shown in the title bar of the calculation dialog.
- 2 Select the channel on which you want to perform the calculations. The name of the selected channel is displayed in the result area of the calculation dialog.
- 3 In the Calculation dialog select the calculation. The progress bar shows the progress for calculations on long records. Click the **Abort** button to abort a calculation.

You will need to repeat (steps of) the above procedure when you want to perform a calculation on another display, channel or time interval.



HINT/TIP

For more information on transitions, pulse and pulse parameters refer to the “IEEE Standard on Transitions, Pulses and Related Waveforms”, IEEE Std 181-2003.

6.5 Waveform display miscellaneous context commands

A variety of functions and commands is directly accessible through the context menu. The context menu gives you quick access to the most commonly used functions. This section describes all display context menu commands that are not covered elsewhere in this manual.

To gain access to the context menu:

- Right-click the display area.

6.5.1 Trace commands

Trace commands let you add, modify and delete traces.

To gain access to the trace commands:

- In the display context menu point to **Trace** ►. The trace submenu comes up.

New Trace

You can add a trace to the currently active pane. By definition the trace will be positioned as the last (lowest) trace.

To add a new trace:

- 1 Click **New Trace...**
- 2 In the **Select Data Source** dialog that comes up select a trace.
- 3 Click **OK** when done or **Cancel** to quit without adding a new trace.

Insert Trace

You can add a trace to the currently active pane on a specific position.

To insert a new trace:

- 1 Point to **Insert Trace** ►
- 2 In the sub menu that comes up click **Before Selected Trace...** or **After Selected Trace...**
- 3 In the **Select Data Source** dialog that comes up select a trace.
- 4 Click **OK** when done or **Cancel** to quit without adding a new trace.

Delete Trace

You can quickly delete a trace from a pane, either by using the context menu command or the keyboard shortcut.

To delete a trace do one of the following:

- Press the **Del** or **Delete** key on your keyboard.
- Select **Delete Trace** in the trace sub menu.

In the confirmation dialog that comes up click **OK**.

Trace Setup

Click **Trace Setup...** to access the Display Setup dialog with the Traces Setup page selected. Here you can set a variety of trace related parameters and modify the trace source.

6.5.2 Pane commands

Pane commands let you add, modify and delete panes.

To gain access to the pane commands:

- In the display context menu point to **Pane ►**. The pane submenu comes up.

New Pane

You can add a pane to the currently active display page. By definition the pane will be positioned as the last (lowest) pane.

To add a new pane:

- Click **New Pane**

Insert Pane

You can add a pane to the currently active display page on a specific position.

To insert a new pane:

- 1** Point to **Insert Pane ►**
- 2** In the sub menu that comes up click **Before Selected Pane** or **After Selected Pane**.

Delete Pane

You can quickly delete a pane from a page, either by using the context menu command or the keyboard shortcut.

To delete a pane do one of the following:

- Press the **Shift+Del** or **Shift+Delete** key combination on your keyboard.
- Select **Delete Pane** in the trace sub menu.

In the confirmation dialog that comes up click **OK**.

Pane Setup

Click **Pane Setup...** to access the Display Setup dialog with the Panes Setup page selected. Here you can set a variety of pane related parameters and modify the pane contents, location, etc.

6.5.3 Page commands

Page commands let you add, modify and delete pages. You can also rename pages and make a copy of the page for use in other programs.

To gain access to the page commands:

- In the display context menu point to **Page ►**. The page submenu comes up.

New Page

You can add a page to the currently active display. By definition the page will be positioned as the last page.

To add a new page:

- Click **New Page**

Insert Page

You can add a page to the currently active display on a specific position.

To insert a new page:

- 1 Point to **Insert Page ►**
- 2 In the sub menu that comes up click **Before Selected Page** or **After Selected Page**.

Delete Page

You can quickly delete a page from a display, either by using the context menu command or the keyboard shortcut.

To delete a page do one of the following:

- Press the **Alt+Del** or **Alt+Delete** key combination on your keyboard.
- Select **Delete Page** in the page sub menu.

In the confirmation dialog that comes up click **OK**.

Rename Page

You can give a page another name.

To rename a page:

- 1 Do one of the following:
 - Press the **Alt+F2** key combination on your keyboard
 - Select **Rename Page** in the page sub menu
- 2 The name of the page in the page control is highlighted. Now you can modify the name. Press **Enter** to accept or **Escape** to cancel.

Copy Page as Picture

You can copy the page as bitmap and enhanced metafile to the clipboard. Use the Paste (Special) command to place the image into other programs. Use the context menu or the keyboard shortcut to access this command.

To copy a page as picture do one of the following:

- Press the **Ctrl+Alt+C** key combination on your keyboard.
- Select **Copy Page as Picture** in the page sub menu.


Page Setup

Click **Page Setup...** to access the Display Setup dialog with the Annotation & Grid page selected. Here you can set a variety of page related parameters.

Print Display

You can make a high resolution copy of the visible page of the display on your printer.

To print a display page:

- 1 Do one of the following:
 - Access the display context menu and click **Print <display name>...**
 - When available in the **toolbar** you can click the **Print** button 
- 2 In the Print dialog that comes up set your (color) preferences and click **Print**.

6.6 Display Setup dialog

The **Display Setup...** command in the dynamic sheet menu and the display context menu is the common starting point for accessing a variety of waveform display properties. Specific properties are also available as (sub) entries in the display context menu. These entries can give access to the Display Setup dialog with the corresponding page selected.

The settings and properties are grouped for easy reference and to keep the user interface as clear as possible. The following main groups are available:

- Display Setup: global display settings and behaviour
- Annotation & Grid: X- and Y-annotation settings as well as grid/separators settings
- Panes Setup: manage panes and their content
- Traces Setup: define trace source, layout and parameters

6.6.1 Display Setup

The Display Setup page gives access to various properties that are relevant to the display look and feel.




Figure 6.42: Display Setup dialog - Display Setup

- A** Display name
- B** Control area settings
- C** Page management
- D** Add, delete and move pages
- E** Page name
- F** Overrange indication
- G** Dynamic display behaviour
- H** Zoom preference

A Display name Each waveform display can be given a descriptive name. Any name with up to 100 characters is allowed. When you deselect the **Show display name in title bar** option, the display title bar will collapse.



HINT/TIP

To show/hide the display title bar instantly you can click on the show/hide title bar icon, the little arrow on top of the title bar. You can also double-click anywhere in the title bar to toggle the title bar's visibility.

B Control area The control area is a part of the display that contains one or more controls. The control area can be hidden as well as individual controls. The control area can hold the following controls:

- **Page control** Manage pages.
- **Time control** Scroll through the waveform data.
- **Replay control** Replay waveform data.
- **Cursor values** Show the values of the active and passive cursor.

Here you can set which controls you want to see. For details refer to "Control area" on page 142.

The **Icon size** sub section allows you to set the size of the controls

- **Small** Default, typically used for 96 DPI display resolution.
- **Medium** For higher display resolution, for example 120 DPI.
- **Large** For touch screens.


C Page management In this section you can add, delete and move pages. You can also rename pages here. Each available page is displayed as a large page icon. The highlighted page is the active page and also the page on which you perform your actions.

To select (activate) a page:


- Click on the page icon of the page that you want to activate. The name of the selected page appears in the *Page Name* text field.

- D Add, delete and move pages** There are four controls that allow you to add, delete or move pages.



To add a page:

-  Click the **Add page** button. This will add a page. The page will be appended to the end of the page list and activated.

To delete a page:

- 1 Select the page icon of the page you want to delete.
- 2  Click the **Delete page** button.

To move a page:

- 1 Select the page icon of the page you want to move.
- 2 To move the selected page do one of the following:
 -  Click the **Move page left** button to move the selected page one position to the left.
 -  Click the **Move page right** button to move the selected page one position to the right.

- E Page name** The name of the currently selected page. You can type new name here.

- F Overrange** Overrange is physical phenomenon, based on the input characteristics of the digitizing equipment.

In general digitizing equipment has 16-bit resolution. This resolution equals 65536 levels. For various reasons only the middle 60000 levels are used, leaving a 4.6% range on each side. This is called the overrange. Depending on the recorded waveform data can be available within this range. For example a sine wave with an amplitude of 8.5 volt acquired with an 8 volt span of the input amplifier will fit in the complete ADC measurement range (which is actually 8.7 volt), but the maximum values will be within the overrange since the actual used range is 8.0 volt.




Figure 6.43: Overrange drawing

- a Overrange information displayed
- b Overrange information suppressed

Here you select if you want to see the data in the overrange yes or no.

- G Dynamic display behaviour** This option allows you to add a live view in your display when acquiring data automatically:
- **No change** Select this option when you do not want an automatic view replacement.
 - **Add live view** Select this option to add a live view when acquisition starts. When acquisition stops the original layout of the display is restored.
 - **Replace view** Select this option to replace a Review view with a live view when acquisition starts. When acquisition stops the original layout of the display is restored.
- H Zoom style** Defines the default zoom style. Each zoom style is always accessible by means of zoom+key(s) combination.

6.6.2 Annotation & Grid

The Annotation & Grid page in the Display Setup dialog box gives access to all settings related to the layout and functionality of the annotation of both the Y-axis and the X-axis. Also general - style related - layout options can be found here.




Figure 6.44: Display Setup dialog - Annotation & Grid

- A** X-Annotation: time and position axis
- B** Show: set visibility of components
- C** Colors: set colors of components
- D** Font: set font for annotation
- E** Y-Annotation: amplitude axis
- F** Grid: define grid settings
- G** Sizes: set separator and event traces thickness

- A** The **X-annotation** area is used to display a time or position scale. The scale supports internal (time-based) and external (position-based) acquisition time bases. When time is used, the x-axis scale can be relative or absolute. When position is used the position can be translated to linear or rotational displacement. For ease of reference the X-annotation scale will be named time scale although it can also refer to a position.

When the time scale is relative time, the time is referenced to the start of the recording. With relative time the start of the recording is considered the start of the time line, i.e. $t=0$.

When the time scale is absolute time, the actual time of day at the start of recording is used as reference without correction.

For full details refer to "The X-annotation area" on page 139.

- B** In the **Show** area you can set which items you want to be visible in the display. Check all that apply.
- C** To set the **Colors** of the various objects and areas click on the corresponding color drop down box. For details on changing colors refer to "Modifying color" on page 62.
- D** **Font** You can set the font properties of the font used in the annotation of your display. Click **Select** to call up the common **Font** dialog box. Make your selections and click **OK**.
- E** **Y-Annotation** On the left-hand side of the graphic display is the Y-annotation area. The properties of this area can be set here: width and cursor readouts. For full details on the Y-Annotation area refer to "The Y-annotation area" on page 135.

- F Grid** You can add grid lines to the display as a visual aid when inspecting waveforms. The Grid section provides the various grid setup features. Grid settings are for panes, for example a setting of 10 horizontal divisions results in ten horizontal divisions per pane.

You can have a horizontal as well as a vertical grid. A horizontal grid places horizontal lines, that is, divides the Y-axis. A vertical grid places vertical lines on the X-axis.

To set the grid lines:

- 1 In the **Show** area select the **Grid** check box
 - 2 In the **Grid** area select the **Horizontal** and **Vertical** check box as required. Enter the required number of divisions for each of these selections. The *Horizontal divisions* are related to the horizontal grid lines style, that is, the Y-axis is divided into the number of divisions you enter here. The *Vertical divisions* are related to the vertical grid lines style, that is, the X-axis is divided into the number of divisions you enter here.
 - 3 In the **Colors** area set the color of the grid lines.
- G Sizes** here you set the sizes of the **Pane separators** and the **Event traces**.

Pane separators are the small horizontal lines that indicate the borders of the panes. Panes are used to display data in separated - individual - areas. Panes can have individual heights and might contain one or more traces.

To modify the pane separators:

- 1 In the **Show** area select the **Pane separators** check box
- 2 In the **Sizes** area under **Pane separators** set the width of the separator lines. This may improve visibility with high resolution printing. Options include:
 - Small: 1 pixel
 - Medium: 3 pixels
 - Large: 5 pixels
- 3 In the **Colors** area set the color of the pane separators.

For details on the Event traces height refer to the section on "Event/digital traces" on page 145.

6.6.3 Panes Setup

The Panes Setup page in the Display Setup dialog provides all functionality for pane management: add and remove panes, reposition and size panes, define the contents of a pane.




Figure 6.45: Display Setup dialog - Panes Setup

- A Page select
- B Pane position and size
- C Pane icon
- D Pane separator
- E Add/remove pane
- F Pane size
- G Move pane up/down
- H Move trace up/down
- I Traces in selected pane
- J Navigator: available traces (data sources)
- K Add/remove trace
- L Pane layout section

A Page select Use the page select scrollbar to select a page. The Panes and Pane Layout section will change to reflect the corresponding setup.


B-G Pane position and size In this section you can add and delete panes, reposition panes and set their size.

To select a pane:


To select a pane for manipulation:

- Click on the pane icon of the pane you want to select.



To add a pane:

-  Click the **Add pane** button. This will add a pane. The pane will be appended to the end of the pane list and activated.

To delete a pane:

- 1 Select the pane icon of the pane you want to delete.
- 2  Click the **Delete pane** button.

To move a pane:

- 1 Select the pane icon of the pane you want to move.
- 2 To move the selected pane do one of the following:
 -  Click the **Move pane up** button to move the selected pane one position up.
 -  Click the **Move pane down** button to move the selected pane one position down.

To size a pane:


You can set the size of each pane individually. To do so proceed as follows:

- 1 Select the pane icon of the pane you want to resize.
- 2 Do one of the following:
 - In the **Height** box enter a value as percentage of the display size.
 - Click on a pane separator and drag it to the required position.


H-L Pane contents and layout In this section you define the traces that are in the pane and their position: add and remove traces and position traces.

To add a trace:



To add a trace you must select a data source and add this source to the list of traces as follows:

- 1 In the list of **Available Traces** select one or more data sources.
- 2 Do one of the following:
 - With the sources selected drag them into the list of **Selected Traces**.
 -  Click the **Add trace** button. This will add the selected trace. The trace will be appended to the end of the trace list.

To delete a trace:

- 1 Click the trace in the **Selected Traces** list you want to delete.
- 2  Click the **Delete trace** button.

To move a trace:

- 1 Click the trace in the **Selected Traces** list you want to move.
- 2 To move the selected trace do one of the following:
 -  Click the **Move trace up** button to move the selected trace one position up.
 -  Click the **Move trace down** button to move the selected trace one position down.

6.6.4 Traces Setup

The Traces Setup page in the Display Setup dialog provides a variety of functionality for trace management: trace position and scaling, source modification and layout. You cannot add or delete traces here. To do so go to the Panes Setup page in this dialog or use one of the techniques described in "Trace commands" on page 186.




Figure 6.46: Display Setup dialog - Traces Setup

- A Page and pane select
- B Trace select, position and size
- C List of available traces
- D Settings of selected trace
- E Source of selected trace
- F Position
- G Color replace
- H Y-Scale settings
- I Graphical representation of traces within pane

A Page and pane select Use the **Page** select scrollbar to select a page. Use the **Pane** select scrollbar to select a pane within the selected page. The list of available traces and the graphical representation will change to reflect the equivalent setup.

B Traces In this area you can select a trace for manipulation. Here you can modify the vertical size and position of a trace within a pane.

To select a trace:

To select a trace for manipulation, do one of the following:

- Click on the trace in the list of available traces (C)
- Click on the graphical representation of the trace (I)

To scale a trace within a pane:

To scale a trace within a pane (without modifying the actual display range) using the graphical area proceed as follows:

- 1 In the graphical area click the trace you want to modify.
- 2 Drag the top and/or bottom handle of the trace to the required position and release the mouse. Note that the **Top** and **Bottom** indicators under **Position** change accordingly while dragging.

Although you modify the scaling of the trace within the pane, you do not scale the display range. You can modify the display range in the Y-scale area.

To position a trace within a pane:

To position a trace within a pane using the graphical area proceed as follows:

- 1 In the graphical area click the trace you want to modify.
- 2 Click and drag the trace indicator to the required position and release the mouse. Note that the **Top** and **Bottom** indicators under **Position** change accordingly while dragging.

C List of available traces Use this list to select a trace.

D Settings This is the general section to set various properties of the selected trace. Areas include:


- Source
- Position
- Y-Scale
- Zero-line and color

- E Source** Typically you set the source of a trace in the Panes Setup page. However, you can modify the source of a selected trace also in this page.

To modify the source of a trace:

To modify the source of trace do one of the following:

- When you know the actual path of the source you can type it directly into the source select text box, or modify the contents.
- Browse for data source:
 - 1 Click on the Data Source Navigator button at the right-hand side of the source select text box.
 - 2 In the Select Data Source dialog that comes up select the new data source.



- 3 Click **OK** when done.

The Select Data Source dialog provides a list of data sources that is filtered to show only the data sources that are applicable in a specific situation.

- F Position** Here you can scale and position a trace within a pane using numeric entry. You can also set a zero line.

To scale and position a trace:

To scale and position a trace using numeric entry:

- 1 Select the trace you want to modify using one of the aforementioned procedures.
- 2 Enter a value for **Top** and **Bottom** as a percentage of the pane height. The graphical representation will change accordingly.

To set a zero line:

When you want to show a zero line for the selected trace in the display:

- Select the **Show zero line** check box

- G Color replace** You can modify the default color of a trace

To set the color of a trace:

- 1 Select the trace you want to modify using one of the aforementioned procedures.
- 2 Select the **Replace channel color with** check box.

- H Y-Scale** Here you can set the Y-scale options for a selected trace. You can set the Y-scale of a trace to one of the following options:

- **Input Range** The Y-scale display range is exactly the same as the input range.
- **Fixed** When set to fixed, begin and end of the Y-scale display range are user-defined.
- **As trace** This option allows you to set the Y-scale display range exactly the same as a selected other trace. Once this option has been set, the selected trace will “follow” the settings from the linked trace.

To modify the display range select the trace you want to modify using one of the aforementioned procedures and do one of the following:

- Select **Fixed** and enter the **From** (upper limit) and **To** (lower limit) values, or
- Select **As trace** and in the list select the trace you want to use.

- I **Graphical representation** This area provides an interactive approach for modifying the trace position and size within a pane.

The following Figure 6.47 on page 206 is an example of a pane with various trace settings.




Figure 6.47: Example of various trace settings

6.7 Display markers

Marker terminology

Display Markers are used to accurately mark a position on your data in the graph area or to label a defined point so that it stands out from the rest of the data. There are several different types of markers available for different purposes. This section outlines the Marker options available to you.

Below is an example of a type of display marker called a trace marker. In this example the markers properties are noted. Markers use a combination of these properties and depending on the user, may or may not include a label.




Figure 6.48: Example of a display marker

- A** Label
- B** Line
- C** Anchor

Within the Review, Zoom or Alt Zoom view there are eight marker types to add annotations to your data:

- The **Trace Marker** can be added to a trace to annotate amplitude of a waveform at a specified time.
- The **X-Range Marker** can be used to annotate time or position difference between two points in a waveform.
- The **Y-Range Marker** can be used to annotate amplitude difference in a waveform and can be placed at a specified time or position.
- The **Slope Marker** can be used to annotate the slope between two points on a waveform.
- The **Time Marker** can be added to the display to annotate a position in the recording.
- The **Full Display Marker** can be added to the display to annotate the width of the view.

- The **Slope Cursor Marker** can be used to annotate the slope at a time or position of a waveform using the slope cursors as reference.
- The **Free Float Label** is a label only, can be positioned on the display and remains at this position, independent of the waveform shown.

All eight marker types can be manipulated using the properties dialog, toolbar and dynamic menu.




Figure 6.49: Markers sub-menus

- A Marker commands
- B Marker types




Figure 6.50: Markers toolbar

- A Show all markers
- B Hide all markers
- C Select and add markers

To show all display markers do one of the following:

- Click **Show all Markers** in the toolbar.
- Using the dynamic sheet menu:
 - 1 Point to **Markers** ▶
 - 2 Click **Show all Markers**

To hide all display markers do one of the following:

- Click **Hide all Markers** in the toolbar.
- Using the dynamic sheet menu:
 - 1 Point to **Markers** ▶
 - 2 Click **Hide all Markers**

To place a display marker do one of the following:

- Position the cursor or cursors on the point(s) of interest in display.
- For trace-related markers (see each individual marker description for more information) make sure the trace you want to add markers to is the active trace.
- Make sure the view you want to add the marker to is active.
- Using the shortcut menu:
 - 1 Right-click the appropriate cursor to access the shortcut menu.
 - 2 In the shortcut menu select the marker type you want to add.

- Using the dynamic sheet menu:
 - 1 Point to **Markers** ▶
 - 2 Point to **Add** ▶
 - 3 Click on the marker type you want to add. The active view and active cursor will be used for adding the marker.

To remove a marker do one of the following:

- Using the shortcut menu:
 - 1 Right-click the marker.
 - 2 Click the **Remove** icon.
- Using the dynamic sheet menu:
 - 1 Point to **Markers** ▶
 - 2 Click the **Remove** icon.

To show the marker properties dialog take one of the following actions:

- Using the shortcut menu:
 - 1 Right-click the marker.
 - 2 Click the **Properties of** icon.
- Using the dynamic sheet menu:
 - Point to **Markers** ▶
 - Click the **Properties of** icon.

To identify the active marker:

The active marker can be identified by the rectangle drawn around it. A marker is automatically active after it is added. It can also be activated using a mouse click.




Figure 6.51: Active display markers

Display marker data sources

After a marker is created, new data sources are added that can be used throughout Perception. Depending on the marker type, various data sources will be added to the system. The data source for display markers are added in the following location:

Display ▶ “DisplayName” ▶ “DisplayMarkers” ▶ “DisplayType” ▶ “MarkerName”

Display type refers to the area where the marker was added, for example the **zoom**, **alt zoom** or **review** area.

6.7.1 Trace marker

When adding a trace marker the anchor will be inserted at the crossing between the active trace and active cursor. The label will be given a default offset but can be repositioned freely to the desired position.

This marker is added to the active trace.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker anchor on the trace.
- **StartTime:** This is the time of the marker anchor on the trace. This time is the time relative to the start time of the recording.

6.7.2 X-range marker

The X-Range marker is added at the amplitude of the active cursor and between the times of the two vertical cursors. After adding the marker, its vertical position can be changed by picking up the marker or dragging the label up and down. It is also possible to move the label around the marker line and horizontally between the start and end anchor of the display marker.

This marker is added to the active trace.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker start anchor on the trace. The start anchor is the anchor at the active cursor.
- **StartTime:** This is the time of the marker start anchor on the trace. This time is the time relative to the start time of the recording. The start anchor is the anchor at the active cursor.
- **EndLevel:** This is the amplitude of the marker end anchor on the trace.
- **EndTime:** This is the time of the marker end anchor on the trace. This time is the time relative to the start time of the recording.
- **DeltaX:** This is the difference between the start and end times of the marker.

6.7.3 Y-range marker

The Y-range marker will be placed at the position of the active cursor. The start anchor is placed at the crossing between the active cursor and the active trace. The end anchor is placed at the same position as the start anchor, but its amplitude is determined by taking the crossing between the passive cursor and the active trace. It is possible to move the marker horizontally by dragging it using the line or the label. You can position the label horizontally across the marker line.

This marker is added to the active trace.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker start anchor on the trace. The start anchor is the anchor at the active cursor.
- **StartTime:** This is the time of the marker start anchor on the trace. This time is the time relative to the start time of the recording. The start anchor is the anchor at the active cursor.
- **EndLevel:** This is the amplitude of the marker end anchor on the trace.

- **EndTime:** This is the time of the marker end anchor on the trace. This time is the time relative to the start time of the recording.
- **DeltaY:** This is the difference between the start and end amplitudes of the marker.

6.7.4 Slope marker

The slope marker is placed between the crossing of the active cursor with the active trace and the passive cursor with the active trace. Once placed, this marker cannot be moved anymore.

The label can be placed at any position on the marker line.

This marker is added to the active trace.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker start anchor on the trace. The start anchor is the anchor at the active cursor.
- **StartTime:** This is the time of the marker start anchor on the trace. This time is the time relative to the start time of the recording. The start anchor is the anchor at the active cursor.
- **EndLevel:** This is the amplitude of the marker end anchor on the trace.
- **EndTime:** This is the time of the marker end anchor on the trace. This time is the time relative to the start time of the recording.
- **DeltaX:** This is the difference between the start and end times of the marker.
- **DeltaY:** This is the difference between the start and end amplitudes of the marker.
- **Slope:** This is the slope between the start and end anchor points of the marker.

6.7.5 Time marker

The time marker is placed at a fixed position of the display. It is added at the position of the active cursor and at least one valid trace is required for adding a time marker because a point of reference is required to calculate a correct position.

The marker is added to the page and runs from the top of the display to the bottom of the display. This marker type does not have a start or end anchor.

The label can be moved vertically across the line. Limited horizontal movement is also possible, the label can be positioned left or right of the marker line.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartTime:** This is the time of the marker start anchor on the trace. This time is the time relative to the start time of the recording.

6.7.6 Full display marker

The full display marker must be added using the horizontal cursors. It is added at the amplitude of the active horizontal cursor. Once added this marker runs from the leftmost to the rightmost position of the view. The label is positioned in the view and keeps its position relative to the view, even if the data is moved.

It is possible to move the label horizontally in the view, and the label can also be moved vertically around the marker line. Because this marker runs from the start of the view to the end of the view, it has no start or end anchor.

This marker type is added to the active trace.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker start anchor on the trace.

6.7.7 Slope cursor marker

This marker is very similar to the slope marker. The only difference is the placement method. To place a slope cursor marker, use the slope cursors. The slope cursor marker is added at the position of the active slope cursor.

Note *After adding the slope cursor marker the slope cursor is hidden by the marker. You can move the slope cursor normally to make it visible again.*

The slope cursor marker is added to the active trace. It is not possible to move the marker after placement.

The data sources that are added for this marker are:

- **LabelText:** This is the text shown in the display marker.
- **StartLevel:** This is the amplitude of the marker start anchor on the trace. The start anchor is the anchor at the active cursor.
- **StartTime:** This is the time of the marker start anchor on the trace. This time is the time relative to the start time of the recording. The start anchor is the anchor at the active cursor.

- **EndLevel:** This is the amplitude of the marker end anchor on the trace.
- **EndTime:** This is the time of the marker end anchor on the trace. This time is the time relative to the start time of the recording.
- **DeltaX:** This is the difference between the start and end times of the marker.
- **DeltaY:** This is the difference between the start and end amplitudes of the marker.
- **Slope:** This is the slope between the start and end anchor points of the marker.

6.7.8 Free float marker

The free float marker is a label only that is positioned on the display and always stays in the same position, independent from time or amplitude changes of the data shown in the display. When added, this marker is placed in the upper left corner of the active view. It can then be moved to any position in the display.

This marker is added to a display page.

This marker has only one data source:

- *LabelText:* This is the text shown in the display marker.

6.7.9 Marker properties

To see the Marker properties option menu right-click on a marker and then choose **properties of <name>**. You can also highlight a Marker and click **Active > Markers > properties of <name>**.




Figure 6.52: Marker Properties dialog

- A Progressive disclosure
- B Anchors; Type Size and Style
- C Hide Label
- D Marker name
- E Automation
- F Insert data source
- G Label Text
- H Marker type

- A Progressive disclosure** Expands or collapses the properties dialog.
- B Anchors** Select between, Type or shape, sizes and different styles.
 - **Anchor size** Selects the required anchor size from the list.
 - **Anchor style** Selects the appropriate style from the list. This may not have any effect on anchors in small size.
- C Hide label** Hides the label. In case of the trace marker this will also hide the line to the label.
- D Marker name** Changes the name of the marker. Changing the marker name will also change the path of data sources created by the marker. Note that double names are not allowed and will be automatically replaced with unique names.

- E Automation** Depending on the marker type one or more of the following items may be available. For more information on automatic markers see "Automatic markers" on page 217 in this manual.
- F Insert data source** Click to insert a data source in the label text. Refer to "Insert and format a data source" on page 64 for more information.
- G Label Text** This is the text that will be displayed in the label of the marker. Note that this text may contain placeholders which are indicated by braces.
- H Marker type** This indicates the type of marker. It also indicates to which page or trace the marker is added.

6.7.10 Automatic markers

You can automate marker placement. To do this you need to connect one or more of the marker's anchor coordinates to a data source. To enable automation select the check box in front of the coordinate that needs to be automated. Then use the data source navigation button to attach the coordinate to the appropriate data source. This can be any available numerical data source.




Figure 6.53: Automatic markers with anchor check box (detail)

If only the position (X) of a marker is set to automatic, the corresponding amplitude (if applicable) is determined using the level of the connected or active trace at the resulting position.

An automatic display marker can be recognized in the display by a small rectangle in the upper right corner of the label. This rectangle is not printed in the report.

If an automatically placed marker is manually moved, it is set to a fixed position and is no longer automatic.




Figure 6.54: Select Data Source

Example:

To set up an auto marker we need a few things first. In this example we will set up a “maximum value” position marker for Chanel A1.

- 1 Firstly we need to set up a formula in the formula sheet option. Click on the Formula sheet tab and enter the following into a row of blank cells:
Name: “ ChA1_Max “
Formula: “ @MaxPos(Active.Group1.Recorder_A.Ch_A1) “

This will show the maximum for Channel 1 on any data channel that you add the label.

- 2 In **Active sheet** display make sure you have data available in **Chanel 1** and select an active Channel with data on which you want the marker to be placed.
- 3 Position the cursor anywhere you like, right-click and **add trace marker**.
- 4 Once you have a trace marker available select it and right-click to edit it. Click **properties of <name>** and in the displayed dialog click **More**.
- 5 Go to **Automation** and select the check box for **Anchor 1 (x)**.

- Now you can click on the **navigation** button and another dialog box “Select Data Source” will open (see Figure 6.55).




Figure 6.55: Active Sheet/Marker Properties dialog/Select Data Source dialog (From left to right)

- Double click or click the “plus” sign next to Formula and select the recently made formula **ChA1_Max** from the list, double click or press **OK** and then **OK** again in the **Marker <name> properties** dialog.

The cursor should now move to the correct position corresponding to the chosen formula written in the formula sheet. The maximum amplitude value should now equal the marker anchor value.

Save display markers

Display markers that are added to a display are also stored in a VWB and experiment when they are saved.

Opening a VWB will already show all manually placed markers even if no data is shown yet. After opening the VWB there are two options:

- A previous recording is opened. This will show the data and not affect the display markers. Once the data is loaded, all automatic markers that can now be evaluated are also shown. Please note that the data should be loaded the same way as it was saved, so used load as active or load using filename where appropriate.
- A new recording is created. The manually placed markers will now disappear and the automatic markers will be shown when their automatic coordinates can be evaluated.

Opening an experiment that contains display markers will show both the data and the display markers (manual and automatic) that were saved when the experiment was saved.

In general: If you start a new recording, manually placed markers are removed from the display. Automatic markers are temporarily hidden until their location is determined.

6.8 External clock support

When you select the external time base in the settings sheet, the clock used to drive the ADC's is the clock signal presented at the external clock input BNC on the system. When you select this mode, the interval between two consecutive samples may not be equidistant. This all depends on the accuracy of the supplied clock signal. Refer to the user manual supplied with your hardware for more details.

Note *External clock is a system wide setting. If you are using multiple mainframes, all connected mainframes will be set to external clock mode.*

Note *External clock is an advanced usage of your data acquisition system; therefore you will have to show the advanced settings sheet settings.*

Through the settings sheet, the external clock units, scaling, shift, Top Dead Centre and delay can be set. See the settings sheet manual for a more detailed explanation of the external clock options.

External clock is most commonly used for applications performing measurements on rotational equipment. Others are most likely using the clock as a movement indicator.

External clock in the display

By default the display will show the signals in seconds. The X-Annotation will be scaled according to the time conventions, HH:MM:SS.dddd where HH is the hours, MM the minutes, SS the seconds and dddd the second fraction. The hours and minutes are automatically blanked for small time values. For external clock this is most likely not the preferred format. Therefore the display can be set into another mode.

To set the display in the external clock support mode:

- 1 Right-click in the display area to access the shortcut menu.
- 2 In the shortcut menu click **Display Setup...**
- 3 In the Display Setup dialog select the **Annotations & Grid** page.
- 4 In the X-Annotation section select the **Position** option as scaling unit (see picture "Property sheet of the display").
- 5 Select one of the following options:
 - Linear
 - Rotational, 360 degrees per cycle
 - Rotational, 720 degrees per cycle
- 6 Click **OK** when done.




Figure 6.56: External clock settings

By default the display will now show the X-Annotation as external clock units per division. Also the clock notation of the display status bar will be shown in the external clock units.




Figure 6.57: Display shows X-Annotation in external clock units with status bar (detail)

Position options

When external clock is selected, the display shows the external clock values relative to the start of the recording. Other options like **Absolute local** and **Absolute UTC** are not available anymore.

The available selections are:

- Linear
- Rotational, 360 degrees per cycle
- Rotational, 720 degrees per cycle

Linear

When the **Linear** option is checked, the X-Annotation will be shown as the number of external clock units after the start of the recording. For larger or smaller units, an engineering prefix will be used. For example when the external clock units are “Clocks” the time per division can be 100.0 mClocks/Div or 10 kClocks/Div. The options to expand and compress the X-Annotation scale will be in decades of the 1, 2, 5 range.

Rotational, 360 degrees per cycle

When the **Rotational, 360 degrees per cycle** option is selected, the X-Annotation will be shown as the number of cycles and the number degrees per cycle. As separator the colon “:” is used to separate the cycles and degrees within the cycle. For example 10:013 is the external clock location where we have 10 cycles and 13 degrees from the start of the recording. The cycles will not contain engineering prefixes. The X-Annotation expand and compress scale will be in the decade ranges 1, 2, 5 for values < 1 degree, and 1,2,5,10,30,60,180 for values > 1 degree and < 360 degrees. Larger values will be scaled in the 1, 2, 5 ranges again.

Rotational, 720 degrees per cycle

When the **Rotational, 720 degrees** per cycle option is selected, the X-Annotation will be shown as the number of cycles and the number degrees per cycle. Each cycle now contains 720 degrees. The X-Annotation expand and compress scale will now include also 360 degrees.

7 Sheet Objects

7.1 Introduction

Most of the work area is occupied by sheets. A number of sheets have a fixed user interface. The active sheet and user sheets do not have a fixed user interface. Their layout and contents is free to configure. You can divide such a sheet into one to four areas and in each area you can place an object.

In this chapter we will discuss the various objects that can make up an active or user sheet. For information on the general usage of sheets refer to "Working with sheets" on page 72 and following.

Currently the following objects can be placed on a sheet:

- Waveform display
- Spectral display (optional)
- XY-display
- Meter array
- User table
- Image
- Video (optional)

7.1.1 Adding and deleting objects

Objects can be easily added to a sheet. Once a sheet is 'full' you cannot add new objects. Nor can you replace an object. In such a case you must delete an object first before you can add a new one.

Objects are placed in the area that you last clicked or in the last available area.




Figure 7.1: Add object shortcut menu

To add an object:

To add an object to a sheet do one of the following:

- In the menu bar choose **[dynamic menu] ▶ Add ▶**. Click an object in the sub menu.
- When visible, in the toolbar select one of the object icons.
- With a right mouse click in the sheet area call the context menu. In the context menu select **Add ▶**. Click an object in the sub menu.

To delete an object:

- 1 Select the object that you want to delete.
- 2 Right-click the object to access the context menu.
- 3 In the context menu click **Delete [object name]**.
- 4 In the confirmation dialog that comes up click **OK**.

To move an object into the Recycle Bin:

Note *The Recycle Bin option is only available when there are multiple objects on the Active/User sheet.*

- 1 Select the separator of the sheet object (e.g. User Table) which you want to delete.




Figure 7.2: Separator

A Separator

- 2 Move the separator to the left or right sheet border.

- 3 Release the separator when a **Recycle Bin** symbol appears.




Figure 7.3: Recycle Bin

A Recycle Bin

- 4 The sheet object which shows the **Recycle Bin** symbol will be deleted.

7.2 **Waveform display**

The waveform display is described in full detail in the chapter “Data Visualization” on page 129 and the following pages.

7.3 Meters

Within Perception you have the possibility to add meters to a sheet. A meter can be a numerical meter, but also an analog / VU or hybrid meter. Usually there are a number of meters organized as an array. The array of meters has a number of properties that resemble the waveform display, for example a title bar and a page control.




Figure 7.4: Meter array example with numerical meters

- A Show/hide title bar
- B Object title bar
- C Page control
- D Parameter select
- E Meter properties
- F Units of displayed value
- G Value
- H Meter title bar

- A Show/hide title bar** To show/hide the meter title bar instantly you can click on the show/hide title bar icon, the little arrow on top of the title bar. You can also double-click anywhere in the title bar to toggle the title bar's visibility.
- B Title bar** You can set the name of the object that is displayed in the title bar through the object's properties.
- C Page control** This is a standard page control to browse through the various pages.
- D Parameter select** Use this control to select quickly a parameter when available.
- E Meter properties** This button calls up the meter properties dialog.
- F Units** Shows the technical units of the displayed value.
- G Value** The value of the selected parameter.
- H Meter title bar** Can show information on the data and data source.

7.3.1 Meter flavors

As standard a variety of meter types is provided. Most meters are available in multiple sizes to allow for a best fit of the available space. The actual size used is determined automatically and is related to the available space for the array.




Figure 7.5: A variety of meters

7.3.2 Data sources for meters

Each meter can be connected to a data source. Data sources for meters can be real-time parameters as provided by the data acquisition system or data sources provided by the Perception environment. Summarized:

Data sources for meters can be either one of the following:

- Real-time parameters from connected acquisition hardware.
- Various system variables (or constants).

For each of these parameters also the highest and lowest value within the current acquisition is calculated.

Real-time parameters

Depending on the type of acquisition hardware that is connected a variety of real-time parameters can be available. A basic set of parameters includes:

- Maximum value
- Minimum value
- Mean value
- Peak-to-peak value
- Root Mean Square (RMS)
- Standard deviation

When available these values can be accessed through the data sources navigator. The realtime parameters are available as a subset from the actual channel data.




Figure 7.6: Data sources for meters

System variables

Almost any system variable can be used as data source for a meter. These are typical stringtype variables or numbers. They can be found in any section and may range from User Name to Ventilator Speed.

7.3.3 Adding meters to a sheet

There are various ways to add one or more meters to a sheet. Refer also to "Adding and deleting objects" on page 225.


Basically there are two options:


- 1 Drag data sources to an empty area on a sheet. This will instantly create an array of meters.
- 2 Add a placeholder to a sheet. You are presented an empty placeholder for a meter array, still to be filled.

To add meters using drag-and-drop:

- 1 Make sure the Data Sources navigator is visible.
- 2 In the Data Sources navigator select one or more parameters / values and drag them onto an empty sheet or sheet area. New meters will be automatically created that fill the entire sheet (area) displaying the selected parameter(s) / value(s). When selecting you can:
 - select an individual parameter / value
 - select all parameters/values of a channel: hold down the Shift-key while dragging a channel. An array will be created that comprises all real-time parameters of the selected channel.
 - select all parameters/values of a channel: hold down the Shift-key while dragging a recorder. A multi-page array will be created that comprises all real-time parameters of the selected recorder.

To add meters using a placeholder:

- 1 To add a meter placeholder to a sheet do one of the following:
 - In the menu bar choose **[dynamic menu] ► Add to sheet ► Meter**.
 - When visible, in the **toolbar** click the **Add Meter** button .
 - Within the sheet area call the context menu. In the context menu select **New Meter(s)...**



- 2 Make sure the Data Sources navigator is visible.
- 3 In the Data Sources navigator select one or more parameters / values and drag them onto the meter placeholder. New meters will be automatically created. When selecting you can:
 - select an individual parameter / value
 - select all parameters/values of a channel: hold down the Shift-key while dragging a channel. An array will be created that comprises all real-time parameters of the selected channel.
 - select all parameters/values of a recorder: hold down the Shift-key while dragging a recorder. A multi-page array will be created that comprises all real-time parameters of the selected recorder.

Replacing meters

You can replace one or more meters by one other meter.

To replace meters:

- 1 Select the meter(s) you want to replace.
- 2 Right-click the selected meter(s) to access the context menu.
- 3 In the context menu click **Replace Meter(s)...**
- 4 In the Select Data Source dialog that comes up select the new data source.
- 5 Click **OK** when done.

7.3.4 Modifying the layout of a meter array

Just as you can divide a sheet into areas you can also divide a meter array into areas.


To modify the layout of a meter array:


To divide a meter array into two or more sections do one of the following:


- Right-click the meter array.
In the context menu that comes up point to **Split ►** and select one of the presented options in the submenus.

Once a layout is selected, splitters appear that divide the array into sections. These splitters can be freely moved. When you hover the mouse over a splitter, the mouse pointer will change into a pointer with arrows. The arrows point in the direction that you can move the splitter. Click and drag the splitter in the required direction.

The following cursor icons are used:

 When this cursor shape is visible you can move the splitter that divides the array area horizontally.

 When this cursor shape is visible you can move the splitter that divides the array area vertically.

 Four way splitter icon: this icon appears when you are in the vicinity of an intersection of a horizontal and vertical splitter. You can now freely move both splitters at the same time.

7.3.5 Inserting, deleting and moving individual meters

Within the array of meters you can insert, delete and move (re-arrange) individual meters.

To select one or more meters:

For many operations you must select one or more meters as follows:

- To select a single meter: click on the meter.
- To select consecutive meters, click the first meter, press and hold down SHIFT, and then click the last meter.
- To select nonconsecutive meters, press and hold down CTRL, and then click each meter.
- To unselect a meter(s): press the Esc key.

To insert meters:

You can insert meters in an existing array by drag-and-drop of the corresponding data sources as follows:

- 1 Select the required data source(s) as described earlier.
- 2 Drag them onto the meter array. You will see a red line between the meters that indicates the insertion point.
- 3 Move the insertion point to the desired location.
- 4 Release the mouse button.

To delete meters:

- 1 Select the meter(s) that you want to delete.
- 2 Right-click the array to access the context menu.
- 3 In the context menu click **Delete Meter(s)**.
- 4 In the confirmation dialog click **OK**.

To re-arrange meters:

You can modify the order in which the meters are shown.

To modify the order proceed as follows:

- 1 Select the meter(s) that you want to move.
- 2 Drag the selection to a new location. While dragging the mouse pointer changes and transparent meters are shown. You will see a red line between the meters that indicates the insertion point.
- 3 Move the insertion point to the desired location.
- 4 Release the mouse button.

7.3.6 Meter properties

The **Properties...** command in the meter context menu is the common starting point for accessing a variety of meter properties.

The settings and properties are grouped for easy reference and to keep the user interface as clear as possible. The following main groups are available:

- General: global meter settings and meter select
- Value: value related settings including alarm levels
- Styles & Colors: image and font colors
- Auto Setup: define default setup settings

General

The General page in the meters properties dialog gives access to various properties that are relevant to the global look and feel of the array.




Figure 7.7: Meter Properties dialog - General

- A Name of meter array
- B Page select
- C Show/hide channel name
- D Meter array layout
- E Previous meter type
- F Selected meter type
- G Next meter type
- H Meter update rate
- I Meter accuracy
- J Page name

- A Name of meter array** Each meter array can be given a descriptive name. Any name with up to 100 characters is allowed. You can modify it here.
- B Page select** Use the page select scrollbar to scroll through the available pages within a multipage array. The name of the selected page is shown in the page name text box J.
- C Show/hide channel name** The title bar of the individual meters shows the name of the data source / parameter that is displayed. By default also the channel name is shown. Deselect this option to hide the channel name.
- D Meter array layout** You can modify the layout of the meter array to create more space. By default all options are set.

You can:

- Deselect *Show meter title bar* to create more horizontal space.
- Deselect *Show page selector* to create more vertical space.



HINT/TIP

To show/hide the meter array title bar instantly you can click on the show/hide title bar icon, the little arrow on top of the title bar. You can also double-click anywhere in the title bar to toggle the title bar's visibility.

- E-G Select / preview meter type** Use the buttons on the left and right to scroll through the available meter types. The preview gives an example of the selected meter type. This preview is also used to give feedback on certain selections you make in this and other pages of the Properties dialog.
- H Update rate** When connected to a data acquisition system the meters can provide real-time information. Here you can set the update rate. The update rate for the meters can be set from 1 to 10 times per second.
- I Accuracy** Here you can set the display accuracy of meters with a digital section. The number of decimals to show can be set from 0 to 9.
- J Page name** The name of the selected page is shown in the page name text box. Any name with up to 100 characters is allowed. You can modify it here.

Value

Each meter within an array of meters has an individual set of properties with respect to alarm levels, colors and data source. The Value page in the Meter Properties dialog allows you to modify these settings.




Figure 7.8: Meter Properties dialog - Value

- A Page select
- B Meter select
- C Enable alarm levels
- D Font color and level settings
- E Copy settings select
- F Meter preview
- G Additional meter settings
- H Background color settings
- I Data source select
- J Page name

A Page select Use the page select scrollbar to scroll through the available pages within a multipage array. The name of the selected page is shown in the page name text box **J**.

B Meter select Use the meter select scrollbar to scroll through the available meters within a multi-meter array. The source of the selected meter is shown in the data source select input field I.

C Enable levels As standard you can set the font color as well as the background color of the meter readout. In addition you can set colors that are used when certain levels are crossed, for example levels that define an alarm situation.

To enable color change for level crossings:

- Select the Enable levels option

D, H Font color and level settings Here you define the font color and level settings. These are combined with the background settings of the meter readout.

To set level crossing indication:

- Select **Enable levels**. You can now set the high and low level and corresponding colors.
- Set the **High level** value and the corresponding font and background colors that you want to use. When the signal is equal to or becomes larger than the set value, the high level colors will be used for display instead of those specified for the normal level.
- Set the **Low level** value and the corresponding font and background colors that you want to use. When the signal is equal to or becomes smaller than the set value, the low level colors will be used for display instead of those specified for the normal level.

For details on changing colors refer to "Modifying color" on page 62.

Use the Meter preview **F** to verify the effect of the various settings. When you are satisfied with the results you can copy the settings to other meters.

E Copy settings Use this control to copy the settings to other meters.


To copy settings:


- 1 Use the drop down list to make a selection. Typical options include:
 - Selected meter
 - Selected page
 - All pages
- 2 Click **Copy Now**

I Data source select Each meter is connected to a data source. You can modify the selected data source here.

To modify the source of a meter:

To modify the source of meter do one of the following:

- When you know the actual path of the source you can type it directly into the source select text box, or modify the contents.
- Browse for a data source:
 - 1 Click on the **Data Source** button  at the right-hand side of the source select text box.
 - 2 In the Select Data Source dialog that comes up select the new data source.



3 Click **OK** when done.

The Select Data Source dialog provides a list of data sources that is filtered to show only the data sources that are applicable in a specific situation.

G Settings This command gives access to settings that are pertinent to a specific meter.




Figure 7.9: Meter specific settings: LED indicator

Meter specific settings for the LED (on/off) indicator include a level setting and a color select for each level.

Styles & Colors

The Styles & Colors page of the meter properties dialog defines the font and background settings for the labels used in a meter.




Figure 7.10: Meter Properties dialog - Styles & Colors

- A** Font and background color
- B** Font family and style
- C** Overrange indication
- D** Preview

A Font and background color Use the font and background color controls to select a color.

To set the font or background color:

- To set the color of the font or background click on the corresponding color drop down box.
For details on changing colors refer to "Modifying color" on page 62.

B Font family and style You can set the font properties of the font used in the meter labels.

To set the font properties do one of the following:

- Click the font you want to use in the drop-down list. The fonts listed are all TrueType fonts.
- Click the style you want to use in the drop down list.

C Overrange You can use the overrange option to set a color for overrange indication. A signal is in overrange when it is outside the display range.

D Preview Use the Meter preview to verify the effect of the various settings.

Auto Setup

The auto setup feature of meters defines how meters are placed in an empty meter placeholder. This feature is especially useful when you drag multiple data sources into an empty meter placeholder.




Figure 7.11: Meter Properties dialog - Auto Setup

A Number of meters

B Meter type

C Sort select

D Preview

A Number of meters You can set the maximum number of meters per page. When the total number of required meters exceeds this limit, one or more new pages are created.

B Meter type Define the default meter type: click on a meter look in the drop down list.

C Sort select You can set the preferred order in which the meter array is filled.

To set the sort order:

1 Select **Use sorting**.

2 Select one of the Sort by options.

D Preview Shows the currently selected meter type and look.

7.3.7 Meter miscellaneous features and functions

This section describes the various meter possibilities that have not been discussed in one of the previous sections.

Meters and the clipboard

Commands are provided for transferring meters using the Windows® Clipboard. These commands are the standard **Cut Meter(s)**, **Copy Meter(s)** and **Paste Meter(s)** commands as well as the standard shortcut keys for these operations.

To transfer meter(s):

To transfer one or more meters do the following:

1 Select one or more meters.

2 Right-click the meter area to access the context menu.

3 In the context menu do one of the following:

- Click **Copy Meter(s)** to duplicate the meters to the clipboard.
- Click **Cut Meter(s)** to transfer the meters to the clipboard and delete them from the meter array.

4 Navigate to the destination (and set the insertion location, if appropriate). The destination can be another location on the same page, a location on another page or a new - empty - page.

5 Right-click the meter area to access the context menu and click **Paste Meter(s)**.

Page commands

Page commands let you add and delete pages. You can also rename and clear pages and make a copy of the page for use in other programs.

To gain access to the page commands:

- In the meter array context menu point to **Page ▶**
The page submenu comes up.
- In the status bar or title bar context menu this submenu is directly available.

You can add a page to the currently active meter array. By definition the page will be positioned as the last page.

To add a new page:

- Click on **New Page**

You can add a page to the currently active meter array on a specific position.

To insert a new page:

- 1 Go to a specific page.
- 2 In the context menu point to **Insert Page ▶**
- 3 In the submenu that comes up click **Before Selected Page** or **After Selected Page**.

You can quickly delete a page from a meter array, either by using the context menu command or the keyboard shortcut.

To delete a page do one of the following:

- Press the **Alt+Del** or **Alt+Delete** key combination on your keyboard.
- Select **Delete Page** in the page submenu.
- In the confirmation dialog that comes up click **OK**.

You can give a page another name.

To rename a page:

- 1 Do one of the following:
 - Press the **Alt+F2** key combination on your keyboard
 - Select **Rename Page** in the page submenu
- 2 In the Page Name dialog that comes up enter a new name.
- 3 Click **OK** to accept.

You can copy the page as bitmap to the clipboard. Use the Paste (Special) command to place the image into other programs. Use the context menu or the keyboard shortcut to access this command.

To copy a page as picture do one of the following:

- Press the **Ctrl+Alt+C** key combination on your keyboard.
- Select **Copy Page** in the page submenu.

Click **Page Properties...** to access the Meter Properties dialog with the General page selected.

You can make a copy of the visible page of the display on your printer.

To print a meter page:

- 1 Access the context menu and click **Print <meter name>...**
- 2 In the Print dialog that comes up set your preferences and click **Print**.

To clear a meter page:

- 1 Access the context menu and click **Clear Page**.
- 2 In the confirmation dialog that comes up click **OK**.

Using the page control

You use the page control primarily to step through the available pages. In addition the page control allows you to modify a page name directly in the control.

To step through the pages click the **Next Page** button and **Previous Page** button. In addition you can use the following keyboard accelerators:

- **Ctrl+Page Up** to go to the previous page

- **Ctrl+Page Down** to go to the next page
- **Ctrl+1 ... 9** to go directly to the indexed page
- **Ctrl+Home** to go to the first page
- **Ctrl+End** to go to the last page




Figure 7.12: Page control functionality

- A Default view
- B Rename page
- C List view
- D Previous page
- E Next page

In the text field of the page control you can:

- **Click:** A drop down list shows all available pages. The currently active page is marked. Click on a page name in the list to jump directly to that page. Note that numbering used by the default naming continues to increase even if previous pages have been deleted. The number is not an index.
- **Double-click:** When you double-click the text field, the name of the page is highlighted. Now you can modify the name. Press **Enter** to accept or **Escape** to cancel.
- **Right-click:** A context menu will come up. Refer to "Page commands" on page 246 for details.

7.4 Images

You can place and scale images, company logos, etc. on your sheet.

You place an image object as described in "Adding and deleting objects" on page 225. A placeholder for the image is shown.

To actually load an image or modify the properties you must access the Image Properties dialog.

To gain access to the Image Properties dialog:

- Right-click the area of the image object.
- In the context menu click **Properties...**




Figure 7.13: Image Properties dialog

- A Image source
- B Image object name
- C Background color
- D Fitting of image within area
- E Link image

A Image source Currently bit mapped images are supported: gif, jpg and bmp. Transparency is not supported.

To load an image:

- 1 In the Image Properties dialog click **Browse...**
- 2 In the Select picture dialog select the file that you want to use and click **Open**.
- 3 Make the modifications as required in the properties dialog and click **OK** when done.

- B Image object name** You can give the object a different name for easy reference when more images are available.
- C Background** Defines the background color of an image that does not completely fill the sheet area.
- D Fitting** An image object is placed within a sheet (area). You can define how the image will fit in the available space.
Fitting options are:
- **No fitting** The image is placed with the original resolution/size. The upper left-hand corner of the image is placed at the upper left-hand corner of the sheet (area).
 - **Fit image to frame** Resizes the image to complete fill the sheet (area) and allows the content proportions to be changed. The content may appear to be stretched if the content and the area have different proportions.
 - **Center image** Centers content with area. The proportions and size of the image are preserved.
 - **Fit image proportionally** Resizes the image to fit a frame while preserving the content proportions. If the image and the area have different proportions, some empty space will result.




Figure 7.14: Image fitting examples

- 1 No fitting
- 2 Center image
- 3 Fit image to frame
- 4 Fit image proportionally


E Link image To link to the image select this option. Deselect this option if you want to embed the image in the virtual workbench.

7.5 User tables

An additional means of presenting information is the user table. The user table is a user-configurable table that can be used to show any non-waveform data source in a tabular form. Examples of non-waveform data sources are:

- (Intermediate) scalar results
- Texts
- System constants and variables
- User variables

Besides presenting them you can easily put the user table in a Perception report, copy it to the clipboard or post the contents to Microsoft® Word and Microsoft® Excel with a variety of options.



1			
2	Cursor 1 XPos	817,1	s
3	Cursor 1 YValue	1,536k	1/min
4			
5	Cursor 2 XPos	833,0	s
6	Cursor 2 XValue	4,020k	1/min
7			
8	7-3-2012	5:37 pm	
9			
10			

Figure 7.15: Example of a formatted user table

- A** Show/hide title bar
- B** Title bar
- C** Row header
- D** Grid
- E** Cell


- A Show/hide title bar** To show/hide the user table title bar instantly you can click the show/hide title bar icon, the little arrow on top of the title bar. You can also double-click anywhere in the title bar to toggle the title bar's visibility.
- B Title bar** You can set the name displayed in the title bar through the user table's properties.
- C Row header** The header of the row can be in one of three modes: with number, without number or off. This can be set in the user table's properties.

- D **Grid** The work area of the user table
- E **Cell** Shows the actual value, or the placeholder when in edit mode.

User tables can be added to the Active sheet or User sheets.

7.5.1 Creating a user table

You can place a user table as described in "Adding and deleting objects" on page 225. This will add an empty default user table to the sheet.



1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

Figure 7.16: Empty default user table

Another method to add a user table is to drag data sources from the Data Sources Navigator to an empty area on the sheet while pressing (and holding) SHIFT + ALT. By doing this a user table is created using the predefined rows and columns (as defined in the user table's properties) and is filled with the selected data sources.

7.5.2 Inserting data into the user table


You can enter data into a cell of the table as follows:

- Type directly into the cell.
- Drag and drop data from the **Data Sources Navigator**.
- Use the shortcut menu of the user table to access the **Insert Data Source** dialog.

Typing into a cell

You can enter random text as well as data source placeholder(s) directly into a cell. To do so, proceed as follows:

- 1 Click the cell you want to use.
A small pencil in the row header indicates that you are now in edit mode:



- 2 Type your text or placeholder. For example, the placeholder “{System.UTCtime!Value,#.###k}” will display the UTC time when not in edit mode.
- 3 Press **Tab**, **Enter** or activate another cell with the mouse when done.


Note *This will delete the text that was already in the cell.*

Using the Data Sources Navigator

You can easily drag and drop one or more data sources directly from the **Data Sources Navigator** into a cell or row header.

To add a single data source from the **Data Sources Navigator**:

- 1 In the **Data Sources Navigator** select the item you want to insert.
- 2 Drag the item to the cell you want to use and release the mouse. The following dialog will come up:



- 3 Select which properties of the selected data source you want to use. If you select multiple properties, you can also define how these properties will be distributed. The possible ways of distribution are explained further on in this chapter.
- 4 Make your selections and click **Insert** when done or **Cancel** to cancel the operation.

Inserting multiple data sources


You can also insert multiple data sources into the user table in one drag and drop action. To do so:

- 1 In the **Data Sources Navigator** select the items you want to insert.
- 2 Drag the items to the cell that represents the upper left-hand corner of the range of cells you want to use and release the mouse.
- 3 From here follow the procedure for a single data source.

Properties and cell distribution

Each data source has three attributes: name, value and units. Depending on the data source not every attribute contains meaningful data. When using multiple attributes in drag and drop mode, these can be distributed in the table in various ways.

As an example have a look at the X-position of a cursor. Assume you want to drop this item on the cell of the second row and the second column.



1					
▶ 2					
3					

Figure 7.17: User table – Properties and cell distribution (Detail) 1

Select all three properties (attributes) and the option **Each property in a single cell, start in left-most column**. The result will be:



1					
▶ 2	Cursor 1XPos	1.116	s		
3					

Figure 7.18: User table – Properties and cell distribution (Detail) 2

If you select the option **Each property in a single cell, start at current column**, the result will be:

1				
▶ 2		Cursor 1 XPos	1.116	s
3				

Figure 7.19: User table – Properties and cell distribution (Detail) 3

If you select the option **Selected properties in one cell, in current column**, the result will be:

1				
▶ 2		Cursor 1 XPos 1.116 s		
3				

Figure 7.20: User table – Properties and cell distribution (Detail) 4


Dropping an item on a row header

In addition to dropping on a single cell, it is also possible to drop on a row header. In this case the distribution is automatic. The name attribute of the data source is inserted in the first column, the value attribute in the second column and the unit attribute in the third column. If the table has more than three columns, they will not be filled. If the table has two columns, only the name and value attributes will be inserted. If there is only one column, only the value attribute will be inserted.

If multiple items are dropped on a row header, this row will be used as top, and all other items will be inserted in the rows below.

Overwriting existing data using drag and drop

If you drag and drop a data source onto a cell that is not empty, the following dialog will come up:




Make your selection and click **Insert** when done or **Cancel** to cancel the drag and drop operation.

Using the Insert Data Source dialog

The third method to insert a data source in a cell is using the shortcut menu. This will also give you direct access to various (string) formatting options. To do so proceed as follows:

- 1 Right-click the cell you want to use. The shortcut menu will come up:



- 2 In the shortcut menu click **Insert Data Source**. The **Insert Data Source** dialog will come up.
- 3 Choose and set up the data source you want to insert and click **OK** when done or **Cancel** to cancel the insert operation. For a full description of the **Insert Data Source** dialog refer to "Insert and format a data source" on page 64.

7.5.3 Editing data in the user table

If the inserted data needs to be adjusted or the data source's attributes need to be changed, this can be done in different ways:

- Type directly into the cell.
- Use the **Data Source Properties** dialog.

Typing into a cell


You can edit the text in a cell in two ways:

- 1 Type directly into the cell.
This will delete the text that was already in the cell.
- 2 Activate the cell and click in the cell to go to **edit mode**. Edit your text or placeholder.
A small pencil in the row header indicates that you are now in edit mode.

Using the Data Source Properties dialog

Calling the **Data Source Properties** dialog to edit a data source that is already in a cell can be done by using the shortcut menu. To do so:

- 1 Right-click in the cell or go to **edit mode** and right-click the data source placeholder that needs editing.
- 2 Choose **Data Source Properties**.



- 3 Make the necessary changes and click **OK** to accept the changes or **Cancel** to discard them.

Modifying the layout of the user table


The user table is initially made up of three columns and ten rows. Rows and columns can easily be added, removed or cleared using the shortcut menu.

Adding rows

To add a row proceed as follows:

- 1 Select a cell in the row where the new row should be inserted above or below.
Selecting multiple cells in different rows is allowed.

- 2 Right-click the cell to call up the shortcut menu.
- 3 In the shortcut menu that comes up:




Choose **Add – Row Above** if you want to add a row above the selected cell(s).

Choose **Add – Row Below** to add a row below the selected cell(s).

Adding columns

To add a column proceed as follows:

- 1 Select a cell in the column where the new column should be inserted to the left or right.
Selecting multiple cells in different columns is allowed.
- 2 Right-click the cell to call up the shortcut menu.
- 3 In the shortcut menu that comes up:



Choose **Add – Columns to the Left** to add a column left of the selected cell(s).


Choose **Add – Columns to the Right** to add a column right of the selected cell(s).

Deleting rows

Deleting a row means removing (not emptying) the row which contains selected cell. To delete a row proceed as follows:

- 1 Select the cell(s) in the row(s) which should be deleted.
- 2 Right-click one of the selected cells to call up the shortcut menu.

- 3 In the shortcut menu that comes up:




Choose **Delete – Row(s)** to delete the row(s) containing the selected cell(s).

Deleting columns

Deleting a column removes the column which contains the selected cell. To delete a column proceed as follows:

- 1 Select the cell(s) in the columns(s) which should be deleted.
- 2 Right-click one of the selected cells to call up the shortcut menu.
- 3 In the shortcut menu that comes up:




Choose **Delete – Row(s)** to delete the row(s) containing the selected cell(s).

Deleting the table

Use the shortcut menu if you want to delete the entire table:

- 1 Right-click somewhere on the user table object to call up the shortcut menu.
- 2 In the shortcut menu that comes up:




Choose **Delete – Table** to delete the table.

- 3 In the confirmation dialog click **Yes** to delete the user table or **No** to abort the action.

Clearing cells

Clearing a cell means the text inside the cell is removed, not the cell itself. To clear a cell proceed as follows:

- 1 Select the cells that need to be cleared.
- 2 Right-click a selected cell to call up the shortcut menu.
- 3 In the shortcut-menu that comes up:



Choose **Clear – Cell(s)** to clear the selected cells.

Choose **Clear – Row(s)** to clear the entire rows which contain the selected cells.


Choose **Clear – Column(s)** to clear the entire columns which contain the selected cells.

Choose **Clear – Table** to clear all cells in the table.

Cell alignment

The text in a cell is left-aligned by default. This can be changed for every cell.


- 1 Select the cells that need cell alignment.
Selecting multiple cells is allowed.
- 2 Right-click one of the selected cells to call up the shortcut menu.
- 3 In the shortcut menu click the desired alignment.



Font and font style

Every cell can have its own font and font style. The size of the row is adjusted to fit the largest font in a row. To adjust the font or font style proceed as follows:

- 1 Select the cells the font and/or font style of which needs to be changed.
- 2 Right-click one of the selected cells to call up the shortcut menu.




- 3 If you only want to change the style, choose the needed style. If the font itself needs to be changed, click **Choose Font...**
- 4 The windows font dialog is shown. Set up the font as desired. Click **OK** to accept the new font or **Cancel** to discard.

7.5.4 User table properties

In the properties of the user table it is possible to change:

- The name of the user table object
- The number of rows and columns
- The way the row header is set up
- If the user table is locked

To access these properties, right-click somewhere on the user table object and click **Table Properties**.



Now the **Properties of User Table** dialog is shown. On this dialog you can make the desired changes. Click **OK** to accept or **Cancel** to discard the changes.





Figure 7.21: Properties of User Table

The new settings can be set as default for all user tables added after the change. To do this, check the **Set as default for new user tables** option.

With the **Lock table** option it is possible to protect the table from undesirable key strokes, drag and drop operations or deletions. If the table is locked, this is graphically visualized by a lock  in the title bar. This lock can only be turned off in the properties.

7.5.5 User table toolbar

The user table has a toolbar. On this toolbar most of the previously mentioned operations can be done. But this toolbar holds some extra features:

- Posting to Excel
- Posting to Word

Posting to Excel

Just like the cursor table the user can post the user table to Excel (2003 or higher) with one click of a button. This can be done in three different ways:

- 1 Post to Excel: This will place the complete table into Excel on a sheet called " Perception - <user table name>" starting at cell A1. If Excel is not active it will be launched. If the sheet already exists, the data will be overwritten.
- 2 Append to Excel: The data will be appended to the data that is already in the sheet called " Perception - < user table name>". The data is then appended on the first empty cell in column A. If Excel is not active it will be launched, and the sheet will be created.

- 3 Copy to Current Cell: The data will be placed in the currently active sheet with the upper left-hand cell of the cursor table in the currently active cell of the sheet. If Excel is not active it will be launched, but no sheet will be created.




Figure 7.22: Post to Excel

Posting to Word

In addition to the posting to Excel it is also possible to post the user table to Word.

When selecting **Post to Word** a check is done if Word is already open and a document is present. If this is not the case, Word will be started and a document will be created.

At the position of the cursor a new (Word) table will be created were the values of the user table are copied to. If this location is inside an existing table, the new table will be created in there. Schematically this looks as shown below (see Figure 7.23).




Figure 7.23: Post to Word

7.6 XY-display

An XY-display is a display that shows data from one or more channels as a function of data from another channel, as opposed to a function of time (time domain display).

A well-known result is a so-called Lissajous curve (see Figure 7.24), in which signals with different frequencies and phase shifts are plotted against each other:




Figure 7.24: Lissajous curves

	Frequency proportion	Phase shift
A	1:1	$\Delta\varphi = 0$
B	1:1	$\Delta\varphi = \frac{1}{2}\pi$
C	1:1	$\Delta\varphi = \frac{1}{4}\pi$
D	2:1	$\Delta\varphi = 0$
E	3:2	$\Delta\varphi = 0$
F	4:3	$\Delta\varphi = 0$

One or more XY-displays can be positioned on the active sheet and on the user sheets. Each XY-display can have multiple pages. Each page of the display can then have any number of traces.

7.6.1 XY-display concepts and components

Concept

By default, an XY-display is linked to a specific time-domain display. The XY-display will apply all layout information from that time-domain display. The active trace in the time-domain display from the time that the link was created will become the X-source used in the XY-display. It will also “follow” the settings of the time-domain display; modifications made in the time-domain will automatically be reflected in the XY-display. You can also link to any other time-domain display. When you link to another time-domain display, all settings from the new time-domain display will be used.

Pages

A page is a part of a display, just like a page is part of a book. Each display has at least one page, but a display can also have multiple pages. Multiple pages are used to display a large number of traces with the same X-axis parameters.

Only one page per display can be shown at a time. The other pages are positioned virtually “behind each other”. You can switch to other pages easily by using the page control. One or more traces can be displayed within a page.

Traces

A trace is the fundamental graphical representation of data from a channel as a function of data from the X-source channel.

Views

In addition to the standard arrangement options, a display page can be divided furthermore be divided into views. A view is a display-in-a-display and is used to represent the same data in a different way, for example as a zoomed part of the original trace(s).




Figure 7.25: XY-display components - part 1

- A XY-display title bar
- B Trace area
- C Y-annotation area
- D X-annotation area
- E Control area

A maximum of four views can be shown within a display page. Depending on the settings, these are:

- Main review view
- Zoom: a detail of the review view.
- Alternate zoom: another detail of the review view.
- Live: live streaming data




Figure 7.26: XY-display components - part 2

- A** X-Y Review
- B** X-Y Live
- C** X-Y Zoom
- D** X-Y Alt Zoom

Each view is shown as an individual display. However, due to the nature of views, they are “connected” to each other.

The XY-display view area in detail

The display view area provides a wealth of functions and information.




Figure 7.27: XY-display components - part 3

- 1** Y-annotation area
- 2** Trace area = the rest
- 3** X-annotation area
- 4** Control area
- A** View type
- B** XY-display title bar (contains the name of the XY-display)
- C** Cursor values
- D** Trace name (active trace)
- E** Y-range scale
- F** Page selector
- G** Frame cursor control
- H** Time frame
- I** X-range scale

- J** Active horizontal cursor on the X-source
- K** Passive horizontal cursor on the X-source
- L** Passive vertical cursor on the Y-sources
- M** Active vertical cursor on the Y-sources
- N** Link to display

A View type You can see and select the type of view here. The following basic types are available:

- Review
- Zoom
- Alternate zoom
- Live

Depending on the basic type selected, various options are available. The view type indicator is highlighted when the view is selected. When selected, it is the “active view”.

B Trace name When highlighted, it denotes the “active” trace.

C Cursor values Here you can see the cursor values as:

- Active cursor value
- Both cursor values
- Difference between the two cursor values

The selection follows the ‘linked’ time display.

D Display title bar

E Y-range scale Shows the Y-annotation scale. You can select how the Y-range should be scaled.

F Page selection control Please refer to the Time Display description for detailed information.

G Frame cursor control You can use this control to move the frame cursor over the time-domain signal. The XY-data of the part covered by the frame cursor will be used to draw the traces.

H Time frame The time frame of the data used to create the XY-display.

I X-range scale Shows the X-annotation scale. You can select how the X-range should be scaled.

J Active horizontal cursor on the X-source This is the active cursor, color-coded red. The cursor will follow the value of the X-source at the time of the active horizontal time display cursor.

K Passive horizontal cursor on the X-source This is the in-active cursor, color-coded blue. The cursor will follow the value of the X-source at the time of the passive vertical time display cursor.

L Passive vertical cursor on the Y-sources This is the in-active cursor, color-coded blue. The cursor will follow the value of the in-active Y-trace at the time of the passive vertical time display cursor.

- M Active vertical cursor on the Y-sources** This is the active cursor, color-coded red. The cursor will follow the value of the active Y-trace at the time of the active vertical time display cursor.
- N Link to display** This will be shown if an XY-display is linked to a time display. The name of time display is shown.

The Y-annotation area

The Y-annotation area is on the left-hand side of the display. It is divided into two sections. The first section is the annotation area. This shows the traces currently available within the page. The second section shows the upper and lower values of the active Y-trace. If the Y-annotation area allows it, all other Y-traces values will be shown. If there is room to display additional values, these will be shown.





Figure 7.28: Y-annotation area

- 1 Annotation area** Names and cursor information
- 2 Scaling information** Here you can see the cursor values as:
 - A Cursor values**
 - Active cursor value
 - Both cursor values
 - Difference between the two cursor values

The selection follows the “linked” time display.
 - B Trace name** The active trace is shown highlighted in the list.
 - C Y-scaling** The values of the Y-grid can be seen here.

The X-annotation area

The X-annotation area is on the bottom of the display. It is divided into two sections. The first section is the annotation area. This shows the current X-source trace within the page. The second section shows the upper and lower values of the X-source. If the X-annotation area allow intermediate values, these will be shown.



1 Annotation area Names and cursor information

2 Scaling information

A X-source name The trace that is used as the X-source.

B Cursor values Here you can see the cursor values as:

- Active cursor value
- Both cursor values
- Difference between the two cursor values

The selection follows the “linked” time display.

C X-Scaling The values of the X grid can be seen here.

Control area

The control area is the part of the XY-display that contains the various controls.



Figure 7.29: Control area

A Page selection control Please refer to the Time Display description for detailed information.

B Frame cursor control You can use this control to move the frame cursor over the time-domain signal. The XY-data of the part covered by the frame cursor will be used to draw the traces.

C Time frame The time frame of the data used to create the XY-display.

Frame cursor control

The frame cursor control enables the automatic movement of the frame cursor for XY calculations. The frame cursor is the time area section displaying the data which is used for calculation.




Figure 7.30: Frame cursor control (detail)

- A** Move frame cursor to the beginning of the time-domain signal.
- B** Automatically move the frame cursor in steps towards the beginning of the recording.
- C** Move the frame cursor one step towards the beginning of the recording.
- D** Stop the automatic frame cursor movement.
- E** Move the frame cursor one step towards the end of the recording.
- F** Automatically move the frame cursor in steps towards the end of the recording.
- G** Move frame cursor to the end of the time-domain signal.

7.6.2 XY-display operations

General

This section describes how to use the various display tools.

Linked display

Within Perception, an XY-display is typically linked to a time-domain display. Pages, colors and traces are all copied from the linked time-domain display. When something changes in this area, the change is copied over to the XY-display. Therefore, when you add a trace to a time-domain display, this trace is also added to the XY-display.




Figure 7.31: Time-domain display

A Name of the time-domain display.

B Link indicator in the XY-display showing that it is linked to the time-domain display "My Display".

When an XY-display is linked to a time-domain display, the link indicator in the XY-display shows which time-domain display it is linked to. When there is no link, this icon is not shown at all.

For more information, please refer to chapter "XY-display shortcut menu" on page 290.

Note *When you restore the link between a time-display and XY-display, the layout of the XY-display will be updated to match the linked display. This will also happen if you change the link from one display to another one. The active trace in the time-domain display from the time that the link was created will become the X-source used in the XY-display.*

Add or remove traces to or from an XY-display

You cannot add or remove traces directly to an XY-display. You need to have a link between the XY-display and the time-domain display, and to configure the time-domain display. Traces that are added to the time-domain display are also added to the XY-display. Traces that are removed from the time-domain display are also removed from the XY-display.

Modifying the display layout

The X-source can be changed within the XY-display. This can be done using the “XY-display properties” dialog (refer to Figure 7.40) or using drag and drop.

To modify the display layout using drag & drop:

- 1** Click on the trace in the Y-annotation area which you want to have as X-source
- 2** Drag the trace to the X-annotation area.

- 3 The drop area will be highlighted. The hand cursor changes into a hand-drop cursor and the Y-trace can be dropped here by releasing the mouse button.




Figure 7.32: XY-display with highlighted drop area (detail)

- A Hand-drop cursor
- B Highlighted drop area

Colors and other layout behaviour are copied from the linked time-domain display.

Zooming and panning in the XY-display

A powerful feature of the display is the ability to zoom in on a segment of interest in the graph. The XY-display supports squared zooming and full free-style zooming in two areas of the XY-data. The second zoom area is called the alternate zoom. All zoom functions on the alternate zoom are performed exactly the same as on a normal zoom, but with the Alt-key pressed down.




Figure 7.33: Zoom areas

- A X-Y Review
- B X-Y Zoom
- C X-Y Alt Zoom

To zoom in:

Click and drag the mouse. A bounding box with a semi-transparent fill will appear, indicating the zoom area. When you release the mouse, a zoom view will be created and filled with the zoomed portion of the original view. The zoom area is shown as a raised semitransparent bounding box in the review view. The alternate zoom area is shown as a sunken semitransparent bounding box in the review view.


To resize a zoom area:

You can resize a zoom area by dragging a side or a corner of the bounding box to another location as follows:

- With the mouse hovering over a border or corner. When an arrow cursor appears, click and drag in the required direction.

To move the zoom area:

You can move the zoom area by dragging it to another location as follows:

- With the mouse hovering over the zoom area. When the four-way cursor  shape appears, click and drag the zoom area to another location.

To unzoom:

- Right-click the view. Click the Unzoom command in the context menu that comes up. The zoom area will disappear.

Replay data

Analyzed data can be replayed within a Review view of the XY-display.

The replay functionality is controlled by the **frame cursor replay control** that is located in the control bar of the display. For more information about replay data, please refer to Figure 7.30 "Frame cursor control (detail)" on page 274.

Interaction between the XY-display and the time display


When linked to a display, the entire layout of the time-domain display is copied to the XY-display.

Frame cursor

A frame cursor will now be shown in the time-domain display. This frame cursor indicates which area of the waveform is included in the XY frame.

The frame cursor will dynamically show you the new area of the XY-display when using the replay buttons. You can also use the frame cursor to look at the XY-characteristics of a position you are interested in. The frame cursor is displayed as a semitransparent orange area with two solid orange lines annotating the start and end times of the frame.

You can move the frame cursor in the time-domain display manually. To do so:

- 1 Hover the mouse over a vertical edge of the frame until you see the bi-directional arrow shaped cursor .
- 2 Click and drag the frame to the desired position.
- 3 Release the mouse button.






Figure 7.34: Time-domain display with frame cursor

- A1** This is the start time of the frame currently shown in the XY-display. The numerical value of this time is annotated at **C**.
- A2** This is the end time of the frame currently shown in the XY-display. The numerical value of this time is annotated at **D**.
- B** The area that is being shown in the XY-display is shown in a transparent red area.
- C** This is the start time of the frame currently shown in the XY-display.
- D** This is the end time of the frame currently shown in the XY-display.

You can change the size of the frame cursor in the time-domain display manually. To do so:

- 1 Hover the mouse over a vertical edge of the frame while pressing down the ALT key until you see the bi-directional arrow-shaped cursor icon with two vertical lines between them .
- 2 Click and drag the frame boundary to the desired position.
- 3 Release the mouse button.



A Bi-directional arrow shaped cursor

Linking

XY-displays may be added to the active sheet and all user sheets. If an XY-display is added to a sheet that already contains a time-domain display, the XY-display will automatically be linked to that display. The active trace in the time-domain display from the time that the link was created will become the X-source used in the XY-display.

If more than one time-domain display exists on the sheet, the active time-domain display will be automatically linked to the new XY-display.

To change the linked time-domain display, do one of the following:

- Right-click in a view of the XY-display. On the shortcut menu that comes up, point to **Link With**. In the submenu that comes up, select the display you want to link to.
- If the XY-display is active, go to the dynamic menu. On the dynamic menu, point to **Link With**. In the submenu that comes up, select the display you want to link to.
- If the XY-display is not active, go to the dynamic menu. On the dynamic menu, point to **XY-display** and then point to **Link With**. In the submenu that comes up, select the display you want to link to.

If no display existed at the moment you added the XY-display, there will be no link. The XY-display will not be automatically linked to a time-domain display if the time-domain display is added last. In these cases, you can setup the link manually.

To link a time-domain display to an XY-display, do one of the following:

- Right-click in a view of the XY-display. On the shortcut menu that comes up, point to **Link With**. In the submenu that comes up, select the display you want to link to.
- If the XY-display is active, go to the dynamic menu. On the dynamic menu, point to **Link With**. In the submenu that comes up, select the display you want to link to.
- If the XY-display is not active, go to the dynamic menu. On the dynamic menu, point to **XY-display** and then point to **Link With**. In the submenu that comes up, select the display you want to link to.

7.6.3 Cursors and basic measurements

The XY-display shows the vertical cursors of the linked time-domain display. They are only shown if they are in the requested frame.

The cursors are shown for the active y-trace and the x-source. The values in the time axis of the vertical cursors are retrieved for the corresponding trace. These are the points where the cursors are displayed in the XY-display.



You can use the toolbar, the dynamic sheet menu or the XY-display shortcut to show/hide the cursors.



Figure 7.35: Dynamic menu with XY-display

- A Grid Show/Hide**
- B Cursor table Show/Hide**
- C Cursors Show/Hide**
- D Zero Lines Show/Hide**
- E Set View to Y-t Display Period** Sets the frame cursor size to correspond to the times of the view in the linked display.

To show or hide cursors:

- Click on the corresponding visibility button in the toolbar.
- Using the dynamic sheet menu when the XY-display is active:
 - Click on the **Show cursors** icon .
- Using the dynamic sheet menu when the XY-display is not active:
 - 1 Point to the desired XY-display
 - 2 Click on the **Show cursors** icon .
- Using the context menu:
 - 1 Right-click in the XY-display area.
 - 2 In the context menu that comes up, click on the required cursor type.

Cursor measurements


The values of the vertical cursors can be displayed in the information window and in the Y-annotation area.

In addition, a window containing all cursor values, including the horizontal ones, can be displayed. The Cursor Table shows the cursor values of the active XY-display.

This window also provides functionality to copy values to the clipboard and to post values to Excel.

To show or hide the Cursor Table, make sure an XY-display is active and do one of the following:

- When available in the **toolbar**, you can click the **Cursor Table** button.
- With the XY-display selected: press the **space bar**.
- Using the **dynamic sheet menu** when the XY-display is selected, click on the **Cursor Table** command.
- Using the context menu:
 - 1 Right click the XY-display area.
 - 2 In the context menu that comes up click the Cursor Table command.
- In addition, you can close the Cursor Table as follows:
 - Click the **Close** button in the title bar of the window.
 - Click the **Close** command in the **Settings** menu of the window.



Name	Left	Right	Delta	Units
Ch B1	935.214 m	647.333 m	287.881 m	V
Ch A4	-1.77968	-2.29533	515.654 m	V
Ch A2	-1.77968	-2.29533	515.654 m	V
Ch B2	-1.77968	-2.29533	515.654 m	V
Time	356.121 m	940.000 m	583.879 m	s

Figure 7.36: Cursor Table of XY-display

- A Menu bar
- B Toolbar
- C Vertical cursors

- A Menu bar** The menu bar has one menu: Settings. The settings menu provides access to all additional features of the Cursor Table.




Figure 7.37: Cursor Table Settings menu

- **Active Trace Values** Show only the values of the vertical cursors and the active trace. Information on the horizontal cursors will also be shown, when available.
- **All Traces Values** Show the values of the vertical cursors and all traces. Information on the horizontal cursors will also be shown, when available.
Values are displayed in technical units.
- **Engineering Format** Select this option when you want the values to be displayed in engineering format. This format is a scientific notation in which the power of ten is a multiple of three.
- **Scientific Format** Select this option when you want the values to be displayed in scientific format. This format is a shorthand way of writing very large or very small numbers. A number expressed in scientific notation is expressed as a decimal number between 1 and 10 multiplied by a power of 10.
- **X-Axis Format** Select this command to set the format used to display X-axis labels.
By default, the labels are displayed as short of a format as possible; only the available information is displayed without leading zeros. In the format dialog, you can set the number of **decimal places** used behind the integral part of the label.
- **Static Cursor Table** Select this option when you want to use the fixed numbers of the horizontal and vertical cursors as references instead of the relative “left/right” and “top/bottom” naming. Use this option if you want the values in the columns related to a cursor to remain in the same column. For example, when you move one cursor to the other side of the other cursor, the indication remains in the same column;

values from one cursor are always in the same column, regardless of the position of the cursor.

Figure 7.38: Static and non-static cursor table

- **Copy to Clipboard** You can copy values to the clipboard and paste these values in another application. You can choose to copy only the values of the horizontal, vertical or slope cursors. The copy includes the column headers.
- **Copy to Excel** You can copy the values directly to Microsoft® Excel with the following options:
 - **Post To** This will place the complete table into Excel on a sheet called “ Perception - display name”. When Excel is not active, it will be launched. When the sheet already exists, data will be overwritten.
 - **Append To** The data will be appended to the data that is already in the sheet called “ Perception - display name”.
 - **Copy to Current Cell** Data will be placed in the sheet currently active. The cell in the upper left-hand corner of the cursor table will be placed in the cell that is currently active in the sheet.
- **Close** Close the cursor table.

B Toolbar The toolbar provides quick access to the most commonly used commands.

C Vertical cursors The vertical cursors area has rows for each trace and a bottom row to display the time information. The columns provide the following information:

- **Name** The name of the trace.
- **Left / Cursor 1** The Y-value of a trace at the named cursor position. The cursor position in time is shown in the Time row. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
- **Right / Cursor 2** The Y-value of a trace at the named cursor position. The cursor position in time is shown in the Time row. A red and blue indicator is used to denote the active (red) and passive (blue) cursor.
- **Delta** The difference between the cursor values.
- **Units** The technical units of each trace.

For more information about controlling the cursors of the linked time display, please refer to "Cursors and basic measurements" on page 163.

7.6.4 XY-display properties

You have access to change the linked display, X-source, frame size setup and the grid and scalings setting in the XY-display.

You can also set the name of the display in this dialog.

To gain access to the XY-display properties, do one of the following:

- When the XY-display is the active component on a sheet, select **Properties** on the dynamic sheet menu.




Figure 7.39: XY-display properties

A XY-display properties

- When the XY-display is not the active component on a sheet, point to **XY-display** on the dynamic sheet menu and select **Properties** in the submenu.
- Right-click anywhere in the XY-display area and select **Properties** in the shortcut menu that comes up.

XY-display settings




Figure 7.40: XY-display properties dialog

- A Display name
- B Link to Y-time-domain display
- C Source for X-axis
- D Frame
- E Always squared display
- F Grid

- A Display name** Edit the name in the text box.
- B Link to Y-time-domain display** Select the desired **Link to Y-time-domain display** from the drop down list.




Figure 7.41: Link to Y-time-domain display

- 1 Highlighted link to domain display

- C Source for X-axis** Select the desired **Source for X-axis** from the drop down list.




Figure 7.42: Source for X-axis

- 1 Highlighted Source for X-axis

- D Frame** Select the desired **Frame length** settings **Samples** or **Seconds**.




Figure 7.43: Frame length

- 1 Highlighted setting for Frame length

- Edit the value in the **Frame length** field.
- Edit the percentage value in the **Overlap** field or click on the up/down arrows.

- E Always squared display** Click the check box to get a squared XY-display. This is useful to identify patterns more easily.

- F Grid** Edit the X/Y divisions field(s) of the **Grid** or click on the up/down arrows.



Figure 7.44: Figure 7.13: Grid X/Y divisions

7.6.5 XY-display shortcut menu

When you right-click in the XY-display, a shortcut menu comes up. This section explains each shortcut in this menu.




Figure 7.45: XY-display shortcut menu

- **Zoom Back** Returns to the previous zoom.
- **Unzoom** Use this option to remove a zoom or Alt-zoom, if present.
- **Link With**
- **Split** Change the display layout
- **Show Grid** Show/Hide the grid
- **Show Cursor Table** Shows the cursor table
- **Set Cursor at Position**
 - 1 Select the desired point with the mouse in the XY-display.
 - 2 Press CTRL and click with the mouse. The cursor is now positioned at the desired point.

OR

 - 1 Select the desired point with the mouse in the XY-display.
 - 2 Right-click and select **Set Cursor at position** option. The cursor is now positioned at the desired point.
- **Show Cursors** Shows/Hides cursors
- **Show Zero Lines** Shows/Hides Zero lines
- **Set View to Y-t Display Period** Sets the frame cursor size to correspond to the times in the linked XY-display.
- **Delete** Deletes the selected XY-display from the sheet.
- **Properties** Shows the XY-display properties.

Link With submenu

This submenu lists the names of the time-domain displays available within Perception.




Figure 7.46: Link With submenu (detail)

Split submenu

Please refer to the “Display Operations” section “Zooming and panning in the XY-display” on page 277 for more information.

7.6.6 Dynamic menu

Perception supports a dynamic menu, which is located on the menu bar. The name of the menu is the same as the sheet that is currently active in Perception.




Figure 7.47: Perception menu bar

A Active menu

The dynamic menu contains commands that depend on the component that is currently active on the sheet.

When a XY-display is the active component, the following menu will appear.



- A** Operations on the layout of the sheet. For more information, please refer to the chapter "Working with sheets" on page 72.
- B** Operations on other components that are not currently active on the sheet. For more information, please refer to the corresponding component.
- C** Operations on the sheet within Perception workbooks. For more information, please refer to the chapter "Workbook" on page 347.
- D** Operations on the component that is currently active on the sheet, in this case the XY-display. For more information on the different menu items, please refer to the shortcut menu items described in the chapter "XY-display shortcut menu" on page 290.

7.6.7 Dynamic toolbar

When one of the components on a sheet becomes active, it will show extra items on the toolbar that depend on the component. For an XY-display, the toolbar items from the following figure are added:

Figure 7.35 "Dynamic menu with XY-display" on page 282.

8 More Sheets

8.1 Introduction

Apart from the sheets discussed so far there are more sheets that are always available: Information, Settings, Diagnostics Viewer and Fiber Status. Depending on the options installed or the hardware connected these sheets can provide more or less functionality.

8.2 Information sheet

By default a standard two-line information sheet is available. This can be expanded by the Information option into a free to configure information tool. Refer to the separately supplied documentation for details.

The Information sheet enables you to add additional information to be stored permanently within a recording file as soon as an acquisition is done.




Figure 8.1: Information sheet - minimum configuration



8.2.1 Default information

By default the User name and Company are filled in. These cannot be changed.

8.2.2 Comment



The Comment field is editable. It can comprise literal text as well as variables.

To enter text in the comment field:

- 1 Enter the edit mode:
 - In the **Information** menu click **Edit Comment**.
 - When available in the **toolbar** click the **Edit Comment** button 
- 2 Type your text.
- 3 Exit the edit mode:
 - In the **Information** menu click **Edit Comment**.
 - When available in the **toolbar** click the **Edit Comment** button 

Within the comment field you can also add placeholders for variables that are updated automatically.

To enter variables in the comment field:

- 1 Enter the edit mode:
 - In the **Information** menu click **Edit Comment**.
 - When available in the **toolbar** click the **Edit Comment** button 
- 2 Position the cursor on the insertion point for the variable. Do one of the following:
 - In the **Information** menu click **Add Data Source...**
 - When available in the **toolbar** click the **Add Data Source...** button 
- 3 In the Select Data Source dialog that comes up select the data source.





Figure 8.2: Select Data Source dialog

- 4 The Select Data Source dialog provides a list of data sources that is filtered to show only the data sources that are applicable in a specific situation. Click **OK** when done.
- 5 Exit the edit mode:
 - In the **Information** menu click **Edit Comment**.
 - When available in the **toolbar** click the **Edit Comment** button 

8.2.3 Additional commands

The available commands are listed in the Information menu. Commonly used commands are available also through the toolbar when visible.

In the menu there are also possibilities to save the information in a separate file. In general the information settings:

- comprise all settings, fields and field values as set in the information sheet,
- can be stored in a separate file with the file extension **.plnfo**,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.




Figure 8.3: Information menu


- A** Information menu when not in edit mode
- B** Information menu when in edit mode

Load Information

You can load information from a variety of sources. Note that you can also load information from files that provide more than the default values. All information will be displayed. However, you cannot modify this additional information, unless you have the Information option installed.

To load information:

To load information from an external source proceed as follows:

- 1 Do one of the following:
 - In the **Information** menu click **Load Information...**
 - When available in the **toolbar** click the **Load Information...** icon 


- 2 In the Load Information dialog that comes up select your file type if required:
 - Information file .plnfo
 - Virtual Workbench .pvwb
 - Experiment .pnrf
- 3 Select the file you want to load.
- 4 Click **Open**.

Save Information

Much in the same way as you can load information you can also save information. You can also save into an existing virtual workbench or experiment. By doing so you will replace the Information within that file. No other data will be altered.

To save information:


To save information into an external source proceed as follows:

- 1 Do one of the following:
 - In the **Information** menu click **Save Information As...**
 - When available in the **toolbar** click the **Save Information As...** icon 
- 2 In the Save Information As dialog that comes up select your file type if required:
 - Information file .plnfo
 - Virtual Workbench .pvwb
 - Experiment .pnrf
- 3 Select the file you want to save into/replace or type a name for a new file.
- 4 Click **Save**.

Refresh comment

When you have placeholders in your comment, you can refresh the actual values.

To refresh the information:

- Do one of the following:
 - In the **Information** menu click **Refresh Comment**.
 - When available in the **toolbar** click the **Refresh Comment** icon 

Print Information

You can make a copy on the printer of the information.

To print a copy of the information:

- 1 Do one of the following:
 - In the **Information** menu click **Print Information...**
 - When available in the **toolbar** click the **Print Information...** icon 
- 2 In the Print dialog that comes up enter your preferences.
- 3 Click **Print**.

8.3 Settings sheet

The settings sheet provides a spreadsheet-style user interface combined with graphical user interface elements to access all hardware related settings. When a hardware setting cannot be found here it does not exist. All the individual settings and their meaning are explained in full detail in appendix "Settings Sheet Reference" on page 534.

8.3.1 Settings sheet layout

The layout of the settings sheet is designed to provide an efficient interface that allows for quick modification of hardware settings of the connected acquisition systems. Features are implemented to modify settings of large systems equally simple as for smaller systems.

The screenshot shows the 'Settings' window for 'Recorder A'. On the left is a sidebar with categories: General (A), Input (B), Real Time Calculations (C), Memory & Timebase (D), Trigger (E), Alarm (F), and Sensors (G). The main area features a 'Simplified block diagram' showing the signal path: Input (AC, DC, GND) → Amplifier (Gain 20 V, Offset 0 V) → Filter (1.25 kHz) → ADC (16 bit) → Storage. Below the diagram is a table of channel settings.

Input	Signal coupling	Input coupling	Span	Offset	Technical units multiplier	Technical units offset
Group 1	DC	SE Positive	20 V	0 V	1 V/V	0 V
Recorder A	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch A1: Ch A1	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch A2: Ch A2	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch A3: Ch A3	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch A4: Ch A4	DC	SE Positive	20 V	0 V	1 V/V	0 V
Recorder C	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch C1: Ch C1	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch C2: Ch C2	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch C3: Ch C3	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch C4: Ch C4	DC	SE Positive	20 V	0 V	1 V/V	0 V
Recorder F	DC	SE Positive	20 V	0 V	1 V/V	0 V
Ch F1: Ch F1	DC	SE Positive	20 V	0 V	1 V/V	0 V

Labels A through O point to various UI elements: A (General settings), B (Input settings), C (Real-time calculations), D (Memory & Timebase), E (Trigger), F (Alarm), G (Sensors), H (Sidebar), I (Signal coupling), J (Input coupling), K (Technical units multiplier), L (Technical units offset), M (Group 1), N (Table header), O (Block diagram).

Figure 8.4: Settings sheet - example

- A General settings
- B Input settings
- C Real-time calculations

- D** Memory and time base settings
- E** Trigger settings
- F** Alarm settings
- G** Sensor operations
- H** Task pane
- I** Channel column
- J** A settings column
- K** A row on channel level
- L** A row on recorder level
- M** A row on group level
- N** Column headers
- O** Graphical feedback and interface

On the left-hand side of the sheet there is a task pane. In this pane the settings are combined into logical groups for easy reference. Use this pane as a 'table of contents' to select a specific settings section, for example the input settings of all basic channels.

The actual settings matrix is based on channel/recorder/group **rows** and setting **columns**:

- Each column gives access to a single setting.
- Each row represents a channel:
 - Channels can be combined into a recorder.
 - Recorders can be combined into groups.

Modifications made on a level are applied to all lower levels, for example a settings change in a recorder row will affect all channels of that recorder. You can select if you want to use the groups and recorders levels.


For many setting sections there is also a graphical user interface: a simplified block diagram that shows the most relevant settings with respect to the actual hardware. A number of settings can be changed directly in the diagram as well. You can hide or show the block diagram.

Depending on your requirements you may want to show or hide certain parts of the interface/matrix. Various commands are also accessible through the sheet context menu.

You can switch between the **basic** and **advanced** mode.

To set or switch the settings sheet layout modes:


- 1 In the main menu select **Settings**.
- 2 In the Settings menu select **Show Settings ▶**.
- 3 In the submenu select:
 - **Basic:** this will show only the relevant settings
 - **Advanced:** this will show all settings
- 4 Or, when visible, use the toolbar icon to set the mode:



You can switch the column header layout.

To modify the column header layout:

- 1 In the main menu select **Settings**.
- 2 In the Settings menu select **Show Header ▶**.
- 3 In the submenu select:
 - **Show Image Only:** this will show icons.
 - **Show Text only:** this will show text.
 - **Show Image and Text:** this will show an icon with text.
- 4 Or, when visible, use the toolbar icon to set the mode:



You can set the width of each column.

To modify the column width:

- 1 Hover with the mouse in the column header area over a column separator. The mouse cursor will change into a double-side arrow.
- 2 Click and drag the column separator to a new location. While dragging a dotted line is used as a visual guidance.

You may want to show or hide the block diagram (when available)

To show or hide the block diagram:

- Click on the grip that is located on top of the column header area.



When applicable you may want to show or hide groups or recorders (or individual events when available).

To show or hide groups, recorders, events:

- 1 In the main menu select **Settings**.
- 2 In the Settings menu:
 - Click **Show Groups** to show/hide the groups.
 - Click **Show Recorders** to show/hide the recorders.
 - Click **Show Event Channels** to show/hide the event channels.
- 3 Or click the corresponding button in the toolbar when available.



- A Groups
- B Recorders
- C Events

Within the settings sheet colors are used to denote the status of settings, for example warning, conflict, updating, etc.





Figure 8.5: Settings sheet legend

You can see the list of available colors and indicators (legend) when applicable.

To show or hide the legend:

- 1 In the main menu select **Settings**.
- 2 In the **Settings** menu click **Show Legend** to show/hide the legend.
- 3 Or click in the **toolbar** when available the **Show Legend** button 

You can modify the colors of various status indications.

To modify a status indication color:

- To set the color of a status indication click on the corresponding color drop down box. For details on changing colors refer to "Modifying color" on page 62.

8.3.2 Modifying settings

The Settings sheet let you enter values and settings in variety of ways. As a result, you may encounter multiple ways of entering a value in a single text box or entry field.

In general:

- You can use the dialog **Tab** key and the **arrow** keys to navigate through the cells in the sheet.
- Once a cell has been modified you can use the **Enter** and **Tab** key to effectuate the setting. Using the Tab key will also move you to the next cell (i.e. the cell to the right of the current cell).

To open a cell for modification:

You will need to "open" a cell in a sheet to modify the content. To do so you can:

- double-click on it.
- click the cell twice.
- click once to select and use a right-mouse click to open.
- click once to select and press Enter.

To enter a value:

To enter a value do one of the following:

- Type a value in an open entry field.
- Choose a value from a drop-down list associated with the entry field.
- When a drop-down list is visible you can still type in another value, when this is supported for that specific setting.
- When a drop-down list is visible you can use the up- and down-arrow key to step through the options.

To modify an option:

- Click an option from the drop-down list. When a drop-down list is visible you can use the up- and down-arrow key to step through the options.

To modify on/off settings:

- To toggle an on/off settings click on the field to select it and click again to toggle the selection.

To modify a color:

- To modify a color click on the corresponding color drop down box. For details on changing colors refer to "Modifying color" on page 62.

Mixed values

When using groups and recorders, the group and recorder row display the same values as set in the lower level. For example when all channels have an input span of 10 Volt, the input span of the corresponding recorder will also be 10 Volt. When not all channels have the same values, the upper level displays the value of the first channel in the range below.

Modify multiple cells

You can modify the contents of multiple cells within a column in one go. There are two fundamental options:

- Use multi-select techniques.
- Use recorders and groups.

To modify multiple cells using multi-select techniques:

You can modify multiple cells in the same column at once. To select multiple cells for editing do one of the following:

- Click on the **header** of a column. This will select all cells in a column. Press and hold down SHIFT, and then click on a cell to edit the contents. Release the Shift key and edit the field. Press Enter when done.
- To select consecutive cells, click the first cell, press and hold down SHIFT, and then click the last cell. Click on a cell to edit the contents. Press Enter when done.
- To select nonconsecutive cells, press and hold down CTRL, and then click each cell. Click on a cell to edit the contents. Press Enter when done.

To modify multiple cells using recorders and groups:

- 1 Make sure groups and/or recorders layout is visible.
- 2 Click on a cell in the group or recorder row.
- 3 Edit the contents.
- 4 Press Enter when done.

8.3.3 Using the block diagram

In various sections a simplified block diagram is available. The function of this block diagram is threefold:

- It gives a graphical representation of the object you want to control. This makes it easier to identify the function of various settings.
- It gives feedback on (the impact of) settings made, for example you can see the physical impact of modifying a switch setting.
- You can use it to control a variety of settings without the need to search through a myriad of columns.







Figure 8.6: Example of a settings sheet block diagram (bridge input)

- A Channel select
- B Activate bridge wizard
- C Bridge representation – Mouse sensitive area
- D Legend
- E A switch – Mouse sensitive area
- F Numeric value
- G Enable/Disable connector pinning
- H Physical input range
- I Spin box
- J A switch – Mouse sensitive area

- A Channel select** Use this control to step back and forth through the available channels. This control also works on groups, recorders and multiple selected channels.
- B Activate bridge wizard** Click the button to open the Bridge Setup.
- C Bridge representation – Mouse sensitive area** Click anywhere in the area to modify the state of the option(s). Each click will put the option in the next state (repeating).
- D Legend** Depending on the type of diagram a legend may be used to clarify used symbols.
- E Excitation – Mouse sensitive area** On/Off switch for the excitation of the Bridge. Click anywhere in the area to modify the state of the option(s). Each click will put the option in the next state (repeating).

- F Numeric value** You can modify numeric values using one of the following methods:
- Double-click on the value: the value will change into an entry field or drop down list. Type or select the required value and press Enter or Tab when done.
 - Place the mouse cursor over the value. The cursor will change into a . Click on the value and drag the cursor left or right to change the value. While dragging the cursor will change into .
 - Click on the value: the value is selected and the cursor will change into a . Turn the mouse wheel up or down to change the value.
- G Enable/Disable connector pinning** Show or hide the connector pinning. In this example the connector pinning of a bridge input connector can be displayed.
- H Input range** This indicator shows the actual physical input range in volts and not in technical units.
- I Spin box** A spin box is a text box that allows you to move, or spin, through a fixed set of values.
- J A switch – Mouse sensitive area** Click anywhere in the area to modify the state of the option(s). Each click will put the option in the next state (repeating).

8.3.4 Additional commands

The available commands are listed in the Settings menu. Commonly used commands are available also through the toolbar when visible.

In the menu there are also possibilities to save the settings in a separate file. In general the settings:

- define the complete hardware setup as specified in the settings sheet,
- can be stored in a separate file with the file extension **.pset**,
- are stored automatically when a workbench is saved and as part of a recording,
- are loaded automatically as part of a complete workbench,
- can be extracted / loaded out of a workbench or recording as separate settings,
- can be saved into a workbench or recording as separate settings.

Load Default Settings

You can restore the hardware settings to their factory default.

To restore the settings to their factory defaults:


- In the **Settings** menu click **Load Default Settings**

Load Settings

You can load settings from a variety of sources.

To load settings:

To load settings from an external source proceed as follows:


- 1 Do one of the following:
 - In the **Settings** menu click **Load Settings...**
 - When available in the **toolbar** click the **Load Settings...** button .
- 2 In the Load Settings dialog that comes up select your file type if required:
 - Settings file .pset
 - Virtual Workbench .pvwb
 - Experiment .pnrf
- 3 Select the file you want to load.
- 4 Click **Open**.

Save Settings

Much in the same way as you can load settings you can also save settings. You can also save into an existing virtual workbench or experiment. By doing so you will replace the settings within that file. No other data will be altered.

To save settings:

To save settings into an external source proceed as follows:

- 1 Do one of the following:
 - In the **Settings** menu click **Save Settings As...**
 - When available in the **toolbar** click the **Save Settings As...** icon .
- 2 In the Save Settings As dialog that comes up select your file type if required:
 - Settings file .pset
 - Virtual Workbench .pvwb
 - Experiment .pnrf
- 3 Select the file you want to save into/replace or type a name for a new file.
- 4 Click **Save**.

Resolve All Conflicts

Conflicts are generated when you make settings that prohibit a 'correct' recording. However, you may choose to start a recording. When you do so the conflicting settings will be resolved before the actual acquisition starts. Conflicts are color coded as defined in the settings sheet legend. You may choose to resolve these conflicts before you start an acquisition.

To resolve all conflicts:

- Do one of the following:
 - In the **Settings** menu click **Resolve All Conflicts**.
 - When available in the **toolbar** click the **Resolve All Conflicts** icon .


Bridge Wizard

For bridge input channels a bridge wizard is available. The wizard allows you to configure your bridge channels more easily. The outcome of the wizard is an optimal match of the amplifier gain/span with your bridge configuration. In addition, when you provide all the information, all settings for shunt calibration are also calculated.

The bridge wizard allows you to configure the bridge amplifier by entering typical known information, derived from specification sheets and/or physical setup descriptions. You can easily enter information from a data sheet into the bridge wizard.

The wizard allows you to set up multiple channels at one go and copy settings from a channel with known correct parameters to other channels.

To set up one or more bridge channels:

- 1 Select no, one or multiple channels in the settings sheet
- 2 Do one of the following:
 - On the **Settings** menu click **Bridge Wizard**.
 - When available in the **toolbar** click **Bridge Wizard** .
 - When available in the graphical area of the settings sheet click the large **Activate bridge wizard** icon in the upper right-hand corner.

- 3 In the Bridge Wizard start-up page:




Figure 8.7: Bridge Setup Start-up

Select the channels that you want to use in the procedure. The channels that were already selected in step 1 are selected here by default.

- 4 Click **Next**

- 5 In **Step 1 of 5** select the type of transducer that you are using.




Figure 8.8: Bridge Setup Step 1 of 5

- 6 Click **Select** if you want to copy settings from another channel.

- Click **Next** and follow the on-screen instructions to complete the procedure. When the process is complete, a summary is displayed.




Figure 8.9: Bridge Setup Step 5 of 5

- Click **Auto balance bridges** if you would like the bridge to be balanced when you exit this dialog. If you select this option and click **Apply and close**, a dialog box will appear asking if you would like to be taken to the bridge balance screen to see the results, click yes or no.




Figure 8.10: Bridge Balance dialog

- Click **Apply and close**.

8.3.5 Print Report

Perception controls a large number of hardware-related settings. You can use the **Print Settings** command to create a listing from these settings. You can modify the content of the printout. You can send the print information to a printer, post the information into a Word document or create a PDF file.

To access the **Print Settings** dialog do one of the following:

- In the **File** menu point to **Print** and click **Settings...**
- If available, in the **Settings** menu click **Print Settings...**
- If available, in the **Settings** toolbar click **Print Settings...**




Figure 8.11: Print Settings dialog

A Print items selection tree

B Command buttons

C Print settings options

A Print items selection tree

Use this tree view to select the items to be printed.

B Command buttons

Load settings...

To load an “external” settings file:

- 1 In the **File** menu point to **Print** and click **Settings from File...**
- 2 In the **File Open** dialog select the file that contains the settings. By default this is a *.pset file. However, it is also possible to select a workbench file (*.pvwb) or a recording file (*.pnrf) and load the settings that are in these files.
- 3 Click **Open**.
- 4 The top of the tree view shows the name of the selected file.

Print Report

Click **Preview** to create a preview of the report. The first page gives an overview of the selected items. If a selected item does not contain any data, this item is not printed. Selected items which are not printed are listed in the “Not Printed” column.

In the Print Preview dialog box do the following:

- 1 Click **Close** to close the **Print Preview** dialog box.
- 2 Click **Print...** to print the report. The standard print dialog will open.
- 3 In the **Zoom** list select a zoom factor.
- 4 Use the **PageUp** and **PageDown** keys to step through a multi-page report.


Post to Word

Click **Post to Word** to post the report to Microsoft® Word. This will open Word and create a report.

Create PDF

Click **Create PDF** to create a PDF file of the settings report. In the **Save As** dialog select a folder and file name and click **Save**.

C Print settings options



Use these options to modify the report layout.

If you do not want to print empty columns select the **Don't show empty columns** check box.

The input range of a channel can either be defined by a from and to value or by a span and offset value. Select **Show from / to** for the first option or else select **Show span / offset**.

Select the **TU per Volt** check box to display technical units per volt. Clear this check box to display volt per technical units.

For external clock settings the scaling can be expressed in clock pulses per unit or in units per clock pulse. Select the **Clock Pulses per Unit** check box to display clock pulses per unit. Clear this check box to display units per clock pulse.

8.3.6 Network and External storage setup

Network setup

Note *The Mainframe network setup and the External storage setup features are only available if the Settings Sheet is active.*

TCP-IP based acquisition system can be re-configured through the settings sheet, for example if a DNS server is put in use, if networks are reconfigured or if connection to the device is desired through a specific network connection on the acquisition system.

To review/update the mainframe network settings:

- In the **Settings** menu click **Mainframe Settings**




Figure 8.12: Mainframe Settings dialog

Please refer to the GEN series user manual for detailed information on configuring network settings.

Note *It is only possible to review/update network settings of currently connected mainframes!*

Setup external storage

Depending on the setup of the acquisition system, three possible ways of storing acquired data are available:

- PC Storage: On the PC control system.
- Mainframe Disk 1, Mainframe Disk 2: On a hard drive mounted in the acquisition system.
- iSCSI 1, iSCSI 2: On an external iSCSI hard drive, connected to the acquisition system.

The storage location setting in the settings sheet can be used to select which way should be used for each mainframe in the system. If an external hard drive (currently iSCSI only) is selected, this drive needs to be properly setup. In some cases this can be done through the mainframe's front panel menu, but another way to do the setup is through the External Storage Setup dialog.

To setup connection to an external storage device:

- In the Settings menu click **External Storage**




Figure 8.13: Mainframe Settings - External Storage Setup dialog

Please refer to GEN series user manual for detailed information on the setup of iSCSI storage.

8.3.7 Power on Setup

The GEN DAQ mainframe can start with the settings set to their default values or reload the stored user settings values. The **Power on Setup** determines this choice. The settings can be persisted on the GEN DAQ mainframe's internal storage. The stored settings are restored automatically at the next startup of the GEN DAQ mainframe.

The **Power on Setup** dialog provides access to the connected mainframe(s) (see Figure 8.14).

Note *The menu item is only enabled when Perception is connected to a GEN DAQ mainframe which supports Power on Setup.*




Figure 8.14: Mainframe Settings - Power on Setup

- A Power on settings:** In this column the Power on settings can be selected, this can either be **System defaults** or **User settings**.
- **System defaults:** The mainframe(s) use the factory system default when starting.
 - **User settings:** The mainframe(s) use the previously stored user settings when starting. When this option is selected and no user settings are stored, this setup cannot be applied.
- B Status:** Checking if a mainframe has a stored setup can be seen in the **Status** field. Precondition: **User settings** is selected.

Note *The stored setup needs to be created with the current mainframe configuration. If the mainframe hardware configuration has changed (e.g.: Removing an acquisition card), new user settings need to be stored.*

- C Store:** The settings are only stored on user request. This can be done for all applicable mainframes at once by using the **Store** button, or for a single mainframe by using the context menu.
- D Reload:** Stored settings are restored at GEN DAQ mainframe startup or on user request. You can use the **Reload** button to reload setting for all applicable mainframes at once, or use the context menu for a single mainframe reload.
- E Acquisition mode:** This mode determines if the acquisition is active after startup of the GEN DAQ mainframe.
 - **Idle:** The GEN DAQ mainframe restores the settings at startup. The acquisition state remains idle.
 - **Preview:** The GEN DAQ mainframe restores the settings at startup and starts the acquisition in preview mode.

Note *In **Preview** mode the RT-FDB (Real-time Formula Database) calculations are performed and calculation results can be exported to the EtherCAT® bus, CAN bus or the GENDAQ API.*

8.4 Fiber Status sheet

HBM offers a range of Fiber Optic isolated digitizers for use with the GEN series data acquisition system. These digitizers are discrete units that are connected to the GEN series data acquisition system through a fiber optic cable for communication and data transfer.

Depending on the type and model these remote front-ends are battery operated, mains operated or use another external power supply.

Because the units can be located on a large distance of the actual laboratory, the units provide an extensive set of on-board diagnostics and status information to verify proper operation. This information is available through the Fiber Status sheet.

When this sheet is not readily available you must add it. To add the Fiber Status sheet do one of the following:

- 1 On the **File** menu point to **New Sheet** and select **Fiber Status** in the submenu.
- 2 Right-click in the tab area of the sheets. On the shortcut menu point to **New Sheet** and select **Fiber Status** in the submenu.
- 3 When the toolbar is available click the **Create new sheet** icon and select **Fiber Status** in the drop-down menu.

Depending on the model battery information may, or may not, be available.

8.4.1 Status information

The following is a list of all available status information in this sheet.

Note *There are no settings here that you can modify.*

Link status



Summary

Gives information about the communication status: OK, bad or no communication

Description

When no errors are detected for more than 1.5 second, the connection is OK. Otherwise the connection is bad. When no 'light' is detected, communication is lost.

Link quality (BER)



Summary

Gives the Bit Error Ratio

Description

The BER is an indication of the link quality. With a typical measurement time the front-end firmware can determine a BER better than 10⁻¹¹ with a confidence level (CL) of > 99%. When a unit starts up, the unit can determine within 10 seconds a BER of 10⁻¹⁰ with a CL of 85%; after 2.5 minutes a BER of 10⁻¹¹ with a CL of 95%.

Cable length



Summary

Cable length in meters

Description

Accuracy is ± 1 meter. For some fiber systems this can go up to 4000 meter standard or even 12000 meter with low-loss cables.

Front-end temperature



Summary

Temperature inside the front-end cabinet

Description

Gives the temperature inside the front-end. Typical values are 15 °C to 25 °C above ambient temperature, depending on the model.

Front-end power level



Summary

Power level indication for the internal electronics

Description

This is a copy of the “power low” indication on the receiver front panel. When not OK the power voltage has gone below 10.4 V (approximately). This situation stays until 9.2 V (approximately) is reached. Below this level the front-end will not function any more.

Front-end power source



Summary

Current power source on which the front-end operates: mains (external) or battery

Description

Depending on the model the unit can operate on mains (external) or battery or 'both'.

Front-end external power status



Summary

Condition when an external power source is used

Description

The voltage level of an external power source: good, under-range (low) or over-range (high).

Total capacity remaining



Summary

Remaining total battery capacity of all installed batteries together

Description

Some front-ends include two batteries. When one battery has 100% and the other one has 80% capacity, the total capacity remaining equals 90%.

Operating time remaining



Summary

Estimated remaining operation time of unit based on capacity and power consumption

Description

Indicates the remaining operation time of the front-end based on total remaining capacity and power consumption. This is an approximation.

Voltage



Summary

Voltage supplied by battery A/B

Description

Voltage supplied by the battery.

Current



Summary

Current of battery A/B. A positive value indicates that the battery is loading

Description

Current of battery A or B. A positive value indicates that the battery is loading; a negative value indicates that the battery is in use.

Capacity rating



Summary

The amount of electrical energy battery A/B can deliver over a certain period of time, measured in Ampere-hours (Ah)

Description

The battery capacity rating provided by manufacturers is the product of 20 hours multiplied by the maximum constant current that a new battery can supply for 20 hours at 20 °C (68 °F), down to a predetermined terminal voltage per cell. It is therefore a theoretical value.

Capacity remaining



Summary

Remaining battery capacity of battery A/B

Description

Remaining battery capacity of battery A or B.

Temperature



Summary

Temperature of battery A/B

Description

Internal temperature of battery A or B.

Charge status



Summary

Indication of the charge status of battery A/B. Can be charging, discharging or idle

Description

Rechargeable batteries can be discharging, charging or idle when no current is drawn.

Charge cycles



Summary

Number of battery charge cycles to date for battery A/B

Description

When a battery is discharged and then recharged it is said to have completed a battery cycle. This is important because battery life is determined by the number of cycles a battery can yield.

Condition



Summary

Condition of the battery A/B

Description

The condition (health) of the battery is determined by the number of battery cycles N. The condition is said to be good for $N < 300$ for a typical battery.

8.4.2 Additional commands

The available commands are listed in the dynamic Fiber Status menu. Commonly used commands are also available through the toolbar when visible.




Figure 8.15: Fiber Status sheet menu

Show Battery Summary

When the front-end has on-board batteries you can select to show or hide the Battery Summary columns **Total capacity remaining** and **Operating time remaining**.

Show battery details

When the front-end has on-board batteries you can select to show or hide the batteries details columns. These columns provide information on a per battery basis.

Temperature unit

Temperature can be displayed in degrees **Celsius** ($^{\circ}\text{C}$), degrees **Fahrenheit** ($^{\circ}\text{F}$) or in **Kelvin** (K).

8.5 Diagnostic Viewer sheet

During operation Perception keeps track of a variety of diagnostic information. This information is related to the Perception application itself, communication with acquisition hardware and various notifications. This information is stored on the computer in XML-based files. For easy access to this information a Diagnostics Viewer sheet is provided

When this sheet is not readily available you must add it. To add the Diagnostics Viewer sheet do one of the following:


- On the **Sheet** menu point to **Manage Sheets...** and select **Diagnostics Viewer** in the table and Load.
- Right-click in the tab area of the sheets. On the shortcut menu point to **New Sheet** and select **Diagnostics Viewer** in the submenu.
- When the toolbar is available click the **Create new sheet** icon and select **Diagnostics Viewer** in the drop-down menu.

8.5.1 Operation

Initially the Diagnostics Viewer sheet comes up empty. Now you need to open a diagnostics file.

To open a diagnostics file:

- On the **Diagnostics Viewer** menu click **Open Diagnostics**. In the file Open dialog select the diagnostics file that you want to see and click **Open**.






Category	Description	Date
i	Parsing commandline filenames	2008-09-04 14:16:06
i	Start main application thread	2008-09-04 14:16:06
i	Starting SOAP Remoting Service	2008-09-04 14:16:06
i	Starting RPC Remoting Service	2008-09-04 14:16:06
w	Sheet Sequencer can not be initialized, InitializationState value: NotAllowed	2008-09-04 14:15:52
i	Creating and Initializing Primary Workbook	2008-09-04 14:15:39
i	Creating PostProcessing and Automation	2008-09-04 14:15:37
i	Initialize SplashScreen	2008-09-04 14:15:37
i	UserMode set to: Advanced	2008-09-04 14:15:37
i	Setting UserMode	2008-09-04 14:15:31
i	Check for RegServer /UnregServer parameters	2008-09-04 14:15:30
i	Loading sheets asynchronously	2008-09-04 14:15:30
i	Parsing commandline parameters (skipping filenames for now)	2008-09-04 14:15:30
i	Registering DDEHandler	2008-09-04 14:15:30
i	Creating GlobalManager	2008-09-04 14:15:28
i	Scanning Startup Parameters	2008-09-04 14:15:28
i	Upgrading settings when necessary	2008-09-04 14:15:27
i	OS Version: Microsoft Windows NT 5.1.2600 Service Pack 3	2008-09-04 14:15:26
i	Application Version: 5.01.8247.1215	2008-09-04 14:15:26

Figure 8.16: Diagnostic Viewer sheet

The information is a list of events, grouped in sessions. By default the most recent session is displayed in full. Chevrons are used to show or hide remaining items in hidden content:

- Click on a chevron pointing downwards to open a session.
- Click on the same chevron now pointing upwards to close a session.

Each event has an icon in front to indicate the type of event:

-  Information: the event has no consequences
-  Warning: a condition that might cause a problem in the future
-  Error: a problem that has already occurred and may prohibit correct operation

8.5.2 Commands

The available commands are listed in the dynamic Diagnostics Viewer menu. Commonly used commands are also available through the toolbar when visible.




Figure 8.17: Diagnostic Viewer menu

Open Diagnostics

Use this command to open one of the available diagnostics files.

To open a diagnostics file:

- On the **Diagnostics Viewer** menu click **Open Diagnostics**. In the file Open dialog select the diagnostics file that you want to see and click **Open**.

Filter Diagnostics

You can set a filter on the diagnostics to view only the events of interest for you.

To filter diagnostics:

- 1 On the **Diagnostics Viewer** menu click **Filter Diagnostics**. The following dialog comes up:




Figure 8.18: Filter Diagnostics dialog

- 2 In this dialog select the **type** of events that you want to see. By default all types are selected.
- 3 For a more detailed filter you can specify a (part of a) text string in the **Category** or **Description** fields of the event entry.

- 4 You may want to apply this filter **as default** for each time you open a Diagnostics Viewer sheet.
- 5 Click **OK** when done.

Auto Refresh

Select this option if you want to refresh the Diagnostics viewer automatically when new events arrive. As standard this option is cleared.

Print Diagnostics

Select this command when you want to print the diagnostics. The print is laid out as displayed on the screen: open and closed sessions.

9 Menu Walkthrough

9.1 Introduction

The Perception work area includes the command menus at the top of your screen. The menu bar provides a number of fixed menus: menus that always are on the same location, do not change their name and provide always the same basic functions, regardless of the state of the software. Apart from these static menus there is also a dynamic menu: a menu related to the context of the selected sheet. These dynamic menus are described in the corresponding sheet section.

9.2 File menu

The file menu is primarily used to open, close and save files related to the work environment.




Figure 9.1: File menu

9.2.1 New...

Select **New...** to start a new work environment based on an experiment or virtual workbench. You can select to start from scratch or use an existing environment.

Start a new work environment

The start dialog automatically appears when you start Perception, or when you select **New** in the **File** menu. You can use this dialog to create a new experiment, redo an existing experiment using actual hardware or review an experiment with data only.




Figure 9.2: Perception Start dialog

Start dialog options:

- 1 If the dialog is not already open do one of the following
 - Choose File ► New
 - If available in the toolbar click the New experiment button
 - Press CTRL+N
- 2 In the dialog select one of the following options:

Start dialog options summary

	Load VWB Environment	Load Hardware and connect	Load Data
New	Default (1)		
New and Auto	Default (2)	Search and select (2+)	
Redo	x (3)		

	Load VWB Environment	Load Hardware and connect	Load Data
Redo and Data	x (3+)	x (3+)	x (3+)
Review	x (4)		x (4)

Set up new blank experiment (1)

Start from the beginning. This creates a new blank experiment based on a default layout. For details of experiments refer to "Experiment" on page 40.

Set up an auto-configured Experiment (2)

This will create an experiment based on available acquisition hardware. If you want factory defaults to be restored select the **and reset hardware** option. Choosing this option will bring up a dialog from which to choose available hardware to connect to.

When you select the auto configure command a dialog comes up that you use to choose the hardware.




Figure 9.3: Hardware select dialog

Select one or more of the available mainframes. Hardware that is dimmed in already in use with the name of the user is shown between parentheses.

Click **Rescan** to rescan the network, click **OK** when done.

Perception will now automatically connect to the selected hardware and create a work environment for you. The connected hardware will be set in Pause mode.

When you select a mainframe, the last used password for that mainframe is used for authorization. When there is no last used password, a default password is used to connect to the mainframe. When this verification fails, you will need to enter the mainframe's password.





Figure 9.4: Enter Password dialog

When entered correctly this password will be saved for later use.

Redo an existing Experiment ⁽³⁾

If you have already performed an experiment and saved it with the correct layout, you can select this option to revert back to the saved workbench, data and hardware set up.

To open from Perception:

- 1 Do one of the following:
 - Select **File** ► **New...** ► **Redo an existing Experiment** ► **OK**
 - Select **File** ► **Open...**
 - If available click the toolbar icon  **Open Experiment**.

You can optionally select and load existing experiment data to include the data from the experiment file.

- 2 In the Open Virtual workbench dialog select the file you want to load and click **Open**.

While the Virtual Workbench is being loaded, a progress dialog is shown. It lists all relevant actions and their success or failure.




Figure 9.5: Load Experiment Progress dialog

Clear the “Automatically close this dialog when finished successfully” option if you want to review the results.

For more information on user modes refer to "Switch to Instrument Panel" on page 45.

Review a stored experiment (4)

Select a previously stored experiment and load the associated Virtual Workbench and data, but do not connect the hardware.

Hardware not found

Typically an experiment/VWB contains information about connected hardware. If you load an experiment/VWB and the hardware is not available or modified, you will be notified of this situation and will be given the option to connect to other hardware as a substitute.

In this case, during loading you are given the opportunity to load the setup of the registered instrument(s) into new ones that are currently available. Whenever a VWB or experiment is loaded and the referenced hardware is not found, the following dialog will be shown:





Figure 9.6: Virtual Workbench Load dialog

- A Replace option
- B Skip option
- C Mainframe name
- D Address of mainframe
- E Mainframe name
- F Refresh
- G List of mainframes
- H Continue

- A Replace option** Select this option if you want to replace the mainframe with another mainframe from the selection list.
- B Skip mainframe** Click this option if the original mainframe should not be replaced.
If this option is selected, an attempt to connect to the original mainframe is made during the actual connection process. You can use this if you do not want to replace the mainframe. You can also use this if the original mainframe has not been powered up or completely booted yet. In this case switch on your hardware and wait for the mainframe to be completely booted and then click **Continue**.
- C Mainframe name** The name of the mainframe in the VWB that cannot be found.
- D Address of mainframe** The IP-address of the mainframe in the VWB that cannot be found.

- E Mainframe name** The name of the mainframe in the VWB that cannot be found.
- F Refresh** The refresh button can be used to refresh the content of the mainframes list. New mainframes can appear in the list or the “in use” status can change.
- G Mainframe selection list** The list of mainframes that are found. Note that this list only contains mainframes of the same type as the original mainframe. It is not possible to load settings of a mainframe type into a different mainframe type.
- H Continue** with the connection process using the selected option. This dialog is shown once for each mainframe that was stored in the VWB or experiment you are loading and that could not be found. A mainframe can only be selected once and if it is not in use by another user. If a mainframe is not selectable, it will still be shown in the list.



Units in use are greyed and the name of the user is displayed. If the available mainframe was previously selected to load into a referenced mainframe, or if it is matched to another mainframe that was in the VWB or experiment, this will be indicated by the term *Loaded* instead of a user name.

Loading settings into a different mainframe

When loading settings into a different mainframe, the configuration of the mainframe may differ from the original mainframe. If this happens, the following rule is used to load the recorders of the mainframe:


When a recorder is loaded, the type of the recorder and it's settings are compared with the stored settings for this recorder. If the recorders are of compatible types and in the correct slots, the settings are loaded. The configuration of the recorder is also compared, only the recorder settings that match exactly are loaded. This is done for all recorders in the VWB or experiment.

Once a load attempt is made for all recorders in the VWB or experiment, the hardware recorders and settings that did not match will not be loaded and are disabled.

Open an existing workbench

If you want to start with an existing workbench select this option. For more information on workbenches refer to "Virtual Workbench" on page 36.

To open an existing workbench:

- 1 Do one of the following:
 - Select **File ► New... ► Open an existing virtual workbench ► OK**
 - Select **File ► Open Virtual Workbench...**
 - When available in the **toolbar** click the **Open Virtual Workbench** button 
- 2 In the Load Virtual Workbench dialog that comes up select your file type if required:
 - Virtual Workbench .pwb
 - Experiment .pnrf
- 3 Select the file you want to load.
- 4 Click **Open**.

When you open an experiment the Perception application by itself will be closed. After loading all new information the Perception application is started with the new experiment settings. While loading the virtual workbench a progress dialog is shown. For details see the remarks for this dialog in "Hardware not found" on page 336.

9.2.2 Open...

This command brings you directly to the Open Experiment for Review dialog.

To open an experiment using the Open command:

- 1 Select **File ► Open...**
- 2 In the Open Experiment for Review dialog select the file you want to load.
- 3 Click **Open**. Refer to Figure 9.1 "File menu" on page 332 for details.

9.2.3 Save

Lets you save your experiment.

To save your experiment:

- Select **File ► Save**. This will save the experiment to its current file.

Note When a recording is made, the data is automatically saved on the PC in your archive directory with the current recording name, including all workbench settings. When you click **Save**, you save (overwrite) the workbench settings within the experiment. The data (recording) that is part of the experiment cannot (and will not) be modified.

9.2.4 Save a Copy As...

The “Save a Copy As...” option stores a copy of the current active experiment.

Note “Save a Copy As...” is only enabled if a new active recording or an experiment is open.

The experiment data will be taken over in the newly created PNRF file. At the end of the save process, the active workbench will be saved into the newly created PNRF file. For more information about Perception storage formats refer to “Export Recording...” on page 356.

- 1 In the **File** menu point to **Save a Copy As...** to open the context menu.




Figure 9.7: File menu with Save a Copy As... option

A Save a copy as

- 2 In the following dialog (see Figure 9.8) navigate to the new path to save the file as a copy. If needed click the **Advanced** button to get the dialog with the advanced settings.




Figure 9.8: Save a Copy As dialog

- A File name** Note that “_Copy.pnrf” will automatically be added to the existing filename.
- B Advanced** Click the **Advanced** button to open the **Configure Save a Copy as** dialog (see Figure 9.9).

- 3 Click the option button(s) in the **Save what** area and/or the check boxes in the **File** area for the settings of the copied file.




Figure 9.9: Configure Save a Copy As dialog


- A Save what settings
- B File settings
- C Full path example
- D File name extension
- E File name

A Save what Click the desired option button:

- **Complete recording**
- **Between cursors**
- **Displayed area**
- **Zoomed segment**
- **Alternate zoomed segment**

Note that you can select either one of these options or the **Sweeps** option button.

- **Sweeps**



Choose the desired sweeps setting for the file to be copied.

- B File** The options below allow for building up a more complex filename, which can include:
- **Recording name** The *recording name*, as set in the Acquisition Control palette.
 - **Recording date**
 - **Recording time**
 - **Autonumber** A number that increases automatically by 1 for every new file, starting at the specified number and consisting of the specified total number of digits.
 - **Trigger** The number of the triggered segment that contains the data to be saved.
 - **Overwrite** When this option is selected, only one file is created each time the action is initiated.

Placeholders

In addition to the options described above, you can also manually edit the filename. Insert placeholders to the filename box (E). The placeholder is inserted on the cursor position within the text box when you select the option. You can cut and paste text to your preference in the filename box (C), in order to set the placeholders and eventual fixed file name text in the desired order. A placeholder is a text identifier between percent (“%”) symbols, which is automatically replaced by another text when its value is calculated (for example %date% will be replaced by the current date). These placeholders are documented in the Export Formats User’s Guide.

Typical placeholders are:

- %recname%
- %date%
- %time%
- %autonumber%
- %trigger%

- C Full path example** Shows what the final file name(s) will look like. When satisfied with the result, click **OK** to save the configuration.

D Extension Supported file format

E File name In this text box you can enter a name for the output file. Note that this might only be part of the whole file name, depending on the rest of the options in the dialog.

9.2.5 Close

Closes the current experiment. However the current Virtual Workbench remains intact.

9.2.6 Open Virtual Workbench...

This command brings you directly to the Open Virtual Workbench dialog.

To open a Virtual Workbench using the Open Virtual Workbench command:

- 1 Select **File ► Open Virtual Workbench...**
- 2 In the Load Virtual Workbench dialog that comes up select your file type if required:
 - Virtual Workbench .pwb
 - Experiment .pnrf
- 3 Select the file you want to load.
- 4 Click **Open**.

When you open a Virtual Workbench the Perception application by itself will be closed. After loading all new information the Perception application is started with the new workbench settings.


While loading the virtual workbench a progress dialog is shown, identical to the one when loading an experiment. For details see the remarks for this dialog in "Hardware not found" on page 336.

9.2.7 Save Virtual Workbench

Lets you save your current virtual workbench.

To save your current virtual workbench:


- Select **File ► Save Virtual Workbench**. This will save the workbench to its current file. If you haven't previously saved your workbench, the Save Virtual Workbench command functions in the same way as the Save Virtual Workbench As... command.

- When available in the **toolbar** click the **Save Virtual Workbench** icon 

9.2.8 Save Virtual Workbench As...

Choose this command to save your workbench to a different file.

To save your virtual workbench with a different name:

- 1 Do one of the following:
 - Select **File** ► **Save Virtual Workbench As...**
 - When available in the **toolbar** click the **Save Virtual Workbench As...** button 
- 2 In the Load Virtual Workbench dialog that comes up select your file type if required:
 - Virtual Workbench .pvwb
 - Experiment .pnrf
- 3 Select the file you want to save into/replace or type a name for a new file.
- 4 Click **Save**.

9.2.9 Revert to Last Opened Setup

This command allows you to return to the initial state of your work environment. This can be the state of the environment after start-up, or the state of the most recent opened VWB.

With this feature you can experiment freely with your setup, without losing the original information. Even after an accidental overwrite of your loaded VWB you can easily restore your workbench and undo the accidental save operation.

When you revert, the original settings file (*.pvwb) will be restored.

To revert to your initial state:

- 1 Select **File** > **Revert to Last Opened Setup...**

- 2 Click **Revert** in the confirmation dialog that comes up:




Figure 9.10: Confirm Revert dialog

The original workbench will be loaded.

9.2.10 Save Configuration for Offline Use...

Use this command when you intend to use the Configuration Manager as described in the appendix "Offline Setup & Configuration Manager" on page 522.


To save the configuration for offline use:

- 1 Select **File ► Save Configuration for Offline Use...**
- 2 In the Save Offline Configuration dialog that comes up select the file you want to save into/replace or type a name for a new file.
- 3 Click **Save**.

9.2.11 New Sheet

You can add sheets to the default layout. Depending on the options installed (including CSI) one or more type of sheets may be available.

To add a new sheet:

- 1 Do one of the following:
 - Point to **File ► New Sheet ►**
 - When available in the **toolbar** click the **New Sheet** button 
- 2 In the submenu that comes up select the sheet you want to add.

9.2.12 Workbook

As standard Perception has one workbook that contains all the sheets you create. As an option Perception allows you to create multiple workbooks. When this option is installed you can create new workbooks, duplicate and delete workbooks. Commands for these operations are available through the Workbook command.

New

To create an additional workbook from scratch use the New command. This will create a new blank workbook that is positioned on top of the current workbook, slightly offset.

To create a new workbook:

- Using the file menu:
 - 1 Point to **File ► Workbook ►**
 - 2 In the submenu click **New** .
- When available in the **toolbar** click the **New Workbook** button 

Duplicate

To create an additional workbook based on a current one use the Duplicate command. This will create a copy workbook that is positioned on top of the current workbook, slightly offset.

To duplicate a workbook:

- 1 Point to **File ► Workbook ►**
- 2 In the submenu click **Duplicate**.

Delete

To remove a workbook use the Delete command.

To delete a workbook:

- 1 Point to **File ► Workbook ►**
- 2 In the submenu click **Delete**.

9.2.13 Archives

The archives section in the Recordings Navigator holds all stored recordings that are available through your PC's environment.

You can add more folders to the Archives directory, or set the current archive folder. For details refer to "Working with archives" on page 95.

Add new folder ...

To add an archive:

- 1 Point to **File** ► **Archives** ►
- 2 In the submenu click **Add new folder ...**
- 3 In the **Browse for Folder** dialog that comes up do one of the following:
 - Browse to and select an existing folder. Click **OK**.
 - Click **Make New Folder**. A new folder is displayed with the default name *New Folder* selected. Type a name for the new folder, and then click **OK**.

To set the current archive folder:

- 1 Point to **File** ► **Archives** ►
- 2 In the submenu click **Set Current...**
- 3 In the **Browse for Folder** dialog that comes up do one of the following:
 - Browse to and select an existing folder. Click **OK**.
 - Click **Make New Folder**. A new folder is displayed with the default name *New Folder* selected. Type a name for the new folder, and then click **OK**.

9.2.14 Set and Test current storage location

Also within the archives menu is the **Continuous data rate** feature which you can use to test the current storage location.

Continuous data rate feature

The Continuous data rate feature is used to test the ability of the available hard disc drives to manage and record data. It is used for measuring the speed at which a disc drive can absorb data and to calculate space requirements.

The required data transfer throughput is determined by the addition of all **active sample channels** and their respective data rates.

This feature will carry out the following automatically:

- When Perception starts for the first time a characterization of the default storage location will be done.
- If any parameter change leads to a data transfer load change, the feedback will be updated accordingly.

- Optional: If hardware permits there is a continuous “real-time” feedback when continuous acquisition and storage is active.

To see the storage display window, click **window** in the file menu and then click **Continuous data rate**. The menu puts a check mark by the side of this command and closes the menu. **Continuous data rate** pane is now showing in the side panel.




Figure 9.11: Continuous Data Rate panel

Clicking on **Details** will bring up the window in Figure 9.12. It shows the amount of data per recorder per unit time that is being used.




Figure 9.12: Continuous Data Rate Details

To select a new storage path open the data storage location preferences by navigating to **File ► Archives ► Set and test current storage location**. You should now see Figure 9.13 appear.




Figure 9.13: Storage Location dialog

To see an overview of storage locations available, click the icon **Available storage locations**. This expands a list of locations in your network you can save data to.

Click **Browse...** and navigate to your new path and click **OK**. After doing this you may want to measure the performance again, do this by clicking **Measure now**. You will now see the following Figure 9.14.




Figure 9.14: Speed test progress indicator

The **Speed Test** indicator will appear briefly and then disappear, momentarily after this the **Performance** rating will be updated with a new figure and date of test, see **Performance** in Figure 9.14 above.

9.2.15 Continuous data rate gauge

To understand the continuous data rate gauge you must use your own rule of thumb to decide whether or not gaps may appear in your recordings.

Whether or not this might happen will depend on your specific system and your test setup.




Figure 9.15: Continuous data rate - 80/100 MB/s

For example if the data rate gauge is at 80% maximum then it's highly likely, unless you are performing very short recordings, that gaps may appear in your recordings.




Figure 9.16: Continuous data rate - 50/100 MB/s

A warning will appear if the continuous data rate gauge is above 40% for a specific storage drive.




Figure 9.17: Storage location warning dialog

This warning is shown because some test setups call for very long continuous recordings at high data rates, the longer a recording runs for the higher the internal memory buffer may become.




Figure 9.18: Continuous Data rate - Buffer warning

- A** Continuous data rate indicator
- B** Warning lights

If the internal memory buffer reaches it's maximum a warning light will be triggered and remain on for the remainder of the recording. This warning light shows that during recording the internal memory buffer exceeded it's maximum and therefore the recording contains data gaps.

If more than one channel (n channels) is recording data, the data rate will increase by n channels times the data rate. Therefore the maximum data rate will be reached n times faster than recording only 1 channel.




Figure 9.19: Data rate and multiple channels

A Warning: When this light is on, gaps have appeared in the data stream.

- The Y-Axis represents the Continuous data rate indicator in Figure 9.19.
- The X-Axis represents the percentage of the maximum available Data rate.

Figure 9.19 shows that if four channels of data are being recorded the Continuous data rate will go into the red four times faster at 25% of the maximum data rate where only 1 channel is recording.


When warning light (**A**) on the continuous data rate or the buffer is lit, it stays on, this acts as a warning to inform the user that data gaps exist somewhere in the recording.

Note *Data gaps do not stop the recording process, the recording will continue as normal when the buffer is below its maximum.*

9.2.16 Load Recording...

Perception provides various options to load a recording. Refer also to "Data source selection for display" on page 104.

To load a recording:

- 1 Do one of the following:
 - Select **File** ► **Load Recording...**
 - When available in the **toolbar** click the **Load Recording...** button 
- 2 In the Load Recording dialog select the file you want to load.
- 3 Select your options in the Load recording and Action section.
- 4 Click **Open**.




Figure 9.20: Load Recording dialog

The Load Recording dialog provides the following options:

- Select how the recording is loaded.
- Select where the recording is displayed.

Load Recording

You can load a recording:

- **As active** By default the active display on the active sheet is connected to the actual hardware. The last made recording is on this display by definition. You can load any other recording as active. This will load the selected recording into the active display on the active sheet, and therefore becomes the active recording. When a new recording is made in hardware, this will again overwrite the currently connected recording in the active display.
- **As reference** While there can only be one active recording there can be multiple reference recordings. The list box allows you to give the recording a meaningful name.
- **Using filename** This option makes the recording available in the system with its own name.

Action


Defines what you want to do with the recording:

- Clear the **Display data** option to add the recording to the list of data sources without creating a display.
- Add the recording to the currently active display.
- Create a new display:
 - In the currently active sheet
 - In a new sheet

File Formats

Perception supports various file formats.

To load a specific file format:

- 1 Do one of the following:
 - Select **File ► Load Recording...**
 - When available in the **toolbar**, click the **Load Recording...** button 

- 2 Load Recording dialog: **Files of type** drop down list shows all available file formats.




Figure 9.21: Files of type list (detail)

A Available file formats

For more information about text file formats, please refer to appendices: “ASCII Recording Loader” on page 885, “CSV Recording Loader” on page 898 and “UFF58 File Format” on page 903.

9.2.17 Export Recording...

Perception can save data directly in a variety of popular formats so you can easily use the recorded data in your preferred analysis programs. Data can only be exported when (part of) the recording is shown in a waveform display. The Perception standard software package comprises three export formats (ASCII, FlexPro and TEAM Data). With the Multiple export option you add over 20 export formats for many popular programs (Excel, CDF AIRBUS, DATS and more...).

To export data:

To export data proceed as follows:

- 1 Select a waveform display: click on the title bar of a display to make it the active display. The title bar will be highlighted.
- 2 Choose **File ► Export Recording...** to open the Export Recording dialog.
- 3 Make the required settings:
 - Select the format.
 - Select the region of interest that you want to export in the “Part of recording to export” section.
 - Set resampling options.
 - Select the channels that you want to export.
- 4 Click the **Settings...** button to modify the settings related to the export and export format.

- 5 Click **OK** to start the export. An estimated time remaining and file size are displayed.




Figure 9.22: Export dialog

- A Export format
- B Part of recording to export
- C Resample options
- D Export statistics
- E Channels to export
- F Export format related settings

- A The **Export format** list box allows you to select one of the available formats. Each format has an individual set of settings pertinent to that format.

- B** You can set the region of interest in the **Part of recording to export** section. These settings refer to the following options are available. Depending of the display and the recording not all options may be enabled.
- **Complete recording** Since a display can contain data from various recordings this option defines the area between the first Start of Recording marker and the last End of Recording marker.
 - **Between cursors** This time interval is limited to the area defined by the position of the two vertical measurement cursors. When the two cursors are at their home position, the number of samples to export will be one (1).
 - **Zoomed segment** With this option the time interval of the export will be set to the start and stop time of the Zoom view. When no Zoom view is available, this option is disabled.
 - **Alternate zoomed segment** With this option the time interval of the export will be set to the start and stop time of the Alternate Zoom view. When no Alternate Zoom view is available, this option is disabled.
 - **Active triggered segment** When data is available with triggered segments you can export a specific triggered segment. For this the active cursor must be positioned within the triggered segment that you want to export. When no triggered segments are available or when the active cursor is positioned outside a triggered segment, this option is disabled.




Figure 9.23: Examples of Part of recording to export

- 1 Zoomed segment
- 2 Alternate zoomed segment
- 3 Between cursors
- 4 Complete recording
- 5 Active triggered segment

C Resample Most HBM Genesis HighSpeed data acquisition systems include the ability to sample different channels at different rates. Some HBM Genesis HighSpeed systems also have a unique feature where channels can be sampled at a slow rate until a trigger occurs, then sample at a higher rate while the trigger condition is true. These powerful features allow you the flexibility to make the best choices for your individual applications. However most analysis programs require uniformly sampled data and cannot accommodate different rates in a single file. For this reason most of the export formats must resample data to a single constant rate during the export. In these cases, the check box for Resample waveform is forced on and cannot be unchecked. You may select between High rate, Low rate and Custom rate.

- **High rate** All selected channels are exported at the highest rate in the recording, which is displayed in the dialog for your information. The fastest channels are unaltered. All slower channels have additional samples inserted by linear interpolation. This option preserves all information in the recording but can produce large file sizes due to the additional samples.
- **Low rate** All selected channels are exported at the lowest rate in the recording, which is displayed in the dialog for your information. The low rate channels are unaltered. All higher rate channels are decimated to the low rate by discarding samples. This option produces smaller files that are useful for an overview, but discards high rate information.
- **Custom rate** All selected channels are exported at any arbitrary rate you define, either higher or lower than the original sample rate(s). This feature is useful for adjusting the sample rate to special rates required by your post-processing, such as 1024 Hz and other power-of-two rates for FFT analysis, or 44.1 kHz and 48 kHz for audio WAV files. Linear interpolation is performed between the nearest original samples and newly computed samples are placed in the output file.

When multi-rate export is supported for an export format, resample is turned off by default and the export file will contain all selected channels at their original sample rate(s) including slow/ fast/slow triggered segments. If desired, resample can still be selected to force all channels to an identical single rate for a uniform matrix.

D The **Export statistics** section provides information on the final file size.

- E Apart from the region of interest to export you can also select which **Channels to export**. The following options are available:
- **Active channel** The channel that is currently selected will be exported. The name of the selected channel is highlighted in the waveform display.
 - **Displayed channels** All channels that are currently visible in the display will be exported.
 - **All channels** All channels within the waveform display, visible or not, will be exported, i.e. all traces on all pages of the waveform display.

- F Export format related export **Settings** are available to fine-tune your export. This option comprises both generic and specific settings. The dialog may have different settings for different export formats.




Figure 9.24: Specific export settings

- A Title of the file
 - B Storage folder
 - C Storage folder naming options
 - D File name
 - E File name options
 - F Path and file name example
 - G Format specific options
 - H Browse for folder
- A You can give a file a descriptive **title**. This is not the file name.

C, H, F Each file is exported to a **folder**. You can enter a name for the folder or **browse** for a folder.

Using the **storage folder naming options** you can modify the path name to include relevant settings:

- Recording date
- Recording time

The result is displayed in the **file name example** section.

D-F Define the **file name** and file name **extension**.

Using the **file name options** you can modify the file name to include relevant settings:

- Sequence number
- Recording name

The result is displayed in the **file name example** section.

G The **options** section provides options that are pertinent to the selected export format.

9.2.18 Print

You can select Display, Settings, Information, Formula (if available) or Report (if available) for printing.




Figure 9.25: File menu with Print options

To print:

- 1 Point to **File > Print >**
- 2 In the submenu click the required option.
- 3 In the Print dialog select your preferences:
 - Color options for display printing
 - Page range options for all others
- 4 Select the basic print options and click **Print**. Settings: refer to Figure 8.11 "Print Settings dialog" on page 313 for more details.

Color options for display printing include:

- **Black on white background** The complete waveform display is printed in black and white, with the background set to white. All color preferences as set in the display properties are ignored.
- **Color on white background** All display parts (traces, annotation, etc.) are printed in the colors as defined in the display properties except for the background. The background is set to white.

- **What You See Is What You Get (WYSIWYG)** When selected, the printout colors are exactly the same as on the screen, including the background.

9.2.19 Preferences...

Various program settings are stored in the Perception Preferences. These settings include, but are not limited to, start-up options, options for updates, video information, display settings, etc.




Figure 9.26: Preferences dialog

To open the Preferences dialog:

- Click **Preferences...** in the File menu.

User Interface Mode startup options

To startup Perception in a specific User Interface Mode:

- 1 Click **Preferences...** in the File menu.
- 2 Select **Start up** in the tree view of the **Preferences** dialog.
- 3 In the **User Interface Mode** drop down list box you have the following three choices:




Figure 9.27: User Interface Mode area (detail)

- A Auto** The software detects the system it is running on and starts in the corresponding mode.
- B Perception Standard** The standard Perception GUI. This is default on PCs and the GEN5i
- C GEN2i Instrument Panel** The Instrument Panel GUI which is default for a GEN2i. For more information refer to Figure 2.4 on page 46.

Perception will start in the defined User Interface mode.

9.2.20 Exit

Select this command to exit Perception.

9.2.21 Definer Mode menu

Introduction to the Definer Mode concept

There are situations in which it is useful that some users are allowed to access or change everything and other users have restricted access to the Perception functionality and are allowed to change only some items or even nothing. To achieve this Perception has a so called Definer Mode. In this mode a Definer is able to disable operations in a Workbench so that other non-Definer users are denied access to these operations. For example, the Definer might disable the File/New menu item so that the non-Definer user is not allowed to create a new Workbench. In the rest of this section the term Definer will be used to describe the Perception user who is working in Definer Mode and the term user will be used to describe the user who is using Perception in the non-Definer Mode.

A Definer is in addition to all other Perception operations able to:

- Create and change Workbenches with restrictions.
- Define a restricted set of operations in a Workbench which a user is allowed to perform.
- Protect the restrictions with a password.

When not in Definer Mode a user who uses a restricted Workbench is able to:

- Open the Workbench and use the unrestricted functionality.

Access to or use of the following items can be made restricted:

- The main menu items
- The main menu sub items
- Toolbars
- Controls
- Sheets

If the restricted Workbench is properly set up a user of this restricted Workbench has only access to the functionality needed to perform the required tasks. Therefore a user can concentrate on the accessible functionality only and does not need to pay attention to all other non-accessible functionality.

This restricted access has several benefits because a user is better guided in the tasks which must be performed.

Some of these benefits are:

- A user is likely to make fewer errors because not needed functionality is not accessible.
- Faster measurements are possible because setup of Perception is faster.
- The Perception software is easier to use because the user can concentrate on only a subset of the Perception functionality.
- Higher safety because a user is guided in his work.
- Higher productivity because a user is guided in his work.
- A user needs less education.
- A user is likely to feel less stress when involved in experiments at which a lot is at stake.

Note *The Definer Mode is available in the Professional and Enterprise Perception versions 6.60 and higher. When using a Workbench which contains restrictions these restrictions are applied in all Perception versions 6.60 and higher. They are ignored in all earlier Perception versions.*

Note *Restrictions in a Workbench are not applied when Perception is in Instrument Panel mode.*

How to create a restricted Workbench

To create a Workbench with restrictions first a Workbench must be setup like normal. After creating this Workbench restrictions can be applied to it. The following steps describe how to create a restricted Workbench:

- 1 Start Perception normally.
- 2 Setup the Workbench layout for the user to work with.
- 3 Enter the Definer Mode (see paragraph “Enter the Definer Mode” on page 369).
- 4 Optionally set up Menu restrictions (see paragraph “Set up Menu restrictions” on page 372).
- 5 Optionally set up Control restrictions (see paragraph “Set up Control restrictions” on page 375).
- 6 Optionally set the read-only state of sheets (see paragraph “Set the Read-Only state of Sheets” on page 377).
- 7 Optionally set a Restrictions Password (see paragraph “Set a Restrictions Password” on page 380).
- 8 Save the Workbench. When saving the Workbench the selected restrictions are also saved in this Workbench.
- 9 Exit the Definer Mode (see paragraph “Exit the Definer Mode” on page 383).

In chapter "Detailed description of Definer Mode functionality" on page 369 these steps are described in detail.

How to change a restricted Workbench

It is possible to change the restrictions in an existing Workbench. The following steps describe how to change the restrictions in an existing Workbench.

- 1 Start Perception normally.
- 2 Load the Workbench containing restrictions (see paragraph “Load a Workbench” on page 385).
- 3 Enter the Definer Mode (see paragraph “Enter the Definer Mode when a restricted Workbench is loaded” on page 371).
- 4 Optionally set up Menu restrictions (see paragraph “Set up Menu restrictions” on page 372).
- 5 Optionally set up Control restrictions (see paragraph “Set up Control restrictions” on page 375).
- 6 Optionally set or remove the read-only state of sheets (see paragraph “Set the Read-Only state of Sheets” on page 377 and “Remove the Read-Only state of Sheets” on page 379).

- 7 Optionally set, change or clear a Restrictions Password (see paragraph “Set a Restrictions Password” on page 380, “Change a Restrictions Password “ on page 381 and “Clear a Restrictions Password” on page 382).
- 8 Save the Workbench. When saving the Workbench the selected restrictions are also saved in this Workbench.
- 9 Exit the Definer Mode (see paragraph “Exit the Definer Mode” on page 383).

In chapter "Detailed description of Definer Mode functionality" on page 369 these steps are described in detail.

Detailed description of Definer Mode functionality

This chapter contains a detailed description of the functionality which is available when the Definer Mode is entered.

- A Enter the Definer Mode
- B Enter the Definer Mode when a restricted Workbench is loaded
- C Set up Menu restrictions
- D Set up Control restriction
- E Set the Read-Only state of Sheets
- F Remove the Read-Only state of Sheets
- G Set a Restrictions Password
- H Change a Restrictions Password
- I Clear a Restrictions Password
- J Exit the Definer Mode
- K Load a Workbench

A Enter the Definer Mode

To enter the Definer Mode perform the following step:

- 1 In the File menu, click the **Definer Mode** item.

Now the Definer Mode is entered.




Figure 9.28: File menu

A check indicates that the Definer Mode is entered.




Figure 9.29: Definer Mode menu item

A new main menu item is added to the menu bar called **Definer**.




Figure 9.30: Definer Mode main menu item

The Definer menu contains the following items:




Figure 9.31: Definer Mode menu

B Enter the Definer Mode when a restricted Workbench is loaded

To enter the Definer Mode when a restricted Workbench is loaded perform the following step:

- 1 In the File menu, click the **Definer Mode** item.

If the loaded Workbench is protected with a restrictions password the following dialog is shown:



Figure 9.32: Enter Restrictions Password dialog

- 2 Enter the restrictions password.

Now the Definer Mode is entered.

Note *On what to do when the user does not know the password refer to paragraph "What to do if the Restrictions Password is not known" on page 389.*

C Set up Menu restrictions

To set up Menu restrictions perform the following steps:

- 1 In the Definer menu, click the **Set Up Menu Restrictions** item.




Figure 9.33: Definer Mode menu item - Set Up Menu Restrictions

2 The **Set Up Menu Restrictions** dialog is shown.




Figure 9.34: Set Up Menu Restrictions dialog

In this window on the left side all Menu items, including the menus of all sheets (not just the active one) are listed.

On the right side of this window the Items of the selected Menu are shown as a tree structure. In this tree structure it is possible to check an item. The checked items are then restricted. If a tree item has sub items beneath it and is (un)checked, all sub-items are also (un)checked.

- 3 Select the items which must be restricted.
- 4 To apply the selected restrictions select the **Apply** or **OK** button.
 Select the **Cancel** button to cancel all changes made since the last time the **Apply** button was selected.
 Select the **Remove all menu restrictions** button to undo all selections.

When an item is restricted by selecting **Apply** or **OK** the restricted items are immediately visually indicated by setting a grey background for the restricted item.

In Figure 9.35 restrictions are applied to some of the sub items in main menu item Control. The restricted items are marked by a grey background in the menu sub items and in the corresponding toolbars.




Figure 9.35: Visualization of restricting some items of a menu in Definer Mode

In Figure 9.36 restrictions are applied to all the sub items in main menu item Control. The restricted items are marked by a grey background in the menu sub items and in the corresponding toolbars.




Figure 9.36: Visualization of restricting all items of a menu in Definer Mode

D Set up Control restrictions

To set up Control restrictions perform the following step:

- 1 In the Definer menu, click the **Set Up Control Restrictions** item.




Figure 9.37: Definer Mode menu item - Set Up Control Restrictions

2 The **Set Up Control Restrictions** dialog is shown:




Figure 9.38: Set Up Control Restrictions dialog

In this window on the left side a list of all Controls is shown.

On the right side of this window the Items of the selected Control are shown as a tree structure. In this tree structure it is possible to check an item. The checked items are then restricted. If a tree item has sub items beneath it and is (un)checked, all sub-items are also (un)checked.

3 Select the items which must be restricted.

4 To apply the selected restrictions select the **Apply** or **OK** button.

Select the **Cancel** button to cancel all changes made since the last time the **Apply** button was selected.

Select the **Remove all control restrictions** button to undo all selections.

When an item is restricted by selecting **Apply** or **OK** the restricted items are **not** visually indicated.

E Set the Read-Only state of Sheets

It is possible to put a sheet in a read-only state. If a sheet is in a read-only state certain functionality on this sheet is not accessible anymore. Which functionality is disabled cannot be defined by the Definer but is predefined by Perception and is sheet specific. In principle when a sheet is in Read-Only mode then only the functionality that allows users (both normal and Definer) to visualize the data is enabled. When the screen is not in Read-Only mode then this restriction is removed.

A sheet can be put in read-only state in two ways.

- 1 Setting the read-only state by using the main menu of the sheet.
Open the menu of the sheet in the main menu and select menu item **Read only**.




Figure 9.39: Active sheet menu

- 2 Setting the read-only state by using the tab of the sheet.
Right click on the tab of the sheet and select **Read only**.




Figure 9.40: Active sheet menu item Read only

If a sheet is in Read-only state this is indicated in the above menus by a check before the menu item.




Figure 9.41: Active sheet menu item Read only selected

F Remove the Read-Only state of Sheets

The read-only state of a sheet can be removed in two ways.

- 1 Removing the read-only state by using the main menu of the sheet. Open the menu of the sheet in the main menu and select menu item **Read only**.




Figure 9.42: Active sheet menu

- 2 Removing the read-only state by using the tab of the sheet. Right click on the tab of the sheet and select **Read only**.




Figure 9.43: Active sheet menu item Read only

The check before menu item **Read only** in the above menus is removed.

G Set a Restrictions Password

It is possible to protect the restrictions in a Workbench from changing by setting a Restrictions Password.

A Restrictions Password has the following properties:

- It must contain at least six characters.
- It is case sensitive.
- It can contain any character.

To set a Restrictions Password perform the following steps:

- 1 In the Definer menu, click the **Set Restrictions Password** item.




Figure 9.44: Definer menu item - Set Restrictions Password

- 2 The **Set Restrictions Password** dialog is shown:




Figure 9.45: Set Restrictions Password dialog

- 3 In the **New password** textbox enter a password.
- 4 In the **Confirm password** textbox enter the same password.
- 5 Select the **OK** button to set the password.

When a restrictions password is set the menu items **Change Restrictions Password** and **Clear Restrictions Password** are selectable and **Set Restrictions Password** cannot be selected. It is possible to change (see paragraph “Change a Restrictions Password” on page 381) or to remove (see paragraph “Clear a Restrictions Password” on page 382) the entered password.




Figure 9.46: Definer menu

H Change a Restrictions Password

To change a Restrictions Password perform the following steps:

- 1 In the Definer menu, click the **Change Restrictions Password** item.




Figure 9.47: Definer menu item - Change Set Restrictions Password

2 The **Change Restrictions Password** dialog is shown:



Figure 9.48: Change Restrictions Password dialog

- 3 In the **Old password** textbox enter the previously set password.
- 4 In the **New password** textbox enter a new password.
- 5 In the **Confirm password** textbox again enter the new password.
- 6 Select the **OK** button to set the new password.

I Clear a Restrictions Password

To remove a Restrictions Password perform the following steps:

- 1 In the Definer menu, click the **Clear Restrictions Password** item.




Figure 9.49: Definer menu item - Clear Restrictions Password

2 The **Clear Restrictions Password** dialog is shown:



Figure 9.50: Clear Restrictions Password dialog

- 3 In the **Old password** textbox enter the previously set password.
- 4 Select the **Clear** button to remove the password.

J Exit the Definer Mode

To exit the Definer Mode perform the following step:

- 1 In the File menu, click the **Definer Mode** item.

Now the Definer Mode is exited.

The check before the **Definer Mode** item is removed.

Main menu item **Definer** is removed.

The restrictions are now applied. The restricted items which were visually indicated are now hidden.

Figure 9.35 on page 374 in paragraph “Set up Menu restrictions” on page 372 shows how menu items and corresponding toolbars of Control are shown in Definer Mode when some items are restricted.

Figure 9.51 shows the result after the Definer Mode is exited.




Figure 9.51: Effect of restricting some items of a menu after exiting Definer Mode

Figure 9.36 on page 375 in paragraph “Set up Menu restrictions” on page 372 shows how menu items and corresponding toolbars of Control are shown in Definer Mode when all items are restricted.

Figure 9.52 shows the result after the Definer Mode is exited.




Figure 9.52: Effect of restricting all items of a menu after exiting Definer Mode

K Load a Workbench

Load a workbench containing restrictions. The workbench is now loaded as it was setup by the Definer with the restrictions applied. If a Workbench contains restrictions an icon is shown in the right corner of the status bar. See Figure 9.53.



Figure 9.53: Icon which indicates that the Workbench contains restrictions

Some details of the effect of restrictions on toolbars and docking panes

In this paragraph some effects of restrictions on toolbars and docking panes are explained.

- A** Linked Toolbar buttons
- B** Linked Toolbars Close buttons
- C** Linked Docking Pane Close buttons
- D** Linked Control elements

A Linked Toolbar buttons

In Perception the buttons on the toolbars have corresponding menu items. So by restricting a menu item the corresponding toolbar buttons also gets restricted.

In Figure 9.54 an example of links between menu items and corresponding toolbar buttons is shown.




Figure 9.54: Visualization of restricting menu items and corresponding toolbar buttons in Definer Mode

B Linked Toolbars Close buttons

If the menu item which is used to show or hide a toolbar is restricted the Close button on the toolbar is removed (when exiting the Definer Mode). The reason for this is if the toolbar is closed it cannot be made visible again because the menu item which takes care of this is not accessible anymore by a user.

In Figure 9.55 an example is given.




Figure 9.55: Effect of restricting a toolbar on the toolbar Close button

- a Close icon
- b File menu entry

C Linked Docking Pane Close buttons

If the menu item to show/hide a Docking Pane (e.g. Acquisition Control, Hardware, and Data Sources) is restricted the Close button on the docking pane is removed (when exiting the Definer Mode). This is done because if the docking pane is closed it cannot be shown anymore because the menu item which takes care of this is not accessible anymore by a user.

In Figure 9.56 an example is given.




Figure 9.56: Effect of restricting a docking pane on the docking pane Close button

a Close icon

D Linked Control elements

In Perception the items on Controls can have corresponding menu items. So by restricting a menu item the corresponding item on the Control also gets restricted.

In Figure 9.57 an example of links between menu items, corresponding toolbar buttons and corresponding items on a Control is shown.




Figure 9.57: Effect of restricting menu items on the corresponding toolbar buttons and items on a Control

- a Effect of restricting menu items on the corresponding toolbar buttons
- b Acquisition control while in Definer Mode
- c Acquisition control after leaving Definer Mode. The restricted items are now hidden.

What to do if the Restrictions Password is not known

If the restrictions password is not known (e.g. the password is forgotten or the creator of the restricted Workbench is not available) contact HBM technical service.

Definer Mode use case examples

- A Disable access to a sheet
- B Set a sheet into the Read-only mode

A Disable access to a sheet

Access to a sheet can be completely disabled. As an example the Information sheet will be disabled. This can be accomplished as follows:

- 1 Open an existing Workbench or create a new one.
- 2 Select menu **Sheets**.
- 3 De-select menu item **Information**.
- 4 Enter Definer mode.
- 5 In Definer menu select **Set Up Menu Restrictions**.
- 6 In Menu selection list select **Sheets**
- 7 In Items selection tree select **Information**.
- 8 Select the **OK** button to apply the restrictions and leave the Set Up Menu Restrictions dialog.
- 9 In Definer menu select **Set Restrictions Password** to protect the restrictions with a password.
- 10 Save the Workbench.
- 11 Exit Definer mode.

When this Workbench is now loaded the Information sheet is not shown and cannot be loaded.

B Set a sheet into the Read-only mode

There are cases where a user should not be able to make changes to a sheet but must still be able to read information on this sheet. For example a user must be able to view the traces on the Active sheet but should not be able to add Data Sources to the Active sheet. This can be accomplished as follows:

- 1 Open an existing Workbench or create a new one.
- 2 Select menu **Active**.
- 3 De-select menu item **Read only**.
- 4 Enter Definer Mode.
- 5 In Definer menu select **Set Up Menu Restrictions**.
- 6 In Menu selection list select **Active**
- 7 In Items selection tree select **Read only**.
- 8 Select the **OK** button to apply the restrictions and leave the Set Up Menu Restrictions dialog.

- 9 In Definer menu select **Set Restrictions Password** to protect the restrictions with a password.
- 10 Save the Workbench.
- 11 Exit Definer Mode.

When this Workbench is now loaded the Active sheet is still visible but cannot be changed. Data sources cannot be added to the sheet. Also several menu items in the context menu of the sheet are disabled.

Figure 9.58 (left side) shows the context menu when the sheet is not in the read only mode and Figure 9.58 (right side) shows the context menu when the sheet is in the read only mode.

Note *If the Read only menu item of a sheet is not made restricted it can still be useful to set a sheet in read only mode. In this way it can be avoided to make unwanted changes to the sheet by accident while working with Perception. It is however at any time possible to remove the read only mode of the sheet.*




Figure 9.58: Context menu of the Active sheet if NOT in read only state (left); context menu of the Active sheet if in read only state (right)

9.3 Edit menu

The Edit menu gives direct access to the various editing commands. You can use these commands to transfer objects or data, depending on the selected item / object.




Figure 9.59: Edit menu

Sometimes editing functions may not be available through the standard Edit menu, but through the context sensitive menu.

9.3.1 Transfer an object

The command method for transferring objects uses the Cut, Copy and Paste commands.

To transfer an object:

- 1 Make a selection.
- 2 In the **Edit** menu choose either **Cut** or **Copy**:
 - The Cut command removes the selection and transfers it (or a reference to it) to the clipboard.
 - The Copy command duplicates the selection (or a reference to it) and transfers it to the clipboard.
- 3 Navigate to the destination (and set the insertion location, if appropriate).
- 4 Choose **Paste**.

The Paste command completes the transfer operation.

9.3.2 Delete an object

The Delete command removes a selection without transferring it to the clipboard for later use.

9.4 Control menu

The Control menu provides access to the basic acquisition controls as well as a timer for Conditional Start Stop, starting and stopping of Voicemark recording, Zero Balance and the possibility to reboot systems. The acquisition controls perform the same function as the controls within the Perception Acquisition Control panel. These commands can also be accessed through the acquisition control icons in the toolbar.




Figure 9.60: Control menu

9.4.1 Basic acquisition control

Four commands are provided for basic acquisition control. For more information also refer to "Acquisition control" on page 114.

Start

The Start command starts continuous acquisition of data. In this mode the recorder(s) acquire(s) data until a stop command is issued.

Stop

To stop an acquisition, select this button. This stops the current recording. When in a sweep acquisition mode, the current sweep will be aborted immediately.

Single Shot

To start a single sweep acquisition select this command. In this mode the recorder acquires data until a valid trigger condition is met and the posttrigger data has been recorded or when a stop command has been received. Sweep length and pre-/ posttrigger values can be set in the Acquisition Control or Settings sheet.

Pause

This command serves two purposes:

- When no acquisition is active it will place the recorder in the pause or stand-by mode. Although the recorder is digitizing, no data is stored in memory or disk. This is useful for monitoring purposes.
- When a continuous acquisition is active, it will place the recorder in a hold mode: although the recorder is digitizing, no data is stored in memory or disk. At this point when Start is selected, the current recording continues; when **Stop** is selected, the recording is finished.

9.4.2 Manual Trigger

The Trigger command is used to send a manual trigger command to the recorder(s) under control.

9.4.3 Voicemark

The Voicemark command is used to add Voicemarks to a recording while the Voicemark is being recorded to PC storage. You can then play back the Voicemark from the display.

While a Voicemark is being recorded, the Voicemark button (**A**) is highlighted and the status bar displays feedback (**B**).




Figure 9.61: Highlighted Voicemark/Feedback status bar

Note *The Voicemark button/Feedback in the status bar is enabled only while Voicemarks are being recorded to PC storage.*

How to use the Perception Voicemark feature

The Perception Voicemark feature allows you to record audio notes while a recording is in process. The audio recording is saved with the PNRF file and is accessible through an icon displayed at the top of the display.

Note *The only equipment required is a microphone or other recording device that is compatible with the Perception PC. Connect the microphone to the PC and then configure it.*

- 1 To access the **Recording devices** setup page in Windows®, right-click on the speaker icon in the Windows® task bar. It is typically in the lower right hand corner:



Figure 9.62: Windows® speaker icon

A Speaker icon

- 2 Right-click to open the context menu (see Figure 9.63).




Figure 9.63: Windows® speaker context menu

- 3 Select **Recording devices** to open the **Windows® Sound** dialog. Select the device you plan to use.




Figure 9.64: Windows® Sound dialog

Click on the **Properties** button to configure the device. Click **OK** to close all dialogs. Your recording device is now ready to be used.

Note *Recording a Voicemark is only possible when a recording is in process.*

- 4 The microphone icon is part of the Perception Controls Toolbar (see Figure 9.65)




Figure 9.65: Voicemark control (microphone not activated)

If you don't see those icons in your toolbar, go to the menu **Window ► Toolbar** and make sure **3- Controls** is selected. The microphone icon will be grey until a recording is started.

- 5 Start a recording and the microphone icon changes to black to show it is active (see Figure 9.66)



Figure 9.66: Voicemark control (microphone activated)

Click on the Voicemark icon to start recording a voicemark. You can also select **Voicemark** from the **Controls** menu or use the **F9** keyboard shortcut. The icon becomes reverse highlighted to show it is in use (see Figure 9.67).




Figure 9.67: Voicemark control (microphone in use)

In addition, **Recording voicemark** is displayed at the bottom of the Perception screen (see Figure 9.68 "Recording voicemark status" on page 397)




Figure 9.68: Recording voicemark status

Speak into the microphone. When you are done, click the microphone icon again to stop the voicemark recording.

- When you view the recorded PNRF file, you will see a voicemark icon at the top of the display. If you hold your mouse over the icon, Perception indicates the time at which the voicemark recording started.




Figure 9.69: PNRF file with additional Voicemark information

A Voicemark recording starting time

- If you right click on the **Voicemark** icon, an option to play the recording is displayed.




Figure 9.70: Voicemark play option

The voicemark will also be played back when the recording is replayed.

9.4.4 Zero Balancing

Zero balancing is a method to set a channel's most currently measured value as the new zero value. For GHS systems, there are two possibilities to accomplish this: Balancing and Zeroing.

- **Balancing** is performed on bridges to avoid overloading the input amplifier at high gains. This is accomplished by inserting a physical current into the bridge to balance the bridge. The net effect is a zero output when the bridge is in balance.
- **Zeroing** is performed on all other sensors. Here a possible offset is measured. This measured value is then used to determine the zero level when scaling the ADC data.

For bridge channels, a balance is performed first. If the bridge channels are not balanced enough, they can be zeroed afterwards. For more information please refer to Figure 9.71.




Figure 9.71: Zero/balance process flow

Zero Balance:

The Zero Balance commands performs zero balancing on all channels which have the "Zero Balance enabled" setting set to "On". For more information, please refer to "Zero Balance and Calibration" on page 678.

Undo Zero Balance:

Select this command to undo the previously performed zero balance.

9.4.5 Timer for Conditional Start Stop

When the timer for **Conditional Start Stop...** is selected the dialog for settings of start, stop and automatic restart are displayed. You can combine the various settings.




Figure 9.72: Timer for Conditional Start Stop

- A Enable timer
- B Conditional start settings
- C Conditional stop settings
- D Automatic restart settings

The Timer for Conditional Start Stop allows you to create an unattended recording sequence. You can define start and stop moments as well as automatic restart options.

To enable the timer:

- Select the **Enable** check box on top of the dialog. Now you have access to the various options.

To use conditional start:

- 1 Select the **Use conditional start** check box. Now you have access to the various options.
- 2 Do one of the following:
 - Specify a date when you want to start on a specific date. The acquisition will start on the specified date at the time as specified at **Every day at**.
 - When you want to start every day on a specific time select the **Every day at** option and set the time. When **Specified date** is also selected, the acquisition will only start once.

To use conditional stop:

- 1 Select **Use conditional stop**. Now you have access to the various options.
- 2 Do one of the following:
 - If you want to stop after a specified amount of time after the start of an acquisition, select the **Stop** option and enter the required value.
 - Specify a date when you want to stop on a specific date. The acquisition will stop on the specified date at the time as specified at **Every day at**.
 - When you want to stop every day on a specific time select the **Every day at** option and set the time. When **Specified date** is also selected, the acquisition will only stop once.

To use automatic restart:

- 1 Select **Use automatic restart**. Now you have access to the various options.
- 2 Do one of the following:
 - Select **unlimited**. The acquisition will restart always until you unselect the **Enable** option.
 - Select **Number of restarts** when you want a specific number of acquisitions.
 - Use the **Start ... after** options to set the time interval between the restarts.

9.4.6 Reboot System(s)

With Reboot System(s), you can reboot mainframe(s)/system(s) remotely, if necessary. Only system(s) which are online and not in use can be rebooted.

Note *This will set the system to its factory default settings, so make sure you have saved the settings before rebooting.*

To reboot a mainframe/system:

- 1 In the menu bar choose **Control ▶ Reboot system(s)...**




Figure 9.73: Reboot System(s)

A Reboot system(s)

- 2 The **Reboot System(s)** dialog opens.




Figure 9.74: Reboot System(s) dialog

- A Online mainframe(s)/system(s)
- B Reboot
- C List of mainframe(s)/system(s)
- D Refresh

- A Online mainframes:** The list of mainframe(s)/system(s) that have been found.
- Enabled check box: The mainframe(s)/system(s) are not in use and can be rebooted. Check the item to reboot the mainframe/system.
 - Disabled check box: The mainframe(s)/system(s) are in use and cannot be rebooted.
- B Reboot:** Click **Reboot** to reboot the mainframe(s)/system(s).




Figure 9.75: Rebooting

The **Rebooting** window (Figure 9.75) closes automatically when all mainframes have been rebooted. Or click **Close** to close this dialog.

- C List of mainframes:** The list of mainframe(s)/system(s) that have been found.
- D Click Refresh** to refresh the list of the mainframes(s)/system(s).

9.5 Automation menu

When you need the results from your tests without delay, the automation feature lets you analyze or export triggered segments of data while or immediately after recording. Now you can extract information from your test data quickly and share the results instantly. This feature also allows for unattended processing of data when long recordings are made. Or use batch processing to easily access and load test data for post analysis and reporting.

In this menu you also find the **Merge Files** feature that allows you to combine multiple files into one recording. In addition you can quickly generate a customized basic report into Word. The **Report to Word** feature is available as a separate option and allows you to create fully customizable, template-based reports.




Figure 9.76: Automation menu

9.5.1 Logfile

You can create a logfile that allows you to store the contents of variables. Storage can be done automatically in one of the automation options, but you can also add entries in the logfile manually.

You can display the logfile in Excel.

Note *The logfile is created as an XML stream. To read it you must have access to an application that can read XML streams, for example Internet Explorer. When you want to open the logfile in Excel you must have Microsoft® Excel 2003 or higher installed.*




Figure 9.77: Logfile examples: XML and Excel

Manual logging

You can manually add entries to the logfile when this option is enabled.

To enable/disable manual logging:

- In the **Automation** menu click **[Enable/Disable] Manual Logging**.
- When available in the **toolbar** click the **[Enable/Disable] Manual Logging** button

Configure Logfile

The contents of the logfile needs to be defined. Apart from the menu entry you have also access to the logfile definition from within the various automation setup dialogs.

To configure the logfile:

- 1 Make sure Manual Logging is enabled, and do one of the following:
 - In the **Automation** menu click **Configure Logfile...**
 - When available in the **toolbar** click the **Configure Logfile...** icon
- 2 In the dialog that comes up make your settings.
- 3 Click **OK** when done.




Figure 9.78: Logfile Configuration dialog


- A** List of available data sources
- B** Additional options
- C** Location and name of the logfile
- D** Browse for folder/file
- E** List of selected data sources
- F** Move data source entry up/down in list
- G** Add/remove data source from list

To set up the logfile configuration proceed as follows:


To add a data source:

To add a data source you must select a data source and add this source to the list of selected data sources as follows:



- 1** In the list of *Available Data Sources* select one or more data sources.

- 2 Do one of the following:
 - With the sources selected drag them into the list of *Selected Data Sources*.
 -  Click the **Add Data Source** button. This will add the selected source. The source will be appended to the end of the source list.

To delete a data source:

- 1 Click the source in the **Selected Data Sources** list you want to delete.
- 2  Click the **Delete source** button.

To move a data source:


- 1 Click the source in the **Selected Data Sources** list you want to move.
- 2 To move the selected source do one of the following:
 -  Click the **Move source up** button to move the selected source one position up.
 -  Click the **Move source down** button to move the selected source one position down.

To set the name of the logfile:

To set the name and storage folder for the logfile do one of the following:

- Type/modify the complete storage path and filename in the filename entry field.
- Click **Browse**. In the Save As dialog that comes up:
 - 1 Select the file you want to save into/replace or type a name for a new file.
 - 2 Click **Save**.

Add to Logfile

To append a new entry manually in the logfile click **Add to Logfile** in the Automation menu or the corresponding button  on the toolbar when available.

Clear Logfile


To completely empty the logfile click **Clear Logfile** in the Automation menu or the corresponding button  on the toolbar when available.

Open Logfile in Excel

You can view the contents of the logfile in Excel. This requires Microsoft® Excel 2003 or higher.

To open the Logfile in Excel:

- Click **Open Logfile in Excel** in the Automation menu.

- When available in the **toolbar** click the **Open Logfile in Excel** button 

Options

For the Logfile two options are provided that expand the usability of the feature:

- Enable logfile record replacement
- Open and refresh in Excel

The **Enable logfile record replacement** option allows you to replace an existing record in the current logfile. The selection of the record is based on a **Unique Record ID (URID)** . Currently the (URID) is the same as the recording ID.

If you select this option, you can make a recording with the same name (and therefore the same (URID)) and automatically replace the logfile entry.

Typical applications:

- 1 You make recordings with automatic logging. Recording one goes well, two goes well and the third goes wrong because a cable is broken. If you now “reset” the recording name and the option was “on”, you can make the third recording again and the third record will be replaced with a new record.
- 2 After ten recordings you notice an incorrect calculation in recording 5. Reload this recording, make the modification and issue a manual replace command. The fifth record will be replaced.

The Enable logfile record replacement has a warning icon in front to alert you of a condition that might cause problems in the future: possible loss of data.

The **Open and refresh in Excel** option makes it possible to monitor all actions while they take place (for example on a secondary monitor).

When this option is selected Excel will be launched the first time a new entry is created. Once open, each new entry will automatically refresh the Excel sheet and therefore become visible immediately.

Note *This only works when Excel is started from within Perception . When launched separately the auto refresh will not work and you will need to do a manual refresh in Excel.*

9.5.2 Process Display

Use the **Process Display** command to manually start a pre-configured automation process after a recording has been made

This command is identical to the **Process** command in the Setup Process Display dialog box. When you use Process Display the settings from the Setup Process Display dialog box are used.

9.5.3 Setup Process Display

The **Setup Process Display** option allows you to transfer data from a waveform display to a file in a specific file format and / or transfer data to another program on request.

Depending on the primary choice you make and the display settings, one or more options within the dialog may not be available. For example when the measurement cursors are not set, you will not have the option to process the data between cursors.

To process display data:

To process data that is currently available in a display, proceed as follows:

- 1 Make the display that you want to use the active display.
- 2 Select **Automation ► Setup Process Display...**
- 3 In the Setup Process Display dialog that comes up make your selections.
- 4 Click **Process** to start processing. A progress dialog comes up.
- 5 Click **Close** in the progress dialog when done.




Figure 9.79: Setup Process Display dialog

- A Time interval
- B Sources for processing
- C Actions list

Note *The various options are similar to export settings. Therefore you may also want to have a look at "File menu" on page 332 and Figure 9.23 on page 359.*

Interval selection

The Interval selection section allows you to specify in detail what part of the data you want to process. Depending on your data source selection and / or display settings one or more of the following options may be available:

- **Complete recording** Since a display can contain data from various recordings, this option defines that the area used is between the first Start of Recording marker and the last End of Recording marker.
- **Between cursors** This time interval is limited to the area defined by the position of the two vertical measurement cursors. When the two cursors are at their home position, this option is disabled.
- **Active triggered segment** When data is available with triggered segments you can export a specific triggered segment. For this the active cursor must be positioned within the triggered segment that you want to export. When no triggered segments are available, or when the active cursor is positioned outside a triggered segment, or when the active display is set to Review-Sweep mode, this option is disabled.
- **Zoomed segment** With this option the time interval of the export will be set to the start and stop time of the Zoom view. When no Zoom view is available, this option is disabled.

- **Alternate zoomed segment** With this option the time interval of the export will be set to the start and stop time of the Alternate Zoom view. When no Alternate Zoom view is available, this option is disabled.
- **Triggered Segments** A specific number of segments will decrease the overall file size as well as time required to process the data. When you select to transfer Triggered segments you can select one of the following options:
 - Process all triggered segments.
 - Use a selected number of triggered segments, starting from the beginning Skip triggered segments.

Data source


Within the Data source section the currently active waveform display is used as data source.

At this point you will have the option to select:

- **Current Trace** Only data from the currently selected active trace is used.
- **Current Pane** Only data from the currently selected active pane is used.
- **Current Page** Only data from the currently selected active (and therefore visible) page is used.
- **All Traces in Display** All data from all traces on all pages of the waveform display are processed.

Automation actions

Here you define what you want to do with the selected data.



A Automation actions



Generally, you can create a list of actions that are performed sequentially. You can select actions from the **Select action and add to action list** box and add them to the **Action list**. The available actions are:

- **Save Perception report** Save the data as an Enhanced Metafile or .pReport file.
- **Post to** Send the data to the FlexPro application.
- **Report to Word** Create a Word report using the data and a predefined template document.
- **Quick report to Word** Create a Word report with minimal configuration.
- **Export to** Save the data to a file after formatting them to one of the available export format specifications.
- **Add to logfile** Save the data to a logfile as XML.
- **Run external program** Launch an external application after collecting the data.
- **Save a copy as** Store a copy of the current active experiment.
- **Print Perception report** Send the data to the default printer.


Each action can be configured separately: select it in the **Action list**, and click **Configure...** In the dialog that shows up enter your options.

In addition, if you have more than one action in the list, you can configure their order of execution.

To move an Automation action:

- 1 Select the action you want to move in the Action list.
- 2 To move the selected action do one of the following:
 -  Click the **Move action up** button to move the selected action one position up.
 -  Click the **Move action down** button to move the selected action one position down.

To delete an Automation action:

- 1 Select the action you want to delete in the **Action list**.
- 2  Click the button **Delete action from list**.

Finally, to execute the configured list of actions, click **Process**.

9.5.4 Recordings Batch Processing

Recordings Batch processing allows you to perform actions on a list of files. The actions defined in this dialog will be applied to all the selected files, with the same time interval and data source configuration.

To process data files:

- 1 Select **Automation ► Recordings Batch Processing...**
- 2 In the Recordings Batch Processing dialog that comes up make your selections.
- 3 Click **Process** to start processing. A progress dialog comes up.
- 4 Click the **Close** button in the progress dialog when done.




Figure 9.80: Recordings Batch Processing dialog

- A Time interval
- B List of files for processing
- C Data source
- D Actions list

Note *The various options are similar to the Setup Process Display dialog. Refer to section "Setup Process Display" on page 409 for further information.*

Interval selection

The Interval selection section allows you to specify what part of the data you want to process.

- **Complete recording** Process the complete recording contained in the selected file(s).

- **Triggered Segments** A specific number of segments will decrease the overall file size as well as time required to process the data. When you select to process Triggered segments you can choose one of the following options:
 - Process all triggered segments
 - Use a selected number of triggered segments, starting from the beginning
 - Skip triggered segments

Recordings

Here you create a list of files to process.

To make a list of files to process:

- Click **Add Files**.
- In the **Add Recording Files** dialog select the file(s) and click Open when done.
- To remove a file from the list select a file and click **Remove**.

Data source

In this section you have the option to select the source of your data for processing. You can either select to:

- Only process the data that resides in the recorders, or
- Process the recorder data as well as the on-line computed data.

Automation Actions

Here you define what you want to do with the selected files. The way of defining a list of actions to perform is the same as in the **Setup Process Display** dialog. Refer to the respective section "Setup Process Display" on page 409 for more information.

9.5.5 Automated Recording Processing

As opposed to the user-initiated Display and Recordings Batch processing, the Automated Recording Processing is driven by the actual acquisition. A post processing task is started automatically at the end of an acquisition or - when triggered segments are used - even while recording.

Combined with the Timer for Conditional Start Stop this allows for powerful automated - unattended - testing.

To start automated processing:

- 1 Select **Automation ► Automated Recording Processing...**
- 2 In the **Recording Automated Processing** dialog that comes up select **Enable automation** first to enable the rest of the options.

- 3 Make your selections in the dialog.
- 4 Click **Close**.

Note *The progress dialog will not come up until an acquisition is started.*




Figure 9.81: Recording Automated Processing dialog

- A Time interval
- B Data source
- C Enable automation
- D Actions list

Interval selection

The Interval selection section allows you to specify what part of the data you want to process and when.

- **Complete recording** Use the complete recording to process. This can only be done once the recording has finished.
- **Triggered Segments** A specific number of segments will decrease the overall size as well as time required to process the data. When you select to process Triggered segments you have the option to:
 - Process data while recording or wait until recording has finished.
 - Process all triggered segments.
 - Use a selected number of triggered segments, starting from the beginning.
 - Skip triggered segments.

With the Triggered Segments selection, you can choose to perform the data processing **While Recording** or **After Recording** from the list box. When you select **After Recording**, the processing will start after the recording has finished. When you select **While Recording**, each triggered segment will be processed as soon as it becomes available.

Data source

In this section you have the option to select the source of your data for processing. You can either select to:

- Only process the data that resides in the recorders, or
- Process the recorder data as well as the on-line computed data.

Automation Actions

Here you define what you want to do with the selected files. The way of defining a list of actions to perform is the same as in the **Setup Process Display** dialog. Refer to the respective section "Setup Process Display" on page 409 for more information.

9.5.6 Actions configuration dialogs

In the Automation Actions section of the Processing dialogs, each action has a Configure button. When you click this button you gain access to additional settings with respect to the processing in general and the application in particular. This section explains the general configuration options of the currently supported actions.

Export

Because this a standard export function refer to "Export Recording..." on page 356 for more details.




Figure 9.82: Example of export settings: ASCII

- A File title
- B Storage folder
- C Storage folder naming options
- D Filename
- E Filename options
- F Path and filename example preview
- G Name format-specific options
- H Browse for folder

The example given here is from ASCII export.

- A You can give a file a descriptive title. This is not the filename.

B, C, H, F Each file is exported to a **folder**. You can enter a name for the folder or **browse** for a folder.

Using the storage folder naming options you can modify the path name to include relevant settings:

- Recording date
- Recording time

Select if you want to overwrite the existing file.

The result is displayed in the **Filename example** section.

D, E, F Define the filename and filename extension.

Using the filename options you can modify the filename to include relevant settings:

- Sequence number
- Recording name
- Title

The result is displayed in the **Filename example** section.

G The Option section provides options that are pertinent to the ASCII export format:

- Time format and control characters
- Optional information to include besides the waveform data

Post to

For a more tightly coupled communication, Perception supports the **Post to FlexPro** action. Posting to an application allows you to send data to an application directly: there is no need to start FlexPro and import or load an external file. The application is started automatically and data is instantly available.




Figure 9.83: Example of Post to FlexPro configuration

- A** Print Options
- B** Time base
- C** Location

Print Options

The configuration dialog above allows to **Print a report**, either for each trigger or for the whole recording. This is not the report from Perception, but a report generated by FlexPro after the analysis.

Time base

Select Absolute time to send the data to FlexPro with their timestamps as recorded.

Select Resample data to use a specific sampling rate. You can either use the recording's high sampling rate or a custom rate. This way the data can be reduced.

Location

Since FlexPro uses a database folder you need to specify this in the Location section. The used filename can be extended with a **prefix** and a number generated by the **auto number** option.

Add to logfile

The logfile feature is described in full detail in "Configure Logfile" on page 405 section.

Print Perception report

This action configuration dialog allows you to print a Perception report. It shows the default **Print** dialog where you may select a printer to send the report to, the page range to be printed, and choose additional print settings.

Save Perception report

When the Save Perception report action is selected to be configured, the Build Storage Path and Filename dialog shows up. It allows you to define the way Perception reports are saved.




Figure 9.84: Build Storage Path and File Name dialog

- A Folder settings
- B File settings
- C Full path example
- D File name extension
- E File name

- A Folder** To select the destination of the report, type a folder name in the **Folder** box or click **Browse** to select an existing one.

The folder name can also contain the **recording date** and/or **recording time**, by selecting the respective check boxes.

B File

The options below allow for building up a more complex filename, which can include:

- **Recording name** The *recording name*, as set in the Acquisition Control palette.
- **Recording date**
- **Recording time**
- **Autonumber** A number that increases automatically by 1 for every new file, starting at the specified number and consisting of the specified total number of digits.
- **Trigger** The number of the triggered segment that contains the data to be saved.
- **Overwrite** When this option is selected, only one file is created each time the action is initiated.

Placeholders

In addition to the options described above, you can also manually edit the filename. Insert placeholders to the filename box (E). The placeholder is inserted on the cursor position within the text box when you select the option. You can cut and paste text to your preference in the filename box (C), in order to set the placeholders and eventual fixed file name text in the desired order. A placeholder is a text identifier between percent (“%”) symbols, which is automatically replaced by another text when its value is calculated (for example %date% will be replaced by the current date). These placeholders are documented in the Export Formats User’s Guide.

Typical placeholders are:

- %rename%
- %date%
- %time%
- %autonumber%
- %trigger%

- C Full path example** Shows what the final file name(s) will look like. When satisfied with the result, click **OK** to save the configuration.

D Extension Use the extension list to choose one of the available extensions, which defines the type of the file that will be saved. This dialog is applicable in two situations: Configuration of the Save Perception report action, and configuration of the report document filename for the Report to Word action. These two situations have different available extensions:

- For the Save Perception report action, the file extension can be:
 - • .emf, for a Windows® Enhanced Metafile type
 - • .pReportData, for a Report file type
- For the Report to Word action's report document filename, the file extension can be:
 - .doc, for Word 97-2003 document format
 - .docx, for Word 2007 document format

E File Name In this text box you can enter a name for the report file. Note that this might only be part of the whole file name, depending on the rest of the options in the dialog.

Save a copy as

When the Save a copy as report action is selected to be configured, the Build Storage Path and Filename dialog shows up. It allows you to define the way the copy is saved. For more information about the settings of "Build Storage Path and File Name" dialog refer to Figure 9.84 "Build Storage Path and File Name dialog" on page 420. All settings are the same except the file extension (.pnrf)

Run External Program

The configuration dialog for this action allows you to define the program to be executed.

Define the program to be executed:

- Click **Browse** to select the program to run.
- Type the command line arguments to input to the program, if applicable.
- Select the **Mode** you want the program's window to run in (*Minimized, Normal, Maximized, or Hidden*).
- Under Automatic execution, you can set the automation action to wait until the program has completed. If this option is not selected, the next automation task will run, without waiting for the external program. In addition, if you select the **With time out** option, the automation will only wait for the specified amount of seconds before continuing with the next action.




Figure 9.85: Configure Run External Program dialog

Report to Word

The configuration dialog of the Report to Word action is described in the separately supplied “ Perception 5.0 – Reporter Option” manual, see Chapters “Report menu” and “Advanced Report”.

Quick report to Word

The configuration dialog of the Quick report to Word action is described in the following chapter "Quick Report to Word" on page 426.

9.5.7 Automation Progress dialog

All processing commands include a progress dialog. The specific information available depends on the type of processing.




Figure 9.86: Automation Progress dialog example

- A Recording
- B Action
- C Progress bar
- D Hide dialog
- E Stop all actions
- F Skip current action
- G List area

- A Recording** Displays the name of the current recording.
- B Action** Displays the current action.
- C Progress bar** Indicates the progress of the current action.
- D Hide** Click this command to hide the progress dialog. To show this dialog again select Window ► Automation Progress.
- E Stop all** Click this command if you want to abort all actions instantly, including the current action.
- F Skip** Click this command if you want to skip the current action instantly and continue with the next one.
- G List area** Displays the list of files to process, including the current one.

9.5.8 Merge Files

Merge Files is a tool to enable you to quickly merge data files together to produce a single file that can be saved.

Before you start the file merge, validate that the files to be merged are available on the PC. If not all files are available, you can:

- 1 Connect the storage device that contains the recording to the PC using peripheral PC hardware if required.
- 2 Copy the files to the PC using the recording manager. Please refer to "Recordings navigation" on page 94 for instructions on how to copy files.

To merge files:

- 1 In the **Automation menu** click **Merge Files**.
- 2 Add the files that should be merged.
- 3 Select an output file location by:
 - Typing an output file location in the output file area.
 - Clicking the **Browse** button and browsing to the output location.
- 4 Click the **Merge files** button.
- 5 Wait for the merge process to be completed.
- 6 Click **Close** to exit the **Merge Files** dialog.




Figure 9.87: Merge Files dialog

- A Merge list
- B Output file path

- C Merge files command
- D Progress bar
- E Add a file to the merge list
- F Remove a file from the merge list
- G Approximate file size
- H Browse for folder or file
- I Cancel the merge operation

A Merge list This is the list of original files that will be merged into a single file. One of the files is shown in bold; this recording file will be used as the master recording. You can change the master recording by double clicking on one of the recordings in the list. The file highlighted is the currently selected master file.

The original files will not be altered in any way.

B Output file path The full path of the merged file. If the file name already exists, you can optionally overwrite the existing file.

C Merge files Starts the merge process.

D Progress bar Shows the progress of the merge process.

E Add file Adds files to the list of files to merge

F Remove Removes the currently selected recording from the merge list.

G Approximate file size Shows the approximate size of the resulting merge file.

H Browse Allows browsing to a file or folder to store the resulting merge file.

I Cancel Cancels the merge process.

9.5.9 Quick Report to Word

The quick report functionality can post various sheet objects to Microsoft® Word with a click of a button. The currently supported objects are:

- Various Display types
- User Table
- Image
- Cursor Table (if visible)

This functionality is available in all versions of Perception .

A quick report can be created manually or automatically. For automation setups refer to "Setup Process Display" on page 409.

To set up the report, the **Quick Report to Word** dialog is used.

To set up the report:

- Click **Automation** in the menu bar and then click **Quick report to word**.
- In the dialog that comes up check which objects you want to report to word, re order them with the blue arrow icons as you wish and click **Report now**.
- Word will open automatically and paste the selected objects into a blank document.




Figure 9.88: Quick Report to Word dialog

- A Perception object name
- B Perception object type
- C Report now command
- D Close this dialog
- E Move object down in the list
- F Move object up in the list

- A Perception object name** The Perception objects that are available at the moment of calling the dialog are listed in this column. The names of the Perception objects are shown. The check box in front of the name indicates if the object is used or not.
Changing the name of an object after closing the dialog is not applied to the Quick Report settings.
- B Perception object type** This column indicates the type of the Perception object.
- C Report now** Performs the actual posting.
- D Close** Close the dialog box window, keeping any existing settings.
- E Move down** Objects are posted in the order they are listed. Use the **Move down** button to move the selected object down in the order.
- F Move up** Use the **Move up** button to move the selected object up in the order.

How it works

When a quick report is created, either manually or automatically, a new blank Word document is created and all selected objects are posted in the order they are listed. After posting, Word is activated and the new document is shown.

Displays

For the quick report option all pages of the display are posted, separated by an empty line.

When a display is posted, it is created using the size of the display on the screen (in pixels), converted to mm/inches. If this size does not fit on the page, it is resized to fit.

The display is posted as-is, using the current layout settings.

Note *The default color scheme used is: Color on white.*

Images

Images are posted to Word using the size of the real image file inside the image object. If the size is larger than the page, it is rescaled to fit on the page.

Note *The fitting properties of the image object have no effect on the output.*

Tables

If a user table or cursor table is transferred to Word, a table is created with the same number of columns as the source using the same division percentage. The created table uses the full width of the page. Fonts and font styles are also sent over to Word.

Note *The values of the data sources inside the table are retrieved at the moment of posting.*

Operation

A **Quick Report to Word** can be created manually or automatically. Both operations are activated in the **Quick Report to Word** dialog box in which the setup is done.

To create a quick report manually:

- 1 Set up Perception with the objects that you want posting.
- 2 In the main menu go to: **Automation ► Quick Report to Word**
In the dialog that comes up:
- 3 Select the objects that you want to be posted.
- 4 Reorder the objects to your preferred order.
- 5 Click **Report now**.
- 6 When posting is done, Word is shown with the new document.

Note *You must save the file in Word to avoid losing data.*

9.6 Window menu

The Window menu provides access to the various palettes and other 'floating' user interface dialogs and controls.

For more details on palettes refer to "Using palettes" on page 66.




Figure 9.89: Window menu

9.6.1 Hardware

The hardware navigator lists all available hardware within a network. This includes all mainframes that you use, is in use by somebody else or is not in use at all. This is also the place where you can select (connect to) the hardware that you want to use for a specific experiment.

To show or hide the hardware navigator:

- In the menu bar choose **Window ► Hardware**. A check mark appears in the tab margin next to the hardware entry if it is currently visible.

For details on the hardware navigator refer to "Hardware navigation" on page 80.

9.6.2 Recording

The recordings navigator lists all available recordings. Recordings can be physically stored in archives on your PC or network, cached in acquisition hardware, or referenced by Perception .

To show or hide the recording navigator:

- In the menu bar choose **Window ► Recording**. A check mark appears in the tab margin next to the recording entry if it is currently visible - either open or auto-hidden.

For details on the recording navigator refer to "Recordings navigation" on page 94.

9.6.3 Data Sources

The data sources navigator allows you to browse and access all data that is available within Perception . This can be referenced/opened recordings, (system) variables, formula results, etc.

To show or hide the data sources navigator:

- In the menu bar choose **Window ► Data Sources**. A check mark appears before the data sources entry if it is currently visible - either open or auto-hidden.

For details on the data sources navigator refer to "Data Sources navigation" on page 108.

9.6.4 Properties

The Properties window displays the properties of a selected item in one of the navigators. Therefore it will be generally used in combination with one or more of the navigators.

To show or hide the properties window:

- In the menu bar choose **Window ► Properties**. A check mark appears before the properties entry if it is currently visible - either open or auto-hidden.

For details on the properties window refer to "Properties window" on page 112.

9.6.5 Automation Progress

All processing commands include a progress dialog. Depending on the type of processing specific information is available.

To show or hide the automation progress dialog:

- In the menu bar choose **Window ► Automation Progress**. A check mark appears before the automation progress entry if it is currently visible.


For details on the progress window refer to "Automation Progress dialog" on page 423.

9.6.6 Acquisition Controls

The Acquisition Control palette is used for quick access to the main parameters of an acquisition. It is also used to control the actual acquisition and to give feedback on the acquisition status of the controlled system(s).

To show or hide the acquisition control:

- In the menu bar choose **Window ► Acquisition Controls ► [control group]**. A check mark appears before a control that is currently visible - either open or auto-hidden.



For details on the acquisition control refer to "Acquisition control" on page 114.


9.6.7 Battery Status

For systems with built-in batteries a battery status palette is available that provides detailed information about the batteries and their "health" in a graphical and condensed format.

Note *This does not include the battery status of remote front-ends. The battery status of remote front-ends is available on a dedicated **Fiber Status** sheet.*

To show or hide the battery status:

- In the menu bar choose **Window ► Battery Status ► [mainframe]**. A check mark appears before a battery status palette that is currently visible.



For details on the battery status refer to .

9.6.8 Status

The Status palette is used for a quick overview of vital system parameters. A large font is used to allow visibility at larger distances.

To show or hide the Status palette:

- In the menu bar choose **Window ► Status**. A check mark appears before the status palette entry when it is visible.

For details on the status palette refer to "Status" on page 125.

9.6.9 Cursor Navigation

The Cursor Navigation Keys are used to easily navigate the display cursors through your displayed waveforms.

To show or hide the Cursor Navigation palette:

- In the menu bar choose **Window ► Cursor Navigation**. A check mark appears before the status palette entry when it is visible.

For details on the Cursor Navigation palette refer to "Cursor navigation" on page 178.


9.6.10 Toolbars

A toolbar contains (buttons with) images that provide quick access to commonly used commands and operations. Perception includes various built-in toolbars that you can show and hide as needed. By default, all built-in toolbars are docked side by side below the menu bar.

To show or hide a specific toolbar:

To show or hide a specific toolbar do one of the following:

- Using the toolbar area:
 - 1 Right-click the toolbar area.
 - 2 In the context menu that comes up click the toolbar that you want to show or hide.
- Using the Window menu:
 - In the menu bar choose **Window ► Toolbars ► [toolbar]**. A check mark appears before a toolbar that is currently visible.



For details on the toolbars refer to "Using toolbars" on page 70.

9.7 Help menu

The Help menu provides access to various support functions.




Figure 9.90: Help menu

9.7.1 Check for Software Updates

Perception uses the InstallShield Update Manager to automatically check for updates of the software. If updates are available, you will see an icon alerting you that updates are available. When you select the icon, you will see a list of available updates. You decide which updates to install. If no updates are available, you will not receive any notification.

Within the Update Manager you can select not to automatically check for updates. However, you can still manually request to run a check for updates. To do this choose the Check for **Software Updates** command in the Help menu. It is recommended that you check for available updates at least once per month.

9.7.2 Update Key...

The Perception software requires a HASP key. HASP (Hardware Against Software Piracy) is a hardware-based (hardware key) software copy protection system that prevents unauthorized use of software applications.

Each HASP key contains a unique ID number used for personalization of the application according to the features and options purchased. Also the key is used for storing licensing parameters, and applications and customer-specific data.

When upgrading the software to a higher level or when additional features are purchased, you will receive a personalized "key file". Use this file to unlock the additional features.

You can find the serial number of your key in **Help ► About Perception**

To update the key information:

- 1 Choose **Help ► Update Key...**
- 2 In the Open dialog locate the Key File (*.pKey), and click **Open**.
- 3 When all is well you should see the following message:



Figure 9.91: Software copy protection dialog

- 4 Click **OK**.

When you added options you can go to **Help ► About Perception ► More...** to see if all options are there.

9.7.3 Open Perception Diagnostics Folder

During normal Perception operation various diagnostic files are kept up-to-date. Also in the rare event of a system malfunction, diagnostic files are created. When something goes wrong and you need to contact HBM support, you should keep these files within reach. They may contain valuable information.

These files are located in a special folder. Use this command to open the diagnostics folder without the need to search for it when requested.

9.7.4 Performance Tests...

You can run performance tests to see if your system is optimized for the Perception application.

To run performance tests:

- 1 Choose **Help ► Performance Tests...**

- 2 The System Performance Tests dialog will open and the tests will start automatically. When done the results are displayed:




Figure 9.92: System Performance Tests dialog

- 3 When required scroll down to see all results.
- 4 Click **Close** when done.

9.7.5 Network Load

It is possible to see a graphical overview of your network load. But next to the load it also shows which mainframe is connected to which network adapter on the PC. This is very useful to check if the hardware connections are done correct.

The dialog is a modal dialog which means it can stay open while continuing the work in Perception. It will update when this is needed.

To see the network load:

- 1 Choose **Help ► Network Load**
- 2 The Network Load dialog will open:




Figure 9.93: Network Load

- A Local PC (main area)
 - A1 Used network adapters (local PC)
 - A2 Unused connected network adapters (local PC)
 - A3 Unused disconnected network adapters (local PC)
- B Network (main area)
- C Acquisition systems (main area)

A Local PC

This area lists all **enabled** network adapters in a predefined “group” order. Possible groups are:

- A1** Used network adapters: Adapters with correct status and used for mainframe connections. This group is only present when connections are made.
- A2** Unused connected network adapters: Adapters with correct status but not currently used for mainframe connection.
- A3** Unused disconnected network adapters: Adapters with disconnected status.

Inside each group the network adapters are ordered alphabetically.




Figure 9.94: Graphical representation of a network adapter

Depending on the “group” a network adapter it’s in, the information inside it is different.

Each Network adapter representation consists out of:

- Name
- IP address
- Network connection state icon
- Network adapter reported Link-speed (Throughput speed)

Note *Only shown for adapters with correct status (excluded is the Loopback adapter).*

B Network

The network area indicates which physical network connections are made (external or internal).




Figure 9.95: Graphical representation of the network connections

When a Mainframe is connected to Perception, there is a complete link between the “Acquisition Systems” and the “Local PC”. Because the GEN series Acquisition systems dynamically know the expected output to the network (and updates when relevant changes are made) we can calculate the expected load to the Network. And the (possible combined) load to the “Local PC”.

Based on the given maximum network throughput speeds, we can extract the load in percentage on each connection.

Note *The most important thing here is that it sometimes is forgotten that a “combined” load to the “Local PC” is created by the physical connections.*

When a recording is started while we have more than 100% network load on **any** connection the following dialog is shown:




Figure 9.96: Network overload message

When the **Show details and stop...** button is pressed, the **Network Load** dialog is shown.

C Acquisition Systems

This area contains the connected mainframes, which are always in the “Used network adapters” group. They are ordered alphabetically.




Figure 9.97: Graphical representation of Acquisition Systems

Each Acquisition system representation consists out of:

- Mainframe name
- Mainframe IP address
- Network connection state icon
- Mainframe reported Link-speed (Mainframe reported throughput speed)
- Synchronization source and state

9.7.6 About Perception

Click this command to see additional information about the application.




Figure 9.98: About dialog

- A Application information
- B License information
- C Support information
- D More information

A Application This section gives information on the version number and build number of the application. This combination defines uniquely which version you have.

B License This section gives information about the license of the software:

- Licensee name and company
- Key serial number
- When available: maintenance expiration date

C Support Website and e-mail address for support.

D More Click this button to get more information on the installed options.




Figure 9.99: About dialog: More

This window shows the installed options. Options that are not installed are greyed out.

Select the Module Versions page to get a list of installed software modules and their version number. This is useful for service purposes.

10 QuantumX in Perception

10.1 Introduction

This section is intended to help first time and existing QuantumX users become familiar with operating a QuantumX using Perception software. It will guide them through the required steps to setup a new experiment including a QuantumX and create a first recording.

This section will explain the basics of using QuantumX with Perception, explaining what can and cannot be done and how to do it.

10.2 Supported QuantumX modules

The following QuantumX data acquisition modules are currently supported by Perception:

Table 10.1: Supported QuantumX modules

Product	Sensors	No. of channels	Sample rates	Max aggregate sample rate	Power consumption
MX1609KB	K-type thermocouples	16	0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, 100, 200, 600 S/s	9.6 kS/s	< 6 W
MX1609TB	T-type thermocouples	16	0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, 100, 200, 600 S/s	9.6 kS/s	< 6 W
MX809B	K, J, T, B, E, N, R, S, C type thermocouples	8	0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, 100, 200, 600 S/s	4.8 kS/s	< 10 W
MX471B	CAN	4 x 128	Asynchronous, max: 1 kS/s CAN data is resampled to 2.5 kS/s	4 x 9.6 kS/s	< 6 W
All B type modules	See product data sheet for specific information				

MX1609KB/TB:

The MX1609 is a thermocouple amplifier. Up to 16 K- resp. T-type thermocouples can be connected to it. Each input is individually configurable and electrically isolated. It is used for measuring temperatures.

MX809B:

The MX809B is a thermocouple amplifier. Up to eight thermocouples can be connected to it. Each input is individually configurable and electrically isolated up to 1 kV. It is used for measuring temperatures.

MX471B:

The MX471B has four connectors that can be individually configured as CAN input or CAN output. When configured as input, up to max. 128 signals and a total of 9600 samples per second can be received. In addition, CCP and XCP (XCP-on-CAN) messages can be received. The MX471B can also operate as a gateway transferring analog input⁽¹⁾ to a CAN-out message. Up to max. 200 signals and a total of 4800 samples/second can be transmitted on CAN bus. The individual CAN signals can be easily configured with the aid of a CAN communication description file in DBC format. For each connector, a bitrate can be set, with maximum of 1 Mbit/s.

For configuring the MX471B, you need to use the MX Assistant tool (see appendix "Configuring the MX471B using the MX Assistant" on page 848).

(1) Analog inputs from other QuantumX units only. For proper connection and more information on CAN out, please refer to the MX471B documentation.

All B-type modules

All other B-type QuantumX modules are supported in Perception for data streaming only. For configuring these modules, you need the MX Assistant tool.

Note

Perception checks the number of connected mainframes against the amount of RAM on the system it is running on. Once the required amount of memory exceeds the amount of RAM in the system, Perception will no longer connect to further mainframes and report back on this. If this happens, extending the amount of RAM in the PC will also increase the number of mainframes that can be simultaneously connected.

10.3 References

This section will not go into full detail on operating Perception, Genesis High Speed equipment or QuantumX equipment. If more information on any of these subjects is required, please refer to:

- Genesis High Speed Data Sheets
- Perception option manuals
- Genesis High Speed Operating Manuals
- QuantumX Data Sheets
- QuantumX Operating manual
- QuantumX Quick Start Guide

10.4 Concepts and terminology

Recorders & time base

Historically, Perception was designed to operate with Genesis High Speed family products that typically support highly configurable setups. Mainframes are compatible with a wide variety of acquisition cards and each user can configure the system to meet their specific needs. All connectors on the same card will sample at the same rate. Thus each card in the mainframe is a Recorder within Perception and each Recorder has multiple channels. This differs from the QuantumX concept where a single unit contains multiple connectors.

For the QuantumX modules, the following approach is used regarding Recorders and sample rate:

- For the **MX1609KB/TB** and **MX809B** modules, each connector represents a Recorder with 1 channel. For each Recorder a sample rate can be configured. This ensures maximum flexibility, as each channel can now be configured to run with its own sample rate. However if all channels need to sample at the same rate, this can be easily accomplished by using time base groups. All channels with the same sample rate capabilities will be grouped together by default.
- For the **MX471B**, each CAN bus connector represents a Recorder with a maximum of 128 CAN bus channels. No sample rate can be configured, because of the asynchronous nature of the data (CAN samples may arrive at irregular intervals).
- For the **all other B type modules**, each input connector represents a Recorder. All channels within this connector should have the same sampling rate. The sample rate of the first signal of the connector is used as sample rate for the Recorder in data storage and representation.

Note *With the "Time monitoring" feature of the MX471B you can define that signal data must be received within a certain time interval at the latest, otherwise the signal will be labeled with Overflow (OVR). Perception will display very high sample values in that case.*

For more information, please refer to

Figure H.18 "Configure CAN signal repetition time" on page 861.

Settings

The Perception approach to settings is, "what you see, you can get". In other words, when setting up the equipment, Perception will only show those possibilities that can actually be selected. While this typically ensures a simple setup process, it may cause some settings to be invisible. This can happen especially in these scenarios:

- Filter frequency missing: If the desired filter frequency is not available, try changing the sample rate.

Filters

Filter naming conventions within Perception may differ from other software. For the currently supported QuantumX modules the following filters are available:

QuantumX module	Perception filter name	MX Assistant/CatMan filter name
MX1609KB or TB MX809B	Bessel IIR (Fc@-3dB)	IIR Bessel, Lowpass
MX1609KB or TB MX809B	Butterworth (Fc@-3dB)	IIR Butterworth, Lowpass
MX471B	-	-

Note *For all other streaming-only modules Perception will **not** shown these settings, but the data that is recorded, is filtered as set up in the MX Assistant.*

PTP

Precision time protocol: protocol to synchronize clocks between multiple devices in a network. It has a better accuracy than NTP at lower cost than GPS/IRIG.

CAN bus

The CAN bus (Controller Area Network) is a serial bus developed by Bosch GmbH in the 80s. It is a Message-based protocol, designed originally for automotive applications, but is nowadays also used as a fieldbus in real-time distributed automation environments.

The nodes on the CAN bus are called Electronic Control Units or shortly ECUs. Two or more nodes are required on the CAN network to communicate. The complexity of the node can range from a simple I/O device up to an embedded computer with a CAN interface and sophisticated software. The node may also be a gateway allowing a standard computer to communicate over a USB or Ethernet port to the devices on a CAN network.

All nodes are connected to each other through a two wire bus. The wires are 120 Ω nominal twisted pair.




Figure 10.1: CAN nodes connected to a CAN bus

Each CAN node is able to send and receive messages, but not simultaneously.

A CAN message or frame consists primarily of the ID (identifier), which represents also the priority of the message, and up to eight data bytes. A CRC, acknowledge slot (ACK) and other overhead are also part of the message.

Message IDs must be unique on a single CAN bus. Message IDs are 11 (or 29 for CAN 2.0B) bits.

A CAN message is transmitted serially onto the bus and may be received by all nodes. To ensure enough transitions for the CAN bus nodes to maintain synchronization, a bit of opposite polarity is inserted after five consecutive bits of the same polarity. This practice is called “bit stuffing” and is necessary due to the non-return-to-zero (NRZ) coding used with CAN. The stuffed data frames are unstuffed by the receiver.

CAN data transmission uses a bit-wise arbitration method for contention resolution. This arbitration method requires all nodes on the CAN network to be synchronized to sample every bit on the CAN network at the same time. This is why CAN is sometimes called synchronous. Unfortunately the term synchronous is imprecise here since the data is transmitted without a clock signal in an asynchronous format.

How the CAN bus arbitration works:

- If a logical **1** is transmitted by all transmitting nodes at the same time, then a logical **1** is detected by all of the nodes, including both the transmitting node(s) and receiving node(s).

- If a logical **0** is transmitted by all transmitting node(s) at the same time, then a logical **0** is detected by all nodes.
- If a logical **0** is being transmitted by one or more nodes, and a logical **1** is being transmitted by one or more nodes, then a logical **0** is detected by all nodes including the node(s) transmitting the logical **1**.

When a node transmits a logical **1** but detects a logical **0**, it realizes that there is a contention and it quits transmitting. Any node that transmits a logical **1** when another node transmits a logical **0** "drops out" and loses the arbitration. A node that loses arbitration stores its message for later transmission and the existing CAN frame bit-stream continues transmitting. This means that the node that transmits the first **1** loses arbitration. So the node that transmits a message with the lowest CAN message identifier transmits more zeroes at the start of the frame, and is therefore the node that wins the arbitration. So, the lower the CAN message ID, the higher the message priority.

A CAN network can be configured to work with two different message/frame formats:

- Standard or base frame format
- Extended frame format (CAN 2.0 B)

The only difference between the two formats is that the CAN base frame supports a length of 11 bits for the message identifier, and the CAN extended frame supports a length of 29 bits for the message identifier.

For configuring the CAN network, typically use is made of a so called CAN communication description file (DBC file). The company **Vector Informatik GmbH** (www.vector.com) offers tools (like CANdb+++) to create such a DBC file.

XCP

The XCP or "Universal Measurement and Calibration Protocol" is a network protocol for connecting calibration systems to Electronic Control Units (ECUs). It is a successor to the CAN Calibration Protocol (CCP) that was developed back in the mid-1990s. XCP support several transport layer protocols, such as Ethernet, USB and CAN (XCP-on-CAN).

The MX471B can read CCP or XCP-on-CAN messages and, in addition, operate as a gateway transferring analog input⁽¹⁾ to a CAN message. For example, MX1609B thermocouple signal data coming in via FireWire being forwarded as CAN-out messages by the MX471B.

- (1) Analog inputs from other QuantumX units only. For proper connection and more information on CAN out, please refer to the MX471B documentation.




Figure 10.2: Example configuration with both CAN input, CAN output and XCP-on-CAN

- * Only CAN bus output of QuantumX Input signals (i.e MX1609KB)
- CCP & XCP-on-CAN: software CANape needed to generate DBC out of A2L

10.5 How to use a QuantumX module in Perception

Typically using a QuantumX module in Perception requires the following workflow, similar to any other measurement in Perception:

- 1 Properly connect all mainframes.
- 2 Start Perception, selecting the user mode of choice (see section "Perception user modes" on page 33).
- 3 Connect to the mainframes in the system.
- 4 To enable time synchronous measurements, enable PTP on the relevant systems⁽¹⁾.
- 5 Setup the rest of the measurement using the settings sheet in Perception.
- 6 Check the settings for conflicts, resolve if found.
 - a Save the settings into a pVWB file to avoid having to setup the settings twice for consecutive tests.
- 7 Check the Perception status, if no warnings. Start the recording.

- (1) Check the hardware manuals for information on how to setup the hardware for proper PTP synchronized recordings.

Using an MX471B type QuantumX module

The workflow of creating a measurement with a MX471B is similar to the previous workflow; however Perception **cannot** setup CAN settings for the MX471B. So in order to properly use the MX471B, a pre-setup is required using another tool. This should happen before connecting to the system with Perception. This results in the following workflow:

- 1 Properly connect all mainframes.
- 2 Setup the MX471B using the MX Assistant software (see appendix "Configuring the MX471B using the MX Assistant" on page 848).
- 3 Disconnect from the MX471B in the MX Assistant.
- 4 Connect to the mainframes in Perception.
- 5 To enable time synchronous measurements, enable PTP on the relevant systems.
- 6 Setup the rest of the measurement using the settings sheet in Perception.
- 7 Check the settings for conflicts, resolve if found.
 - a Save the settings into a pVWB file to avoid having to setup the settings twice for consecutive tests⁽¹⁾.
- 8 Check the Perception status, if no warnings. Start the recording.

- (1) Note that the MX471B CAN settings that were setup using the MX Assistant are not part of the pVWB. These settings always need to be checked and potentially setup through the MX Assistant software.

Using multiple QuantumX modules of the same type in Perception

Upon receiving a new QuantumX unit, its default name is the mainframe type. So an MX1609B module is called MX1609, MX809B is called MX809 and MX471B is called MX471. Perception uses these mainframe names to present the mainframes in the user interface.

When multiple mainframes are used, they may have the same name. In that case Perception only shows a single entry with a warning symbol. There are several ways to resolve this scenario. Refer to chapter "First time connecting" on page 461 on how to resolve this using Perception, or refer to Figure H.6 "Rename module" on page 852 for more information on how to resolve the issue using external tooling.

10.6 Connection basics

Two typical workflows when using a QuantumX module are:

- Measuring with a tethered GEN series system (i.e. a GEN3t).
- Measuring with an integrated GEN series system (i.e. a GEN3i).

Example configuration with a GEN3t:




Figure 10.3: Perception, GEN3t and single MX1609KB for temperatures - Using PTPv2 switch

Note *In most cases a PTP aware switch is used to ensure PTP synchronization. When using a normal (non PTP aware) switch, PTP synchronization might fail. See "Synchronized recording setup" on page 474 for details.*

Example configuration with a GEN3i:




Figure 10.4: GEN3i with three QuantumX MX1609KB "B" version modules

- Note** Setup only shows GEN3i. GEN3i can be replaced by GEN3iA/GEN7i.
- Note** * *All* modules must be "B" versions; one module must set to "clock master" and connected to the GEN3i PTP Ethernet.
- Note** Perception only supports Ethernet communication with the QuantumX modules. This means that the FireWire connection of the QuantumX unit cannot be used for communication with Perception. It may however be used to setup synchronization between several QuantumX modules and/or to power the module via the FireWire power out port that is available on some of the Genesis High Speed mainframes. Refer to the GEN series hardware manual for more information.



HINT/TIP

This setup uses multiple network ports on the GEN3i PC section. Use fixed IP address setup with different base IP address and non-overlapping IP-ranges (Combination of base IP address and net mask) for each of the GEN3i network ports to make sure the setup always works.

Background network details

If the network ports are configured for DHCP setup, each of the connections using the APIPA protocol to find a free IP address. As none of the network ports are linked together the APIPA protocol does not detect the address used any of the network devices in this setup. At random all QuantumX systems might end up with exactly the same network IP address. If this happens the systems are not uniquely addressable anymore and the communication fails.

Background FireWire chaining details

Using a FireWire connection between QuantumX modules may impact the measurement systems time synchronization behaviour. This paragraph explains the details of a FireWire connection and its influence on the sync source in detail.

In Perception, open the **Settings Sheet** tab and in the **General** group, select **Mainframe**.

With **Mainframe** the time sync source can be set to PTP or Auto.




Figure 10.5: Perception settings tab/General group/Mainframe

- A Settings Sheet tab
- B Mainframe option in General group
- C Sync source setting

For the **Sync source** setting, dependent whether or not the QuantumX system is also connected via FireWire to another QuantumX system, time synchronization will behave differently. See next table:

Sync source	FireWire connected	Time synchronization source
Auto	No	RTC MX471B
Auto	Yes	FireWire input source
PTP	No	PTP master
	Yes	Setup depended*

* Only one QuantumX in a FireWire chain can have an external time source. If multiple units in one chain are setup for an external source, only one will actually use that source. The other units will synchronize to that unit via FireWire. Perception will indicate these units as having a conflict as the actual time synchronization source (FireWire) is different from the selected one (PTP). To solve the conflict, leave one unit in the chain to PTP and set the others to Auto.

10.7 Configuring a QuantumX module

Configuring a MX1609KB/TB and MX809B

The relevant settings to setup an MX1609KB/TB and a MX809B module are available in the settings sheet. For more information refer to the section on settings (see "Settings sheet" on page 299) and the appendix "Settings Sheet Reference" on page 534).

Configuring a MX471B

To configure a MX471B module, the MX Assistant tool is used. This is described in Appendix: "Configuring the MX471B using the MX Assistant" on page 848. It describes:

- How to change the network settings of a MX471B.
- How to change the MX471B module name.
- How to configure the general CAN bus settings.
- How to configure the CAN signal settings.
- How to configure the CAN signal repetition time.

Configure other modules

Time source selection and channel and mainframe naming are available for all modules in Perception. Use the MX Assistant to configure all other settings of the module.

10.8 First time connecting

Once a proper hardware setup is created and all equipment is turned on, Perception should be able to discover the QuantumX modules on the network.

Connecting

Once a proper hardware setup is created and all equipment is turned on, Perception should be able to find the equipment on the network.






Figure 10.6: Hardware Navigator in Perception

The hardware navigator in Perception shows all equipment that was discovered on the network.

If everything is OK it will be shown using the informational icon . In some cases the exclamation icon  will be shown.

Here is a list of known causes and solutions:

Cause	Description	Solution
Same name	Perception requires your equipment to be uniquely named.	Connect to the mainframe*, rename it using the network setup dialog, then rescan the unused hardware and connect to the next device. Repeat these steps until all units are uniquely named.
Incorrect network configuration	If the unit's Ethernet settings do not match (one of) the PCs Ethernet settings it is not possible to setup a point to point TCP/IP connection.	Start a connection to the mainframe. During the connection phase a dialog will be shown that allows the network settings to be changed**.
Unsupported equipment	Perception is able to detect all members of the QuantumX family; however only B-type hardware is supported.	Unsupported hardware cannot be used from Perception.
Unresponsive hardware	In some rare cases, communication between QuantumX units and Perception may be blocked.	Reboot the system and restart Perception. If the problem persists, please contact technical support.

* The identification mechanism can be used to determine which unit is or will be connected.

** When using Perception remotely, make sure that the PC and mainframes network settings match before connecting!

Once the equipment is discovered, a connection can be established. See chapter "Perception Start-up" on page 42 on how to start with Perception. Alternatively this can be done by double clicking the item in the hardware navigator, or using the right click menu and selecting Connect. Using multi-select, it is possible to connect to multiple units at the same time. The progress of the connection process is shown in the connection dialog. The connection will go through several steps potentially requiring input to successfully complete.

The following actions will be performed:

- 1 Checking the network IP address setup. If the current network setup of the equipment conflicts with the network setup of the PC, the network setup dialog can be used to ensure correct network settings. Use the information stated on available network adapters to configure the network correctly, or use DHCP configuration if this is supported in the network.




Figure 10.7: Network IP Address Setup dialog

Note *Reconfiguring the network of a mainframe may take some time as this typically requires a (partial) reboot of the system.*

- 2 Firmware upgrade: To ensure dependable behaviour, Perception enforces a fixed firmware version to the equipment. If the equipment's firmware is not up to date, or a newer version is loaded, Perception will load a predetermined firmware version into the module. Note that the firmware upgrade process may take some time to complete.

Note *DO NOT POWER OFF OR DISCONNECT EQUIPMENT DURING THE FIRMWARE UPGRADE PROCESS.*

Identification

In case of multiple units it may be difficult to determine which navigator entry matches which unit. For a QuantumX it is possible to use the identification functionality by right clicking in the hardware tree and selecting **Identify**. The corresponding unit will now have a blinking power LED and the identify menu item will be checked. The blinking can be stopped by clicking the **Identify** item again.




Figure 10.8: Identify hardware

Note *The identification feature is not available for all type of hardware. If the feature is not available for selected hardware the menu item will be disabled.*

MX471B

When connected to a MX471B module, only the CAN channels for which a signal has been activated will be visible in Perception. CAN signals which are deactivated are not visible. CAN signals can be activated (or deactivated) using the MX Assistant tool. For more information, please refer to "Configuring the CAN signal settings" on page 854.

Each MX471B CAN connector is mapped to a single Recorder in Perception. Only CAN connectors for which at least one signal has been activated will be mapped to a Recorder.




Figure 10.9: Example configuration of a MX471B with one recorder and three activated CAN signals

A Mapped MX471B CAN connector

10.9 Configuring the hardware via the Settings Sheet

Within Perception, preparing equipment for measurements is done through the settings sheet. Once connected to the equipment, the setting categories that are available will be enabled.




Figure 10.10: Setting categories

Typically all **Basic (Reduced Settings)** are shown, it is also possible to show **Advanced (All Settings)** by using the right click menu on the setting column headers.




Figure 10.11: Basic/Advanced settings

This is especially interesting when setting up the system for synchronized measurement between multiple units using PTP, as more detailed PTP information will be shown.

General Mainframe	Storage location	Sync source	Alarm out	Trigger delay	PTP Master MAC-address	PTP Role
GEN3I	PC Storage	PTP 1	Alarm High Level	516 µs	00-09-E5-FF-00-14	Master
MX1609_Test_1_BHardware	PC Storage	PTP 1	Disabled	0 s	00-09-E5-FF-00-14	Slave
MX1609_Test_2_BHardware	PC Storage	Auto	Disabled	0 s	⊖	⊖

Figure 10.12: Settings information

Information that is currently not relevant is marked with the ⊖ sign. These settings may become relevant later on depending on other settings, in the example above when the sync source is set from **Auto** to **PTP**.

When connected to a unit it is also possible to review or change the unit's network settings by activating the settings sheet, and then going to the **Settings** ► **Mainframe Network Setup** menu item.




Figure 10.13: Mainframe Settings - Network Setup menu

The mainframe network setup dialog will show all connected units and within the unit the available configurable Ethernet connections.

Note *The new settings will only take effect when disconnecting the unit. When the network settings are changed, disconnecting from the unit will take longer because the unit will be rebooted.*

Saving and loading a setup

After setting up the experiment it is possible to store the setup information to a file on disk for future reference; such a file is called a Virtual Workbench within Perception. It contains information on:

- The connected units
- The time base grouping of the units and recorders
- The hardware settings of the connected units
- The layout of Perception
(displays, meters information and any other experiment related information)

To save a virtual workbench follow the following steps:

- 1 Connect to the units to configure.
- 2 Setup the units' settings.

- 3 Setup Perception layout.
- 4 Use **File ► Save Virtual Workbench** or **File ► Save Virtual Workbench As** and select the name and location for the virtual workbench.

Besides the manual setup and creation of a virtual workbench, Perception also stores setup information in every recording that is created in the PC Storage location. There are multiple ways to redo an experiment with the same setup:

- 1 Select **File ► Open Virtual Workbench** and select the **pVWB** or **PNRF** file containing the experiment setup to use




Figure 10.14: Open Virtual Workbench

- 2 Select **File ► New** and select **Redo an existing Experiment** from the Perception start dialog




Figure 10.15: Perception start dialog

A Redo an existing Experiment

10.9.1 MX471B specific settings

Note For the MX471B module only a limited number of settings can be configured via the settings sheet. Use the MX Assistant for the other settings.

Recorder (General group)

In Perception, open the **Settings Sheet** tab and in the **General** group, select **Recorder**.

Here the Recorder can be enabled or disabled and the Recorder name can be changed.




Figure 10.16: Perception settings tab/General group/Recorder

- A Recorder option in General group
- B Settings Sheet tab
- C Recorder name
- D Enable/Disable option

Note The CAN data recorded by the MX471B is asynchronous in nature and the sample rate can therefore not be set. The data may be up-sampled in Perception in case synchronous data is required to complete an operation.

Note These settings are not stored into the MX471B. These settings are lost when the MX471B is disconnected. If you want to keep these settings you have to save them in a Virtual Workbench file.

Can-Bus (Input group)

In Perception, open the **Settings Sheet** tab and in the **Input** group, select **CAN-Bus**

With **CAN-Bus** the display range can be adjusted. The initial value is taken from the CAN channels minimum and maximum value which are defined outside of Perception. For more information, please refer to "Configuring CAN signal minimum/maximum value" on page 863.




Figure 10.17: Perception settings tab/Input group/CAN-Bus

- A CAN-Bus option in Input group
- B Settings Sheet tab
- C Range from
- D Range to

Note *The range only adjusts the display range settings in Perception. These settings are not stored into the CAN amplifier settings of the MX471B. This means the adjusted display settings are lost when the MX471B is disconnected. If you want to keep these settings you have to save them in a Virtual Workbench file. Or adjust the CAN signal minimum/maximum value settings in the MX471B device. For more information, please refer to "Configuring CAN signal minimum/maximum value" on page 863.*

When there is conflict with the display range, the involved CAN channel gets colored:




Figure 10.18: CAN channel conflict

A Colored conflict area

A conflict is indicated if the range is 0 or negative. A range conflict might prevent you from seeing a trace in the Perception time display.

You can adjust the display range either via Perception or via the MX Assistant:

Adjusting display range via:	When	Reboot of QuantumX device needed	Changes lost on reboot/disconnect
MX Assistant	A physically different range is measured.	Yes	No
Perception	Data is only available for a specific portion of physical measurement range.	No	Yes

In the MX Assistant, the display range can be changed via the CAN Sensor adaptation dialog. (See "Configuring the MX471B using the MX Assistant" on page 848).

10.10 Combining QuantumX and GEN series

Synchronized recording setup

To ensure aligned data when recording with multiple measurement devices, those devices should be synchronized. Perception, in combination with Genesis High Speed and QuantumX modules offers a single synchronization method to accomplish this, PTP or Precision Time Protocol.

To setup a synchronized recording take the following steps after connecting to the units:

- 1 Start GEN series mainframe with PTP enabled with PTP tolerance set to 150 ns (default value).

Note *All modules connected through FireWire should be set to Auto, also the ones that are connected but not supported by Perception, these modules can be set to Auto using the MX Assistant.*

- 2 Wait until the Time base status changes to **PTP Synchronized**.




Figure 10.19: Time base status

A PTP Synchronized

Note *PTP synchronization may fail when using a non-PTP aware switch. If this is the case, **and** you are not using an external PTP grandmaster, set the PTP tolerance of the GEN series mainframe to 1000 ns or higher. The QuantumX will now become the master in the PTP network, and the GEN series mainframe(s) will only report it is out of sync when the difference with the grandmaster exceeds the selected tolerance. If a higher tolerance is not acceptable **OR** you are using an external grandmaster, a PTP aware switch is required.*

- 3 Ensure that status is **PTP** and not **PTP : Conflict**.
- 4 In the settings sheet verify that all units use the same PTP Master by checking the PTP Master MAC-address. (Advanced setting).

General Mainframe	Storage location	Sync source	Alarm out	Trigger delay	PTP Master MAC-address	PTP Role
GEN3i	PC Storage	PTP 1	Alarm High Level	516 µs	00-09-E5-FF-00-14	Master
MX1609_Test_1_BHardware	PC Storage	PTP 1	Disabled	0 s	00-09-E5-FF-00-14	Slave
MX1609_Test_2_BHardware	PC Storage	PTP 1	Disabled	0 s	00-09-E5-FF-00-14	Slave

Figure 10.20: Settings MAC-Address, setup without FireWire connection between QuantumX mainframes

In the settings sheet verify that all units use the same PTP Master⁽¹⁾ by checking the PTP Master MAC-address. (Advanced setting). The value shown in the PTP Master MAC-address is the MAC-address of the PTP master clock used by the mainframe in that row. If the mainframe is the master this will be the MAC-address of the mainframe itself. If the mainframe is a slave it should be another address. To perform a synchronized recording, all mainframes should use the same PTP master, and thus the PTP master MAC-addresses for all slave mainframes should be the same. In the example shown above, the GEN3i is the PTP master to both MX1609 mainframes. So the PTP MAC-address shown for all units is the MAC-address of the GEN3i.

- 5 Ensure that the PTP Master is either a GEN series mainframe or an external PTP master clock.
 - 6 Repeat these steps for all mainframes in the connected mainframes.
- (1) In most typical PTP setups all data acquisition will be using the same PTP clock and all Master MAC-addresses should be the same. Only when using multiple subnets it may be valid if two different MAC-addresses are shown.

Possible topologies

When using PTP synchronization in an Ethernet network, make sure the PTP synchronized modules are connected using a PTP aware switch. Using a standard switch will cause the PTP to randomly loose synchronization, resulting in an unsynchronized recording.




Figure 10.21: GEN7t with single QuantumX MX1609KB - Overview

For detailed information on PTP setup, please see the Genesis High Speed hardware manuals.

QuantumX as master

QuantumX can be master within a PTP network. However when using only QuantumX units, this may result in an unsynchronized recording as the QuantumX typically has no reference to an absolute time. Perception will recognize this and try to match the QuantumX data to its own internal absolute time, however due to internal latencies of the data, this will not happen at the same time for all mainframes. This will introduce a data shift that matches the size of the latency. Typically the shift will be on the order of 400 μ s. If a recording is started with QuantumX as in the PTP master role, Perception will show a warning notification stating that the recording may not be properly synchronized.




Figure 10.22: Clock Synchronization warning

PTP Exceptional behaviour

When correctly configured, the PTP protocol should provide a stable synchronized recording. It is possible however that the PTP master fails at a given moment (power outage, hardware failure). When this happens, the PTP protocol will select a new master clock device.

When the new master is selected a number of scenarios may occur:

- 1 The new master time signal is very close to the original master
Within Perception you may see an indication that synchronization was lost and recovered. All equipment continues running synchronized to the new master.
- 2 The new master is ahead of time
If the new master's time is very far ahead of the original master clock the system behaviour depends on connected hardware.
For QuantumX, Perception will detect a jump forward in time. The last known 'old' sync sample will be marked, and the first 'new' sample will be marked with an event mark in the display. Between these two samples there will be no data, but all measured samples are written into the recording.
- 3 The new master is back in time
If the new master's time is back in time compared to the original master clock the system behaviour depends on connected hardware.
For QuantumX, Perception will detect a jump back in time. The last known 'old' sync sample will be marked, and the first 'new' sample will be marked with an event mark in the display. Data that is reported at a time which overlaps with the previous synchronization time will be discarded!

FireWire synchronization

When using multiple QuantumX modules, it is possible to combine PTP synchronization with FireWire synchronization between the QuantumX modules. To setup the system like this, set at least one of the QuantumX modules to PTP as described earlier. For the other systems that will be synchronized to the PTP QuantumX via FireWire, make sure the Sync source is set to Auto.




Figure 10.23: GEN3i with multiple MX1609KB/MX1609TB - Using PTP switch

Note * Multiple QuantumX modules might require more than one power supply. For more information, please refer to the QuantumX data sheets for power consumption.

Using FireWire synchronization may be the better option from a cost point of view as it does not require a PTP aware switch. This only applies if the system contains more units than can be connected to a single PTP-aware switch, or in case the QuantumX units are connected directly to an integrated GEN series unit.

Note Refer to the QuantumX manual for detailed information on synchronization methods.

When using FireWire create the following setup:

General Mainframe	Storage location	Sync source	Alarm out	Trigger delay	PTP Master MAC-address	PTP Role
GEN3I	PC Storage	PTP 1	Alarm High Level	516 µs	00-09-E5-FF-00-14	Master
MX1609_Test_1_BHardware	PC Storage	PTP 1	Disabled	0 s	00-09-E5-FF-00-14	Slave
MX1609_Test_2_BHardware	PC Storage	Auto	Disabled	0 s	⊖	⊖

Figure 10.24: Setup using fire wire

- 1 Set GEN series to **PTP 1**
- 2 Set the QuantumX connected to the PTP capable switch to **PTP 1**
- 3 Set the QuantumX modules that should be FireWire slave to the PTP QuantumX to **Auto**

After all modules are synced:

- 1 The GEN series has PTP Role Master, or slave to an external PTP master clock
- 2 The QuantumX modules have PTP Role Slave, the PTP Master MAC-address of all QuantumX modules set to PTP should be the same as the PTP Master MAC-address of the GEN series

Note *In case multiple QuantumX mainframes are set to PTP **and** connected using FireWire, only one mainframe will use PTP synchronization. The other mainframes will use FireWire synchronization. Mainframes that are set to PTP, but that use FireWire will show this as a conflict. To avoid conflicts, make sure only one mainframe in the FireWire chain is set to PTP.*

10.11 Perception with a QuantumX via a CX27B

One way to connect a QuantumX module to the rest of your system is using a CX27B. Main advantage of this is the reduction in cabling, and potential to connect multiple QuantumX modules to a single integrated GEN series system without the need for a PTP aware switch. Consider the following points when set up QuantumX via a CX27B.

10.11.1 Hardware setup

For general information on using a CX27B and its capabilities, please refer to the CX27B data sheet which can be found on this website:

www.hbm.com/en/2131/quantumx-cx27/

Direct connection to an integrated GEN series mainframe




Figure 10.25: Connection of a GEN series mainframe and QuantumX

Note Please make sure to use the Ethernet connector on the back of the CX27B when working with PTP synchronization as the front Ethernet connector does **not** support PTP.

CX27B combined with a tethered GEN series mainframe and/or other QuantumX modules




Figure 10.26: Connection of a GEN series mainframe, PC and QuantumX

Note Please make sure to use the Ethernet connector on the back of the CX27B when working with PTP synchronization as the front Ethernet connector does **not** support PTP.

10.11.2 Synchronization and network setup

When using the CX27B in a BPX002 backplane, all QuantumX units are interconnected through a FireWire bus. This means there is only one Ethernet connection, which is on the CX27B.

Note Make sure to connect the CX27B to the network.

As there can be only one FireWire synchronization master, this should be set to PTP. The CX27B needs to be set up to PTP Sync mode, all other modules should be in Auto mode.

Similar as using a single QuantumX unit, the CX27B also has an Ethernet port to connect it to the network, and also similar, this setup should be correct for the CX27B to properly operate within the network.

Because the CX27B is a transparent switch for Perception, its synchronization mode and network cannot be setup through Perception. Please use the MX Assistant to setup the CX27B network and synchronization functions.

10.11.3 Miscellaneous information

Although using the CX27B in a BPX002 backplane has some great advantages in reducing the required cabling, there are also some limitations⁽¹⁾ to be aware of when working in combination with Perception.

- **Aggregate sample rate**

Depending on the exact setup of QuantumX modules, running them at their maximum sample rate might produce more data than can be passed through the CX27B. Perception will **not** warn about this, as the CX27B is a transparent switch. Please refer to manuals and specification sheets of the exact hardware in your setup for more information.

- **Network setup**

If the CX27B is not properly configured for the network, attempting to connect to modules attached to it within Perception will show a network setup dialog. However, this will **not** try to adapt the setup of the CX27B, but of the module you are connecting to. As this will have no effect to the actual communication setup in this case, the connection will eventually fail. In this case, please use the MX Assistant to properly setup the Ethernet settings of the CX27B.

- **Using additional CX27B features**

The CX27 has a variety of additional features (such as EtherCAT[®] out) which cannot be used from Perception. However, it is possible to turn these on using the MX Assistant.

Note *These features were not tested in combination with Perception.*

- **PTP Status**

Because the CX27B only acts as a communication switch for other QuantumX modules to Perception, its PTP status is **not** read or shown by Perception. Please wait long enough to allow PTP to synchronize after turning on and configuring the system. MX Assistant maybe used to enquiry the current PTP status.

Note *It is highly recommended not to connect to the system using multiple software platforms at the same time.*

(1) While this chapter explains some limitations, the exact specification of the CX27B can be found in its data sheet which is available on the website. Specifications are not included in this manual as they might be improved with product updates over time.

A Acquisition and Storage

A.1 Introduction

Note *When you are using Perception Version 8, some of the information in this manual may be outdated. Especially the acquisition modes described in chapter "5 Acquisition Control and Status" on page 113 and appendix "A Acquisition and Storage" on page 483 have been updated in Perception Version 8. For more information on new acquisition modes, please visit the Perception product page for the document "Perception V8 Acquisition Modes Quick Start".*

Data acquisition within modern HBM Genesis HighSpeed instruments is based on the concept of a **recorder**. A recorder consists of a number of acquisition **channels** that share the same basic recording parameters: sample rate, sweep length and pre- and posttrigger length. Usually a single recorder is physically identical to a single acquisition card. Multiple recorders can be placed in a single **mainframe**. The mainframe is the housing for the recorders, provides the power and includes the interface for the local area network. A mainframe has its own network address (IP address). Within the Perception software recorders can be combined into logical **groups** for easy reference. Recorders within a group are not bound by physical mainframes.

For the sake of simplicity we will consider a single channel in this section.




Figure A.1: Simplified generic single channel data acquisition system

- A** SigCon / Amp
- B** ADC
- C** Downsampler
- D** RAM
- E** Trigger Detector
- F** Acquisition Logic
- G** Internal high speed data bus

In Perception a separation is made between acquisition and storage. **Acquisition** is the act of digitizing analog data and making it available for monitoring or storage. **Storage** is the actual archiving of digitized data. **Recording** (verb) is acquisition + storage.

A.2 Acquisition

For more information on acquisition control refer to "Acquisition control" on page 114.

This section provides the fundamental acquisition control.




Figure A.2: Acquisition control

- 1 **Status display** Shows the current status of the acquisition.
- 2 **Acquisition control** The following controls are available:

- **Preview** This button serves two purposes:
 - When no acquisition is active it will place the recorder in the pause or stand-by mode. Although the recorder is digitizing, no data is stored in memory or disk. This is useful for monitoring purposes.
 - When an acquisition is active, the button will update to **Pause** once **Record** is selected (see Figure A.3). Using the control now it will place the recorder in a hold mode: although the recorder is digitizing, no data is stored in memory or disk. At this point the **Record** button will change into **Resume** (see Figure A.4), when **Resume** is selected, the current recording continues, when **Stop** is selected, the recording is finished.




Figure A.3: Acquisition control - Record selected




Figure A.4: Acquisition control - no data in memory or disk

- **Record**
The Record command starts acquisition of data.
- **Stop**
To stop an acquisition, select this button. This stops the current recording. When in a sweep acquisition mode, the current sweep will be aborted immediately.
- **Trigger**
The button is used to send a “manual” trigger command to the recorder(s) under control.

These acquisition controls are combined with the various storage modes.

A.3 Storage

A generic data acquisition system provides two storage paths as shown in the "Introduction" on page 483 (Figure A-1):

- Store data in on-board RAM at high speed
- Transfer data directly at reduced speed to the controlling PC or (when installed) to a local disk.

In addition to these storage paths a system provides two fundamental storage modes:

- **Sweeps:** data storage of predefined length. Sweeps typically use a trigger to define the start and end of the sweep.
- **Continuous:** data storage of an undefined length. The end of this storage mode can be defined by various events, as described later.

When data is stored, this data is organized in recordings. A recording is defined as all the data that has been stored between the start of acquisition (Record command) and the end of acquisition. The end can be defined in various ways. A recording can have one or multiple sweeps, a continuous data stream or a combination of both.

In Perception, a recording is organized as a PNRF file (Perception Native Recording File).

The storage mode defines how data is digitized and saved. The continuous storage mode will store all data. The Sweep storage mode will store only the sweeps. However, the resulting file - or recording - will be different for the various storage modes.




Figure A.5: Record - Storage: Continuous




Figure A.6: Acquisition: Record - Storage: Sweeps only




Figure A.7: Acquisition: Record – Storage: Single Sweep only

The basic storage modes can be combined to create more advanced storage modes:

Dual In this mode, sweeps as well as continuous data is stored. Therefore the end result is a recording that comprises the higher speed sweeps as well as the lower speed continuous data in between the sweeps.

Slow-Fast Sweep In this mode sweep data with different sample rates are stored. The difference with the dual mode is the fact that the slower data stream is now actually a slower speed sweep, i.e. it has a predefined length and requires a trigger. The trigger position is the same as the trigger of the first high-speed sweep. The recording stops at the end of the slow sweep, without regard to the set number of fast sweeps.

A.3.1 More on sweeps

Figure A.1, as shown in the "Introduction" on page 483 is a very simplified block diagram of the general concept of a single channel digitizer. Once the analog values have been converted by the ADC into binary codes, they are stored in successive order in a buffer memory, the on-board RAM. This memory can be divided into multiple segments to allow for the storage of multiple sweeps.

If the last storage location of a segment is filled and acquisition is still taking place, the first storage location is overwritten with a new sample, followed by the second storage location, etc.




Figure A.8: Ring buffer operation of memory

- A Data storage
- B Begin
- C End

The physical memory therefore forms a ring buffer, into which information can be continuously added (Figure A.8). This process of filling the ring buffer memory terminates only when the recording logic indicates that the sweep must be ended. Once the sweep recording has stopped, the content of the buffer memory becomes available to the control PC for processing. This is also called **circular recording**. Sweep data is automatically moved from onboard RAM memory to the recording file.

A.3.2 Pre-trigger sweeps

As we have seen, data emerging from the ADC is stored in the buffer memory. When recording, the memory is continuously refreshed with new sample values, until storage is halted. The information available in the memory is a **history** of the recorded signal up to the moment of “end-of-sweep”. The extent of this history depends on the sample rate and the data storage capacity (length) of the memory. If we assume a memory length of 40 000 samples and a sample rate of 10 000 samples per second, then the time window of the history will be:

(EQ 1)

$$t_{window} = \frac{40000}{10000} = 4 \text{ seconds}$$

Storage into the ring buffer can be stopped only by a 'stop' signal from the recorder. This signal is called the "trigger".




Figure A.9: Ring buffer with trigger and end-of-recording

- A Data storage
- B Begin
- C End
- D Trigger
- E End of recording

Since the trigger stops the storage, all stored information is termed pre-trigger information. When storage stops because the acquired signal has met a trigger condition, only pre-trigger information is available - information recorded before the signal met the trigger condition.



Figure A.10: Full pre-trigger storage: pre-trigger = 100%

More often one is interested in what happened just before and after the condition was met. To achieve this aim, a delay is introduced. Once the trigger condition is met, storage is stopped - not immediately, but only after a programmable delay counter has counted out. The memory now contains pre-trigger information and posttrigger information.




Figure A.11: Pre-trigger / posttrigger storage: $0\% < \text{pre-trigger} < 100\%$

The usage of a variable delay counter allows for a user-definable pre-trigger length. The length of the pre-trigger segment equals the length of the memory segment minus the delay. When the length of the delay is equal to, or exceeds, the length of the memory segment, only posttrigger information is available.




Figure A.12: Full posttrigger storage: pre-trigger = 0%




Figure A.13: Delayed trigger storage: pre-trigger < 0%

A Delay

A.3.3 Fast sweep stretch storage



Figure A.14: A single trigger event



Figure A.15: A Second trigger initiating a sweep stretch


If a second trigger (transient event) is encountered during posttrigger data collection, the triggered sweep is automatically extended to record the second event completely including additional posttrigger data. For more information see "Advanced settings" on page 575.

A.3.4 More on continuous data storage

The most important difference between continuous data storage and sweeps in a system is the fact that sweeps are stored in on-board volatile RAM, while continuous storage takes place on the controlling PC's hard disk (or local hard disk when installed).

The continuous data storage provides four modes:

- Standard** The continuous mode is standard when storage is started and stopped manually as depicted below:



- Circular** The continuous mode is circular when storage is started and stopped manually AND the length of the buffer is defined. Operation is now similar to standard sweep storage, but storage is on PC hard disk and not in volatile memory. In this mode the lead-out is specified which is basically the same as the posttrigger segment in a swept recording.



- Stop on trigger** The continuous mode now operates like a pre-trigger sweep, but with storage on the PC hard disk, not in volatile memory.



- **Specified time** The continuous mode now stores data until the specified time has elapsed.



A.4 Time base

The power of modern data acquisition techniques is achieved by *digitizing* analog information. Digitizing is the conversion of the instantaneous value of an analog signal (static or dynamic) into a numeric value. When the signal varies, *sampling* the instantaneous amplitude at sufficiently rapid intervals converts this signal into a series of numbers that can represent the original analog signal.

A.4.1 Real-time sampling and time base

Real-time sampling is a straightforward sampling method and is the only method to record non-periodical phenomena. In this method, the intervals between the samples taken of the original signal are as short as possible and equidistant. If the sample rate used is high enough, the original signal can be reconstructed without any additional processing.

The sample rate is determined by the time base: the time base is a clock that generates pulses used to drive the A-to-D Converter. Within a system you can have the following time base options:

- **Internal time base** When you select the internal time base, the clock used to drive the ADC's is the built-in clock.
- **External time base** When you select the external time base, the clock used to drive the ADC's is the clock signal presented at the external clock input BNC on the system. When you select this mode, the interval between two consecutive samples may not be equidistant. This all depends on the accuracy of the supplied clock signal. Refer to the user manual supplied with your hardware for more details.

The above selection is made in the Settings Sheet > Recorder > Time base Source.

When internal time base is selected there can be two related options:

- **Internal Clock Base Decimal** This setting is used to create time base values that are base 10, for example 1 MHz, 100 kHz, 50 kHz, 2.5 Hz, etc. These values are derived from a main oscillator that operates at a base 10 frequency, for example 1 MHz.
- **Internal Clock Base Binary** This setting is used to create time base values that are base 2, for example 1.024 MHz, 512 kHz, 64 Hz, etc. These values are derived from a main oscillator that operates at a base 2 frequency, for example 1.024 MHz.

The above selection is made in the Settings Sheet > Mainframe > Internal Clock Base and is therefore mainframe-wide, i.e. the same for all recorders.

A binary clock base is a useful time base settings when doing FFT's (frequency domain analysis).

See image Figure A.16 for a schematic overview of the clock base selection.




Figure A.16: Clock base selection

A.4.2 Time base settings for FFT's

When doing FFTs, there are two topics that affect the acquisition:

- 1 It makes life easier when the final FFT yields spectral lines with a distance Δf that is a "nice" value. Otherwise stated: the FFT bin size should preferably be a nice value. Sometimes, this is also called the "frequency resolution". The bin size is determined by the actual frame size or frame length: **bin size** = $1 / T$ in which T is the total frame size time. E.g. a one-second frame size will result in a 1 Hz bin size, a 0.5 second frame size results in a 2 Hz bin size.
- 2 The frame size in samples should be equal to a power of two. Fundamentally, most FFT algorithms work on data sets with a length of 2^N .

The binary clock base of the internal time base in combination with the division factors allow for a broad range of values that meet both requirements. In the table below (see "Examples of FFT bin sizes" on page 497), various sample rates are given, as well as the corresponding division factor (divisor). The table shows the bin sizes that result from these sample rates in combination with various sweep lengths.

Example: from the table (see "Examples of FFT bin sizes" on page 497) you can read that a sample rate of 40.960 kHz and a frame length of 8192 samples result in a 5 Hz bin size, i.e. the spectral lines are 5 Hz from each other.

"Nice" values are considered to be "minor" values that easily fit in "major" values for (grid) display purposes.

In the table below, the values are in the colored cells and basically comprise the range 1.25, 2.5, 5, 10, 20.

Table A.1: Examples of FFT bin sizes

TIME BASE MAIN = 1.024 MHZ		FFT SIZE (FRAME LENGTHS)					
		256	512	1024	2048	4096	8192
SMP/S	DIVI-SOR	FFT BIN SIZE IN HZ					
1024000	1	4000	2000	1000	500	250	125
512000	2	2000	1000	500	250	125	62.5
256000	4	1000	500	250	125	62.5	31.25
204800	5	800	400	200	100	50	25
128000	8	500	250	125	62.5	31.25	15.625
102400	10	400	200	100	50	25	12.5
51200	20	200	100	50	25	12.5	6.25
40960	25	160	80	40	20	10	5
25600	40	100	50	25	12.5	6.25	3.125
20480	50	80	40	20	10	5	2.5
12800	80	50	25	12.5	6.25	3.125	1.5625
10240	100	40	20	10	5	2.5	1.25
5120	200	20	10	5	2.5	1.25	0.625
4096	250	16	8	4	2	1	0.5
2560	400	10	5	2.5	1.25	0.625	0.3125
2048	500	8	4	2	1	0.5	0.25
1280	800	5	2.5	1.25	0.625	0.3125	0.0156
1024	1000	4	2	1	0.5	0.25	0.125

Additional information

The Nyquist frequency ($f/2$) is the maximum frequency that can be accurately measured by a digitizer sampling at a rate of (f). Otherwise stated: a digitizer sampling at a rate of (f) cannot measure an input signal with frequency components exceeding $f/2$ without experiencing "aliasing" inaccuracies.

Nyquist's theorem determines the range of frequencies that can be measured. They range from DC to one half the sampling rate at which the data was captured. An FFT of a sweep of N points produces $N/2$ frequency domain data points within the range of frequencies between DC and the Nyquist frequency. So the frequency resolution is:

(EQ 2)

$$\Delta f = \frac{\text{samplerate} / 2}{N / 2}$$

For example, assuming that a frame has 8192 points ($N=8192$) and a sample rate has 40.96 kHz. This will yield the following:

- Frequency resolution $\Delta f = (1/2 * 40960) / (1/2 * 8192) = 5$ Hz
- Number of frequency domain points: $N/2 = 4096$
- The minimum frequency component that can be measured is equal to the frequency resolution $\Delta f = 5$ Hz
- The maximum frequency component that can be measured is $40.96 \text{ kHz} / 2 = 20.48 \text{ kHz}$

The FFT X-scale (frequency) will start at 5 Hz, end at 20480 Hz, and has 4096 points.

It is just described using Nyquist's theorem how to come to the FFT X-scale. However, because most times the analog signal passes through an anti-aliasing filter at the input, the entire frequency span is not useable. A filter has a flat response from DC to a frequency lower than the Nyquist frequency and then rolls off. No filter can make a steep transition instantly.

Therefore the frequency span is typically set to a smaller value. Usually a value of 0.390625 is chosen that is, not divide by 2 (Nyquist) but by 2.56. For the Δf calculation this has no influence: $\Delta f = \text{sample rate} / N$. Only the frequency span is smaller. In the above example $40.96 \text{ kHz} / 2.56 = 16 \text{ kHz}$.

B Digital Trigger Modes

B.1 Introduction

Within a typical HBM Genesis HighSpeed data acquisition system, each and every channel is equipped with a **trigger detector**, which makes it possible to record just the phenomenon of interest, instead of having to search the full memory to find it. The trigger detector gives the system the power to capture elusive, short and unpredictable events. It determines how easily you can extract the event of interest.

The word **trigger** has a dual meaning in recording techniques. In the passive sense, the instrument is triggered, i.e. the instrument responds to a certain stimulus. In the active sense, as in trigger point, it indicates the point (in time) where the instrument triggers an event. In both cases, trigger refers to a known, pre-defined situation.

The trigger can be generated in several ways:

- by the user, i.e. **manually**
- using an externally applied signal, i.e. **external** trigger
- when the acquired **signal** complies with a certain condition: the trigger condition. Each channel within a recorder can trigger this recorder.

For transient recording the third option is of great importance. The trigger facilities determine to a large extent the application capabilities of the data acquisition system – i.e. how effectively the data can be captured.

In this chapter the trigger capabilities of HBM Genesis HighSpeed data acquisition systems and the Perception support will be explained in full detail.

Each channel within a recorder can trigger this recorder. This functionality is realized by combining all channel triggers into a logical OR combination. When one of the channels (or multiple channels) generates a trigger, the complete recorder triggers. Each channel's trigger detector can be switched off or set to one of the modes described in this chapter.

Note *This chapter describes all GEN series trigger options. However, not every acquisition card will support each described option. Check the specifications of each acquisition card to find out what options are supported for this specific card.*




Figure B.1: Channel triggers combined

- A Channel 1
- B Channel n
- C Channel x
- D Recorder Trigger

B.2 Understanding digital triggering

Technically speaking, there are two approaches to determine the known, pre-defined situation of the signal: analog or digital.

Each channel in the GEN series system is equipped with a digital trigger detector. Digital triggering has the benefit of stable vertical reference levels, no horizontal jitter, and not depending on signal frequency.

A disadvantage of a digital trigger detector is its inability to detect events that occur between two consecutive samples. This does not usually interfere with normal operation because the event is not recorded anyway.

B.2.1 Digital trigger detector

Figure B.2 shows a simplified diagram of a **single-level** digital trigger detector. Digitized values coming from the ADC are fed into an Arithmetic (and) Logic Unit – ALU. The value that comes out of the ALU is then referenced against a preset value (trigger level). The result can be either positive, i.e. the value is larger, or negative, i.e. the value is smaller. Based on this information the level crossing detector verifies if a level crossing in the correct direction has occurred and if so, sends out a trigger.




Figure B.2: Single-level trigger detector

- A ADC DATA
- B ALU
- C Level crossing detect
- D Trigger
- E DELAY
- F Compare value

The delay register in front of the ALU is used to compare the ADC value with “older” values. This means that triggering does not react to specific levels, but to the differential signal or **slope**.

As explained later in this chapter, a signal must actually cross the preset level. This is to avoid erroneous triggering due to a small amount of noise on the signal. To make the trigger detector even more stable when noisy signals are used, the single-level trigger detector has been expanded with a **hysteresis**. After the level detector signals a level crossing, a new level crossing will only be signaled if the input signal first goes outside the hysteresis band and then returns to the trigger level.

For the advanced trigger modes, the single-level trigger detector with programmable hysteresis has been implemented twice to provide a **dual-level** trigger detector. Levels are usually referenced as *primary* trigger level and *secondary* trigger level.

B.2.2 Valid trigger conditions

Trigger detection is based on level crossing: A signal has to cross a specified level to be considered a trigger condition. As a consequence, reaching the required level is not a valid trigger condition. Since trigger detection is digital, inter-sample analog values are omitted.

In the following graphs these conditions are shown.




Figure B.3: Level crossing detector

- A Trigger
- T Trigger level
- Sample
- Last sample before trigger
- Trigger

Figure B.3 shows the basic trigger mode with a specified level (**T**) and a level crossing in positive direction. In Figure B.3 **A** the trigger occurs on the first sample after the level crossing. Figure B.3 **B** shows the situation in which a sample equals the specified level. Trigger does not occur until a sample is actually above the specified level.

Since the trigger detector requires a level crossing, no trigger occurs when a signal is above the set level when recording starts. This is depicted in Figure B.3 C.

Figure B.4 shows the influence of the hysteresis. The difference is that a second level (H) is used to “arm” the level trigger detector. In other words, the trigger level has been expanded to be a trigger zone that spans multiple levels.




Figure B.4: Trigger level hysteresis

- A Trigger
- T Trigger level
- H Hysteresis level
- Sample
- Trigger
- Set hysteresis
- Reset hysteresis

B.3 Trigger modes

Using the various trigger modes, your data acquisition system is expanded to an extremely versatile transient recorder. The trigger circuits may be configured to trigger on many types of phenomena. In this section the different trigger modes and their extensions are discussed in detail.

B.3.1 Basic trigger mode

The basic trigger mode can be compared to the trigger mode available when using an analog trigger detector, for example as found on a classic scope.




Figure B.5: Basic trigger mode

A Trigger

In this mode, a single-level trigger detector is active, the primary level. As mentioned previously, the signal needs to actually cross the preset level. Both the level and direction of crossing can be selected.

Relevant settings for this mode:

- Mode: basic
- Primary level: any value within the input range
- Direction: positive or negative
- Hysteresis: any relevant value

B.3.2 Dual trigger mode

In dual trigger mode two detectors are active and working simultaneously: the primary level **P** and the secondary level **S**. With two levels, it is possible to define a range that the input signal must be within. As soon as the signal becomes larger than the upper level or smaller than the lower level, the detector generates a trigger. By inverting the slopes of both detectors, the trigger is generated when the signal returns into the specified range.

Figure B.6 shows the various possibilities.




Figure B.6: Dual trigger mode

A Trigger

Any value for each level and the slope of the primary level can be selected. The slope of the secondary level is automatically set to the opposite direction.

Diagrams **1** and **3** show a signal that exits the range. Diagrams **2** and **4** show signals that enter the range.

Relevant settings for this mode:

- Mode: dual
- Primary level: any value within the input range
- Secondary level: any value within the input range
- Direction: positive or negative for primary level; secondary level is automatically set to the opposite direction
- Hysteresis: any relevant value is used for both levels.

B.3.3 Window trigger mode

For the window trigger mode, both levels are used. One of the levels has a dual function, arm and trigger. The other level is used as a disarm level. To generate a trigger, the trigger detector must be armed. This is done by crossing the arm/trigger level in the opposite direction. Once armed, the trigger is generated by crossing the arm/trigger level in the set direction, unless the disarm level has been crossed after the arm level has been.




Figure B.7: Window trigger mode

A Trigger

Diagrams **1** and **3** show the intended use of the window trigger mode, detecting a dip in a repetitive signal. Diagrams **2** and **4** show alternatives, detecting a peak pulse in a repetitive signal.

The window trigger mode is very useful if a periodic signal is monitored and the system must be triggered on peak level changes. This mode is most effective on uni-polar signals, for example a TTL level pulse train. For bi-polar signals the dual-window trigger mode is more suitable as described in the following section.

Relevant settings for this mode:

- Mode: window
- Primary level: any value within the input range
- Secondary level: any value within the input range
- Direction: positive or negative for primary level; secondary level is automatically set to the opposite direction
- Hysteresis: any relevant value is used for both levels.

B.3.4 Dual-window trigger mode

The dual-window trigger mode is a more sophisticated version of the window trigger mode. Now both levels are used as an arm/trigger/disarm level. This allows the trigger detector to react to a dip in both directions.




Figure B.8: Dual-window trigger mode

A Trigger

Diagram 1 shows one situation, whereas Diagram 2 shows the other situation with the same settings. In this mode, the following conditions determine the trigger result:

- Level crossing in opposite set direction = arm level
- Level crossing in set direction = disarm when other level is armed
- Level crossing in set direction = trigger when level is armed

Since this is true for both levels, a “dip” in both directions is detected, as shown in Diagrams 1 and 2 (see Figure B.8).

Relevant settings for this mode:

- Mode: dual-window
- Primary level: any value within the input range
- Secondary level: any value within the input range
- Direction: positive or negative for primary level; secondary level is automatically set to the opposite direction
- Hysteresis: any relevant value is used for both levels.

B.3.5 Sequential trigger mode

The two level comparators are set in a sequence in this mode. One is used to arm the trigger detector while the other one is used to actually generate the trigger. If the incoming signal crosses the level of the first comparator, the second is activated (armed).




Figure B.9: Sequential trigger mode

A Trigger

This mode can be used to help eliminate false triggering due to noise or hysteresis. The concept is sometimes also referred to as a sensitivity window.

Although not very common, you can also set the level of the primary detector to a value lower than the secondary detector. This will give you the options shown in diagrams 3 and 4 (see Figure B.9).

Relevant settings for this mode:

- Mode: sequential
- Primary level: any value within the input range
- Secondary level: any value within the input range
- Direction: positive or negative for primary level; secondary level is automatically set to the opposite direction
- Hysteresis: any relevant value is used for both levels.

B.3.6 Trigger qualifier

The trigger detectors of a channel can also be used as a qualifier. A trigger qualifier is a situation that enables (arms) the recorder trigger features. The recorder trigger features are a combination of various channel, external, between-recorders and other trigger options.

There are two qualifier modes:

- Basic single-level qualifier. Level detector operates identical to "Basic trigger mode" on page 505
- Dual-level qualifier. Level detector operates identical to "Dual trigger mode" on page 506.

When in qualifier mode, the output of the trigger detector is sent to a qualifier line of the recorder trigger logic. For a full description of the recorder trigger features see "Recorder and system trigger" on page 519.

B.4 Trigger add-ons

The trigger modes mentioned can be combined with a variety of extra features, allowing triggers on almost any signal.

Some of these extra features are used to fine-tune the selected trigger mode. Other extra features expand the capabilities of the basic trigger detector.

The following simplified diagram is from the settings sheet and shows the building blocks that make the complete channel trigger logic.




Figure B.10: Channel trigger logic

A To recorder trigger

From left to right, the following add-ons are available:

- **Slope** detector: allows to trigger on a slope instead of level
- **Pulse** qualifier: detects or rejects trigger conditions that meet a specific time frame
- **Hold off:** disables the trigger detector for a set period of time after a trigger condition
- **Interval:** defines a time interval between two consecutive trigger conditions
- **Events:** counts the number of trigger conditions before an actual trigger is generated

B.4.1 Slope detector

All trigger functions described so far work on the absolute level of the incoming signal. The slope detector allows the same functions to work on the *difference* between samples. This means that the triggering does not react to specific levels, but to the differentiated signal or slope. The slope detector is also known as differentiator or dY/dt detector. The output of the slope detector is the difference between the newest sample and the sample that was recorded the given number of sample intervals ago.




Figure B.11: Slope trigger

- A Trigger
- B Original signal
- C Differentiated signal

With the slope triggering, it is possible to trigger on a specific change in slope of the signal, for example on a spike on a repetitive signal. If the slope (or frequency) of the signal exceeds the specified level, a trigger is generated.

B.4.2 Pulse detector

The pulse detector can be used together with the basic (slope) trigger level detector. It can be used for two opposite purposes:

- Detect trigger conditions smaller than a set period of time: **pulse detect**
- Detect trigger conditions larger than a set period of time: **pulse reject**

All operations of the trigger detector are the result of crossing the level of a comparator.

Pulse detect

If, after crossing, the condition of the comparator is **NOT** stable for the specified period of time, the crossing is a valid trigger condition, i.e. it is a short pulse (or noise), and a trigger is generated.

Pulse reject

If, after crossing, the condition of the comparator is stable for at least a specified period of time, the crossing is a valid trigger condition, i.e. it is a long enough pulse that must be recorded, and a trigger is generated.

The pulse detector operates on samples. In the Perception software, this is translated into time.




Figure B.12: Pulse detect/reject methods

A Trigger

B Width

Figure B.12: In Diagrams **1** and **2**, the pulse detection is depicted. In Diagram **1**, when the trigger level is crossed, the signal remains above the trigger level for a time interval larger than pulse width **W**. In Diagram **2**, there is a situation in which the signal returns through the trigger level within pulse width **W**. A trigger is generated on a “small” pulse.

In Diagrams **3** and **4**, the opposite situation is depicted, pulse reject. Now “small” pulses are not recognized as trigger condition, while a wider pulse generates a trigger.

The pulse detector can be used for both trigger levels. Combined with a hysteresis setting, the pulse detector is less sensitive to noise on the signal.

B.4.3 Holdoff

The trigger hold off feature is used to disable the trigger detector for a period of time after a trigger condition has been met.

This can be used to generate only one trigger on a slowly decaying repetitive signal, or to eliminate the effect of after-ringing. Using a 16 bit counter, triggering can be disabled for as long as 6.5535 seconds when sampling at 10 kS/s.




Figure B.13: Trigger hold off

A Trigger

B Hold off

The feature is most useful in combination with the interval timer and/or the event counter.

B.4.4 Interval timer

A highly sophisticated trigger add-on is the interval timer. The interval timer is used to define a time relation between two trigger events. When the time relation is correct, a trigger is generated.

The following relations are possible:

- **Less:** The time interval between two consecutive trigger events is less than the specified time interval.
- **More:** The time interval between two consecutive trigger events is more than the specified time interval.
- **Between:** The time of the second trigger event is within a specified time interval that starts a specified time after the first trigger event.
- **NotBetween:** The time of the second trigger event is not within a specified time interval that starts a specified time after the first trigger event.

The interval timer operates on samples (2 to 65535). In the Perception software, this is translated into time. At 1 MS/s sample rate, this results in a maximum of 65.535 millisecond.

Interval timer - Less

This interval time mode is fairly straightforward. When the second trigger event is within the set time interval, a trigger is generated.




Figure B.14: Interval timer - Less

A Trigger

B Interval

The time interval is reset on the first new trigger event. For example, this feature allows additional pulses to be detected in a standard train of pulses.

Interval timer - More

This interval timer mode is more complicated. When the second trigger event is within the set time interval, no trigger is generated and the time interval is reset on each trigger event. When a new trigger event occurs after the specified time interval, i.e. the interval is not reset in time, then a trigger is generated at the end of the specified time interval.

The reset moments are denoted with a dotted line and the actual trigger moment is denoted with a straight line.




Figure B.15: Interval timer - More

A Trigger

B Interval

For example, this function allows a "missing" pulse to be detected in a standard pulse train.

Interval timer - Between

For the Between mode, basically two timers are used: one to set the start of a time window and a second one to set the width of the time window. The second trigger event must be within this time window.




Figure B.16: Interval timer - Between

The following sequence explains what happens:

- 1 The first trigger event starts Interval Timer 1.
 - 2 A second trigger event occurs before Interval Timer 1 has expired and the timer is reset.
 - 3 A third trigger event occurs before Interval Timer 1 has expired and the timer is reset.
 - 4 Interval 1
 - 5 Interval Timer 1 expires and Interval Timer 2 is started.
 - 6 Interval 2
 - 7 Interval Timer 2 expires while no trigger event occurred within the set period. The complete trigger logic is reset.
 - 8 The first new trigger event starts Interval Timer 1.
 - 9 A second trigger event occurs before Interval Timer 1 has expired and the timer is reset.
 - 10 Interval Timer 1 expires and Interval Timer 2 is started.
 - 11 A trigger event occurs before Interval Timer 2 expires and a trigger is generated.
- A** Trigger

The first interval timer can be compared to the trigger hold off feature described above. The second interval timer defines a period in which a trigger event must occur. If not, it is not a related trigger event.

Interval timer - NotBetween

The inverse function of the Between mode of the interval timer is the NotBetween mode. The second interval is not used to define a trigger-safe area, but to denote a trigger-restricted area. A trigger event within the first interval is valid. A trigger event within the second interval resets the trigger logic. A trigger is also generated when both interval timers expire. A typical use of this mode is to detect changes in the interval between pulses ("too early" / "too late" detection).




Figure B.17: Interval timer - NotBetween

The following sequence explains how this mode functions:

- 1 The first trigger event starts Interval Timer 1.
 - 2 Interval 1
 - 3 If a trigger event occurs within the first interval, a trigger is generated.
 - 4 End of sweep.
 - 5 The first new trigger event starts Interval Timer 1.
 - 6 Interval Timer 1 expires and Interval Timer 2 is started.
 - 7 A trigger event occurs within the second interval. Interval Timer 1 is restarted.
 - 8 Interval 2
 - 9 Interval Timer 1 expires and Interval Timer 2 is started.
 - 10 Interval Timer 2 expires and a trigger is generated.
- A Trigger

B.4.5 Event counter

Sometimes it is not possible to trigger on a specified condition using a selected trigger mode alone, because several events meet the required situation. So far, we have seen “filters” that can be used to narrow the range of trigger candidates, like hold off and interval timer.

As a last resource, the event counter can be used. The event counter counts all channel triggers that have been detected and generates a system trigger when the count equals a user defined value.

B.5 Recorder and system trigger

The trigger modes and features described so far are channel-based. Each analog channel within a GEN series system has a digital trigger detector. The trigger signals of all channels of a single recorder are combined through a logical OR to generate a combined trigger. This trigger can be combined with an external trigger and qualifiers. The final result is a recorder trigger. The triggers that are generated by individual recorders can be distributed to other recorders and mainframes.

The following simplified diagram is from the Perception software and shows the building blocks that make the complete recorder trigger logic. Please note that not all features may be available depending on the exact hardware used.




Figure B.18: Recorder trigger logic

The heart of the recorder trigger logic is the “Combine” block. Here all trigger sources come together and, depending on their setting, can generate a recorder trigger. This can be blocked, however, by qualifiers: If one of the qualifiers is not armed, no recorder trigger can be generated.

- **Channel 1 through N:** These are the channel triggers as described earlier. Refer to Figure B.1 “Channel triggers combined” on page 500 for a more accurate diagram.
- **External Trigger In:** This is an external trigger signal that is mainframe-related: The input connector is placed on the mainframe controller. You can select to use it on rising or falling edge, all input cards in the mainframe will use the same edge. Each input card can select to use the external trigger as a trigger source or not.
- **Qualifier 1 through N:** These are the qualifiers as described earlier: See “Trigger qualifier” on page 510.

- **External Trigger Out:** The recorder trigger can be used to send a trigger signal to the outside world. The output connector is placed on the mainframe controller. You can select to use it on active High or Low level output, all input cards in the mainframe will use the same output level. Each input card can select to send the trigger to the external trigger output or not.
- **Internal Trigger Line 1 through 3:** There are three internal trigger lines. These are used to transfer recorder triggers from one recorder to another. Each recorder can select to set its recorder trigger on one or more lines. It can also pick up a trigger from one or more lines.
- **Master/Sync:** Multiple mainframes can be synchronized by using the Master/Sync module. When in use, a recorder can put the recorder trigger on the Master/Sync trigger line and/or pick up the trigger from the Master/Sync trigger line. When Master/Sync operation is not used, this line functions just like the other three trigger lines. Depending on the hardware capabilities of the Master/Sync module, trigger line 3 can also be used to synchronize triggers between mainframes.

B.6 Channel alarm

Each channel has the capability to generate an alarm. An alarm situation is detected with a basic dual level detector.

There are two alarm modes:

- Basic single-level alarm. The alarm line is active as long as the signal exceeds the level in the specified direction. For details on the level comparator see "Basic trigger mode" on page 505.
- Dual-level alarm. The alarm line is active as long as the signal exceeds one of the two levels in the specified direction. For details on the level comparators see "Dual trigger mode" on page 506.

The output of the alarm detector is sent to an alarm line and combined (OR-ed) with alarm conditions of the other channels and recorders. The result is available as an external output located on the mainframe controller.

C Offline Setup & Configuration Manager

C.1 Introduction

The offline setup mode in Perception allows you to create and setup your experiment, based on the hardware you have, without actually being connected to that hardware. You can modify hardware settings, create formulas and reports all based on the hardware you have and save this as a virtual workbench. When you are connected to your hardware you can load this workbench and you are up and running.

The offline setup is based on two components:

- The Configuration Manager.
- The Perception offline setup mode.

The **Configuration Manager** is an additional program that acts as if it is actual hardware. The “hardware” can be configured.

The **Perception offline setup mode** is a program mode that allows you to communicate with the “simulated” hardware in the Configuration Manager instead of the actual hardware. Perception ‘knows’ it is in offline mode and will make the required communication changes accordingly without influencing the normal operation of the software.

The hardware configuration for use with this mode is stored:

- automatically with each experiment when starting a recording as part of the .pnrf file,
- when saving a Virtual Workbench as part of the .pVWB file,
- manually when required in an **.pOfflineConfig** file.

Although the file is created from within Perception, the file itself is not used by Perception. When required Perception uses information stored in the settings sheet.

The offline setup mode / Configuration Manager:

- does not allow you to make recordings,
- does not allow you to load recordings,
- supports most of the GEN DAQ products configurations.

Note *The offline configuration file is an exact copy of your hardware, including mainframe capabilities, options, cards installed, IP address, etc. It is therefore unique to a specific setup. Not all hardware* is supported within offline setup, so some of the hardware* may not be shown in offline mode.*

** Hardware used, depending on the Perception version.*

C.2 Creating offline configuration information

As mentioned earlier, offline configuration information is created automatically when saving experiments and virtual workbenches.

To save offline configuration information in a blank PNRF file:

- 1 Open a new experiment, see "Set up new blank experiment" on page 334.
- 2 Connect to hardware, see "Add and remove a data acquisition system" on page 82.
- 3 Make a recording.
- 4 Save the experiment, see "Save" on page 339.

You can save the offline configuration any time in a separate file.

To save the configuration for offline use:

- 1 Do one of the following:
 - Select **File ► Save Configuration for Offline Use...**
 - In the **Hardware Navigator** do a right-click to call up the context menu. In the **context menu** click **Save Configuration for Offline Use...**
- 2 In the Save Offline Configuration dialog that comes up select the file you want to save into/ replace or type a name for a new file.
- 3 Click **Save**.

Once you have saved a configuration you can use it together with the Configuration Manager.

C.3 Configuration Manager

The Configuration Manager is a separate application.

To start the Configuration Manager:

- Choose **Start ► All Programs ► HBM ► Perception ► Configuration Manager**.
- *The application will start with an empty work area.*

Before you can start using the application you must load a saved configuration file.

To open a saved configuration:

- 1 In the **File menu** click **Open...**
- 2 In the Open Offline Configuration File dialog that comes up select your file type if required:
 - Configuration file *.pOfflineConfig
 - Virtual Workbench *.pVWB
 - Experiment *.pnrf
- 3 Select the file you want to load.
- 4 Click **Open**.




Figure C.1: Configuration Manager - example

- A Menus** The menus in the menu bar contain commands for performing tasks.
- B Mainframe** You can have multiple mainframes in a configuration. Both Tower and 19" rack mainframes are supported.
- C Power button** The power button can be used to switch on/off the mainframe.
- D Master/Sync card** Actual position of this card depends on mainframe type.
- E Interface card** The interface card includes the actual installed options like GPS, IRIG, SCSI interface when installed.
- F Empty slot** Slot(s) not occupied by interface or acquisition cards.
- G Acquisition cards** The acquisition cards represent the actual installed cards. When you hover with the mouse over a card, a tooltip comes up with a short description of the installed card.
- H Work area** Empty area for mainframes.
- I Title bar [mainframe name]** Indicates the currently selected mainframe.
- J Close button** Mainframe remove button.
- K Title bar [file name]** Name of the offline configuration file.

C.3.1 Moving mainframes

Within an offline configuration there can be one or more mainframes. You can remove, import and export mainframes and save (new) configuration files.

To save a configuration file:

- 1 In the **File menu** click **Save As...**
- 2 In the Save Offline Configuration File dialog that comes up select the file you want to replace or type a name for a new file.
- 3 Click **Save**.

Various commands operate on the currently selected mainframe.

To select or deselect a mainframe:

To select or deselect a mainframe do one of the following:

- Click on the mainframe you want to select.
- Click the **Mainframe menu**. In the menu that comes up click the mainframe name. The selected mainframe is denoted with a check mark.

You can remove a mainframe from the current configuration to create a new configuration.

To remove a mainframe:

- Select **File ► Remove Mainframe**.
- Click the mainframe **Close** button.

You can import individual mainframes from other configuration files to create a custom configuration without the need to be connected to real hardware.

To import a mainframe:

- 1 Select **File > Import Mainframe...**
- 2 In the Import Offline Configuration File dialog that comes up select the file you want to import.
- 3 Click **Open**.

You can also export individual mainframes into a configuration file for later use.

To export a single mainframe:

- 1 Select the mainframe you want to export.
- 2 Select **File ► Export Mainframe....**
- 3 In the Export Offline Configuration File dialog that comes up select the file you want to replace or type a name for a new file.
- 4 Click **Save**.

C.3.2 Using mainframes

You can use mainframe(s) by switching on the power.

To switch on the power of a mainframe:

Do one of the following:

- Click the **power button** on the mainframe.
- Select **Power ► Power On All** to switch on the power of all mainframes.
- Select **Power ► Power On ►** . In the sub menu that comes up select the individual mainframe you want to switch on.

After switching on a mainframe, the mainframe display will show start up messages.

To switch off the power of a mainframe:

Do one of the following:

- Click the **power button** on the mainframe that is on.
- Select **Power ► Power Off All** to switch off the power of all mainframes.
- Select **Power ► Power Off ►** . In the sub menu that comes up select the individual mainframe you want to switch off.

C.3.3 Miscellaneous configuration commands

To open a recently used file:

- Select **File** ► **Recent opened files** ► . In the submenu that comes up select the file you want to use.

To exit the Configuration Manager:

- Select **File** ► **Exit** to quit the application.

For more information:

- Select **Help** ► **About** to see additional information about the application.
 - Click the **More...** button to get a list of installed software modules and their version number.

C.4 Perception offline setup mode

To start Perception in offline mode:

- Choose **Start ► All Programs ► HBM ► Perception ► Perception Offline**.

Once Perception is started, the offline setup mode is also noted in the right-hand corner of the status bar at the bottom of the application:




Figure C.2: Status bar (detail)

C.4.1 Using the offline setup mode

To use the Perception offline setup mode you must:

- Start Perception in offline setup mode as described in the previous section.
- Start the Configuration Manager with the correct setup as described in "Configuration Manager" on page 525.
- Switch on the mainframes as described in "Using mainframes" on page 528.

At this point you can operate Perception as usual: create display setups, reports, modify settings, etc., and save all this as a Virtual Workbench.

When you are not in offline setup mode you can use this Virtual Workbench for normal operation: it will connect to the actual hardware as usual with all the settings and modifications you have made earlier to this workbench.

To load a mainframe in offline setup mode:

To load a mainframe when in offline setup mode from the Configuration Manager:

- 1 Start the Configuration Manager with the correct setup as described in "Configuration Manager" on page 525.
- 2 Switch on the mainframes as described in "Using mainframes" on page 528.

- 3 In Perception call up the Hardware Navigator. Because you are in offline setup mode, only hardware that is available through the Configuration Manager is displayed in a new tree "Offline Hardware":




Figure C.3: Hardware navigator

- 4 Proceed as usual (refer to "Add and remove a data acquisition system" on page 82 for details).

C.5 Hints, tips and techniques

This section gives additional information on the Perception offline setup mode.

C.5.1 Limitations

When using the offline mode you cannot:

- use real hardware,
- make actual recordings,
- open recordings.

Note *Not all hardware is usable in the offline configuration tool. Below is a list of hardware that will typically work when using offline configuration:*

Mainframes:

- GEN7t Transient Recorder and Data Acquisition System
- GEN16t Transient Recorder and Data Acquisition System
- GEN5i Portable Data Recorder
- GEN2i Portable Data Recorder

Note *If the mainframe has an IM2 module, some mainframe features will not show up in the offline configurator.*

Acquisition cards:

- 1-GN410-2 GEN series GN410 Bridge ISO 200 kS/s Input Card
- 1-GN411-2 GEN series GN411 Bridge ISO 1 MS/s Input Card
- 1-GN412-2 GEN series GN412 Differential 100 MS/s Input Card
- 1-GN413-2 GEN series GN413 Differential 25 MS/s Input Card
- 1-GN440-2 GEN series GN440 Universal ISO 200 kS/s Input Card
- 1-GN441-2 GEN series GN441 Universal ISO 1 MS/s Input Card
- 1-GN810-2 GEN series GN810 Basic 200 kS/s Input Card
- 1-GN811-2 GEN series GN811 Basic 1 MS/s Input Card
- 1-GN812-2 GEN series GN812 Basic ISO 1 MS/s Input Card
- 1-GN813-2 GEN series GN813 Basic XT ISO 1 MS/s Input Card
- 1-GN814-2 GEN series GN814 Basic XT ISO 200kS/s Input Card
- 1-GN1610 GEN series GN1610 Basic/IEPE/Charge 250 kS/s 16 channel Input Card
- 1-GN3210 GEN series GN3210 Basic/IEPE/Charge 250 kS/s 32 channel Input Card

- 1-GN3211 GEN series GN3211 Basic/IEPE/Charge 20 kS/s 32 channel Input Card
- 1-GN4070-2 GEN series GN4070 Binary marker HV Input Card
- 1-GN6470-2 GEN series GN6470 Binary Marker Input Card

C.5.2 Perception without a key

The Perception software requires a HASP key. HASP (Hardware Against Software Piracy) is a hardware-based (hardware key) software copy protection system that prevents unauthorized use of software applications. You must have the HASP@4 USB Token installed in a USB port before you can run the software.

However, you can use Perception without a key in offline setup mode. When you start Perception without a key automatically the software is launched in offline setup mode and you can use it to create Virtual Workbenches based on a loaded configuration file in the Configuration Manager.

D Settings Sheet Reference

D.1 Settings Sheet – Introduction

The **settings sheet** provides a spreadsheet-style user interface combined with graphical user interface elements to access all hardware-related settings. If a hardware setting cannot be found here, it does not exist.

The settings sheet uses two important concepts:

- 1 It shows only those settings that are physically available to you with the currently connected hardware.
- 2 By itself the settings sheet does not have “intelligence”. All capabilities and settings are “fetched” from the hardware. When a modification is made, the modification is sent to the firmware that controls the hardware, verified, maybe modified by the firmware to comply with physical limits, and sent back to the software. This concept allows for connection of a great variety of hardware. Also new hardware, now and in the future, can be connected to the software without software modifications or installation of additional software modules.

The layout of the settings sheet is designed to provide an efficient interface that allows for quick modification of hardware settings of the connected acquisition systems. Features are implemented to modify settings of large systems equally simple as those of smaller systems.

On the left-hand side of the settings sheet there is a task pane. In this task pane the settings are combined into logical groups for easy reference. Use this task pane as a “table of contents” to select a specific settings section, for example the input settings of all basic channels.

The actual settings matrix is based on channel/recorder/group rows and setting columns:

- Each column provides access to a single setting.
- Each row represents a channel:
 - Channels can be combined into a recorder.
 - Recorders can be combined into groups.

Modifications made on a certain level are applied to all lower levels, for example a settings change in a recorder row will affect all channels of this recorder. You can select if you want to use the groups and recorder levels. For more details on how to use the settings sheet refer to the appropriate section in the manual. This part of the manual focuses on the details of the specific settings.

Important: Please note that all available settings within all supported hardware components are listed here, although not all may apply to your situation.

D.1.1 Conventions

Throughout this section of the manual, text written in **bold** refers to topics that you can find by that name in the settings sheet. Text written in *italics* refers to an actual setting. Example: You can set the **Sync source** in the **Mainframe** section to *RTC*, *GPS* or *IRIG*.

If a setting is Read-Only, you cannot modify this setting. This is indicated by an (RO) note after the name of the setting. Example: Type (RO).

As mentioned in section "Settings Sheet Layout", the settings sheet has two viewing modes: basic and advanced. In this section the basic settings are described first, followed by the advanced settings if available.

D.2 General group

D.2.1 Introduction

The **General** group within the settings sheet comprises global settings and selections of the connected hardware. Here you can find common settings related to **mainframes** and **recorders**. In addition, general channel settings are located here. These types of settings include channel type information, usage and channel mode settings.

D.2.2 Mainframe

Introduction

A **mainframe** is a physical housing that provides the power, holds an interface unit for communication and data transfer, one or more acquisition cards and miscellaneous hardware. Typically an acquisition card holds one **recorder**. Communication is performed through a local area network. A mainframe has its own network address (IP address).

For each mainframe in your data acquisition system you typically set up the logical name, timing and synchronization constraints as well as communication parameters.

Detailed timing settings can be found in the **Mainframe** section of the **Memory and Time base** group (on page 574).

Basic settings

External trigger in direction



Summary

Sets the edge sensitivity of the external trigger input.

Description

If **External trigger in** is enabled, this setting generates a trigger on the recorder whenever the external trigger signal has the specified direction.

External trigger out



Summary

Sends the internal recorder trigger to the external trigger output on the mainframe.

Description

The recorder's trigger detector output is directed to the mainframe's external trigger output connector.

Although this is a per-recorder setting, there is only one external trigger output for the complete mainframe. Each individual recorder can be set to produce an external output trigger.

However, a level setting (if provided by the hardware) is mainframe-wide and cannot be set on a per-recorder basis.

Name



Summary

Logical name of mainframe.

Description

This is the name of the mainframe as used throughout Perception . It is not the "physical" or "network" name of the mainframe that identifies it on the network. Editing the network name is possible from the mainframe, please refer to your hardware manual for more information on how to do this.

The logical name is also used in hardware-related data sources such as fan speeds, temperatures and similar information. These data sources may be used in features such as system monitoring, reporting or formula database.

You can also find the name setting in the hardware tree where it identifies your hardware.

Storage location



Summary

Storage location for streaming data.

Description

The storage location indicates the physical location where recording data will be stored. When choosing mainframe storage the recording data will be stored to a device physically attached to or inside the mainframe such as a SCSI disk or memory card. PC storage will record data to the PC hard drive or a network location. To find out how to configure the exact location on the network or hard drive please refer to the appropriate section of this manual.

Sync source



Summary

Defines the source used for the actual time synchronization in a mainframe.

Description

The synchronization source is used to synchronize recordings within recordings with the mainframe. The internal clock (RTC) of a system is synchronized with the PC time every time Perception connects to the system. Time Zone Correction is also applied. This correction is added to the source's UTC time when "local time" is requested.

When working with multiple mainframes, the internal clocks of the mainframes may differ. Even if initially set accurately, real clocks will differ after some time due to clock drift, caused by clocks counting time at slightly different rates. To solve this issue in a multiple mainframe setup, it is possible to use global synchronization sources like IRIG and GPS.

The most common synchronization sources are *RTC* (internal clock), *IRIG*, *GPS* and *PTP*.

For detailed information on IRIG, GPS and PTP consult your hardware manual.

Master/Sync mode



Summary

Defines the system's role in a Master/Sync configuration.

Description

Defines whether or not the system is part of a Master/Sync configuration and if yes, which role it has in this setup.

Master/Sync is a model for a communication protocol where one system has unidirectional control over one or more other systems. Once a Master/Sync relationship between systems is established, the direction of control is always from the master to the slaves.

The most common modes are *Master*, *Sync* and *Stand-Alone*.

For details on Master/Sync operation refer to the separate manual that came with your Master/Sync hardware option.

Advanced settings

Auto charge



Summary

When turned ON the battery will be charged when connected to the main power supply.

Description

If the main power supply is connected to the system and the Auto Charge option is turned ON, the system will automatically charge the battery/batteries until full. When full the system will perform trickle charging to keep the battery/batteries full.

Auto power



Summary

When turned ON the system will switch to main power supply when connected.

Description

When the Auto Power option is turned ON and the main power supply is connected to the system, the system will run on the power directly received from the connected external power supply instead of the internal power supply (battery).

External Trigger In Minimum Pulse Width



Summary

Filter spikes from digital signals.

External Trigger In Minimum Pulse Width



Description

The minimum pulse width can be used to filter the input signal from high-frequency noise. If the input has some noises/signals which contain higher frequencies (or shorter pulse widths) than the used filter time, the system filters out these values.

The best filter time setting is application dependent if the test environment introduces signal spikes on the measurement though electrical or magnetic disturbances AND the pulses that should be detected are wide enough. The noise can be filtered out by selecting a filter time value larger than the typical spike width but shorter than the expected valid pulse width.

For example, if a 1 kHz signal with 100 kHz noise is applied, adjusting the filter time to 10 μs is the best choice.

The default setting is 0.5 μs . This will basically not filter based on pulse width.

The table below shows the different characteristics for each setting of the input filter.

Selections	
Filter Time (μs) ¹	Min detected pulse width (μs) ¹
0.5	> 0.40
1	> 0.90
2	> 1.90
5	> 4.90
10	> 9.90

(1) The character of the setting is shown in the table. According to the table, if the filter time is set on 1 μs , the input signal with the pulse width of 0.8 μs cannot be detected. However, there is a tolerance on the setting so for example, the input signal with the pulse width of 0.95 μs (or larger than 0.91 μs) can be detected. This is illustrated below.




Figure D.1: Pulse width settings

Alarm out



Summary

Sets the function of the alarm output on the mainframe.

Description

Each channel has the capability of generating an alarm. The output of a channel's alarm detector is sent to an alarm line and combined (OR-ed) with alarm conditions of the other channels and recorders. The result is available as an external output located on the mainframe controller.

This setting can have one of the values *Alarm High Level*, *Alarm Low Level*, or *Recording High Level*. When *Recording High Level* is selected, the output connector on the controller is high when a recording is in process. When *Alarm High Level* is selected, the output is high when channel alarm detectors activate on the alarm line. When *Alarm Low Level* is selected, the output is low when the alarm line level is active; the signal is therefore the inverse of the previous setting.

Trigger Out delay



Summary

The delay between the actual trigger event and the pulse on the External Trigger output can be controlled by means of the Trigger Delay setting.

Trigger Out delay



Description

This value defaults to 516 μ s for compatibility reasons. Reducing the delay is especially useful when the External Trigger output controls external equipment like a high-speed camera.

Note Use the lower case character “u” for “ μ ” and do not type the “s”, e.g. type “300 u” for 300 microseconds. Enter “0” to select the lowest possible delay. Enter “1” to select the highest value again.

External startmode



Summary

Enables the possibility to initiate a start of the acquisition through an external signal.

Description

When the external start setting is turned on and a signal is applied to the external start pin, a new acquisition is started. If the acquisition is already running, nothing will happen. This allows automated start of the data acquisition system in a larger measurement system.

Note This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details.

Note For more detailed information on hardware connection, signals and pinning; refer to the GEN DAQ hardware manual.

External Start Minimum Pulse Width



Summary

Filter spikes from digital signals.

External Start Minimum Pulse Width



Description

The minimum pulse width can be used to filter the input signal from high-frequency noise. If the input has some noises/signals which contain higher frequencies (or shorter pulse widths) than the used filter time, the system filters out these values.

The best filter time setting is application dependent if the test environment introduces signal spikes on the measurement though electrical or magnetic disturbances AND the pulses that should be detected are wide enough. The noise can be filtered out by selecting a filter time value larger than the typical spike width but shorter than the expected valid pulse width.

For example, if a 1 kHz signal with 100 kHz noise is applied, adjusting the filter time to 10 μs is the best choice.

The default setting is 0.5 μs . This will basically not filter based on pulse width.

The table below shows the different characteristics for each setting of the input filter.

Selections	
Filter Time (μs) ¹	Min detected pulse width (μs) ¹
0.5	> 0.40
1	> 0.90
2	> 1.90
5	> 4.90
10	> 9.90

- (1) The character of the setting is shown in the table. According to the table, if the filter time is set on 1 μs , the input signal with the pulse width of 0.8 μs cannot be detected. However, there is a tolerance on the setting so for example, the input signal with the pulse width of 0.95 μs (or larger than 0.91 μs) can be detected. This is illustrated below.




Figure D.2: Pulse width settings

External stopmode



Summary

Enables the possibility to initiate a stop of the acquisition through an external signal.

Description

When the external stop setting is turned on and a signal is applied to the stop pin and an acquisition is running, the acquisition will be stopped. If no acquisition is running, nothing will happen. This allows automated stop of the data acquisition system in a larger measurement system.

Note *This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details.*

Note *For more detailed information on hardware connection, signals and pinning; refer to the GEN DAQ hardware manual.*

External Stop Minimum Pulse Width



Summary

Filter spikes from digital signals.

External Stop Minimum Pulse Width



Description

The minimum pulse width can be used to filter the input signal from high-frequency noise. If the input has some noises/signals which contain higher frequencies (or shorter pulse widths) than the used filter time, the system filters out these values.

The best filter time setting is application dependent if the test environment introduces signal spikes on the measurement though electrical or magnetic disturbances AND the pulses that should be detected are wide enough. The noise can be filtered out by selecting a filter time value larger than the typical spike width but shorter than the expected valid pulse width.

For example, if a 1 kHz signal with 100 kHz noise is applied, adjusting the filter time to 10 μs is the best choice.

The default setting is 0.5 μs . This will basically not filter based on pulse width.

The table below shows the different characteristics for each setting of the input filter.

Selections	
Filter Time (μs) ¹	Min detected pulse width (μs) ¹
0.5	> 0.40
1	> 0.90
2	> 1.90
5	> 4.90
10	> 9.90

- (1) The character of the setting is shown in the table. According to the table, if the filter time is set on 1 μs , the input signal with the pulse width of 0.8 μs cannot be detected. However, there is a tolerance on the setting so for example, the input signal with the pulse width of 0.95 μs (or larger than 0.91 μs) can be detected. This is illustrated below.




Figure D.3: Pulse width settings

PTP Master MAC-address



Summary

Shows the MAC-address of the PTP master.

Description

When the sync source is set to PTP this field becomes relevant.

The MAC-address of the best PTP master is shown here. This could be another PTP (grand) master or the mainframe itself. The value “00-00-00-00-00-00” is shown while doing an initial PTP master search.

Events that may occur while synched with a PTP master:

- A better PTP master is found
This better PTP master is used, and its MAC-address will be shown
- PTP master lost
The mainframe searches for the best PTP master and uses this. This could mean either another mainframe or the mainframe itself.

During changing of PTP masters, the old known MAC-address will be shown but the status will be “out-of-sync”.

The mainframe also monitors the synchronization interval of the PTP master. For best sync accuracy a GHS system requires this update rate to be at least once per second. If the PTP master fails to meet this requirement a notification is shown in Perception. An interval greater than once a second significantly reduces the PTP synchronization accuracy and may even cause mainframes to lose PTP clock synchronization.

A GHS system acting as master uses an update rate of once per second.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

PTP Role



Summary

Shows the assigned role of the mainframe in a PTP setup.

Description

When the sync source is set to PTP this field becomes relevant.

The PTP master selection process assigns roles to all participants. Only one participant will be selected as master.

This field can have the following values:

- None: The PTP master selection process is ongoing.
- Master: The master selection process has assigned this mainframe the role 'Master'. The "PTP Master MAC-address" now indicates the MAC-address of the mainframe.
- Slave: The master selection process has assigned this mainframe the role 'slave'. The "PTP Master MAC-address" now indicates the MAC-address of the used PTP Master.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

PTP Tolerance



Summary

Select the maximum allowed deviation between the mainframe and PTP master before an "out-of-sync" will be reported.

PTP Tolerance



Description

When the sync source is set to PTP this field becomes relevant.

The PTP Tolerance indicates the maximum allowed deviation between the time from the PTP master and the internal mainframe time. If the deviation exceeds the given PTP tolerance, the sync status will go to 'sync lost' and if a recording is in progress, a timemarker is added to the recording.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

Use Accurate Master



Summary

When ON, a warning will be shown if the master found is **not** an accurate master.

Description

PTP clocks have a clock class indicating the accuracy. The clock class is an assigned number in the range of 0 to 255. The lowest number has the highest accuracy. Commercial available grandmasters normally have clock class 6. This means that the time source is traceable to a primary source (e.g. GPS). When enabled this option means that if a master with clock class 8 or higher is found, a warning will be shown. Also recordings made in with a clock class 8 master clock and accurate master setting enabled will receive a mark indicating that no accurate master was used.

This option means that only a master with clock class 7 or better will be accepted as master in the master selection process.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

PTP Delay Method



Summary

Indicates the delay method for the PTP signal.

Description

HBM systems are designed to work with End-to-End Two-Step PTP protocol only. This End-to-End protocol measures and compensates the delay between the mainframe to the PTP master, including PTP aware switches.

Next to this “End-to-End” protocol there is also the “Peer-to-Peer” protocol. In this protocol each PTP aware device in the chain between PTP master and mainframe does its own time delay compensation. This protocol reduces the load on the PTP master for correcting different delays for different mainframes behind different PTP aware devices when using the “End-to-End” protocol. This also means each device needs to be setup for this “Peer-to-Peer” protocol. As explained earlier: The HBM systems currently do not support this protocol.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

Clock Class



Summary

Indicates the clock class of the master clock used by the mainframe.

Clock Class



Description

This is the clock class used to determine if the master clock is an accurate master when the **Use Accurate Master setting** is enabled.

Most important clock classes to be aware of are:

- **Clock class 6** designates a clock that is synchronized to a primary reference time source⁽¹⁾. A clock class 6 clock shall not be a slave to another clock in the domain.
- **Clock class 7** designates a clock that was previously clock class 6 but that has lost the ability to synchronize with its primary reference time source. A clock class 6 clock shall not be a slave to another clock in the domain.
- **Clock class 248** is the default clock class.
- **Clock class 255** is a clock class for slave only clocks.

Note

The clock class, combined with the clock accuracy defines the overall quality of a PTP Clock in the PTPv2 protocol. The overall quality is used in the best master clock protocol to select the best clock in the PTP network.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

(1) Examples (but not limited to) of primary reference time sources are GPS and IRIG.

Accurate Clock Status



Summary

Indicates if the current master clock is or is not an accurate clock.

Accurate Clock Status



Description

Based on the master clocks' class it is determined if the master clock is an accurate master clock. The evaluation may result, in the following three states:

- Unknown: The clock class of the master clock could not be determined. It is uncertain if the current clock is an accurate clock.
- Not found: The currently selected master clock is **not** an accurate master clock.
- Found: The currently selected master clock **is** an accurate master clock.

Note

This option is only available if supported by the mainframe. See the GEN DAQ hardware manual for details and detailed PTP explanation.

D.2.3 Recorder

Introduction

A **recorder** consists of a number of acquisition channels that share the same basic recording parameters, sample rate, sweep length and pre- and post-trigger length. Usually a single recorder is physically identical to a single acquisition card. Multiple recorders can be placed in a single **mainframe**.

The recorder acquisition parameters can be found in the **Time base groups** section of the **Memory and Time base** group (on page 581).

Note *The acquisition parameters of all recorders in a group will be the same. If different settings are required, move recorders into different groups.*

Basic settings

Name



Summary

Logical name of the recorder.

Name



Description

This is the name of the recorder as used throughout Perception . It is not a “physical” name.

The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Note

If a recorder with the same name already exists in the group, that recorder will be automatically renamed to a unique name. Two recorders with the same name cannot exist in the same group.

Enabled



Summary

When ON the recorder can be used for acquisition and data storage.

Description

To increase performance, usability and system overview it is possible to turn off those parts of your system that you do not use during a certain experiment. Powering off unused hardware will also limit the amount of storage space required.

Groups



Summary

Shows the group that the recorder is in and allows the group to be changed.

Groups



Description

Recorders are grouped together based on their capabilities. The time base settings, such as the sampling rate, sweep/continuous and related settings, are the same for all recorders in a group. This allows the system to be set up much more quickly, since the settings are applied to all recorders within the group. The groups setting allows the groups to be changed in the settings sheet.

Type



Summary

Shows the type of the recorder.

Description

The type of the recorder provides information on what type of recorder is in which slot of the mainframe. This setting is informational only.

Resolution



Summary

This is the resolution of the recorder.

Description

The resolution of the samples from a recorder depend on the hardware capabilities of that recorder. Some recorders support both 16 and 24 bit resolution. 24 bit resolution is more precise, but it also doubles the bandwidth and storage usage. Some features of a card may be only available at a specific resolution.

Note

Detailed information about precision and card-specific features are available in the GEN DAQ manual or card specification sheet.

Advanced settings

Output 1



Summary

Allows signal out for certain events in the acquisition.

Description

To allow the data acquisition system to be integrated into a larger measurement system or to monitor the data acquisition system, signals can be generated for certain events during the acquisition. The signal is raised on the pin assigned to output 1.

Note

This option is only available if supported by the mainframe AND the recorder. See the GEN DAQ hardware manual for details.

Note

For more detailed information about hardware connection, signals and pinning, see the GEN DAQ hardware manual.

Output 2



Summary

Allows signal out for certain events in the acquisition.

Description

To allow the data acquisition system to be integrated into a larger measurement system or to monitor the data acquisition system, signals can be generated for certain events during the acquisition. The signal is raised on the pin assigned to output 2.

Note

This option is only available if supported by the mainframe AND the recorder. See the GEN DAQ hardware manual for details.

Note

For more detailed information about hardware connection, signals and pinning, see the GEN DAQ hardware manual.

External start/stop enabled



Summary

Enables an acquisition start/stop to be initiated by an external signal.

Description

When the external start/stop setting is turned on and a signal is applied to the external start pin, a new acquisition is started. If the acquisition is already running, nothing will happen. If a signal is applied to the stop pin and an acquisition is running, the acquisition will be stopped. This allows the data acquisition system to start/stop automatically in a larger measurement system.

Note

This option is only available if supported by the mainframe AND the recorder. See the GEN DAQ hardware manual for details.

Note

For more detailed information about hardware connection, signals and pinning, see the GEN DAQ hardware manual.

D.2.4 Analog channel

Introduction

An **analog channel** is any channel that converts instantaneous values of a signal – that represents a physical phenomenon – into numeric values using digitizing. Digitizing is done by means of an A-to-D converter.

In this section you can set the global parameters. You can also set the **Amplifier mode** for channels that support multiple input configurations.

Detailed settings of an analog input channel can be found in the related section of the **Input** group.

Basic settings

Name



Summary

Logical name of the channel.

Description

This is the name of the channel as used throughout Perception . It is not a “physical” name.

The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Note

If a channel with the same name already exists in the recorder, that channel will be automatically renamed to a unique name. Two channels with the same name cannot exist in the same recorder.

Type (RO)



Summary

Channel type

Description

The channel type is a read-only property and describes what kind of channel it is. For example, the channel type can be GEN series 100MS/s Fiber Amp. The type of the channel is determined by the acquisition cards which are used.

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Amplifier mode



Summary

Switch between various modes if available. Selected type is reflected in **Input** group.

Amplifier mode



Description

Most channels can only be used in one amplifier mode; this mode is described as “basic” mode. However, there are also channels which support different modes like the bridge amplifier. This amplifier can work in basic mode, basic sensor mode and in bridge mode.

Once a type has been set, you can find the detailed settings of the selected type of input in the **Input** group.

Color



Summary

Default trace color in displays.

Description

When recorded data from this calculator is displayed, the default trace color is defined by this setting. The trace color can always be changed via the display trace properties.

Storage



Summary

When ON the channel is enabled for data storage.

Description

The storage setting determines whether or not the data of this channel will be stored during a recording.

Out enabled



Summary

Enables analog output signal on mainframe front panel of remote front-end channel.

Description

When working with a fiber optic isolated digitizing front-end it is possible to enable an analog output signal on the mainframe front panel. This signal is equivalent to the measured signal at the front-end.

Power enabled



Summary

Enables remote front-end channel to be switched on.

Description

When working with a fiber optic isolated digitizing front-end it is possible to switch the power at the front-end on or off under software control. By switching the power off, the operating time of the front-end before recharging will be extended.

Power status (RO)



Summary

Power status of remote front-end channel.

Description

When working with a fiber optic isolated digitizing front-end this field displays status information from the front-end channel.

Typical power status values are: "Power Off", "No Signal", "Warming Up" and "Power OK".

Advanced settings

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition system's capacitance for proper operation.

Note 1



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Advanced settings

Note 2



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 3



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 4



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

D.2.5 Marker (Events)

Introduction

As opposed to an analog channel, **Marker (Events)** channels only register two levels of information: on and off, high and low, or open and close. This information is represented on the inputs as a “low” voltage (typically < 1 V) and a “high” voltage (typically > 2 V). Each channel basically provides 1-bit internal information, in contrast to the typical 16-bit data from an analog channel.

Detailed settings can be found in the **Marker (Events)** section of the **Input** group (on page 645).

Basic settings

Name



Summary

Logical name of the channel.

Name



Description

This is the name of the channel as used throughout Perception . It is not a “physical” name.

The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Note

If a channel with the same name already exists in the recorder, that channel will be automatically renamed to a unique name. Two channels with the same name cannot exist in the same recorder.

Color



Summary

Default trace color in displays.

Description

When recorded data from this calculator is displayed, the default trace color is defined by this setting. The trace color can always be changed via the display trace properties.

Storage



Summary

When ON the channel is enabled for data storage.

Description

The storage setting determines whether or not the data of this channel will be stored during a recording.

Technical unit high



Summary

Label for logical high level.

Description

A marker channel has only two different output values, logical low (0) or logical high (1). With “Technical unit high” it is possible to link a label to the logical high value. This label is shown as the Y value in a display when the marker channel is displayed.

Technical unit low



Summary

Label for logical low level.

Description

A marker channel has only two different output values, logical low (0) or logical high (1). With “Technical unit low” it is possible to link a label to the logical low value. This label is shown as the Y value in a display when the marker channel is displayed.

Note 1



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Advanced settings

Note 2



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 3



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 4



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

D.2.6 Timer/Counter

Introduction

Timer/Counter channels are usually combined on a card that also provides other digital functionality.

Typical capabilities include:

- Up/down counter
- Frequency/RPM measurement
- Position measurement

In this section you set the global parameters for the channels. Once storage is enabled you can set the details in the **Timer/Counter** section of the **Input** group.

Refer to your hardware manual to find details on capabilities and connections.

Basic settings

Name



Summary

Logical name of the channel.

Description

This is the name of the channel as used throughout Perception . It is not a “physical” name.

The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Note

If a channel with the same name already exists in the recorder, that channel will be automatically renamed to a unique name. Two channels with the same name cannot exist in the same recorder.

Color



Summary

Default trace color in displays.

Description

When recorded data from this calculator is displayed, the default trace color is defined by this setting. The trace color can always be changed via the display trace properties.

Storage



Summary

When ON the channel is enabled for data storage.

Storage



Description

The storage setting determines whether or not the data of this channel will be stored during a recording.

Note 1



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Advanced settings

Note 2



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 3



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 4



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

D.2.7 CAN-Bus

Introduction

CAN-Bus (Controller Area Network bus) is a rugged, digital serial bus designed for industrial environments. Introduced by Bosch in the mid-1980s for in-vehicle communications, it is used in myriad applications including factory automation, building automation, aircraft and aerospace as well as in cars, trucks and buses. CAN-Bus replaces bulky wiring harnesses with a two-wire differential cable.

CAN-Bus uses a broadcast method for placing frames on the wire somewhat similar to Ethernet. Bus distance is based on speed, ranging from a maximum of 40 meters at 1 Mbps to a maximum of six kilometers at 10 Kbps. At speeds up to 125 Kbps, CAN provides fault tolerance. If one of the two wires is cut or shorted, the other keeps transmitting.

Currently CAN-Bus channels cannot be configured within Perception, an external tool is required to do CAN-Bus setup, prior to connecting to the CAN-Bus device in Perception.

Basic settings

Name



Summary

Logical name of the channel.

Description

This is the name of the channel as used throughout Perception . It is not a “physical” name.

The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Note

If a channel with the same name already exists in the recorder, that channel will be automatically renamed to a unique name. Two channels with the same name cannot exist in the same recorder.

Color



Summary

Default trace color in displays.

Color



Description

When recorded data from this calculator is displayed, the default trace color is defined by this setting. The trace color can always be changed via the display trace properties.

Storage



Summary

When ON the channel is enabled for data storage.

Description

The storage setting determines whether or not the data of this channel will be stored during a recording.

Note 1



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Advanced settings

Note 2



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

D.3 Memory and Time base group

D.3.1 Introduction

In the Perception software a difference is made between acquisition and storage. Acquisition is the act of digitizing analog data and making it available for monitoring or storage. Storage is the actual archiving of digitized data. Recording (verb) is defined as acquisition + storage.

The acquisition of data is determined by a sample rate and an acquisition mode.

The storage mode defines how data that is digitized and acquired will be saved. The continuous storage mode will always store data, regardless of the acquisition mode. The sweeps storage mode will store only the sweeps, regardless of the acquisition mode. However, the resulting file – or recording – will be different for the various combinations of acquisition and storage mode.

To make all this possible, the **Memory and Time base** group allows you to set the clock base or time base (for the sample rate) and the memory usage for the storage modes. For more details on acquisition and storage modes refer to the appropriate section in this manual.

D.3.2 Mainframe

Introduction

The time base is used as the basis for the digitizing sample rate. The mainframe section of the **Memory and Time base** group allows you to select the source of your time base. Typically you will have the option to select between (internal) *decimal*, (internal) *binary* and *external*.

If *external* is selected, an externally applied signal is used to define the sample rate and sample moments. For external time base a variety of options is available to tailor the system to your needs.

If an internal base is selected, you can have a decimal base that gives you “standard” sample rates, or a binary base. The binary clock base of the internal time base in combination with the various division factors allow for a broad range of sweep length values that meet FFT requirements.

More details about your system’s capabilities can be found in the related hardware manual.

Basic settings

Clock base



Summary

Sample rate basis

Description

The sample rate of the digitizer is determined by the clock base: The clock base is a clock that generates pulses used to drive the A-to-D converter. You have the following clock base options:

- **Decimal or binary internal:** If you select the internal clock base, the clock used to drive the ADC is the built-in clock.
- **External:** If you select the external clock base, the clock used to drive the ADC is the clock signal present at the external clock input.

The internal clock has two operating modes:

- Internal Clock Base *Decimal*: This setting is used to create clock base values that are base 10, for example 1 MHz, 100 kHz, 50 kHz, 2.5 Hz, etc. These values are derived from a main oscillator that operates at a base 10 frequency, for example 1 MHz.
- Internal Clock Base *Binary*: This setting is used to create clock base values that are base 2, for example 1.024 MHz, 512 kHz, 64 Hz, etc. These values are derived from a main oscillator that operates at a base 2 frequency, for example 1.024 MHz.

Advanced settings

Unit



Summary

The X-units of the external clock signal.

Unit



Description

A string representing the X-unit used for the connected external clock source.

This unit is returned if the X-unit of a data source is requested. Whereas “s” is used for all internal clock base X-units, this unit is used for all external clock X-units.

Unit scaling



Summary

The unit scaling factor of the external clock signal.

Description

This setting is one of the two settings that determine the **scale result**. The unit scaling is the number of “units” that represents a number of clock pulses (= **Clock Scaling**).

For example: If three pulses received from the external clock signal represent eight “Units”, the **Unit Scaling** needs to be set to 8, and the **Clock Scaling** needs to be set to 3.

Clock scaling



Summary

The clock scaling factor of the external clock signal.

Clock scaling



Description

Clock scaling is the second setting that determines the **scale result**. The clock scaling is the number of clock pulses that represents a number of “units” (= **Unit Scaling**).

For example: If three pulses received from the external clock signal represent eight “Units”, the **Unit Scaling** needs to be set to 8, and the **Clock Scaling** needs to be set to 3.

Clock shift



Summary

The clock shift is the offset in X-scale applied after scaling.

Description

To determine the X-position of a sample while using external clock, the **clock shift** is added to the result of multiplying the **scale result** by the pulse number received from the connected external clock.

Otherwise stated:

$X\text{-Position} = ((\text{Unit Scaling}/\text{Clock Scaling}) * \text{External Clock Pulse number}) + \text{Clock Shift}$

Example:

Unit Scaling : 1, Clock Scaling: 360, Clock Shift = 0.5.

Every pulse received from the external clock source is multiplied by a scale result of 1/360 **Unit**. As there is a clock shift we need to add 180/360 (= 0.5) to this. Result: First clock pulse received results in 181/360 **Unit**, second pulse = 182/360 **Unit**, etc.

External Clock Minimum Pulse Width



Summary

Filter spikes from digital signals.

Description

The minimum pulse width can be used to filter the input signal from high-frequency noise. If the input has some noises/signals which contain higher frequencies (or shorter pulse widths) than the used filter time, the system filters out these values.

The best filter time setting is application dependent if the test environment introduces signal spikes on the measurement though electrical or magnetic disturbances AND the pulses that should be detected are wide enough. The noise can be filtered out by selecting a filter time value larger than the typical spike width but shorter than the expected valid pulse width.

For example, if a 1 kHz signal with 100 kHz noise is applied, adjusting the filter time to 10 μs is the best choice.

The default setting is 0.1 μs . This will basically not filter based on pulse width.

The table below shows the different characteristics for each setting of the input filter.

Selections	
Filter Time (μs) ¹	Min detected pulse width (μs) ¹
0.1 (default setting)	> 0.00
0.2	> 0.10
0.5	> 0.40
1	> 0.90
2	> 1.90
5	> 4.90
10	> 9.90

- (1) The character of the setting is shown in the table. According to the table, if the filter time is set on $1\ \mu\text{s}$, the input signal with the pulse width of $0.8\ \mu\text{s}$ cannot be detected. However, there is a tolerance on the setting so for example, the input signal with the pulse width of $0.95\ \mu\text{s}$ (or larger than $0.91\ \mu\text{s}$) can be detected. This is illustrated below.




Figure D.4: Pulse width settings

TDC enable



Summary

If turned ON, an external signal is used to locate the Top Dead Center position.

Description

For rotation-based measurements it can be convenient to automatically shift the horizontal annotation so that zero degrees in the annotation match with the zero degrees position of the object under test. This is done by using an external signal. The Nth pulse (**TDC delay**) on this input is used to mark the 0:000.0 position. The **Clock Shift** can be used if the TDC detector is not positioned at zero degrees.

TDC delay



Summary

Determines which external Top Dead Center signals should be skipped.

TDC delay



Description

If **TDC enable** is ON, the Nth pulse on the TDC input is used for marking the 0:000.0 position. Because initially incorrect TDC pulses may occur, it is useful to skip the first TDC signals received from the TDC detector before marking the 0:000.0 position.

This setting determines the number of TDC detector signals that are skipped before marking.

Use qualifier



Summary

If turned ON, the alarm is used as TDC qualifier.

Description

Use this option to disable the TDC detection as long as the **Alarm** is not active. The required alarm settings can be found in the **Alarm** group. The system's alarm is used to "hold" the TDC detection as long as the alarm is not active. When the alarm becomes active as defined by the settings in the **Alarm** group, the TDC pulses are forwarded to the system.

Scale result



Summary

The scale result (factor) used to create the X-scaling.

Scale result



Description

The scale result is constructed by dividing the **unit scaling** by the **clock scaling**.

To determine the X-position of a sample this factor is multiplied with the pulse number received from the connected external clock. This value is then added to the **Clock Shift** and the X-position is known.

Otherwise stated:

$$\text{X-Position} = (\text{Scale Result} * \text{External Clock Pulse number}) + \text{Clock Shift}$$

D.3.3 Time base groups

Introduction

Within the **Time base** groups section of the **Memory and Time base** group you set all parameters related to storage modes.

When data is stored, this data is organized in recordings. A recording (noun) is defined as all data that has been stored between the start of acquisition (START command) and the end of acquisition. The end can be defined in various ways. A recording can have one or multiple sweeps, a continuous data stream or a combination of both.

Refer to the hardware manual of your data acquisition system for more details on available storage modes.

Basic settings

External clock divider



Summary

Reduction factor of the external clock rate.

External clock divider



Description

This setting is available if the mainframe **Clock base** is set to *External*. In this case the clock used to drive the ADC converter for the channels is the signal present at the external clock input connector. This sample rate can be further reduced using this value. The actual sample rate is the external clock divided by the clock divider setting.

Slow sweep time base



Summary

The lower sample rate of the digitizer.

Description

For storage modes with two sample rates, this setting defines the number of samples per second for the lower speed sweep. It is enabled when the **Storage mode** is *Slow-Fast Sweep*.

Slow sweep trigger position



Summary

Sets the trigger position within the slow sweep.

Description

The trigger position within a sweep defines the amount of pre- and posttrigger information to be stored. In the *Slow-Fast Sweep* storage mode, the low-speed sweep uses the trigger of the high-speed sweep.

When set to zero the complete sweep contains posttrigger data. When set to the sweep length the sweep contains all pre-trigger data.

Slow sweep length



Summary

The total amount of data to be recorded for slow sweeps.

Description

This setting is enabled when the **Storage mode** is *Slow-Fast Sweep*. It sets the number of samples that the slow-speed sweep will contain.

Fast sweep time base



Summary

Sets the main (high) sample rate of the recorder for digitizing.

Description

This setting defines the main (or high) sample rate of the recorder. The upper limit is defined by the actual hardware in use.

Fast sweep mode



Summary

Defines how the data is stored.

Fast sweep mode



Description

This setting is available if the **Storage mode** is *Sweeps*, *Dual*, or *Slow-Fast Sweep*. The available sweep modes are *Normal*, *Pre-Trigger*, and *Delayed*:

- In *Normal* mode, the storage becomes active as soon as the trigger is generated, and lasts for the length defined by the **Fast sweep length** setting, and (optionally) the **Slow sweep length** if the selected **Storage mode** is *Slow-Fast Sweep*.
- In *Pre-Trigger* mode, samples are stored before and after the sample where the trigger is positioned. Therefore it is necessary to define the whole sweep length and, in addition, the number of samples that will be stored before the actual trigger position. These two settings are defined for the fast-rate and (optionally) the slow-rate digitizer by:
 - (a) Fast sweep length and Fast sweep trigger position
 - (b) Slow sweep length and Slow sweep trigger position
- In *Delayed* mode a trigger is detected, the storage remains inactive for a certain time, and then a full sweep is recorded. The delay is given in number of samples by the **Fast sweep trigger delay** and (optionally) the **Slow sweep trigger delay** setting.

Fast sweep trigger position



Summary

Sets the trigger position within the fast sweep.

Description

The trigger position within a sweep defines the amount of pre- and posttrigger information to be stored. This setting is only available if the **Fast sweep mode** is *Pre-Trigger*.

When set to zero the complete sweep contains posttrigger data. When set to the sweep length the sweep contains all pre-trigger data.

Fast sweep length



Summary

The total amount of data to be recorded for fast sweeps.

Description

This setting is enabled if the **Storage mode** is *Sweeps*, *Dual* or *Slow-Fast Sweep*. It sets the number of samples that each recorded sweep will contain.

Fast sweeps



Summary

Number of sweeps to be acquired.

Description

If **Fast sweep count enabled** is ON, this setting allows the user to define a specific number of sweeps to be recorded. The recording (acquisition + storage) will stop automatically when all the sweeps have been processed.

Fast sweep count enabled



Summary

Enables multiple sweeps to be acquired within a single recording.

Description

This setting is available when the **Storage mode** is *Sweeps* or *Dual*.

Switch this option on to allow a recording to have a fixed number of sweeps defined by the **Fast sweeps** setting. If this setting is switched off, a recording will have an infinite number of sweeps, which means that it has to be stopped manually.

Continuous time base

Summary

The sample rate of the digitizer for continuous storage mode.

Description

If the **Storage mode** is set to *Continuous* or *Dual*, this sets the number of samples per second that the digitizer (A-to-D converter) will convert.

Continuous mode

Summary

Defines how the data is stored in continuous mode.

Description

If the **Storage mode** is *Continuous*, this setting can take one of three possible values: *Standard*, *Circular Recording*, or *Stop On Trigger*. It defines the precise way of storing data to the controlling PC's (or local) hard disk, as explained in the manual of your data acquisition device.

- For the *Standard* mode, the user manually starts and stops the storage. There are no other relevant settings to be set.
- For the *Circular Recording* mode, the **Continuous length** needs to be defined before the user can manually start and stop the storage.
- For the *Stop On Trigger* mode, the **Continuous lead-out** needs to be defined. The acquisition is started manually and stopped automatically after the defined recording time once a trigger is detected.
- For the *Specified time* mode, the **Continuous length** needs to be defined. The acquisition is started manually and stopped automatically after the defined recording time.

Continuous length

Summary

The total amount of data to be recorded.

Continuous length



Description

If the **Continuous mode** is set to *Circular Recording*, this is the storage buffer size in time units. The samples stored for any acquisition time length never exceed the number defined by this setting.

Continuous lead-out



Summary

Posttrigger segment of a continuous circular recording.

Description

Sets the length of data to be stored after the detection of a trigger on the selected recorder when performing a continuous recording with the **Continuous mode** set to *Stop On Trigger*. The data length is defined in time units, which is equivalent to the number of samples divided by the sampling rate.

Note

*If **Continuous lead-out** > **Continuous length**, the **Continuous length** setting is ignored.*

This setting is similar to the posttrigger segment of a sweep, when performing a sweep-based acquisition. The samples are now stored on PC hard disk instead of volatile memory.

Advanced settings

Fast sweep trigger delay (Advanced)



Summary

Shifts the trigger position outside the sweep length.

Fast sweep trigger delay (Advanced)



Description

This setting is enabled only if the **Fast sweep mode** is set to *Delayed*. When a trigger is detected, the storage is set to start after the specified number of samples. Thus, the recording is “postponed” for a time interval after trigger generation, and only posttrigger information is recorded.

Fast sweep stretch (Advanced)



Summary

When a second trigger (transient event) is encountered during posttrigger data collection, the triggered sweep is automatically extended to record the second event completely including additional posttrigger data.

Description

The sweep stretch is a function of the fast sweep and available on the following storage modes:

- Sweeps
- Dual: on the fast sweep

When OFF (disabled) the system operates as usual: upon each trigger event it acquires the selected amount of pre-trigger and posttrigger data at the fast time base rate. A fixed number of samples are acquired for each trigger, so all sweeps are the same length.

When ON (enabled) the system operates as usual; however, additional triggers detected during the posttrigger data collection are accepted and these restart the posttrigger count. The fast sweep length is correspondingly “stretched” to include the new trigger(s) and additional posttrigger data. Therefore there is no predetermined limit on the length of a sweep, and each sweep may be a different length depending on the number of triggers.

Note

When the system is in dual mode only the standard storage mode is supported for the continuous data stream and not the circular or stop-on-trigger mode.

D.4 Input group

D.4.1 Introduction

The **Input** group within the settings sheet comprises all data acquisition channels that are currently available within your measurement system. Channels that are not supported by your hardware are not included. However, channels that are supported by your hardware, but not enabled, are displayed as disabled (greyed).

Various channels within the acquisition hardware can be configured for multiple purposes. To modify this you need to go to the **General** group where you can select the operation mode of a specific channel if applicable.

For example there are analog channels that can be configured to be used as a basic amplifier or as an accelerometer input. Both options will be displayed in the **Input** group, but only the selected option is active, the other is disabled.

D.4.2 Basic-voltage

Introduction

Of all input channels the **basic-voltage** input channel is the most straightforward. The basic-voltage input channel can either be a Single-Ended (SE) input or a differential input.

Signal coupling (how the signal is fed into the amplifier) can either be AC or DC, depending on your hardware. Input coupling (how the amplifier itself is configured) can be single-ended (positive or negative) or differential, also depending on your hardware.

The diagram on top of the settings can be of assistance in determining the correct setup.

Here you can also set the amplifier range and offset as well as the filter characteristics.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Signal coupling



Summary

Defines how the analog signal is "coupled" into the amplifier.

Signal coupling



Description

This setting defines how the analog signal is "coupled" into the amplifier. The coupling feature defines which signal component (content) is passed to the amplifier.

When "AC" is selected, the AC content of a signal without any DC bias voltage is measured. With DC selection, both AC and DC content are passed to the amplifier.

A "GND" mode is usually provided to ground an amplifier to minimize the influence of random noise.

Depending on the capabilities of your hardware additional settings can include "AC external probe", "DC external probe", "Reference" or "1PPS Sync". Refer to your hardware manual for these non-standard settings.

Input coupling



Summary

Mode of operation of the input amplifier.

Description

This setting determines how the input signal is routed to the amplifier. If for example "Single-Ended Positive" is selected, the negative input of the amplifier is grounded and the positive input is connected to the incoming signal. For a better understanding it is useful to look at the graphics on top of the settings sheet.

The available modes depend on the type of channel. Typical values are: "Single-Ended Positive", "Single-Ended Negative" and "Differential".

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition systems capacitance for proper operation.

Fine gain



Summary

Select *fine gain* to adjust the input span to the signal in small steps for a maximum dynamic range without clipping the signal.

Description

This setting is used to adjust the input span in small steps. If for example the entered *span* is 2.4 V, the *offset* is 0 V, the technical units multiplier is 1 and the technical units offset is 0, the amplifier range will be set from +2 V to -2 V. However, if *fine gain* is switched on, the amplifier range will be set from -1.2 V to +1.2 V. The amplifier range is shown in the graphics at the top of the settings sheet.

D.4.3 Basic-sensor

Introduction

The **basic-sensor** input channel operates as a basic-voltage channel with an additional excitation voltage/current capability. It is a derivative of the bridge amplifier. To enable this channel type you must select the correct mode in the **Amplifier mode** setting of the applicable bridge channel. This is done in the **Analog Channel** section in the **General** group.

Signal coupling (how the signal is fed into the amplifier) can either be AC or DC, depending on your hardware. Input coupling (how the amplifier itself is configured) is differential by nature.

Here you can set the amplifier range and offset as well as the filter characteristics and excitation parameters.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Signal coupling



Summary

Defines how the analog signal is "coupled" into the amplifier.

Description

This setting defines how the analog signal is "coupled" into the amplifier. The coupling feature defines which signal component (content) is passed to the amplifier.

When "AC" is selected, the AC content of a signal without any DC bias voltage is measured. With "DC" selection, both AC and DC content are passed to the amplifier.

A "GND" mode is usually provided to ground an amplifier to minimize the influence of random noise.

Input coupling



Summary

Mode of operation of the input amplifier.

Description

This setting determines how the input signal is routed to the amplifier. If for example "Single-Ended Positive" is selected, the negative input of the amplifier is grounded and the positive input is connected to the incoming signal. For a better understanding it is useful to look at the graphics on top of the settings sheet.

The available modes depend on the type of channel. Typical values are: "Single-Ended Positive", "Single-Ended Negative" and "Differential".

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Excitation



Summary

Enable or disable excitation.

Description

Switch the excitation on or off. The excitation type can be either voltage or constant current.

Excitation type



Summary

Set the excitation type.

Excitation type



Description

Select the excitation type. The excitation type can be either voltage or constant current. Select the one required by the application.

Excitation span



Summary

Span value for voltage-type excitation.

Description

When **Excitation type** is set to *Voltage* this setting represents the Full Scale voltage that is applied. The span is twice the **Excitation range**. This setting is ignored when **Excitation type** is set to *Current*.

Excitation range



Summary

Range value for voltage-type excitation.

Description

When **Excitation type** is set to *Voltage* this setting represents the range of the voltage that is applied. The excitation range is bipolar and therefore half the **Excitation span**. This setting is ignored when **Excitation type** is set to *Current*.

Excitation current



Summary

Current value for current-type excitation.

Description

When **Excitation type** is set to *Current* this setting represents the current that is applied. This setting is ignored when **Excitation type** is set to *Voltage*.

Advanced settings

Enable Scan for TEDS



Summary

Enable or disable TEDS sensor auto-detection.

Description

Switch on to include this channel in the search for TEDS sensors, both automatically or manually invoked.

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition systems capacitance for proper operation.

Fine gain



Summary

Select *fine gain* to adjust the input span to the signal in small steps for a maximum dynamic range without clipping the signal.

Description

This setting is used to adjust the input span in small steps. If for example the entered *span* is 2.4 V, the *offset* is 0 V, the technical units multiplier is 1 and the technical units offset is 0, the amplifier range will be set from +2 V to -2 V. However, if *fine gain* is switched on, the amplifier range will be set from -1.2 V to +1.2 V. The amplifier range is shown in the graphics at the top of the settings sheet.

D.4.4 Bridge

Introduction

Of all input channels the **bridge** input channel is the most sophisticated channel.

The classic DC Wheatstone bridge circuit is a very sensitive indicator used with a variety of transducers for both static and dynamic measurements. The bridge is composed of four resistances. A DC excitation voltage is applied to the bridge and the voltage across the center terminals is fed to the input of the amplifier. When the voltages on all four resistors are identical, the bridge is balanced.

When used for instrumentation, a strain gauge (or other “transducer”) replaces one or more resistors in the bridge, and as the strain gauge undergoes dimensional changes (because it is bonded to a test object), it unbalances the bridge and produces an output voltage proportional to the strain.

Because a correct setup of a bridge requires numerous settings, a bridge wizard is available that allows you to set up your bridge channel(s) instantly without errors. You can also use the bridge wizard to swiftly copy settings from one channel to one or more other channels.

When you set up your bridge channel you should also refer to your hardware manual because some settings are related to hardware changes that you can make yourself.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Gain/Span



Summary

Amplifier gain

Description

Defines the gain that the amplifier applies to the input. In other words, it is the amount of increase in voltage expressed as the ratio of output to input. From the context menu of the column header you can swap between **Gain** and **Span** readout.

Excitation



Summary

Sets system excitation yes or no.

Description

Use this settings to enable or disable the excitation. It is good practice to remove excitation before you connect or disconnect a (bridge) sensor to the input.

Excitation type



Summary

Selects type of system excitation.

Description

The bridge circuit can be supplied with either a voltage or a current. Choose the one that applies.

Excitation span



Summary

Span value for voltage-type excitation.

Description

When **Excitation type** is set to *Voltage* this setting represents the Full Scale voltage that is supplied as excitation to the bridge circuit. The span is twice the **Excitation range**. This setting is ignored when **Excitation type** is set to *Current*.

Excitation range



Summary

Range value for voltage-type excitation.

Description

When **Excitation type** is set to *Voltage* this setting represents the range of the voltage that is supplied as excitation to the bridge circuit. The excitation range is bipolar and therefore half the **Excitation span**. This setting is ignored when **Excitation type** is set to *Current*.

Excitation current



Summary

Current value for current-type excitation.

Description

When **Excitation type** is set to *Current* this setting represents the current that is sent through the bridge circuit. This setting is ignored when **Excitation type** is set to *Voltage*.

Sensitivity (RO)



Summary

Returns the measured voltage as function of applied strain and excitation.

Description

This value represents the degree to which changes in the applied strain or stress causes changes in the measured output voltage as function of the applied excitation.

Bridge type



Summary

Bridge completion type

Description

Specifies the configuration of the internal and external resistors that all together complete the bridge circuit. Typical values are *Quarter*, *Half*, *Full*, where *Full* means that the bridge consists only of external resistors.

Gauge resistance



Summary

Electrical resistance of the strain gauge.

Description

The resistance of a strain gauge is defined as the electrical resistance of the gauge when no strain or stress is applied. Typically a strain gauge has a nominal resistance between 120 and 1000 Ohms.

Bridge factor



Summary

Bridge factor used for the actual measurement.

Description

Defines the number of gauges that are placed in a position and orientation so as to be exposed to physical strain. The other, passive gauges are isolated from all mechanical stress.

Shunt location



Summary

Location of the shunt resistor.

Description

Specifies whether the shunt resistor that is currently in use is *Internal* or *External*.

Shunt value



Summary

Resistive value of shunt, external or internal.

Description

The shunt value is the electrical resistance of the shunt resistor that is currently in use. If **Shunt location** is set to *Internal* this value matches the value of the resistor in the mainframe, if set to *External* it matches the resistance of the external custom resistor.

Shunt active Gauge



Summary

Active gauge for shunt calibration.

Description

Defines the location of the shunt resistor: either in parallel with the gauge that is located in the positive arm of the bridge circuit or in parallel with the gauge located in the negative arm.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Technical units offset



Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Filter type



Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Filter frequency high



Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Enable Scan for TEDS



Summary

Enable or disable TEDS sensor auto-detection.

Description

Switch on to include this channel in the search for TEDS sensors, both automatically or manually invoked.

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition systems capacitance for proper operation.

Fine gain



Summary

Select *fine gain* to adjust the input span to the signal in small steps for a maximum dynamic range without clipping the signal.

Description

This setting is used to adjust the input span in small steps. If for example the entered *span* is 2.4 V, the *offset* is 0 V, the technical units multiplier is 1 and the technical units offset is 0, the amplifier range will be set from +2 V to -2 V. However, if *fine gain* is switched on, the amplifier range will be set from -1.2 V to +1.2 V. The amplifier range is shown in the graphics at the top of the settings sheet.

D.4.5 Charge

Introduction

The charge amplifier transfers the input charge to another reference capacitor and produces an output voltage equal to the voltage across the reference capacitor. Thus, the output voltage is proportional to the charge of the reference capacitor and to the input charge respectively. Hence, the circuit acts as a *charge-to-voltage converter*. As a result of the Miller effect, the input impedance of the circuit is reduced. Therefore, all additional capacitance, like wiring and amplifier capacitance, are virtually grounded and have no influence on the output signal.

The advantages of using a charge amplifier instead of a voltage amplifier are:

- The piezo element transducer can be used in much hotter environments than voltage amplifiers with internal electronics can be.
- Gain is dependent only on the feedback capacitor, whereas voltage amplifiers, which are greatly affected by the input capacitance of the amplifier and by the parallel capacitance of the cable.

The disadvantage of using a charge amplifier instead of a voltage amplifier is:

- The frequency response of a charge amplifier is limited by the first stage input amplifier. The proportional amount of charge that is produced in the sensor needs to be fed into the reference capacitor simultaneously.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Signal coupling



Summary

Defines how the analog signal is "coupled" into the amplifier.

Description

This setting defines how the analog signal is "coupled" into the amplifier. The coupling feature defines which signal component (content) is passed to the amplifier.

When "AC" is selected, the AC content of a signal without any DC bias voltage is measured. With DC selection, both AC and DC content are passed to the amplifier.

A "GND" mode is usually provided to ground an amplifier to minimize the influence of random noise.

The signal coupling can be set to GND or Charge.

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass Finite Impulse Response filter.
- **Bessel:** This is a lowpass Infinite Impulse Response (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

D.4.6 CAN-Bus

Introduction

CAN-Bus (Controller Area Network bus) is a rugged, digital serial bus designed for industrial environments. Introduced by Bosch in the mid-1980s for in-vehicle communications, it is used in myriad applications including factory automation, building automation, aircraft and aerospace as well as in cars, trucks and buses. CAN-Bus replaces bulky wiring harnesses with a two-wire differential cable.

CAN-Bus uses a broadcast method for placing frames on the wire somewhat similar to Ethernet. Bus distance is based on speed, ranging from a maximum of 40 meters at 1 Mbps to a maximum of six kilometers at 10 Kbps. At speeds up to 125 Kbps, CAN provides fault tolerance. If one of the two wires is cut or shorted, the other keeps transmitting.

Currently each LIBERTY CAN-Bus Node must be configured prior to use by using the LIBERTY CAN Configuration Utility.

In this section you can set the general properties of the CAN-Bus channel like span, offset, units and filter type.

Basic settings

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Range to



Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Technical units



Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted high-frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

D.4.7 IEPE

Introduction

An **accelerometer** measures the acceleration and local gravity it experiences. Both are typically expressed in SI units meters/second² ($m \cdot s^{-2}$) or popularly in terms of g-force. For a moving object, the output of the accelerometer is off from the true acceleration by a 1 g factor in the local vertical axis. In the other, non-vertical axis the accelerometer measures acceleration and the equivalent specific external force. Counter-intuitively, an accelerometer at rest (zero acceleration) on the earth's surface will indicate the acceleration of gravity of 1 g because it is reading the ground reaction force.

Accelerometers can be used to measure vibration on cars, machines, buildings, process control systems and safety installations. They can also be used to measure seismic activity, inclination, machine vibration, dynamic distance and speed with or without the influence of gravity.

The electronics within typical (ICP™ / IEPE) accelerometers require excitation power from a constant-current-regulated, DC voltage source.

The accelerometer channel is a derivative of a basic-voltage channel. To enable this channel type you must select the correct mode in the **Amplifier mode** setting of the applicable channel. This is done in the **Analog Channel** section in the **General** group.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Sensor



Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Sensor Status



Summary

Physical status of the sensor connected to the channel.

Description

This setting only checks if the sensor physically connected and if possible some details on the type of sensor. The setting does not show if the sensor attached matches the sensor selected in the sensor setting. The setting will be updated automatically if a change in status is detected.

Shows the status of the sensor connected to the channel.

Auto detect TEDS



Summary

Enable or disable TEDS sensor auto-detection.

Auto detect TEDS



Description

Switch on to include this channel in the search for TEDS sensors, both automatically or manually invoked.

Excitation



Summary

Enable or disable excitation.

Description

Switch the excitation on or off. The excitation type is constant current by definition.

Excitation current



Summary

Value of the excitation current.

Description

This sets the value of the excitation current.

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Span



Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition system's capacitance for proper operation.

Fine gain



Summary

Select *fine gain* to adjust the input span to the signal in small steps for a maximum dynamic range without clipping the signal.

Description

This setting is used to adjust the input span in small steps. If for example the entered *span* is 2.4 V, the *offset* is 0 V, the technical units multiplier is 1 and the technical units offset is 0, the amplifier range will be set from +2 V to -2 V. However, if *fine gain* is switched on, the amplifier range will be set from -1.2 V to +1.2 V. The amplifier range is shown in the graphics at the top of the settings sheet.

D.4.8 Current loop

Introduction

The **current loop**, also known as 4-20 mA channel, is a standard in industrial and process sectors. It operates based on Ohm's law by leading the current through an internal shunt resistor and Kirchoff's current law that stipulates that the sum of all currents flowing toward a point are equal to all currents flowing into that point.

These types of sensors typically use a 4 mA zero level current, which means they can detect a broken wire or other problem by differentiating between 0 mA and 4 mA. Using a current means the signal can be used with longer lead wires and is less prone to electrical disturbances.

This allows for a cost-effective, precise current measurement with some valuable diagnostic information all-in-one channel.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Signal coupling



Summary

Defines how the analog signal is "coupled" into the amplifier.

Signal coupling



Description

This setting defines how the analog signal is "coupled" into the amplifier. The coupling feature defines which signal component (content) is passed to the amplifier.

When "AC" is selected, the AC content of a signal without any DC bias voltage is measured. With DC selection, both AC and DC content are passed to the amplifier.

A "GND" mode is usually provided to ground an amplifier to minimize the influence of random noise.

Depending on the capabilities of your hardware additional settings can include "AC external probe", "DC external probe", "Reference" or "1PPS Sync". Refer to your hardware manual for these non-standard settings.

Span



Summary

Peak-to-peak scale that the digitizer can measure at the input.

Description

Sets the full input range (peak-to-peak) of the amplifier. Combined with the *offset* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Offset



Summary

Offset positions the waveform around the specified DC.

Description

Adds a specified DC value to the measured waveform. Combined with the *span* it defines the physical measurement range. You can also use *range from* and *range to* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Range to



Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Technical units offset



Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Filter type



Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Filter frequency high



Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Impedance (RO)



Summary

Input impedance is the effective resistance and capacitance seen at the input to the digitizer.

Description

This setting is read-only and shows the effective resistance and capacitance seen at the input to the digitizer.

Capacitance



Summary

This is the capacitance range of the channel.

Capacitance



Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition systems capacitance for proper operation.

Fine gain



Summary

Select *fine gain* to adjust the input span to the signal in small steps for a maximum dynamic range without clipping the signal.

Description

This setting is used to adjust the input span in small steps. If for example the entered *span* is 2.4 V, the *offset* is 0 V, the technical units multiplier is 1 and the technical units offset is 0, the amplifier range will be set from +2 V to -2 V. However, if *fine gain* is switched on, the amplifier range will be set from -1.2 V to +1.2 V. The amplifier range is shown in the graphics at the top of the settings sheet.

D.4.9 Marker (Events)

Introduction

As opposed to an analog channel, **Marker (Events)** channels only register two levels of information: on and off, high and low, or open and close. This information is represented on the inputs as a “low” voltage (typically < 1 V) and a “high” voltage (typically > 2 V). Each channel basically provides 1-bit internal information, in contrast to the typical 16-bit data from an analog channel.

Depending on the hardware in use you can set the threshold level and a hysteresis level.

Basic settings

Invert



Summary

Inverts the input signal.

Description

Selection of this item will invert the signal.

Hysteresis



Summary

Sets the hysteresis range to ensure a clean on/off transition.

Description

This value defines the difference in the input signal before the opposite logic level will be set. This setting will be used together with the **Threshold Voltage** to define predefined switching levels.

Pull-up



Summary:

Uses the internal pull-up resistor for open collector signals.

Description:

This function can be used to select an internal resistor to work as a “pull-up”. It can be used for so-called “open collector” switches. These only supply a “short circuit” to ground when activated, but no active voltage when not activated.

Threshold level



Summary

Transition level to go from low to high.

Description

This value defines the input level from where the output transition from low to high will take place. This setting is used together with **Hysteresis** to ensure a defined switching level.

D.4.10 Thermocouple

Introduction

Thermocouples are widely used to measure temperature. A variety of thermocouples are available, suitable for different measuring applications. They are usually selected based on the temperature range and sensitivity needed.

The required cold-junction compensation is done in (front of) the data acquisition system. To achieve accurate measurements, the necessary linearization is done by the firmware in the data acquisition system.

Within the software there is also support for the commonly used Pt-100 and Pt-1000 Resistance Temperature Detectors (RTDs).

Basic settings

Type



Summary

Type of temperature sensor.

Description

Selects the kind of temperature sensor used on this input. Each type of sensor has a specific sensitivity, temperature range and other characteristics.

Scale



Summary

Temperature scale

Description

Selects the temperature unit of the sensor in use. Typical values are Kelvin, Celsius and Fahrenheit.

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range.

Range to



Summary

Upper limit of the input span.

Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass Finite Impulse Response filter.
- **Bessel:** This is a lowpass Infinite Impulse Response (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

D.4.11 Resistance thermometers

Introduction

Resistance thermometers can be used to measure temperature, just like thermocouples. Where thermocouples use the thermo-electrical effect of two materials, thermo-resistors use the change in electrical resistance to measure the temperature. This typically means they provide better stability and accuracy, but also requires the sensor to be electrically fed and usually offers a smaller temperature range to be measured.

Another difference to a thermocouple sensor is that thermo-resistors are offered in various wiring configurations, each with its own up- and downsides; for proper usage the correct wiring needs to be selected.

For more detailed information on how to configure these sensors and connect them to the data acquisition system, please refer to the datasheet of the acquisition card you are using.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Type



Summary

Type of temperature sensor.

Description

Selects the kind of temperature sensor used on this input. Each type of sensor has a specific sensitivity, temperature range and other characteristics.

Scale



Summary

Temperature scale

Scale



Description

Selects the temperature unit of the sensor in use. Typical values are Kelvin, Celsius and Fahrenheit.

Wiring

Summary

Wiring of the sensor to the amplifier

Description

Specifies how the sensor is connected to the amplifier and how the sensor is powered. Basic sensors are connected through two wires but more complex sensors may also use three or four wires.

Three or four wire sensors maybe powered through an external power source. Please refer to the documentation of the sensor and amplifier that is used for more detailed information.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its "Filter type" and "Filter Frequency", often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

Filter type



The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate

Filter frequency high



- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

Advanced settings

Capacitance



Summary

This is the capacitance range of the channel.

Description

The capacitance of a channel can be of interest when using certain sensors. Some sensors depend on the acquisition systems capacitance for proper operation.

D.4.12 Timer/Counter

Introduction

Timer/Counter channels are usually combined on a card that also provides other digital functionality.

Typical capabilities include:

- Up/down counter
- Frequency/RPM measurement
- Quadrature (position) measurement
- Angle (position) measurement

Refer to your hardware manual to find details on capabilities and connections.

In this section you set the Timer/Counter mode, reset operation, pulses per rotation for RPM and Angle measurements and the standard parameters like range and technical units.

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, sensors for all available amplifier modes are available.

Timer/Counter mode



Summary

Select the channel measurement mode.

Description

Select the mode of operation of the channel. Depending on the requirements, the channel can be set to count, to measure RPM, frequency, Angle, or to do quadrature decoding.

Reset mode



Summary

Defines on what event the counter should be reset.

Reset mode



Description

On some kinds of selections for **Timer/Counter mode** there is the possibility to reset the timer. Typical values are: Manual, Start of Acquisition.

Note

*Not all **Timer/Counter modes** have this selection enabled.*

Measuring Time



Summary

Measuring (or gate) time for RPM and frequency.

Description

Selection of the time period to measure the RPM or frequency. The gate-time determines the time interval used to resolve the count or period for the frequency or RPM information. It therefore also automatically determines the possible accuracy of the measurement. Remark: This can only be selected at certain types of **Timer/Counter mode**.

Pulses per rotation



Summary

Required value when measuring RPM (Revolutions per minute) or the Angle.

Pulses per rotation



Description

Revolutions per minute (abbreviated rpm, RPM, r/min, or r·min⁻¹) is the number of full rotations completed in one minute.

The actual count value divided by the “pulses per rotation” setting yields the RPM or Angle value.

Angular rotation is determined by the count value divided by the number of pulses per degree or rotation. Angles are always in the range 0 to 360 degrees. When using an Angle with ref pos Timer/Counter mode then reset events will result in the Angular rotation begin set to 0 (zero).

Range from



Summary

Lower limit of the input span.

Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Range to



Summary

Upper limit of the input span.

Range to



Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range. You can also use *span* and *offset* to set the measurement range. To switch between these two alternatives make a right mouse click in the column header. In the shortcut menu that comes up click **Show Ranges** to toggle the modes.

Frequency Prescaler



Summary

Allows onboard frequency dividing.

Description

By using this setting the incoming frequency is divided by the **Frequency Prescaler** value in the hardware. Making it possible to handle higher frequencies.

Technical units multiplier



Summary

Multiplier “a” in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor “a” in the formula above.

The other related settings are “Technical units offset” and “Technical units”.

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Invert clock pin



Summary

Inverts the clock input signal.

Description

Select this setting to invert the clock input signal.

Clock pin pull-up



Summary

Use the internal pull-up resistor to support open-collector driven clock input signal.

Description

The output of an open-collector output essentially acts as either an open circuit (no connection to anything) or a short-circuit to ground.

When connected to the pull-up resistor a correct voltage is applied to the clock input when the switch is open.

Clock pin hysteresis



Summary

Sets the hysteresis range of the clock input signal to ensure a stable transition from one state to another.

Description

This value defines the difference in the level of the clock input signal before the opposite logic level will be set.

This setting together with the threshold level defines a stable transition from one logic state to the other.

Clock pin threshold voltage



Summary

Defines the transition level of the clock input signal.

Description

This setting defines at what level the clock input must switch. Combined with the hysteresis it ensures a stable and defined transition.

Invert direction pin



Summary

Inverts the direction input signal.

Description

Select this setting to invert the direction input signal.

Direction pin pull-up



Summary

Use the internal pull-up resistor to support open-collector driven direction input signal.

Description

The output of an open-collector output essentially acts as either an open circuit (no connection to anything) or a short-circuit to ground.

When connected to the pull-up resistor a correct voltage is applied to the direction input when the switch is open.

Direction pin hysteresis



Summary

Sets the hysteresis range of the direction input signal to ensure a stable transition from one state to another.

Description

This value defines the difference in the level of the direction input signal before the opposite logic level will be set.

This setting together with the treshold level defines a stable transition from one logic state to the other.

Direction pin threshold voltage



Summary

Defines the transition level of the direction input signal.

Description

This setting defines at what level the direction input must switch. Combined with the hysteresis it ensures a stable and defined transition.

Invert reset pin



Summary

Inverts the reset input signal.

Description

Selection of this item will invert the signal from this input for the reset.

Reset pin pull-up



Summary

Uses the internal pull-up resistor for open collector signals.

Description

This function can be used to select an internal resistor to work as “pull-up”. It can be used for so-called “open collector” switches. These only supply a “short circuit” to ground, but no active voltage.

Reset pin hysteresis



Summary

Sets the hysteresis range to ensure a clean on/off transition.

Description

This value defines the difference in the input signal before the opposite level will be set. This setting will be used together with the **Reset threshold level** voltage to define predefined switching boundaries.

Reset pin threshold voltage



Summary

Transition level to go from low to high.

Description

This value defines the input level from where the output transition from low to high will take place. This setting is used together with **Reset Pin Hysteresis** to ensure a defined switching level.

Advanced settings

Minimum Pulse Width



Summary

Filter spikes from digital signals.

Description

The minimum pulse width can be used to filter the input signal from high-frequency noise. If the input has some noises/signals which contain higher frequencies (or shorter pulse widths) than the used filter time, the system filters out these values.

The best filter time setting is application dependent if the test environment introduces signal spikes on the measurement though electrical or magnetic disturbances AND the pulses that should be detected are wide enough. The noise can be filtered out by selecting a filter time value larger than the typical spike width but shorter than the expected valid pulse width.

For example, if a 1 kHz signal with 100 kHz noise is applied, adjusting the filter time to 10 μs is the best choice.

The default setting is 0.1 μs . This will basically not filter based on pulse width.

The table below shows the different characteristics for each setting of the input filter.

Selections	
Filter Time (μs) ¹	Min detected pulse width (μs) ¹
0.1 (default setting)	> 0.00
0.2	> 0.10
0.5	> 0.40
1	> 0.90
2	> 1.90
5	> 4.90
10	> 9.90

- (1) The character of the setting is shown in the table. According to the table, if the filter time is set on $1\ \mu\text{s}$, the input signal with the pulse width of $0.8\ \mu\text{s}$ cannot be detected. However, there is a tolerance on the setting so for example, the input signal with the pulse width of $0.95\ \mu\text{s}$ (or larger than $0.91\ \mu\text{s}$) can be detected. This is illustrated below.




Figure D.5: Pulse width settings

D.4.13 Resistor

Basic settings

Sensor



Summary

Sensor connected to the channel. Selecting a sensor will automatically setup the channel using information from the sensor database.

Description

When acquiring data, sensors are used to convert physically changing phenomena to measurable signals. To properly record this data, the acquisition system must be correctly configured. This can be achieved by manually entering the information in the relevant fields in the settings sheet, but an easy and less error-prone alternative is to use the sensor database. By selecting the correct sensor all relevant settings are automatically set.

Note

This column is only available with the sensor database option, only sensors for the current amplifier mode are available.

Completion Resistance



Summary

Electrical resistance of the bridge.

Description

The schematic in Figure D.6 below indicates the value of resistor R2. The resistor values are hardware dependent. For GEN series hardware, 120 and 350 Ohm internal resistors are typically available and there is an option to connect an external value. For more detailed and specific information, please refer to the hardware manual.




Figure D.6: Resistor mode block diagram

Excitation span



Summary

Span value for excitation.

Excitation span



Description

This setting represents the Full Scale voltage that is applied. The span is twice the **Excitation range**.

Excitation range



Summary

Range value for excitation.

Description

Represents the range of the voltage that is applied. The excitation range is bipolar and therefore half the **Excitation span**.

Wiring

Summary

Wiring of the sensor to the amplifier

Description

Specifies how the sensor is connected to the amplifier and how the sensor is powered. Basic sensors are connected through two wires but more complex sensors may also use three or four wires.

Three or four wire sensors maybe powered through an external power source. Please refer to the documentation of the sensor and amplifier that is used for more detailed information.

Range from



Summary

Lower limit of the input span.

Range from



Description

Defines the lower limit of the input span. Combined with the *range to* it defines the physical measurement range.

Range to



Summary

Upper limit of the input span.

Description

Defines the upper limit of the input span. Combined with the *range from* it defines the physical measurement range.

Technical units multiplier



Summary

Multiplier "a" in a technical units formula:

$$y = a \cdot x + b \quad (x = \text{input})$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the system or convert the measured input into a different unit. The technical units multiplier is the scaling factor "a" in the formula above.

The other related settings are "Technical units offset" and "Technical units".

Technical units offset



Summary

Offset “b” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units offset is the offset factor “b” in the formula above.

The other related settings are “Technical units multiplier” and “Technical units”.

Technical units



Summary

Units of “y” in a technical units formula:

$$y = a.x + b \text{ (x = input)}$$

Description

The measured input data can be transformed to a different scale by using the linear equation described above. This can be used for example to calibrate the channel or convert the measured input into a different unit. The technical units define the new units.

The other related settings are “Technical units multiplier” and “Technical units offset”.

Filter type



Summary

Removes unwanted frequency signal components by selecting the correct filter type.

Description

A filter can be used to suppress unwanted high-frequency signal components. A filter is defined by its “Filter type” and “Filter Frequency”, often called cut-off frequency.

Typical available filter types are:

- **FIR:** This is a lowpass **F**inite **I**mpulse **R**esponse filter.
- **Bessel:** This is a lowpass **I**nfinite **I**mpulse **R**esponse (IIR) filter.

The cut-off frequency of the filters is defined by the “Filter Frequency” setting.

Filter frequency low



Summary

Frequency below which the power is 0.5 the power of the pass band (-3 dBpoint) when using bandpass filters.

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the Filter type. The filter frequency low is only available when using a bandpass filter.

Filter frequency high



Summary

Frequency above which the power is 0.5 the power of the pass band (-3 dBpoint).

Description

The filter frequency defines the pass band of the filter. This frequency is also often called the cut-off frequency. This is the frequency where the signal has been attenuated to half the power of the pass band.

The available filter frequencies depend on the sample rate and the *Filter type*.

Typical available values are:

- **FIR:** 1/4, 1/10, 1/20 and 1/40 of the sample rate
- **Bessel:** 1/10, 1/20, 1/40 and 1/100 of the sample rate

D.5 Sensors group

D.5.1 Introduction

The **Sensors** group includes more procedures than settings. These procedures are typically used for various calibration purposes of bridge amplifiers, although some of them (balancing) can also be used in combination with basic-sensor channels.

The need for calibration arises frequently in the use of strain gauge instrumentation. Periodic calibration is required, of course, to assure the accuracy and/or linearity of the instrument itself. More often, calibration is necessary to scale the instrument's sensitivity (by adjusting gauge factor or gain) so that the registered output corresponds conveniently and accurately to some predetermined input.

The **Sensors** group provides the means to accurately determine the zero point of a bridge or sensor, to verify proper operation by means of shunt verification, and to calibrate a channel using one- or two-point calibration methods.

D.5.2 Shunt verification

Introduction

Decreasing the resistance of a bridge arm by shunting with a larger resistor offers a simple, potentially accurate means of simulating the action of a strain gauge. This method, known as shunt verification, does not place severe tolerance requirements on the shunting resistor and is relatively insensitive to modest variations in contact resistance.

Because of its numerous advantages, shunt verification is the normal procedure for verifying or setting the output of a strain gauge instrument relative to a predetermined mechanical input at the sensor.

The **Shunt verification** section provides the means to do one-click verification. It also allows you to observe the output of the bridge with a shunt applied.

Task pane

Within the **Shunt verification** section there is an area above the settings that provides:

- A graphical representation of the verification circuit
- A task pane with verification-related commands and feedback

You can also use the diagram to modify settings.

The task pane provides the following groups: **Control** and **Warnings**.

Control

Within the **Control** group there is a single command:

- **Verify** Click this command to verify the impact of the shunt resistor.

To verify the selected channel(s) the system must be acquiring data. Typically the *Pause* mode is used to do this. When the system is not acquiring data, a confirmation dialog will come up.

The verify process by itself will bring in the shunt resistor and measure the output variation (**Deflection**). This value will be compared to the **Target** value and the **Error** will be calculated.

Warnings

Within the **Warnings** group you can define a personal warning level: the error measured during verification that is unacceptable. Percentages are given as a percentage of the **Target**.

- **Warning level** Set the warning level as a percentage of the **Target**. If the error is equal to or above the set level, a warning will be generated.
- **Detected warnings** The number of detected warnings after the last verify command
- **Show only channels with warnings** If checked, only the channels that have a warning will be displayed in the settings grid. For large channel count systems this gives an instant overview of the conflicting channels.

Basic settings

Actual value (RO)

923.8

Summary

Shows actual values when monitoring is on.

Description

Use the column header context menu to turn on monitoring of the actual value of the channel. The actual value will be shown in Volts and is updated about once a second.

No Shunt (Volt/TU) – (RO)



Summary

Measured value without shunt resistor.

Description

The **No Shunt** value is the output of the bridge if no shunt resistor is applied to the active gauge(s). This value is measured when you click the verify button in the graphics area related with the shunt verification settings. The system will automatically turn off the shunt resistor and then measure the output of the bridge.

Verification of the bridge using a shunt resistor typically requires the bridge to be unloaded. The value of the bridge without a shunt resistor may be displayed as a voltage output or in technical units. If using technical units, please make sure that your bridge amplifier has been set up correctly by going through the bridge wizard, or loading a settings file or experiment containing hardware settings. The system will use the information from these sources to translate between voltage and technical units. Failing to load or set the relevant information may cause values to look inappropriate.

Shunt (Volt/TU) – (RO)



Summary

Measured value with shunt resistor.

Description

The **Shunt** value is the output of the bridge if a shunt resistor is applied to the active gauge(s). This value is measured when you click the verify button in the graphics area related with the shunt verification settings. The system will automatically turn on the shunt resistor and then measure the output of the bridge.

Verification of the bridge using a shunt resistor typically requires the bridge to be unloaded. The value of the bridge without a shunt resistor may be displayed as a voltage output or in technical units. If using technical units, please make sure that your bridge amplifier has been set up correctly by going through the bridge wizard, or loading a settings file or experiment containing hardware settings. The system will use the information from these sources to translate between voltage and technical units. Failing to load or set the relevant information may cause values to look inappropriate.

Deflection (Volt/TU) – (RO)



Summary

Measured difference between the **No Shunt** and **Shunt** measurement.

Description

After the **No Shunt** and **Shunt** values have been measured, the difference between these values is taken and displayed as the **Deflection** value. This value may be displayed in technical units or volts. You can switch between these two options by right-clicking the column header and selecting or deselecting *Show Values in TU*.

Target (Volt/TU)



Summary

Calculated target deflection

Description

When doing a shunt verification, the measured **Deflection** is compared to an expected deflection. The **Target** is the expected deflection. The value entered here will be used to verify if the difference between the bridge output value with and without a shunt resistor is within the specified tolerance. The difference between this value and the **Deflection** is represented as the error of the balance.

You can enter this value in technical units or in volts. Right-click the column header and turn the *Show Values in TU* option on or off as desired.

Error (TU/Volt) – (RO)



Summary

Difference between measured and target value.

Description

The difference between the **Target** value and the **Deflection** is represented as the **Error** of the verification. The error is noted as the absolute difference between the values.

You can enter this value in technical units or in volts. Right-click the column header and turn the *Show Values in TU* option on or off as desired.

Error (%) – (RO)



Summary

The correction made during balancing as a percentage.

Error (%) – (RO)



Description

The **Error** value as a percentage.

The difference between the **Target** value and the **Deflection** is represented as the **Error** of the verification. The error is calculated as the relative difference between the target and the deflection using the following formula:

$$\text{Error}(\%) = \text{Deflection} / \text{Target} * 100$$

You can also set up a tolerance for the error by setting the **Warning level (%)** that is shown in the graphics area of the shunt verification. If the calculated error exceeds the tolerance it will be shown in the settings sheet warning color. Refer to the color legend to see what your warning color is and how to change it.

Shunt location



Summary

Location of the shunt resistor.

Description

Specifies whether the shunt resistor that is currently in use is *Internal* or *External*.

Shunt value



Summary

Resistive value of shunt, external or internal.

Shunt value



Description

The **Shunt value** is the electrical resistance of the shunt resistor that is currently in use. If **Shunt location** is set to *Internal*, this value matches the value of the resistor in the mainframe. If set to *External*, it matches the resistance of the external custom resistor.

Note *When selecting an internal user mounted shunt resistor or an external shunt resistor you need to make sure that the correct shunt value is entered. The system by itself has no means to verify the correct values.*

Shunt active Gauge



Summary

Active gauge for shunt calibration.

Description

Defines the location of the shunt resistor: either in parallel with the gauge that is located in the positive arm of the bridge circuit or in parallel with the gauge located in the negative arm.

D.5.3 Zero Balance and Calibration

Introduction

This section is used to calibrate a channel by means of Zero balance, a single- or two-point calibration. Start and end points can be entered manually or be part of the standard bridge configuration.

The procedure measures a point and converts it to a given value. By doing so, the technical units multiplier is corrected.

A Wheatstone bridge is said to be in balance if the output voltage equals zero. This situation occurs when the bridge resistors (clockwise named R1, R2, R3, R4) have the following relation:

Note *This balance condition is valid independent of line resistance and excitation voltage.*

However, due to resistance tolerances or an inherent deviation (pre-load), a residual voltage may be present in the initial situation. To compensate for this error, the output of the bridge can be nulled.

Also, within the restrictions of your hardware, any “offset” voltage can be compensated here for basic-sensor channels.

Task pane

Within the Channel calibration section there is an area above the settings that provides:

- A graphical representation of the balance circuit
- A task pane with related commands and feedback

This task panel provides the following groups: Zero Balance, Warnings, Calibrate, Control and Amplifier




Figure D.7: Zero Balance and Calibration

- A Zero balance area
- B Warnings area
- C Calibration area
- D Control area
- E Amplifier area

Within the **Zero balance** group there are two commands:

- **Zero balance** This command will actually balance the channel(s) which have the setting “Zero balance enabled” setting set to “On”. To Zero balance the channel(s) the system must in Pause mode. When the system is not in this mode we set the mode to Pause while balancing. After balance the system will be set back to Idle. For more info see section "Zero Balancing" on page 398.
- **Verify** This command will only measure the actual input value(s) without making a physical (electrical) correction. Use this command to verify if all selected channels are still within your specifications.

Warnings

Within the **Warnings** group you can define a personal warning level: the error remaining after balancing that is unacceptable. Percentages are given as a percentage of the **Full Scale** range. Example: a **Full Scale** range of $\pm 5\text{ V}$ (= 10 V span) can have a 1% remaining error. This equals a physical deviation of $0.01 \times 10\text{ V} = 0.1\text{ V}$.

- **Warning level** Set the warning level as a percentage of the **Full Scale**. If the remaining error is equal to or above the set level, a warning will be generated.
- **Detected warnings** The number of detected warnings after the last balance or verify command
- **Show only channels with warnings** If checked, only the channels that have a warning will be displayed in the settings grid. For large channel count systems this gives an instant overview of the conflicting channels.

Calibration

Within the **Calibrate** group there are two commands: Start point and End point.

- **Start point** Apply a start reference value to the selected channel(s) and click **Start point**. This will measure the voltage that corresponds to the set start point reference value.

- **End point** Apply an end reference value to the selected channel(s) and click **End point**. This will measure the voltage that corresponds to the set end point reference value.

Control

- **Calibrate** Click **Calibrate** to actually apply the measured values to the technical units of the selected channel(s).

Amplifier

This group shows the input range of the amplifier(s) of the selected channel(s).

Basic settings

Zero Balance Enabled



Summary

Allows the channel to be zero balanced.

Description

Specifies whether the channel is allowed to be zero balanced. This option must be *ON* for actual zero balancing.

Calibration method



Summary

Type of calibration: single or two-point.

Calibration method



Description

Depending on what you want to do, you should select an appropriate **Method** of calibration. Single-point calibration can be used to determine the slope or **Technical units multiplier** of the channel. Single-point calibration requires only a single point, the end point. The start point is assumed at 0. You can also use a two-point calibration method to determine both the slope or **Technical units multiplier** and the **Technical units offset** of a channel.

Manual Entry



Summary

If ON, uses manually entered values, if OFF, measures the values.

Description

When doing a sensor channel calibration you have two options for all calibration methods. The first option is to manually set a known reference level point in **technical units** and then apply a known input signal to the channel you want to calibrate and measure this signal. The second option is to manually set a known reference point in **technical units** and also manually set the actual level.

Start point reference



Summary

Theoretical start value

Description

The **Start point reference** is the value you want to be recorded when the **Start point actual** value is measured. After you have completed the calibration, this is the value that will be displayed when the actual start point signal is applied to the amplifier.

Start point actual



Summary

Actually measured start value

Description

The actual start value is the real value at the start point. If **Manual entry** is set to *ON*, you can manually enter a value to use for calibration, for example from a spec-sheet. If the **Use shunt** setting is enabled, the actual start point will be the value measured at the amplifier without the shunt resistor.

Use the Measure Start button in the graphic area of this sheet to start the actual measurement.

End point reference



Summary

Theoretical end value

Description

The **End point reference** is the value you want to be recorded when the **End point actual** value is measured. After you have completed the calibration, this is the value that will be displayed when the actual end point signal is applied to the amplifier.

End point actual



Summary

Actually measured end value

End point actual



Description

The actual end value is the real value at the end point. If **Manual entry** is set to *ON*, you can manually enter a value to use for calibration, for example from a spec-sheet. If the **Use shunt** setting is enabled, the actual end point will be the value measured at the amplifier with the shunt resistor.

Use the Measure End button in the graphic area of this sheet to start the actual measurement.

Use shunt for end point



Summary

If *ON*, uses a shunt resistor to measure the end value.

Description

When calibrating **bridge amplifier** channels, it is possible to use a **shunt resistor** to get a measured start and end point. If the **Use shunt** setting is set to *ON*, doing a start measurement using the Measure Start button in the graphic area will automatically turn off the shunt resistor before doing the measurement. When using the Measure End button in the graphics area while the **shunt resistor** is set to *ON*, the shunt resistor will automatically be turned on before doing the measurement.

If you intend to use the **shunt resistor** for channel calibration, it is good practice to balance the channel or channels you want to set up. Doing this will automatically prepare the channel calibration values.

Status (RO)



Summary

Displays the status and result of the balancing.

Status (RO)



Description

This column will show the balancing status of the channel. Typical values are *Not Balanced* and *Balanced*. If **Balance enable** is set to *OFF*, the status is not applicable.

Deviation (TU) – (RO)



Summary

The correction made when balancing.

Description

Shows the correction that was made when the channel was balanced. This setting can be shown in technical units (default) and in volts. Use the column header context menu to toggle the view. The deviation is also shown as a percentage of the **Span** in a separate column. If **Balance enable** is set to *OFF*, the deviation is not applicable.

Deviation (%) – (RO)



Summary

The correction made during balancing as a percentage.

Description

The **Deviation** value as a percentage.

Remainder (TU) – (RO)



Summary

The value that could not be corrected.

Remainder (TU) – (RO)



Description

Shows the value that could not be corrected during balancing of the channel. This setting can be shown in technical units (default) and in volts. Use the column header context menu to toggle the view. If **Balance enable** is set to *OFF*, the remainder is not applicable.

Remainder (%) – (RO)



Summary

The correction made during balancing as a percentage.

Description

The **Remainder** value as a percentage.

D.6 Real-time calculators group

D.6.1 Introduction

The **Real-time calculators** group within the settings sheet comprises all cycle based calculators that can be setup for real-time calculators and all other settings related to how these channels behave within your measurement system.

Channels that are not supported by your hardware are not included. However, channels that are supported by your hardware, but not enabled, are displayed as disabled (greyed).

The cycle based calculators use data from the input/general section as input for the calculations performed. If input channels are used for real-time calculators, they can still be disabled for storage, in that case only the calculated results are stored and the raw data is discarded. Please note that calculation results/trigger points can be affected by the setup of the input channels. For example filtering may introduce a phase shift or amplitude change to the signal being calculated. Cycle based calculators do **not** automatically compensate for these influences. This can be done by changing the settings of input channels in the **Input** group.

Note *Real-time calculators do not introduce a phase shift to the data.*

D.6.2 Cycle based calculator

Introduction

In order to setup a cycle based calculator, first the source on which the calculation needs to be done needs to be selected. The listed sources are a combination of Analog channels, Timer/Counter channels and Cycle Source of the same recorder. Depending on the selected input channel, the list of calculations allowed is updated.

Currently all cycle based calculators operate on a periodic basis and not sample by sample. The period is determined by the selected cycle source (either a fixed time or a cycle detect on one of the analog input signals of the card).

Calculations allowed on “Analog channel” source:

Single channel calculation:

- Area
- Crest factor
- Energy
- Maximum
- Mean
- Minimum
- None
- Peak to Peak
- RMS

Note *Selecting a “cross channel” calculation type enables the **Source 2** column, containing the analog channels of the recorder.*

Calculations allowed on “Timer/Counter channel” source:

Single channel calculation:

- Frequency
- Frequency (gated)
- None
- RPM of Angle

Calculations allowed on “Cycle Source” source:

Single channel calculation:

- Cycles
- Cycle Frequency
- None

Note *These are based on the cycle source, which in turn uses an analog channel’s input to determine where cycles start and end. The output of these channels depends on **Cycle Source** settings.*

Basic settings

Enabled



Summary

When ON the channel is enabled for calculation and data storage.

Description

The enabled setting determines whether or not the data of this channel will be stored during a recording.

Name



Summary

Logical name of the channel.

Description

This is the name of the channel as used throughout Perception. The logical name is used in the data sources navigator and is used for the display, formula database, reporting, etc.

Source



Summary

The source of data on which the calculation is performed.

Description

This is the calculation source on which a calculation is wanted.

Calculation



Summary

The calculation performed by this channel on the selected source.

Description

This is the calculation performed on the calculation source data. Only Calculations that are valid for the selected source data type are shown here. When the selected source data type changes the Calculation is set to "None".

Cycle Source



Summary

The used cycle source for the calculation.

Description

This is the cycle source used for the calculation. It shows the name which can be found in the “Cycle Source” grid.

Range From



Summary

Lower limit of the measurement range.

Description

Defines the lower limit of the measurement range. Combined with the *range to* it defines the physical measurement range.

Range To



Summary

Upper limit of the measurement range.

Description

Defines the upper limit of the input measurement range. Combined with the *range from* it defines the physical measurement range.

Technical Unit



Summary

Units of the calculated quantity.

Description

The unit which is used throughout Perception to display which quantity is calculated.

Note 1



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Advanced settings

Note 2



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 3



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

Note 4



Summary

An additional field to enter miscellaneous information.

Description

Use this field to enter any additional information as text.

D.6.3 Cycle Source

Introduction

Every recorder that is real-time math capable can use multiple cycle sources. A cycle source is the source of the interval to calculate over. There are two types of cycle sources:

- 1 Timer based
- 2 Cycle detect based

In case a timer is selected, the cycle source is **not** related with any of the input data, instead on a pre-defined regular interval, calculations are performed. Calculation will always be performed at the given interval.

In case a cycle detect is selected, the interval between calculations is not constant, but determined by the signal on the source of the cycle detector. Besides having an influence on the time when calculations are performed, the source input signal may also impact whether calculations can be performed at all. If the shape (combination of amplitude and frequency) of the source signal can no longer be resolved to cycles, or if the cycles coming out no longer fall within the calculation specifications, this will be indicated in the recording and/or live display showing the cycle based calculator using this detector as cycle source.

Basic settings

Cycle Source



Summary

Method of cycle detection.

Description

Select if cycle detection should be performed based on analyzing an input signal or if a timer should be used that initiates calculations every **Timer Duration** seconds.

Available methods of cycle detection are:

- Cycle detect
- Timer

Timer Duration



Summary

Time to use in each calculation.

Description

After every timer duration, the samples within that duration are processed by the cycle based calculator and a new output value is generated.

Note

The timer duration is only available if the cycle detect is set to timer.

Source



Summary

Channel which input is used to determine cycles for this recorder.

Description

The signal coming in through this channel is analyzed by the cycle source to determine if/where new cycles start. These times are then distributed to the calculations on the recorder to invoke new calculations over the cycle.

Note

The timer duration is only available if the cycle detect is set to cycle detect.

Level



Summary

Base-line to use for the cycle detection.

Description

Cycles are detected as crossings through the base line of a signal. For a typical sine wave generator this level is 0, however there maybe influences that introduce an (DC) offset to the signal. Use this setting to compensate for this value in the cycle detection if you want to detect cycles based on crossing the base of the signal.

Note

The timer duration is only available if the cycle detect is set to cycle detect.

Hysteresis



Summary

Sets the hysteresis range for the cycle detect.

Description

The hysteresis is used to reduce the influence of noise for the **Cycle Detect**. If a signal contains noise it can cause a false level crossing. Increasing the hysteresis can help to avoid this.

With a hysteresis the cycle detect level is expanded to be a cycle detect zone that spans multiple levels. As a consequence the actual level crossing position is less clearly defined.

Note

The timer duration is only available if the cycle detect is set to cycle detect.

Direction



Summary

Sets the response direction of the level.

Description

This setting is used to determine in which direction the input signal should cross the level. The possible directions are: *Rising, Falling*.

Cycles



Summary

Sets how many level detects are required before a cycle based calculator calculates.

Description

Cycle based calculators perform calculations based on a certain period of time, the actual number of cycles required is based on the nature of your applications. Use the Cycles setting to determine how many cycles should be used.

Note

Use 0.5 to use half cycle accuracy.

D.6.4 Formula Database

Introduction

Real-time Formula Database (RT-FDB) calculators can be configured much like formulas in the Formula sheet of the Analysis option supporting flexible expressions. The RT-FDB expressions are executed in real-time while acquisition is active.

Calculations in the Formula Database are defined as:

name = expression

The name is available in the Data Sources navigator as a variable when storage is enabled (see Figure D.8). It can be found as an item in the Active.RTFormulas tree.

The name can be used as parameter in another expression, regardless of the physical order in the database.

You can enter calculations much like you would write them on paper. Standard mathematical rules apply.

Real-time Calculators		Formula Database			Unit	Result type	Storage
		Name	Expression				
GEN7X-EDRIVE							
1	MyInput	Recorder_B.Ch_B3			SyncAnalog		
2		This is a comment					
3	Multiplier	1.5 * System.Constants.Pi			Scalar		
4	MyScaledInput	RTFormulas.MyInput * RTFormulas.Multiplier + 2		V	Sync		
5	CycleInput	@HWFilter(Recorder_B.Ch_B2; 1)			SyncFilteredAnalog		
6	CycleSource	@CycleDetect(RTFormulas.CycleInput)			Cycles		
7	RMSofScaledInput	@CycleRMS(RTFormulas.MyScaledInput; RTFormulas.CycleSource)		V	Async		
8							
9		AnAlias is another name for an existing definition: it has the same type as the original					
10	AnAlias	RTFormulas.Multiplier			Scalar		
11							

Figure D.8: Example of a formula database setup

- A** Defines **MyInput** as an alias to the physical input signal Recorder_B.Ch_B3 (a synchronous signal sampled with the sample rate set for Recorder_B).
- B** Defines **Multiplier** as a scalar with value $(2.5 * \pi)$.
- C** Defines **MyScaledInput** which represents a new synchronous signal with the same sample rate as Recorder_B. The expression $(RTFormulas.MyInput * RTFormulas.Multiplier + 0.4)$ is evaluated for every sample of physical input signal **Recorder_B.Ch_B3**.
- D** Defines **CycleInput** as a lowpass filtered version of input signal Recorder_B.Ch_B2.
- E** Defines **CycleSource** as a cycle signal representing the detected cycles on the defined **CycleInput** signal using default cycle detector settings.
- F** Defines **RMSofInput** as an asynchronous signal which represents the RMS values of **MyScaledInput** calculated between the successive detected cycles of the cycle signal **CycleSource**.

The example above (see Figure D.8) shows a read-only column (**F** - Result type) which indicates the result type of each expression which is one of:

- Sync: a signal with values at equidistant time intervals; i.e. sampled using an internal time base.
- Asynch: a signal with values at non-equidistant time intervals; i.e. values computed at timestamps of cycle source events.
- SyncAnalog: a sync signal of an analog input channel.
- SyncFilteredAnalog: a sync signal of a lowpass filtered analog input channel.
- SyncTcFreq: a sync signal of a Timer/Counter channel in frequency mode.
- SyncTcCount: a sync signal of a Timer/Counter channel in counter mode.
- SyncTcAngle: a sync signal of a Timer/Counter channel in angle mode.
- SyncEventBit: a sync signal of a marker (event) channel.
- Scalar: a single numerical value.
- Cycles: a signal representing detected cycles on a periodic synchronous signal.

Limitations apply to the operations/functions that can be used in combination with certain result types.

Introduction to RT-FDB Boolean formulas

The Boolean family of RT-FDB formulas extend the real-time formula database with possibility to output and operate on values true (one) and false (zero). This allows for decision making logic to be added to the real time formula database.

The output types of these formulas are:

- SyncBool
- AsyncBool

Similar to the standard arithmetic functions, these two types cannot be mixed. Entering formulas that combines these two output types will return an error explaining the condition.

The underlying type of these variables is the same as a sync or async (Float or Double) that just takes values of 1.0 and 0.0 and does not blend in with any of the existent output types.

RTFDB Boolean formulas can be divided into two types:

- **Arithmetic Boolean formulas:** These take inputs signals or scalars in general as an input, process them and return a Boolean result.
- **Combinatorial formulas:** These only take other Boolean values or scalars as input. Any scalar input different than “zero” is considered as “one”.

When shown in Perception, the Boolean function have a different default range for better reading:

Instead of:

-10 to 10 is **-1 to 2**

The following table shows differences between **RT-FDB calculators**, **Analysis option formulas** and **Cycle Based calculators**:

	RT-FDB calculators	Analysis option formulas	Cycle Based calculators
Execution	Real-time during acquisition	Recorded data	Real-time during acquisition
Execution location	Supported mainframe and acquisition cards	PC Running Perception	Supported acquisition cards
Results can be stored in PNRF	✓	✗	✓
Triggering on results	✓ (planned)	✗	✓
Input data	Input signals and RT-FDB from mainframe	All (recorded) data sources	Input signals of own acquisition card
Input signals filtering	HW Filter before digital filter All other functions after digital filter	All input signals are used with filters applied as recorded	Input signals are digitally filtered for all functions and cycle detectors
Result editing	Results cannot be changed after recording	Formulas can be changed updating the results	Results cannot be changed after recording
CAN publishing	✓ (Asynchronous and scalar results)	✗	✗
GENDAQ API publishing	✓ (Asynchronous and scalar results)	✗	✗

Errors and warnings

Entered expressions are checked for correctness as they are entered or modified. These checks may result in an error or warning. Warnings are indicated with a yellow triangle after the line number as shown in Figure D.9.

Real-time Calculators		Name	Expression
Formula Database			
GEN7X-EDP			
FOR 1		MyInput	Recorder_B.Ch_B3
FOR 2			This is a comment
FOR 3		Multiplier	1.5 * System.Constants.Pi
FOR 4		MyScaledInput	RTFormulas.MyInput * RTFormulas.Multiplier + 2
FOR 5		CycleInput	@HWFilter(Recorder_B.Ch_B2; 1)
FOR 6		CycleSource	@CycleDetect(RTFormulas.CycleInput; 70)
FOR 7		RMSof Scaled Input	@CycleRMS(RTFormulas.MyScaledInput; RTFormulas.CycleSource)
FOR 8			

Figure D.9: RT-FDB warning notification

A Warning indicator

When clicking on the yellow triangle a description of the warning appears:





Figure D.10: Real Time Formulas warning message

This warning indicates that the entered parameter has been clipped automatically to a valid value. A recording can still be made when one or more warnings are present.

Errors are indicated with a red error symbol before the line number as shown in Figure D.11:



Real-time Calculators		NAME	f_x Expression
Formula Database		Name	Expression
GEN3	1	MyInput	Recorder_B.Ch_B3
	2		This is a comment
	3	Multiplier	1.5 * System.Constants.Pi
	4	MyScaledInput	RTFormulas.MyInput * RTFormulas.Multiplier + 2
	5	CycleInput	@HWFilter(Recorder_B.Ch_B2: 1)
	6	CycleSource	@CycleDetect(RTFormulas.CycleInput)
	7	RMSofScaledInput	@CycleRM(RTFormulas.MyScaledInput, RTFormulas.CycleSource)
	8		

Figure D.11: RT-FDB error message

A Error indicator

Resource usage

The complete set of expressions is deployed on the mainframe hardware using the following algorithms:

- A CycleDetect formula is deployed on the acquisition card of the analog input.
- A CycleEvent formula is deployed on the acquisition card of the event bit input.
- Calculations on synchronous input data are deployed on the acquisition card where the source of the synchronous data resides.
- A CycleInterval formula is deployed on the first acquisition card which needs this cycle source.
- Calculations on asynchronous data are deployed on the mainframe.
- The number of CycleDetect, CycleEvent and CycleInterval formulas that can be deployed on a recorder is limited.
- Every synchronous result which is enabled for storage increases the required storage bandwidth.

Basic arithmetic operations

The basic arithmetic operations (+, -, * and /) are supported on the following result types:

Table D.1: Operation result type

Expression1 type	Expression2 type	Operation result type	Limitations
Scalar	Scalar	Scalar	
Scalar	Synch	Synch	
Synch	Scalar	Synch	
Synch	Synch	Synch	Both sync signals must stem from the same acquisition card
Scalar	Async	Async	
Asyn	Scalar	Async	
Async	Async	Async	

Note The unary minus operation (-) is supported on: scalars, sync and async signals.

Data storage

Storage mode	Sample based calculations sample rate	Cycle based calculations sample rate
Sweep	Fast Sweep sample rate	Fast Sweep sample rate
Continuous	Continuous sample rate	Continuous sample rate
Dual	Sweeps: Fast Sweeps Sample rate Continuous: No data recorded	Sweeps: No data recorded ⁽¹⁾ Continuous sample rate ⁽²⁾
Slow-Fast Sweep	No data recorded	No data recorded

(1) This means data is not visible when displayed on a display in Sweep mode.

(2) Calculations are performed at the Fast Sweep sample rate and then down sampled and stored at the Continuous sample rate.

Note Real-time formulas are not supported when the system is in external time base mode. Deployment of any RT-FDB formula will fail when in external time base mode. Please switch the clock base setting to Decimal or Binary when working with real-time formulas.

Basic settings

Name



Summary

Logical name of the calculator result.

Description

This is the name as used throughout Perception. The logical name is used in the data sources navigator, the display and the fieldbus.

Expression



Summary

The expression to use for the calculator.

Description

This can be a composite of input signals, numerical values, calculator results, functions and mathematical operators describing the calculation(s) to execute. In case the **Name** field is empty, the contents for the expression are treated as comment.

Technical Unit



Summary

Units of the calculated quantity.

Description

The unit which is used throughout Perception to display which quantity is calculated.

Result type(RO)



Summary

Shows the type of the calculator result.

Description

Indicates the data type of the result. The result type can be:

- Sync (sample based)
- Async (cycle based)
- Cycles (cycle source output)
- Scalar
- SyncAnalog (analog input channel)
- SyncFilteredAnalog (filtered version of analog input channel)
- SyncTcFreq (Timer/Counter channel in frequency mode)
- SyncTcCount (Timer/Counter channel in counter mode)
- SyncTcAngle (Timer/Counter channel in angle mode)
- SyncEventBit (event channel bit)

Storage



Summary

When ON the calculator result is enabled for data storage.

Description

The storage setting determines whether or not the calculator results will be stored during a recording.

Color



Summary

Default trace color in displays.

Color



Description

When recorded data from this calculator is displayed, the default trace color is defined by this setting. The trace color can always be changed via the display trace properties.

Range from



Summary

Lower limit of the measurement range.

Description

Defines the lower limit of the measurement range. Combined with the *range to* it defines the physical measurement range.

Range to



Summary

Upper limit of the measurement range.

Description

Defines the upper limit of the measurement range. Combined with the *range from* it defines the physical measurement range.

Real-time calculators - Functions

Most functions accept parameters with different types. The following table shows the function result type for functions which accept multiple input parameters.

Table D.2: Functions result types

Input types	Function result type
Scalar and scalar	Scalar
Scalar and async	Async
Scalar and sync	Sync
Async and async	Async
Async and sync	Sync
Sync and sync	Sync

Note *All @Cycle... functions produce cycle based results and thus always produce async results.*

@Abs

Function

Calculates the **absolute** value of the parameter.

Syntax

`@Abs(Input1)`

Parameters

Input1 Input of type: scalar, sync or asyn

Output

The absolute value of *Input1* with the same type as *Input1*.

Description

Calculates the absolute value of the input.

Positive values remain unchanged, negative values change their sign. This function can be used to rectify signals or to force positive values for results.

Example

The following example creates a sine wave and rectifies this signal:

```
Signal = @SineWave(100)
Rectif = @Abs(RTFormulas.Signal)
```

@And

Function

Computes the combinatorial **And** between two Boolean inputs.

Syntax

```
@And(Bool_Input1; Bool_Input2)
```

Parameters

Bool_Input1 Boolean Input signal 1

Bool_Input2 Boolean Input signal 2

Output

One (Boolean True) if both input signals are true, zero (Boolean False) otherwise.

Description

Computes the combinatorial And between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \ \&\& \ \text{BoolInput2}$$

Example

The following example computes And for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
AndSig = @And(Boolean_Signal_1; Boolean_Signal_2)
```

@AronConversion

Function

Calculates the given phase in a 2 phase to 3 phase **conversion**.

Syntax

@ AronConversion(*Input1*; *Input2*; *PhaseNumber*)

Parameters

Input1 Input signal phase 1
Input2 Input signal phase 2
Cd The number of the phase to calculate

Output

The value of the given phase.

Description

Calculates the given phase in a 2 phase to 3 phase conversion.

The underlying math is as:

Phase number = 1 => $out = input1 - ((input1 + input2) / 3)$
Phase number = 2 => $out = ((-1) * input1) - input2) / 3$
Phase number = 2 => $out = input2 - ((input1 + input2) / 3)$

Example

The following example calculates the value of the phases from the signals measured with Ch_A1 and Ch_A2:

```
Phase1 = @AronConversion(Recorder_A.Ch_A1;
Recorder_A.Ch_A2; 1)
Phase2 = @AronConversion(Recorder_A.Ch_A1;
Recorder_A.Ch_A2; 2)
Phase3 = @AronConversion(Recorder_A.Ch_A1;
Recorder_A.Ch_A2; 3)
```

@ATan

Function

Calculates the **arctangent** of the input parameter.

Syntax

`@ATan(Input1)`

Parameters

Input1 Input of type: scalar, sync or async

Output

The arctangent of *Input1* with the same type as *Input1*.

Description

The ATan function returns the angle for which the tangent equals the argument. The angle is returned in radians in the range between $-\pi/2$ and $+\pi/2$. The arctangent is the inverse trigonometric function of the tangent.

Example

The following example calculates Pi by multiplying ATan(1) by four:

```
Pi = 4 * @ATan(1)
```

@ATan2

Function

Calculates the **arctangent** of the two input parameters.

Syntax

`@ATan2(Input1, Input2)`

Parameters

Input1 Input of type: scalar, sync or async

Input2 Input of type: scalar, sync or async

Output

The arctangent of the inputs.

Description

The ATan2 function computes the value of the arc tangent of Input1/Input2, using the signs of both parameters to determine the quadrant of the angle. The angle is returned in radians in the range between $-\pi$ to $+\pi$.

Example

The following example calculates Pi by multiplying ATan2(1,0) by two:

```
Pi = 2 * @ATan2(1;0)
```


@BetweenBand

Function

Determines if an input is **between** the values of two other inputs

Syntax

@BetweenBand(*Input1*; *Bound1*; *Bound2*)

Parameters

Input1 Input signal 1.
Bound1 Bound to check.
Bound2 Bound to check.

Output

One (Boolean True) if signal 1's value is between the bounds, zero (Boolean False) otherwise.

Description

Determines if a signal is between the bounds of two other inputs.

The underlying math is as:

```

Lowbound = min(bound1,bound2)
Highbound = max(bound1,bound2)
If (input1 >= Lowbound && input1 <= Highbound)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 is between the values of the signal measured with Ch_A2 and Ch_A3:

```

BBandSig = @BetweenBand(Recorder_A.Ch_A1;
                        Recorder_A.Ch_A2; Recorder_A.Ch_A3)

```

@Cosine

Function

Calculates the **cosine** of the input parameter.

Syntax

`@Cosine(Input1)`

Parameters

Input1 Input of type: scalar, sync or async signal

Output

The cosine of *Input1* with the same type as *Input1*.

Description

The Cosine function computes the trigonometric cosine of the input angle expressed in radians.

Example

The following example calculates the cosine of $\pi/2$:

```
CosHalfPi = @Cosine(System.Constants.Pi / 2)
```

@CycleArea

Function

Calculates the **area** under curve.

Syntax

@CycleArea(*Input1*, *Cd*)

Parameters

<i>Input1</i>	Input of type sync
<i>Cd</i>	The cycle source to use

Output

The area under the curve of *Input1*, the output type is async.

Description

The CycleArea function computes the area under the curve of Input1 between two successive cycles present in Cd.

Example

The following example creates a periodic cycle timer with an interval of 0.1 s. The async area signal represents the area under the input signal Recorder_A.Ch_A1 at 0.1 s intervals:

```
CycleTimer = @CycleInterval (0.1)
Area       = @CycleArea (Recorder_A.Ch_A1 ;
                        RTFormulas.CycleTimer)
```

@CycleCount

Function

Counts the number of **cycles**.

Syntax

```
@CycleCount(Cd)
```

Parameters

Cd The cycle source to use

Output

The async signal representing the number of cycles since start of recording.

Description

The CycleCount function counts the number of cycles present in *Cd*. In case the cycle source is a cycle detector this function accounts for the number of cycles set for the detector: the result of this function counts the number of cycles at the input of the cycle detector.

Example

The following example creates a cycle detector on Recorder_B.Ch_B6, and an asynchronous waveform counting the number of cycles found:

```
Filtered_B6 = @HWFilter(Recorder_B.Ch_B6; 0)  
CycleSource = @CycleDetect(RTFormulas.Filtered_B6)  
NumCycles   = @CycleCount(RTFormulas.CycleSource)
```

@CycleCrestFactor

Function

Calculates the **crest** factor of a signal.

Syntax

@CycleCrestFactor(*Input1*; *Cd*)

Parameters

Input1 Input of type sync

Cd The cycle source which determines the calculation period

Output

The crest factor of *Input1* between two successive cycles of cycle source *Cd*.
The output type is async.

Description

This function calculates the crest factor: the absolute peak amplitude of *Input1* divided by the RMS value of *Input1*.

For a pure sinusoidal input signal the crest factor is $\sqrt{2}$.

Example

The following example calculates the energy of input signal Recorder_A.Ch_A1 for every two full periods:

```

Input      = Recorder_A.Ch_A1
Filtered   = @HWFilter(RTFormulas.Input; 0; 500)
Cd         = @CycleDetect(RTFormulas.Filtered; 2)
CrestFactor = @CycleCrestFactor(RTFormulas.Input;
                                RTFormulas.Cd)

```

@CycleDetect

Function

Detects cycles on a filtered analog input signal.

Syntax

@CycleDetect(*Input1*; *Cycles*; *Level*; *Hysteresis*; *HoldoffTime*; *Direction*)

Parameters

- Input1* The filtered analog input signal on which to detect cycles. This needs to be the output of a @HWFilter function.
- Cycles* The number of cycles to use (0.5, 1, 2, 3 ... 50; default is 1).
- Level* The detection level; default is 0.
At least 1 and no more than 2000 events per second can be processed by the cycle detector. Outside of this range no cycles are detected (no trace is shown and meter shows dashes). Therefore, the 'Cycles' argument controls the operating range. The table below lists the range.

'Cycles'	Valid results in 'Operating range'
0.5	[0.5 Hz; 1 kHz]
1	[1 Hz; 2 kHz]
2	[2 Hz; 4 kHz]
...	...
50	[100 Hz; 200 kHz]

- Hysteresis* The "Hysteresis" above and below the detection level; default is 1. "Hysteresis" can be an absolute value or relative to the channel's span. Check "Hysteresis Mode" argument description.
- Hysteresis Mode* An integer value that defines the "Hysteresis" mode.
0 - Absolute mode
1 - Relative [to span percentage] mode.
In this mode, the "Hysteresis" value must vary between 1 and 10. Check additional notes. Default value is 0, absolute.
- HoldoffTime* The holdoff time to use for edge detections: edges detected within the holdoff time are suppressed; default is 0.
- Direction* Set the direction of the signal to react on (0 for rising, 1 for falling; default is rising); ignored when Cycles is 0.5.

Output (SyncBool / AsyncBool / Scalar)

A cycle signal representing detected cycles.

Description

The CycleDetect function detects cycles of periodic signals on a physical analog input. Each CycleDetect function uses a dedicated hardware cycle detector with a block diagram shown in Figure D.12.




Figure D.12: Cycle detector block diagram

The analog input signal is lowpass filtered with a **HWFilter** function. The filtered signal is fed to two edge detectors:

- Detecting rising edges
- Detecting falling edges

Both detectors use the **Level** setting as detection level which needs to be crossed, the **Hysteresis** level is used by both detectors to re-arm the level detector. **Hysteresis** parameter will be clipped from 1 to 10 percent of the channel's span, even if in absolute mode.

The **Edge selector** selects rising edges or falling edges depending on the *Direction* setting when the *Cycles* setting is greater or equal to 1. The **Edge selector** selects both rising and falling edges when the *Cycles* setting is 0.5 and the *Direction* setting will be ignored.

The selected edges are fed to the **Holdoff timer** which suppresses edge detections within the Holdoff time setting after the last passed edge detection.

Note *The Holdoff timer is a non-retriggerable one-shot timer.*

Finally the edge detections are passed to a divider which passes 1 out of N edge detections, where N equals the *Cycles* setting (for $Cycles \geq 1$) or 1 for $Cycles = 0.5$.

The output of the divider is a cycle signal which can be used to end/restart calculation periods of cycle based calculation functions (@CycleXXX).

Limitations

HoldoffTime: the holdoff time is rounded to a multiple of the sample interval.

Example

The following example creates a HWFilter and a cycle detector on Recorder_B.Ch_B6 to detect full cycles on each rising edge. The input signal is lowpass filtered at 500 Hz, and edges within 700 μ s are suppressed:

```

CdFilterFreq = 500
CdHoldoff    = 700u
Filtered     = @HWFilter(Recorder_B.Ch_B6; 0;
                    RTFormulas.CdFilterFreq)
CycleSignal  = @CycleDetect(RTFormulas.Filtered; 1; 0;
                    1; RTFormulas.CdHoldoff; 0)

```

The following example uses the same filtered signal as the previous, but this time has a relative hysteresis of 5% of the channel's span and a 50 ms hold off time:

```

CycleSignal  = @CycleDetect(RTFormulas.Filtered; 1; 0;
                    5; 0.050; 1)

```


@CycleEvent

Function

Detects **cycles** on an **event** channel bit.

Syntax

@CycleEvent(*Input1*; *Cycles*; *HoldoffTime*; *Direction*, *Timeout*)

Parameters

<i>Input1</i>	The event bit input signal
<i>Cycles</i>	The number of cycles to use (0.5, 1, 2, 3 ... 50; default is 1)
<i>HoldoffTime</i>	The hold off time to use for edge detections: edges detected within the hold off time are suppressed; default is 0
<i>Direction</i>	Set the direction of the event bit to react on (0 for rising edge, 1 for falling edge; default is rising edge); ignored when <i>Cycles</i> is 0.5 (which means both rising and falling edge)
<i>Timeout</i>	Timeout value in seconds. Select 0 to disable timeout function. Default value is 0, "disabled"

Output

A cycle signal representing detected cycles or expired timeouts. The timeout shall only be active when it is enabled.

Description

Detects cycles on an event bit input.

Timeout

The timeout timer monitors if cycle signals are generated within the specified **Timeout** time frame. Each cycle signal resets the timeout timer. When the timeout timer expires a cycle signal is generated. This cycle signal is handled by the cycle based functions (@CycleXXX).

Example

The following example creates a cycle detector on an event bit input. Every other rising edge of the event bit input results in a cycle:

```
Cd = @CycleEvent(Recorder_A.Ev_A7_01; 2)
```

@CycleFrequency

Function

Calculates the input **frequency** of a **cycle** source.

Syntax

```
@CycleFrequency(Cd)
```

Parameters

Cd The cycle source

Output

An async signal representing the frequency of the input signal of the cycle source.

Description

The **CycleFrequency** function uses the cycle source information to calculate the frequency of the cycle detector input signal. The function compensates for the number of (half-)cycles parameter of the cycle detector *Cd*. The resolution of the function output depends on the following:

- The sample rate of the cycle detector input signal: higher sample rates give higher resolution.
- The number of cycles parameter of the cycle detector: higher number of cycles gives a higher resolution (but at a lower async result rate).

Example

The following example creates a filter and a cycle detector on an analog input channel and computes the frequency of the input signal:

```
Filtered = @HWFilter(Recorder_A.Ch_A1; 0  
Cd        = @CycleDetect(RTFormulas.Filtered; 2; 0; 1)  
Ch_A1_Freq = @CycleFrequency(RTFormulas.Cd)
```

@CycleFundamentalPhase

Function

Calculates the **phase** difference of the **fundamental** frequency present in two input signals.

Syntax

@CycleFundamentalPhase(*Input1*; *Input2*; *Cd*; *MinCycleFrequency*)

Parameters

<i>Input1</i>	Reference input signal
<i>Input2</i>	Input signal
<i>Cd</i>	The cycle source which determines the calculation period
<i>MinCycleFrequency</i>	The minimum cycle frequency to account for

Output

The phase difference of the fundamental frequency present in *Input1* and *Input2*.

Description

The **CycleFundamentalPhase** function calculates the fundamental frequency from the input frequency of cycle source *Cd*. The phase of this fundamental frequency is determined for *Input1* and *Input2*, the output of this function is the difference between these two phases.

The output is in the range from 0 to 2π radians, and indicate how much *Input2* is ahead of the reference *Input1*.

In case *Input1* or *Input2* do not contain the fundamental frequency, the output of this function is unpredictable.

Limitations

The *MinCycleFrequency* parameter is used to limit the resource usage of this function: it sets the minimum cycle source frequency. In case the actual cycle source frequency drops below the *MinCycleFrequency* the function does not calculate the phase difference anymore and yields a QNaN (Quiet Not-a-Number) value.

Example

The following example computes the fundamental phase difference between analog inputs Ch_A1 and Ch_A2:

```
Filtered = HWFilter(Recorder_A.Ch_A1; 0)
Cd       = @CycleDetect(RTFormulas.Filtered; 2; 0; 1)
PhaseDiff = @CycleFundamentalPhase(Recorder_A.Ch_A1;
                                     Recorder_A.Ch_A2; RTFormulas.Cd; 20)
```

@CycleFundamentalRMS

Function

Calculates the **RMS** value of the **fundamental** frequency present in the input signal.

Syntax

```
@CycleFundamentalRMS(Input1; Cd; MinCycleFrequency)
```

Parameters

Input1 Input signal
Cd The cycle source which determines the calculation period
MinCycleFrequency The minimum cycle frequency to account for

Output

The RMS value of the fundamental of *Input1* for each detected cycle *Cd*.

Description

The **CycleFundamentalRMS** function calculates the RMS value of the fundamental of the signal for each detected cycle of cycle source *Cd*.

Limitations

The *MinCycleFrequency* parameter is used to limit the resource usage of this function: it sets the minimum cycle source frequency. In case the actual cycle source frequency drops below the *MinCycleFrequency* the function does not calculate the RMS anymore and yields a QNaN (Quiet Not-a-Number) value.

Example

The following example computes the fundamental RMS of analog input Ch_A1:

```
Filtered = HWFilter(Recorder_A.Ch_A1; 0
Cd        = @CycleDetect(RTFormulas.Filtered; 2; 0; 1
Rms       = CycleFundamentalRMS(Recorder_A.Ch_A1;
                               RTFormulas.Cd; 20)
```

@CycleInterval

Function

Generates **cycle** events at a fixed time **interval**.

Syntax

```
@CycleInterval(Interval; LeadinTime)
```

Parameters

Interval The time between two successive cycle events in seconds
LeadinTime The first cycle event offset time (default value is 0)

Output

A cycle signal with cycle events.

Description

The **CycleInterval** function creates a cycle signal with cycle events at fixed time intervals of interval seconds. The first cycle event occurs at (Interval + LeadinTime) seconds since start of acquisition.

Both the *Interval* and *LeadinTime* are rounded to a multiple of the sample interval (1 / sample rate).

- The minimum *Interval* that can be specified is 500 μ s.
- The *LeadinTime* must be in the range of *-Interval* to *+Interval*.

Example

The following example creates a cycle interval timer which generates cycle events every second, with the first cycle event at 0.5 seconds after start of the acquisition:

```
CycleTimer = @CycleInterval(1; -0.5)
```

@CycleMax

Function

Calculates the **maximum** value of a sync signal.

Syntax

`@CycleMax(Input1; Cd)`

Parameters

Input1 The sync input signal

Cd The cycle source which determines the calculation period

Output

The maximum value of *Input1* between two cycle events of *Cd*.

Description

The **CycleMax** function calculates the maximum value of the input signal during the calculation period.

Example

The following example calculates the maximum value of a signal during a full period:

```
Filtered    = @HwFilter(Recorder_A.Ch_A1; 0)
CycleDetect = @CycleDetect(RTFormulas.Filtered; 1; 0;
                          1)
Max         = @CycleMax(Recorder_A.Ch_A1;
                       RTFormulas.CycleDetect)
```


@CycleMean

Function

Calculates the **mean** value of a sync signal.

Syntax

`@CycleMean(Input1; Cd)`

Parameters

Input1 The sync input signa

Cd The cycle source which determines the calculation period

Output

The mean value of *Input1* between two cycle events of *Cd*.

Description

The **CycleMean** function calculates the mean value of the input signal during the calculation period.

Example

The following example calculates the mean value of a signal during a full period:

```
Filtered    =@HWFilter(Recorder_A.Ch_A1; 0)
CycleDetect =@CycleDetect(RTFormulas.Filtered; 1; 0;
                        1)
Mean        =@CycleMean(Recorder_A.Ch_A1;
                        RTFormulas.CycleDetect)
```

@CycleMin

Function

Calculates the **minimum** value of a sync signal.

Syntax

`@CycleMin(Input1; Cd)`

Parameters

<i>Input1</i>	The sync input signal
<i>Cd</i>	The cycle source which determines the calculation period

Output

The minimum value of *Input1* between two cycle events of *Cd*.

Description

The **CycleMin** function calculates the minimum value of the input signal during the calculation period.

Example

The following example calculates the minimum value of a signal during a full period:

```

Filtered    = @HWFilter(Recorder_A.Ch_A1; 0)
CycleDetect = @CycleDetect(RTFormulas.Filtered; 1; 0;
                          1)
Min         = @CycleMin(Recorder_A.Ch_A1;
                       RTFormulas.CycleDetect)

```

@CyclePeakToPeak

Function

Calculates the **peak-to-peak** value of a sync signal.

Syntax

```
@CyclePeakToPeak(Input1; Cd)
```

Parameters

Input1 The sync input signal

Cd The cycle source which determines the calculation period

Output

The peak-to-peak value of *Input1*.

Description

The **CyclePeakToPeak** function calculates the peak-to-peak value of the input signal during the calculation period.

Example

The following example calculates the peak-to-peak value of a signal during a full period:

```
Filtered        =@HWFilter(Recorder_A.Ch_A1; 0)
CycleDetect =@CycleDetect(RTFormulas.Filtered; 1; 0;
                          1)
Pk2Pk            =@CyclePeakToPeak(Recorder_A.Ch_A1;
                          RTFormulas.CycleDetect)
```

@CyclePhase

Function

Calculates the **phase** difference between two **cycle** signals.

Syntax

```
@CyclePhase(Cd1; Cd2)
```

Parameters

Cd1 The input cycle signal

Cd2 The reference cycle signal

Output

The phase difference between the input cycle signal and the reference cycle signal.

Description

The **CyclePhase** function calculates the phase difference between an input and a reference cycle signal. The output is in the range from 0 to 2π radians, and indicate how much *Cd1* is ahead of the reference *Cd2*.

Example

The following example calculates the phase difference between cycle detects on Ch_A1 and Ch_A2:

```
InpFilter = HWFilter(Recorder_A.Ch_A1; 1)
RefFilter = HWFilter(Recorder_A.Ch_A2; 1)
InpDetect = @CycleDetect(RTFormulas.InpFilter; 1; 0;
                        1)
RefDetect = @CycleDetect(RTFormulas.RefFilter; 1; 0;
                        1)
PhaseDiff = @CyclePhase(RTFormulas.InpDetect;
                        RTFormulas.RefDetect)
```

@CycleRMS

Function

Calculates the **RMS** value of a sync input signal.

Syntax

```
@CycleRMS(Input1; Cd2)
```

Parameters

Input1 The sync input signal

Cd The cycle source which determines the calculation period

Output

The RMS value of *Input1*.

Description

The **CycleRMS** function calculates the RMS value of a sync input signal.

Example

The following example calculates the RMS value of Ch_A1:

```
InpFilter = HWFilter(Recorder_A.Ch_A1; 1)
InpDetect = @CycleDetect(RTFormulas.InpFilter; 1; 0;
                        1)
RMS       = @CycleRMS(Recorder_A.Ch_A1;
                    RTFormulas.InpDetect)
```

@CycleRPM

Function

Calculates the **RPM** value of from the angle difference on *input1* for each detected cycle.

Syntax

@CycleRPM(*Input1*; *Cd*)

Parameters

<i>Input1</i>	Input signal
<i>Cd</i>	The cycle source which determines the calculation period

Output

The RMS value of the fundamental of *Input1* for each detected cycle *Cd*.

Calculates the RPM value from the angle difference on *Input1* for each detected cycle *Cd*.

Description

The **CycleRPM** function calculates the RPM value from the angle difference on *Input1* for each detected cycle of cycle source *Cd*.

Example

The following example calculates the RPM value from the angle measured with *Ch_A8*:

```
InpFilter = HWFilter(Recorder_A.Ch_A1; 1)
InpDetect = @CycleDetect(RTFormulas.InpFilter; 1; 0;
                        1)
RMS       = @CycleRMS(Recorder_A.Ch_A8;
                    RTFormulas.InpDetect)
```

@CycleTHD

Function

Calculates the **total distortion** of an input signal.

Syntax

@CycleTHD(*Input1*; *Cd*; *MinCycleFrequency*)

Parameters

Input1 The sync input signal
Cd The cycle source which determines the calculation period
MinCycleFrequency The minimum cycle frequency

Output

The total distortion of the input signal.

Description

The **CycleTHD** function calculates the RMS value of *Input1* and the RMS value of the fundamental frequency **F** present in *Input1*. The fundamental frequency **F** is the calculated input frequency of the cycle source *Cd*.

The CycleTHD (expressed as a percentage) is calculated from the two RMS values using the following equation:

$$\text{CycleTHD} = 100 * \sqrt{\left(\frac{\text{RMS}_{\text{input}}}{\text{RMS}_{\text{fundamental}}}\right)^2 - 1}$$

Limitations

The *MinCycleFrequency* parameter is used to limit the resource usage of this function: it sets the minimum fundamental frequency of which the total distortion is determined. In case the actual cycle source frequency drops below the *MinCycleFrequency*, the function does not calculate the distortion anymore and yields a QNaN (Quiet Not-a-Number) value.

The $\text{RMS}_{\text{input}}$ value is based on all frequencies present in the input signal (from DC to half the sample rate).

Example

The following example calculates the CycleTHD of input channel Ch_A1 (provided that the input frequency is above 20 Hz):

```
InpFilter = HWFilter(Recorder_A.Ch_A1; 1)
InpDetect = @CycleDetect(RTFormulas.InpFilter; 1; 0;
                        1)
CycleTD   = @CycleTHD(Recorder_A.Ch_A1;
                      RTFormulas.InpDetect, 20)
```


@DegreesToRadians

Function

Converts an angle from **degrees to radians**.

Syntax

@DegreesToRadians(*Input1*)

Parameters

Input1 The angle in degrees

Output

The angle in radians.

Description

The **DegreesToRadians** converts the angle *Input1* from degrees to radians using the following equation:

$$\text{DegreesToRadians} = \frac{\pi}{180} * \text{Input1}$$

Example

The following example converts an angle in degrees to radians:

```
AngleRadians = @DegreesToRadians
              (RT.Formulas.AngleDegrees)
```

@DQ0Transformation

Function

Applies the **DQ0Transformation** to the input signals.

Syntax

`@DQ0Transformation(Phase1; Phase2; Phase3; RefAngle; Comp; Transform; Orientation)`

Parameters

<i>Phase1</i>	The sync phase 1 input signal
<i>Phase2</i>	The sync phase 2 input signal
<i>Phase3</i>	The sync phase 3 input signal
<i>RefAngle</i>	The reference angle signal in radians
<i>Comp</i>	The resulting component selection: 0=direct, 1=quadrature, 2=zero
<i>Transform</i>	The transformation rule to use: 0=amplitude, 1=power (default is amplitude)
<i>Orientation</i>	The orientation rule to use: 0=wiki, 1=matlab (default is wiki)

Output

The direct, quadrature or zero component of the DQ0 transformation depending on *Comp*.

Description

The direct-quadrature-zero (DQ0) transformation (also known as Park's transformation) is a mathematical transformation used to simplify the analysis of three-phase systems.

For a more detailed description, please refer to the Reference Guide of the Perception Analysis User manual.

Example

The following example calculates the direct, quadrature and zero components using the amplitude transformation rule and the wiki orientation rule:

```
Direct = @DQ0Transformation(Recorder_A.Ch_A1;
Recorder_A.Ch_A2; Recorder_A.Ch_A3;
RTformulas.Angle; 0; 0; 0)
```

```
Quadrature = @DQ0Transformation(Recorder_A.Ch_A1;  
Recorder_A.Ch_A2; Recorder_A.Ch_A3;  
RTformulas.Angle; 1; 0; 0)  
  
Zero = @DQ0Transformation(Recorder_A.Ch_A1;  
Recorder_A.Ch_A2; Recorder_A.Ch_A3;  
RTformulas.Angle; 2; 0; 0)
```

@Equal

Function

Determines if an input is **equal** to another input.

Syntax

`@Equal(Input1; Input2)`

Parameters

Input1 Input signal 1
Input2 Input signal 2

Output

One (Boolean True) if signals have an equal value, zero (Boolean False) otherwise.

Description

Determines if a signal has the same value as another.

The underlying math is as:

```

Epsilon = 1e-9
If (abs(input1-input2) < Epsilon)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signals measured with Ch_A1 and Ch_A2 have an equal value:

```
EqualSig = @Equal(Recorder_A.Ch_A1; Recorder_A.Ch_A2)
```

@GreaterEqualThan

Function

Determines if an input is **greater than** or **equal** to another input.

Syntax

@GreaterEqualThan(*Input1*; *Input2*)

Parameters

Input1 Input signal 1

Input2 Input signal 2

Output

One (Boolean True) if signal 1 has a greater or equal value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a greater or equal value than another.

The underlying math is as:

If (input1 >= input2)
 Out = True
Else
 Out = False

Example

The following example determines if the signal measured with Ch_A1 has a greater or equal value than the signal measured with Ch_A2:

```
GreaterEQSig = @GreaterEqualThan (Recorder_A.Ch_A1 ;  
                                  Recorder_A.Ch_A2)
```

@GreaterThan

Function

Determines if an input is **greater than** another input.

Syntax

```
@GreaterThan(Input1; Input2)
```

Parameters

<i>Input1</i>	Input signal 1
<i>Input2</i>	Input signal 2

Output

One (Boolean True) if signal 1 has a greater value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a greater value than another.

The underlying math is as:

```

If (input1 > input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 has a greater value than the signal measured with Ch_A2:

```

GreaterSig = @GreaterThan(Recorder_A.Ch_A1;
Recorder_A.Ch_A2)

```

@HWFilter

Function

Creates a lowpass **filter** on an analog input.

Syntax

@HWfilter(*Input1*; *Type*; *Fc*)

Parameters

<i>Input1</i>	The sync analog input signal
<i>Type</i>	The filter type to use: 0=wideband, 1=Bessel
<i>Fc</i>	The cutoff frequency in Hz

Output

A lowpass filtered version of the analog input *Input1*.

Description

The **HWFilter** function creates a lowpass filtered version of an analog input signal specifically to be used as input for a CycleDetect function. The actual used cutoff frequency may differ from *Fc* depending on the sample rate and the availability of filter settings.

Limitations

The output of a **HWFilter** can only be used for one CycleDetect.

Example

The following example creates a lowpass filter on analog input Ch_A1 using a cutoff frequency of 100 Hz, and use that as an input for a cycle detector:

```
InpFilter = HWFilter(Recorder_A.Ch_A1; 1, 100)
InpDetect = @CycleDetect(RTFormulas.InpFilter; 1; 0; 1)
```

@LessEqualThan

Function

Determines if an input is **less than** or **equal** to another input.

Syntax

`@LessEqualThan(Input1; Input2)`

Parameters

Input1 Input signal 1

Input2 Input signal 2

Output

One (Boolean True) if signal 1 has a lower or equal value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a lower or equal value than another.

The underlying math is as:

```

If (input1 <= input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 has a lower or equal value than the signal measured with Ch_A2:

```

LessEQSig = @LessEqualThan(Recorder_A.Ch_A1;
Recorder_A.Ch_A2)

```


@LessThan

Function

Determines if an input is **less than** another input.

Syntax

@LessThan(Input1; Input2)

Parameters

Input1 Input signal 1

Input2 Input signal 2

Output

One (Boolean True) if signal 1 has a lower value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a lower value than another.

The underlying math is as:

```

If (input1 < input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 has a lower value than the signal measured with Ch_A2:

```

LessSig = @LessThan(Recorder_A.Ch_A1;
Recorder_A.Ch_A2)

```

@Max

Function

Calculates the **maximum** of two inputs.

Syntax

`@Max(Input1; Input2)`

Parameters

Input1 The first input signal

Input2 The second input signal

Output

The maximum value of *Input1* and *Input2*.

Description

The **Max** function yields the maximum of *Input1* and *Input2*.

Example

The following example calculates the maximum of input Ch_A1 and Ch_A2:

```
InpMax = @Max(Recorder_A.Ch_A1; Recorder_A.Ch_A2)
```

@Min

Function

Calculates the **minimum** of two inputs.

Syntax

@Min(*Input1*; *Input2*)

Parameters

Input1 The first input signal

Input2 The second input signal

Output

The minimum value of *Input1* and *Input2*.

Description

The **Min** function yields the minimum of *Input1* and *Input2*.

Example

The following example calculates the minimum of input Ch_A1 and Ch_A2:

```
InpMin = @Min(Recorder_A.Ch_A1; Recorder_A.Ch_A2)
```

@Modulo

Function

Calculates the remainder of a truncated division.

Syntax

@Modulo(*Input*; *Divisor*)

Parameters

<i>Input1</i>	The input
<i>Divisor</i>	The divisor

Output

The remainder of the truncated division *Input* over *Divisor*.

Description

The **Modulo** function calculates the remainder of a truncated division using the following equation:

$$\text{Modulo} = \text{Input} - \text{Divisor} * \text{trunc}\left(\frac{\text{Input}}{\text{Divisor}}\right)$$

Where $\text{trunc}(x)$ is defined as rounding x to an integer value towards zero, i.e. $\text{trunc}(-1.2)$ yields -1.

Note *The result of this function always has the same sign as **Input**.*

Example

The following example calculates the modulus of input Ch_A1 and 3.1:

```
InpMod = @Modulo(Recorder_A.Ch_A1; 3.1)
```

@Not

Function

Negates the Boolean Input.

Syntax

`@Not(Bool_Input)`

Parameters

Bool_Input1 Boolean Input signal

Output

Reverse of the boolean input signal.

Description

Negates the provided Boolean input.

The underlying math is as:

$$\text{Out} = \text{!(BoolInput)}$$

Example

The following example negates Bool_Output_Formula:

```
NotSignal = @Not( Boolean_Signal)
```

@NotEqual

Function

Determines if an input is **not equal** to another input.

Syntax

`@NotEqual(Input1; Input2)`

Parameters

<i>Input1</i>	Input signal 1
<i>Input2</i>	Input signal 2

Output

One (Boolean True) if signals have a different value, zero (Boolean False) otherwise.

Description

Determines if a signal value is not equal to another.

The underlying math is as:

```

Epsilon = 1e-9
If (!(abs(input1-input2) < Epsilon))
    Out = True
Else
    Out = False

```

Example

The following example determines if the signals measured with Ch_A1 and Ch_A2 have a not equal value:

```

NEqualSig = @NotEqual (Recorder_A.Ch_A1;
    Recorder_A.Ch_A2)

```

@Or

Function

Computes the combinatorial **Or** between two Boolean inputs.

Syntax

`@Or(Bool_Input1; Bool_Input2)`

Parameters

Bool_Input1 Boolean Input signal 1

Bool_Input2 Boolean Input signal 2

Output

One (Boolean True) if any of the input signals is true, zero (Boolean False) otherwise.

Description

Computes the combinatorial Or between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \ || \ \text{BoolInput2}$$

Example

The following example computes Or for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
OrSig = @Or(Boolean_Signal_1; Boolean_Signal_2)
```

@OutsideBand

Function

Determines if an input is **outside** the bounds of two other inputs.

Syntax

@OutsideBand(*Input1*; *Bound1*; *Bound2*)

Parameters

<i>Input1</i>	Input signal 1
<i>Bound1</i>	Bound to check
<i>Bound2</i>	Bound to check

Output

One (Boolean True) if signal 1's value is outside the bounds, zero (Boolean False) otherwise.

Description

Determines if a signal is outside the bounds of two other inputs.

The underlying math is as:

```

Lowbound = min(bound1,bound2)
Highbound = max(bound1,bound2)
If (input1 <= Lowbound || input1 >= Highbound)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 is outside the values of the signal measured with Ch_A2 and Ch_A3:

```

OBandSig = @OutsideBand(Recorder_A.Ch_A1;
                        Recorder_A.Ch_A2; Recorder_A.Ch_A3)

```


@RadiansToDegrees

Function

Converts an angle from **radians to degrees**.

Syntax

@RadiansToDegrees(*Input1*)

Parameters

Input1 The angle in radians

Output

The angle in degrees.

Description

The **RadiansToDegrees** converts the angle *Input1* from radians to degrees using the following equation:

$$\text{RadiansToDegrees} = \frac{180}{\pi} * \text{Input1}$$

Example

The following example converts an angle in radians to degrees:

```
AngleDegrees = @RadiansToDegrees
              (RT.Formulas.AngleRadians)
```

@Ramp

Function

Generates a **ramp** (sawtooth) signal.

Syntax

@Ramp(*Freq*; *Phi*)

Parameters

Freq The frequency of the ramp signal in Hz

Phi The phase shift of the generated signal in radians (default 0)

Output

A generated ramp signal ranging from -1 to +1.

Description

The **Ramp** function generates a ramp signal with given frequency and phase shift.

Example

The following example generates a ramp signal of 100 Hz:

```
MyRamp = @Ramp (100)
```

@(RT-FDB)And

Function

Computes the combinatorial **And** between two Boolean inputs.

Syntax

`@And(Bool_Input1; Bool_Input2)`

Parameters

Bool_Input1 Boolean Input signal 1 (SyncBool / AsyncBool / Scalar)

Bool_Input2 Boolean Input signal 2 (SyncBool / AsyncBool / Scalar)

Output (SyncBool / AsyncBool / Scalar)

One (Boolean True) if both input signals are true, zero (Boolean False) otherwise.

Description

Computes the combinatorial And between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \ \&\& \ \text{BoolInput2}$$

Example

The following example computes And for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
AndInp = @And(Boolean_Signal_1; Boolean_Signal_2)
```

Note *Any scalar input different than zero (0) is considered as true (1).*

@(RT-FDB)Equal

Function

Determines if an input is **equal** to another input.

Syntax

@Equal(*Input1*; *Input2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog / Scalar)

Input2 Input signal 2 (Sync / Async / Analog / Scalar)

Output (Sync / AsyncBool)

One (Boolean True) if signals have an equal value, zero (Boolean False) otherwise.

Description

Determines if a signal has the same value as another.

The underlying math is as:

```

Epsilon = 1e-9
If (abs(input1-input2) < Epsilon)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 the value of 0.5, outputting 1 if true or 0 if not.

```
EqualInp = @Equal (Recorder_A.Ch_A1; 0.5)
```

@(RT-FDB)GreaterEqualThan

Function

Determines if an input is **greater than** or **equal** to another input.

Syntax

@GreaterEqualThan(*Input1*; *Input2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog / Scalar)

Input2 Input signal 2 (Sync / Async / Analog / Scalar)

Output (SyncBool, AsyncBool)

One (Boolean True) if signal 1 has a greater or equal value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a greater or equal value than another.

The underlying math is as:

```

If (input1 >= input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 has a greater or equal value than 1.5, outputting 1 if true or 0 if false.

```
GETInp = @GreaterEqualThan(Recorder_A.Ch_A1; 1.5)
```

@(RT-FDB)GreaterThan

Function

Determines if an input is **greater than** another input.

Syntax

@GreaterThan(*Input1*; *Input2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog / Scalar)

Input2 Input signal 2 (Sync / Async / Analog / Scalar)

Output (SyncBool / AsyncBool)

One (Boolean True) if signal 1 has a greater value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a greater value than another.

The underlying math is as:

```

If (input1 > input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if 3.2 is greater than the signal measured with Ch_A1, outputting 1 if true or 0 if false.

```
GTInp = @GreaterThan(3.2; Recorder_A.Ch_A1)
```

@(RT-FDB)InsideBand

Function

Determines if an input is **inside** the **bounds** formed by the values of two other inputs.

Syntax

@InsideBand(*Input1*; *bound1*; *bound2*)

Parameters

<i>Input1</i>	Input signal 1 (Sync / Async / Analog)
<i>Bound1</i>	Bound to check (Sync / Async / Analog / Scalar)
<i>Bound2</i>	Bound to check (Sync / Async / Analog / Scalar)

Output

One (Boolean True) if signal 1's value is between the bounds, zero (Boolean False) otherwise.

Description

Determines if a signal is between the bounds of two other inputs.

The underlying math is as:

```

Lowbound = min(bound1,bound2)
Highbound = max(bound1,bound2)
If (input1 >= Lowbound && input1 <= Highbound)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 is inside the bounds formed by 2 and 4, outputting 1 if true or 0 if false.

```

IBInp1 = @InsideBand(Recorder_A.Ch_A1; 2; 4)
IBInp2 = @InsideBand(Recorder_A.Ch_A1; 4; 2)

```

Note *Both syntaxes have the same behaviour.*

Note *This formula is not supported in EtherCAT®.*

@(RT-FDB)LessEqualThan

Function

Determines if an input is **less than** or **equal** to another input.

Syntax

@LessEqualThan(*Input1*; *Input2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog / Scalar)

Input2 Input signal 2 (Sync / Async / Analog / Scalar)

Output (SyncBool / AsyncBool)

One (Boolean True) if signal 1 has a lower or equal value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a lower or equal value than another.

The underlying math is as:

```

If (input1 <= input2)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 has a lower or equal value than 5, outputting 1 if true or 0 if false.

```
LETInp = @LessEqualThan(Recorder_A.Ch_A1; 5)
```


@(RT-FDB)LessThan

Function

Determines if an input is **less than** another input.

Syntax

@LessThan(*Input1*; *Input2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog / Scalar)

Input2 Input signal 2 (Sync / Async / Analog / Scalar)

Output (SyncBool / AsyncBool)

One (Boolean True) if signal 1 has a lower value than signal 2, zero (Boolean False) otherwise.

Description

Determines if a signal has a lower value than another.

The underlying math is as:

If (input1 < input2)
 Out = True
Else
 Out = False

Example

The following example determines if the signal measured with Ch_A1 is lower than 0.7, outputting 1 if true or 0 if false.

```
LTInp = @LessThan(Recorder_A.Ch_A1; 0.7)
```

@(RT-FDB)Not

Function

Negates the Boolean Input.

Syntax

@Not(*Bool_Input*)

Parameters

Bool_Input Boolean Input signal (AsyncBool / SyncBool / Scalar)

Output (SyncBool / AsyncBool / Scalar)

Reverse of the boolean input signal.

Description

Negates the provided Boolean input.

The underlying math is as:

$$\text{Out} = \text{!(BoolInput)}$$

Example

The following example negates Bool_Output_Formula:

```
NegInp = @Not(Boolean_Signal)
```

Note Any scalar input different than zero (0) is considered as true (1).

@(RT-FDB)NotEqual

Function

Determines if an input is **not equal** to another input.

Syntax

@NotEqual(*Input1*; *Input2*)

Parameters

Input1 Input signal 1
Input2 Input signal 2

Output

One (Boolean True) if signals have a different value, zero (Boolean False) otherwise.

Description

Determines if a signal value is not equal to another.

The underlying math is as:

```

Epsilon = 1e-9
If (!(abs(input1-input2) < Epsilon))
    Out = True
Else
    Out = False

```

Example

The following example determines if the signals measured with Ch_A1 is not equal to 2, outputting 1 if true or 0 if false.

```
NEInp = @NotEqual (Recorder_A.Ch_A1; 2)
```

@(RT-FDB)Or

Function

Computes the combinatorial **Or** between two Boolean inputs

Syntax

`@Or(Bool_Input1; Bool_Input2)`

Parameters

Bool_Input1 Boolean Input signal 1 (SyncBool / AsyncBool / Scalar)

Bool_Input2 Boolean Input signal 2 (SyncBool / AsyncBool / Scalar)

Output (SyncBool / AsyncBool)

One (Boolean True) if any of the input signals is true, zero (Boolean False) otherwise.

Description

Computes the combinatorial Or between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \ || \ \text{BoolInput2}$$

Example

The following example computes Or for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
OrInp = @Or( Boolean_Signal_1; Boolean_Signal_2)
```

Note *Any scalar input different than zero (0) is considered as true (1).*

@(RT-FDB)OutsideBand

Function

Determines if an input is **outside** the **bounds** of two other inputs.

Syntax

@OutsideBand(*Input1*; *bound1*; *bound2*)

Parameters

Input1 Input signal 1 (Sync / Async / Analog)
Bound1 Bound to check (Sync / Async / Analog / Scalar)
Bound2 Bound to check (Sync / Async / Analog / Scalar)

Output (SyncBool / AsyncBool)

One (Boolean True) if signal 1's value is outside the bounds, zero (Boolean False) otherwise.

Description

Determines if a signal is outside the bounds of two other inputs.

The underlying math is as:

```

Lowbound = min(bound1,bound2)
Highbound = max(bound1,bound2)
If (input1 < Lowbound || input1 > Highbound)
    Out = True
Else
    Out = False

```

Example

The following example determines if the signal measured with Ch_A1 is outside the bounds formed by 2.5 and 3.5, outputting true if out of bounds, or false otherwise.

```

OBInp1 = @OutsideBand(Recorder_A.Ch_A1; 2.5; 3.5)
OBInp2 = @OutsideBand(Recorder_A.Ch_A1; 3.5; 2.5)

```

Note *Both syntaxes have the same behaviour.*

Note *This formula is not supported in EtherCAT®.*

@(RT-FDB)TriggerOnBooleanChange

Function

Fires a software **trigger** when a **Boolean** input **changes** state and meets the conditions provided by a given configuration.

Syntax

@TriggerOnBooleanChange(*RT-FDB channel*; *Direction*)

Parameters

RT-FDB channel Boolean Channel to be monitored for triggers (SyncBool)
Direction Direction of level crossing to be checked (Scalar)
 1 – Trigger on Positive Edge
 2 – Trigger on Negative Edge
 3 – Trigger on Both Edges

Output (Void)

This formula has no output.

Description

Fires a software trigger when an Input crosses a level and meets another input's configuration

The underlying math is as:

```

If (Direction = 1)
  If((RT-FDB channel = True) & (PreviousInput = False)
    FireTrigger()
    PreviousInput = True

If (Direction = 2)
  If((RT-FDB channel = False) & (PreviousInput = True)
    FireTrigger()
    PreviousInput = False

If (Direction = 3)
  If((RT-FDB channel = True) & (PreviousInput = False)
    FireTrigger()
    PreviousInput = True
  Else If((RT-FDB channel = False) & (PreviousInput = True)
    FireTrigger()
    PreviousInput = BelowThreshold
  
```

Example

The following example configures a Trigger to fire when BooleanSignal1 changes from false to true:

```
TrigInp = @TriggerOnBooleanChange (BooleanSignal1; 1)
```

The following example configures a Trigger to fire when BooleanSignal1 changes from true to false:

```
TrigInp = @TriggerOnBooleanChange (BooleanSignal1; 2)
```

The following example configures a Trigger to fire when BooleanSignal1 changes state:

```
TrigInp = @TriggerOnBooleanChange (BooleanSignal1; 3)
```

Note

Since the triggers generated through the RT-FDB structure are software triggers, there are some limitations to this functionality. There is a delta time between RT-FDB software triggers of at least 102 milliseconds, which means the triggers that should be fired in less than 102 ms after a previous fired trigger will be discarded.

In Figure D.14 is an example of the triggering behaviour:




Figure D.13: Behaviour of the RT-FDB triggering

Table D.3: Operations with Trigger RT-FDB Formulas

Operation	Sample based results synchronous	Cycle based results asynchronous	Storage in PNRF recording	Published to EtherCAT®
TriggerOnBoolean Change	✓	✗	Triggers Only	✗
TriggerOnLevel	✓	✗	Triggers Only	✗

@(RT-FDB)TriggerOnLevel

Function

Fires a software **trigger** when an input crosses a given threshold.

Syntax

@TriggerOnLevel(*RT-FDB channel*; *Level*; *Direction*)

Parameters

<i>RT-FDB channel</i>	Channel to be monitored for triggers (Sync)
<i>Level</i>	Level for the trigger condition (Sync, Scalar)
<i>Direction</i>	Direction of level crossing to be checked (Scalar)
	1 – Trigger on Rising Edge
	2 – Trigger on Falling Edge
	3 – Trigger on Both Edges

Output (Void)

This formula has no output.

Description

Fires a software trigger when an Input crosses a level and meets another input's configuration

The underlying math is as:

```

If (Direction = 1)
    If((RT-FDB channel > Level) & (PreviousInput = BelowThreshold)
        FireTrigger()
        PreviousInput = AboveThreshold

If (Direction = 2)
    If((RT-FDB channel < Level) & (PreviousInput = AboveThreshold)
        FireTrigger()
        PreviousInput = BelowThreshold

If (Direction = 3)
    If((RT-FDB channel > Level) & (PreviousInput = BelowThreshold)
        FireTrigger()
        PreviousInput = AboveThreshold
    Else If((RT-FDB channel < Level) & (PreviousInput = AboveThreshold)
        FireTrigger()
        PreviousInput = BelowThreshold

```

Example

The following example configures a Trigger to fire when TestSignal passes through 10 with a rising edge:

```
TrigInp = @TriggerOnLevel (TestRTFDBChannel; 10; 1)
```

The following example configures a Trigger to fire when TestSignal passes through -10 with a falling edge:

```
TrigInp = @TriggerOnLevel (TestRTFDBChannel; -10; 1)
```

The following example configures a Trigger to fire when TestSignal passes through 10 with any edge (both edge mode):

```
TrigInp = @TriggerOnLevel (TestRTFDBChannel; 10; 3)
```

Note

Since the triggers generated through the RT-FDB structure are software triggers, there are some limitations to this functionality.

There is a delta time between RT-FDB software triggers of at least 102 milliseconds, which means the triggers that should be fired in less than 102 ms after a previous fired trigger will be discarded.

In Figure D.14 is an example of the triggering behaviour:




Figure D.14: Behaviour of the RT-FDB Triggering

Table D.4: Operations with Trigger RT-FDB Formulas

Operation	Sample based results synchronous	Cycle based results asynchronous	Storage in PNRF recording	Published to EtherCAT®
TriggerOnBooleanChange	✓	✗	Triggers Only	✗
TriggerOnLevel	✓	✗	Triggers Only	✗

@(RT-FDB)Xor

Function

Computes the combinatorial **Exclusive Or** between two Boolean inputs.

Syntax

```
@Xor(Bool_Input1; Bool_Input2)
```

Parameters

Bool_Input1 Boolean Input signal 1 (SyncBool, AsyncBool, Scalar)

Bool_Input2 Boolean Input signal 2 (SyncBool, AsyncBool, Scalar)

Output (Sync / Async Bool / Scalar)

One (Boolean True) if one and only one of the Boolean inputs is one, zero (Boolean False) otherwise.

Description

Computes the combinatorial Exclusive Or between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \wedge \text{BoolInput2}$$

Example

The following example computes Exclusive Or for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
XorInp = @Xor(Boolean_Signal_1; Boolean_Signal_2)
```

Note Any scalar input different than zero (0) is considered as true (1).

@SampleCount

Function

Counts the amount of **samples** that have been captured since start of recording.

Syntax

@SampleCount(*Input1*)

Parameters

Input1 Signifies a channel on a recorder

Output

A counter that starts at 0 and increases by 1 for every sample captured. The output type is sync.

Description

This function counts the samples that have been produced and makes it available as a signal.

Example

```
Input            = Recorder_A.Ch_A1  
sampleCount = @SampleCount(RTFormulas.Input)
```

@Sine

Function

Calculates the **sine** of the input parameter.

Syntax

`@Sine(Input1)`

Parameters

Input1 Input of type: scalar, sync or async

Output

The sine of *Input1* with the same type as *Input1*.

Description

The **Sine** function computes the trigonometric sine of the input angle expressed in radians.

Example

The following example calculates the sine of $\pi/4$:

```
SinQuarterPi = @Sine(System.Constants.Pi / 4)
```

@SineWave

Function

Generates a **sine wave** signal.

Syntax

@SineWave(*Freq*; *Phi*)

Parameters

Freq The frequency of the sine wave signal in Hz
Phi The phase shift of the generated signal in radians (default 0)

Output

This function generates a sine wave signal with amplitude 1.

Description

The **SineWave** function generates a sine wave signal with given frequency and phase shift.

Example

The following example generates a sine wave signal of 100 Hz:

```
MySine = @SineWave(100)
```

@SpaceVectorInverseTransformation

Function

Applies the **inverse space vector transformation** to the parameters.

Syntax

@SpaceVectorInverseTransformation(*Alpha*; *Beta*; *Zero*; *Comp*; *Transform*)

Parameters

<i>Alpha</i>	The alpha component
<i>Beta</i>	The beta component
<i>Zero</i>	The zero(system) component
<i>Comp</i>	The resulting component selection: 0=phase1, 1=phase2, 2=phase3, 3=magnitude, 4=angle[rad]
<i>Transform</i>	The transformation rule to use: 0=amplitude, 1=power (default is amplitude)

Output

The phase1, phase2, phase3, magnitude or angle component of the inverse space vector transformation depending on *Comp*.

Description

The space vector transformation (also known as Clarke transformation) is a mathematical transformation used to simplify the analysis of three-phase systems.

For a more detailed description, please refer to the Reference Guide of the Perception Analysis User manual.

Example

The following example calculates the alpha component of the space vector transformation:

```
Phase1 = @SpaceVectorInverseTransformation(RTFormulas.
      Alpha; RTFormulas.Beta; RTFormulas.Zero;0; 0)
```


@SpaceVectorTransformation

Function

Applies a **SpaceVectorTransformation** to the parameters.

Syntax

@SpaceVectorTransformation(*Phase1*; *Phase2*; *Phase3*; *Comp*; *Transform*)

Parameters

<i>Phase1</i>	The sync phase 1 input signal
<i>Phase2</i>	The sync phase 2 input signal
<i>Phase3</i>	The sync phase 3 input signal
<i>Comp</i>	The resulting component selection: 0=alpha, 1=beta, 2=zero(system), 3=magnitude, 4=angle[rad]
<i>Transform</i>	The transformation rule to use: 0=amplitude, 1=power (default is amplitude)

Output

The alpha, beta, zero, magnitude or angle component of the space vector transformation depending on *Comp*.

Description

The space vector transformation (also known as Clarke transformation) is a mathematical transformation used to simplify the analysis of three-phase systems.

For a more detailed description, please refer to the Reference Guide of the Perception Analysis User manual.

Example

The following example calculates the alpha component of the space vector transformation:

```
Alpha = @SpaceVectorTransformation(Recorder_A.Ch_A1;
Recorder_A.Ch_A2; Recorder_A.Ch_A3; 0; 0)
```

@Sqrt

Function

Calculates the **square root** of the input parameter.

Syntax

`@Sqrt(Input1)`

Parameters

Input1 Input of type: scalar, sync or async

Output

The square root of *Input1* with the same type as *Input1*.

Description

The **Sqrt** function computes the square root of the *Input1*.

Example

The following example calculates the square root of 2:

```
Sq2 = @Sqrt(2)
```

@Tan

Function

Calculates the **tangent** of the input parameter.

Syntax

@Tan(*Input1*)

Parameters

Input1 Input of type: scalar, sync or async

Output

The tangent of *Input1* with the same type as *Input1*.

Description

The **Tan** function computes the tangent of the *Input1* which is expressed in radians.

Example

The following example calculates the tangent of $\pi/4$:

```
MyTan = @Tan(System.Constants.Pi / 4)
```

@Xor

Function

Computes the combinatorial Exclusive **Or** between two Boolean inputs.

Syntax

```
@Xor(Bool_Input1; Bool_Input2)
```

Parameters

Bool_Input1 Boolean Input signal 1

Bool_Input2 Boolean Input signal 2

Output

One (Boolean True) if one and only one of the Boolean inputs is one, zero (Boolean False) otherwise.

Description

Computes the combinatorial Exclusive Or between two Boolean inputs.

The underlying math is as:

$$\text{Out} = \text{BoolInput1} \wedge \text{BoolInput2}$$

Example

The following example computes Exclusive Or for Bool_Output_Formula_1 and Bool_Output_Formula_2:

```
MyXor = @Xor( Boolean_Signal_1; Boolean_Signal_2)
```

D.6.5 RT-FDB Publishing

Some Real-time Formula Database (RT-FDB) results can be published to external devices using a fieldbus or the GENDAQ API.

Once the RT-FDB formula is added, it will become available for publishing. Typically, these formulas are either manually entered or generated by an application such as “eDrive”, however the system also offers some reserved internal information.

Note Only *async* and *scalar* result types can be published on the fieldbus.

Reserved information	
AcquisitionState	Indicates the systems acquisition state.
AcquisitionTime	Current duration of the acquisition.
Latency	Recording time for internally process the RT-FDB data.

Note Depending on the available (fieldbus) options in the mainframe, the publication target is enabled in the **Real-time Calculators Publishing** row (see Figure D.15).




Figure D.15: RT-FDB - Publishing area

- A Click button to create CAN DBC file of current setup
- B Name of connected GEN series mainframe
- C Resource usage
- D Deployment status
- E CAN bus load contribution

- A Save CAN DBC file as...** Clicking button saves the current configuration as a CAN DBC file.
- B Mainframe: GEN7X-EDRIVE** This links allows to open the details of the RT-FDB load in the specific mainframe.
- C Resource usage** Indicates the load of the RT-FDB calculation in the mainframe processing unit.
- D Deployment status** The deployment status indicates if the formula(s) can be processed by the mainframe. If this does not state **Succeeded**, the problem is typically indicated in the RT-FDB - Publishing area by a coloured line and icon (see Figure D.16).

Real-time Calculators Publishing			
	Publish to CAN	CAN Message ID	CAN Message Byte Range
GEN7X-EDRIVE			
AcquisitionState (reserved)		100	0...3
AcquisitionTime (reserved)		101	0...3
Latency (reserved)		102	0...3

Figure D.16: Deployment status - error message

Clicking on the icon will show the cause of the problem in more detail:




Figure D.17: Error message details

Figure D.17: Error in deployment caused by missing “eDrive” license. Some formulas, such as “SpaceVectorTransformation”, are only available with licensed applications.

- E CAN bus load contribution** The CAN bus load contribution shows how much the amount of published data contributes to the total CAN bus load (see Figure D.15). The total load is based on the CAN bus bandwidth as set in the “Mainframe Settings” dialog (see Figure D.19) and the update rate selected there.

Note *This is **not** the full load on the CAN bus, only the amount contributed by the mainframe CAN bus publishing. This means that even though this number is below 100%, it is still possible the CAN bus is overloaded.*

Basic settings for RT-FDB - Publishing

Publish to GENDAQ API

Summary

Enables publishing to the GENDAQ API.

Description

If enabled, the results of this formula will be included in the data that is published through the GENDAQ API data retrieval calls.

Publish to EtherCAT®



Summary

Enables publishing to EtherCAT®.

Description

If enabled, the calculator results are published as CoE SDO and PDO on the EtherCAT® fieldbus.

Publish to CAN



Summary

Enables publishing to the connected CAN bus.

Description

If enabled, the results of this formula will be included in the data that is published through the CAN fieldbus.

CAN message ID



Summary

The formula will be published with this message ID.

Description

The formula will be automatically assigned to the first free message ID, at the first free CAN location.




Figure D.18: CAN message - Automatic indexing

The **Automatic indexing** dialog (see Figure D.18) from the **CAN bus setup** window (see Figure D.19) is used to determine the start index. The CAN message ID can be manually changed. If it is set to an ID / location combination that is already in use by another formula, an error will be generated. When this happens, the formulas in the RT-FDB will not be correctly deployed to the mainframe. Starting an acquisition in this state will result in an omission of RT-FDB results.

CAN Message Byte Range



Summary

The formula will be published at these bytes in the message frame.

CAN Message Byte Range



Description

The formula will be automatically assigned to the first free message ID (see Figure D.18), at the first free CAN location. When enabling the first formula for publish to CAN, it will be set to the start index from the mainframe properties, starting at byte **0..3**. When nothing is changed and a second formula is enabled, this will be published at the same message ID, but from byte **4..8**. Formulas will also use 4 bytes as the values are published as 32 bit floating-point numbers.

The CAN message ID can be manually changed. If it is set to an ID / location combination that is already in use by another formula, an error will be generated. When this happens, the formulas in the RT-FDB will not be correctly deployed to the mainframe. Starting an acquisition in this state will result in an omission of RT-FDB results.




Figure D.19: Mainframe settings - CAN bus setup

D.7 Trigger group

D.7.1 Introduction

Within the HBM Genesis HighSpeed data acquisition systems, typically each and every channel is equipped with a **trigger detector**, which makes it possible to record just the phenomenon of interest, instead of having to search the full memory to find it. The trigger detector gives the system the power to capture elusive, short and unpredictable events. It determines how easily you can extract the event of interest.

Using the various trigger modes, your data acquisition system is expanded to an extremely versatile transient recorder. The trigger circuits may be configured to trigger on many types of phenomena. In this section the different trigger modes and their extensions can be set.

The graphical representation can be very helpful in understanding the various modes and options.

Please refer to the manual that came with your digitizing equipment for more details on specific capabilities within your system.

D.7.2 Recorder

Introduction

Trigger settings on the **recorder** level define how you can combine the channel triggers with “external” trigger conditions. By definition the channel triggers (if on for a specific channel) are OR-ed to generate a recorder trigger.

The “external” trigger conditions define other situations for triggering. The recorder trigger can also be made available to other recorders in the same or in a Sync mainframe. The recorder can also be set to use one or more of these triggers.

The diagram gives a visual indication on the flow of the various triggers and trigger sources.

Basic settings

External trigger in



Summary

Enables the use of the external trigger input on the mainframe.

External trigger in



Description

The trigger can come from an external signal which is fed to the respective port on the mainframe's controller module. If this setting is enabled, a logical OR is applied to the combination of the internal trigger detectors of each channel and the external trigger signal.

Although this is a per-recorder setting, there is only one external trigger input for the complete mainframe. Each individual recorder can be set to accept this trigger.

However, a direction setting (if provided by the hardware) is mainframe-wide and cannot be set on a per-recorder basis.

External trigger out level



Summary

Sets the active level of the external trigger output.

Description

This setting is applicable if **External trigger out** is enabled.

Depending on your hardware, one or more of the following settings may be applicable:

- If its value is set to *High Level*, the output voltage of the output port is high only when a trigger occurs (an active-high pulse).
- If its value is set to *Low Level*, the output voltage is constantly high and becomes low when a trigger occurs (an active-low pulse).
- If its value is *Hold High Level*, the output signal becomes high when a trigger occurs and stays high until the end of the acquisition.

External qualifier in



Summary

If enabled, qualifies the trigger logic.

Description

When enabled, the qualifier signal is used as a “gate” for the channel and external triggers.

As long as the qualifier is inactive, no trigger event is passed and the recorder will not (generate a) trigger.

When enabled and the qualifier is active, triggers are “passed” and the recorder can (generate a) trigger.

Advanced settings

System trigger 1



Summary

Sends and/or receives a trigger to/from another recorder using this trigger line.

Description

There are three trigger lines on the hardware that can be used to transfer trigger signals among recorders. Each recorder can use these lines as input to or output from its trigger detection logic, or even both. Therefore this setting can take the values *Disabled*, *Transmit*, *Receive*, or *Transceive*.

System trigger 2



Summary

Sends and/or receives a trigger to/from another recorder using this trigger line.

System trigger 2



Description

There are three trigger lines on the hardware that can be used to transfer trigger signals among recorders. Each recorder can use these lines as input to or output from its trigger detection logic, or even both. Therefore this setting can take the values *Disabled*, *Transmit*, *Receive*, or *Transceive*.

System trigger 3



Summary

Sends and/or receives a trigger to/from another recorder using this trigger line.

Description

There are three trigger lines on the hardware that can be used to transfer trigger signals among recorders. Each recorder can use these lines as input to or output from its trigger detection logic, or even both. Therefore this setting can take the values *Disabled*, *Transmit*, *Receive*, or *Transceive*.

System trigger 3 transfer mode



Summary

Selects whether system trigger 3 is reserved for transferring calculated channel trigger signals or not.

Description

By default system trigger 3 is used to transfer trigger signals of calculated data between recorders.

In order to transfer trigger signals of measured data like system trigger 1 and 2, system trigger 3 must be set to *Measured data*. This setting can take either the value *Calculated data* or *Measured data*.

Master slave trigger



Summary

Sends and/or receives a trigger to/from another mainframe using this trigger line.

Description

When multiple mainframes are used to perform acquisition(s), a master/slave module is used in order to synchronize them. The master/slave line is used to transfer trigger signals between mainframes, and this setting configures how it is used.

D.7.3 Analog channel

Introduction

The **Analog channel** trigger is the center of the trigger capabilities within the data acquisition system.

The most sophisticated version is based on a digital trigger detector. For the advanced trigger modes this single-level trigger detector with programmable hysteresis has been implemented twice to provide a dual-level trigger detector with selectable hysteresis on each channel. Levels are usually referenced as primary trigger level and secondary trigger level. Various combinations of these levels provide trigger modes like basic, alarm, window, sequential and more.

In addition, capabilities are available that provide slope triggering, pulse detection, hold-off, interval detection and event count.

A separate section in this manual is committed to the numerous trigger capabilities.

Basic settings

Trigger mode



Summary

Sets the mode of the trigger detector.

Trigger mode



Description

Use this setting to enable trigger detection on a channel. The possible trigger modes are: *Off, Basic, Dual, Window, Dual Window, Sequential, Basic Qualifier, Dual Qualifier*. Refer to your hardware manual for more information on the trigger capabilities of your system.

Primary level



Summary

Sets the value of the primary level detector.

Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

As a consequence reaching the required level is not a valid trigger condition. Since trigger detection is digital, inter-sample analog values are omitted.

This setting defines the level of the primary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Note

*If the **dY/dt Trigger** is enabled, this setting is actually measured in technical units per second (for example V/s).*

Secondary level



Summary

Sets the value of the secondary level detector.

Secondary level



Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

As a consequence reaching the required level is not a valid trigger condition. Since trigger detection is digital, inter-sample analog values are omitted.

This setting defines the level of the secondary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Hysteresis



Summary

Sets the hysteresis range for both trigger detectors.

Description

The hysteresis is used to reduce the influence of noise for the **Primary level** and the **Secondary level**.

If a signal contains noise it can cause a trigger detector to produce a false trigger. Increasing the hysteresis can help to avoid this.

With a hysteresis the trigger level is expanded to be a trigger zone that spans multiple levels. As a consequence the actual trigger position is less clearly defined.

Direction



Summary

Sets the response direction of the primary level. The direction of the secondary level will be set to the opposite direction by definition.

Description

This setting is used to determine in which direction the input signal should cross the primary level. Depending on the **Trigger mode**, the direction is used to arm or trigger the input. The possible directions are: *Rising, Falling*.

Advanced settings

dY/dt Trigger



Summary

Enables slope trigger to react on the difference in amplitude between a number of samples.

Description

Enabling this setting means that the trigger detector reacts on the difference of the input signal levels between the number of samples specified in **Delta time window**, rather than the signal level of the current sample. In other words, the triggering mechanism detects a slope change on the input signal.

Delta time window



Summary

Sets the time window for the **dY/dt Trigger**.

Delta time window



Description

This setting is available if the **dY/dt Trigger** is enabled.

The trigger detector calculates the signal slope in the time interval defined by this setting. If the slope matches the conditions set by the settings **Direction**, **Primary level** and **Secondary level** (if applicable), a trigger is generated and positioned at the window's last sample.

Pulse detector



Summary

Enables pulse detection/rejection.

Description

The pulse detector can be used together with the basic (slope) trigger level detector. The possible values are: *Disabled*, *Detect*, *Reject*. The **Pulse width** is used to define the width of the pulses which should be detected or rejected.

Pulse width



Summary

Sets the width of the pulse detection/rejection.

Description

Use this setting to set the width of the pulses which should be detected or rejected. The pulse width is only used if the **Pulse detector** is set to *Detect* or *Reject*. The value is specified in seconds or external time base units depending on the mainframe **Clock base** setting.

Hold-off time



Summary

Disables the trigger detector for a specified period of time after a valid trigger has been generated.

Description

The trigger hold-off feature is used to disable the trigger detector for a period of time after a valid trigger has been generated. This can be used to generate only one trigger on a slowly decaying repetitive signal, or eliminate the effect of after-ringing.

The feature is most useful in combination with the interval **Timer** and/or the **Event counter**.

Timer



Summary

Defines a time relation between two consecutive trigger events.

Description

The interval timer is used to define a time relation between two trigger events. If the time relation is correct, a trigger is generated. The possible timer modes are: *Disabled, Less, More, Between, NotBetween*.

Timer window start



Summary

Defines the first interval used for the interval timer.

Timer window start



Description

Depending on the interval timer mode, there is a difference in functionality for this setting:

- For the *Less* and *More* mode, this setting is the width of the interval.
- For *Between* and *NotBetween*, this setting is the time after which the **Timer window width** interval is used.

The value is specified in seconds or external time base units depending on the mainframe **Clock base** setting.

Timer window width



Summary

Defines the second interval used for the interval timer.

Description

The trigger window width is only used if the **Timer** mode is set to *Between* or *NotBetween*.

The value is specified in seconds or external time base units depending on the mainframe **Clock base** setting.

Event counter



Summary

Counts a number of trigger events before the actual trigger is generated.

Description

The event counter adds all generated triggers and generates a final trigger if the count equals the preset value.

D.7.4 Marker channel

Introduction

You can trigger on a marker (event) channel. Marker channels have only two electrical states: high and low. You can trigger on a transition between the two levels.

Basic settings

Trigger mode



Summary

Sets the mode of the marker channel trigger detector.

Description

Use this setting to enable trigger detection on a marker channel.

Depending on your hardware possible trigger modes are: *Off*, *Rising*, *Falling*, *Qualifier High* and *Qualifier Low*.

D.7.5 CAN-Bus channel

Introduction

You can trigger on a CAN-Bus channel. Essentially the result of a CAN-Bus channel is a range of numbers, just like digitized analog data.

The trigger capabilities include basic trigger modes on a dual-level trigger detector with hysteresis.

Basic settings

Trigger mode



Summary

Sets the mode of the CAN-Bus channel trigger detector.

Description

Depending on your hardware possible trigger modes are: *Off*, *Basic*, *Dual*, *Basic Qualifier* and *Dual Qualifier*.

Primary level



Summary

Sets the value of the primary level detector.

Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

As a consequence reaching the required level is not a valid trigger condition. Since trigger detection is digital, inter-sample analog values are omitted.

This setting defines the level of the primary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Secondary level



Summary

Sets the value of the secondary level detector.

Secondary level



Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

As a consequence reaching the required level is not a valid trigger condition. Since trigger detection is digital, inter-sample analog values are omitted.

This setting defines the level of the secondary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Hysteresis



Summary

Sets the hysteresis range for both trigger detectors.

Description

If a signal contains noise it can cause a trigger detector to produce a false trigger. Increasing the hysteresis can help to avoid this.

With a hysteresis the trigger level is expanded to be a trigger zone that spans multiple levels. As a consequence the actual trigger position is less clearly defined.

Direction



Summary

Sets the response direction of the primary level. The direction of the secondary level will be set to the opposite direction by definition.

Direction



Description

This setting is used to determine in which direction the input signal should cross the primary level. Depending on the **Trigger mode**, the direction is used to arm or trigger the input. The possible directions are: *Rising, Falling*.

D.7.6 Calculated Channel

Introduction

A calculated channel produces results on which you can trigger. Calculated channels support Basic trigger mode (see "Basic trigger mode" on page 505) and Dual trigger mode (see "Dual trigger mode" on page 506). For detailed information about triggering on calculated channels see "Trigger detector" on page 822.

Trigger mode



Summary

Sets the mode of the calculated channel trigger detector.

Description

Use this setting to enable trigger detection on a calculated channel. The possible trigger modes are: *Off, Basic, Dual*.

Primary level



Summary

Sets the value of the primary level detector.

Primary level



Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

This setting defines the level of the primary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Secondary level



Summary

Sets the value of the secondary level detector.

Description

The fundamental trigger detection is based on level crossing: a signal has to go through a specified level before it is considered to be a trigger condition.

This setting defines the level of the secondary trigger detector. **Direction** and **Hysteresis** are used to further define the actual trigger condition.

Hysteresis



Summary

Sets the hysteresis range for both trigger detectors.

Description

The hysteresis is used to reduce the influence of small variations in the result of a calculated channel for the **Primary level** and **Secondary level**.

Direction



Summary

Sets the response direction of the primary level. The direction of the secondary level will be set to the opposite direction by definition.

Description

This setting is used to determine in which direction the input signal should cross the primary level. Depending on the **Trigger mode**, the direction is used to arm or trigger the input. The possible directions are: *Rising*, *Falling*.

D.8 Alarm group

D.8.1 Introduction

Most boards allow you to generate an **alarm**. Alarm detection typically uses a simplified trigger detector. While a trigger detector generates a trigger signal that controls the acquisition/storage, an alarm condition only flags a specific situation. Usually this signal is also available as an electric signal on the data acquisition system.

D.8.2 Channel

Introduction

The alarm capabilities of an analog **channel** typically include two trigger modes on a dual-level trigger detector.

Basic settings

Alarm mode



Summary

Sets the mode of the alarm detector.

Description

Use this setting to enable an alarm on a channel. Typical enabled alarm modes are *basic*, which uses a single level detection, and *dual*, which uses two levels.

Refer to the general trigger section for more details.

Primary level



Summary

Sets the value of the primary level for the alarm detector.

Description

The fundamental alarm detection is based on level crossing: a signal has to go through a specified level before it is considered to be an alarm condition.

As a consequence reaching the required level is not a valid alarm condition. Since alarm detection is digital, inter-sample analog values are omitted.

This setting defines the level of the primary alarm detector. **Direction** is used to further define the actual alarm condition.

Refer to the general trigger section for more details.

Secondary level



Summary

Sets the value of the secondary level for the alarm detector.

Description

The fundamental alarm detection is based on level crossing: a signal has to go through a specified level before it is considered to be an alarm condition.

As a consequence reaching the required level is not a valid alarm condition. Since alarm detection is digital, inter-sample analog values are omitted.

This setting defines the level of the secondary alarm detector. **Direction** is used to further define the actual alarm condition.

Refer to the general trigger section for more details.

Alarm direction



Summary

Sets the response direction of the primary level. The secondary level will be set to the opposite direction.

Description

Use this setting to control the alarm logic. You can select whether an alarm should be generated on a *falling* or *rising* signal. If you set the value to *falling* with a **dual alarm mode**, this means the **Primary level** will be detected on a *falling* signal and the **Secondary level** on a *rising* one.

Refer to the general trigger section for more details.

D.8.3 Marker

Introduction

The alarm capabilities of a marker channel typically include only a high and a low capability.

Basic settings

Alarm mode



Summary

Sets the mode of the alarm detector.

Description

Use this setting to enable an alarm on a channel. Typical enabled alarm modes for markers are *High* or *Low*, which use a specific level change, and *Both Edges*, which uses any level change.

Please refer to your hardware manual to read more about the alarm capabilities of your system as the capabilities may differ depending on the hardware used.

D.8.4 Timer/Counter

Introduction

Currently there are no alarm capabilities for Timer/Counter channels.

E Real-Time Calculations Explained

E.1 Introduction

A calculated channel performs real-time calculations on samples of an input signal for the duration of a calculation period. The calculated channel produces a result at the end of such a calculation period. After producing a result, a new calculation is started. Which calculation formula is used can be selected for each calculated channel. Calculated channels operate only when using an internal time base (decimal or binary). All calculated channels are disabled when an external time base is used.




Figure E.1: Real-time calculations block diagram

The cycle source output is used by all calculated channels (except the Timer/Counter channels) to end the current calculation period, produce a calculation result and to start a new calculation. A recorder has one cycle source. The following cycle sources can be selected:

- A periodic timer providing a signal at a fixed interval that can be selected.

- A cycle detector allowing calculation periods to be based on cycles of an analog input signal.

A recorder has multiple calculated channels. Three types of calculated channels are available:

- Analog calculated channels process samples of an analog input channel. The calculation periods are determined by the cycle source.
- Cycle source calculated channels provide information about the selected cycle source. Two formulas are available: Cycles (a square wave representing the actual calculation periods) or Cycle frequency (a trace representing the input frequency of the cycle source).
- Timer/Counter calculated channels process samples of a Timer/Counter input channel which is set to either frequency or RPM mode.

E.2 Cycle source

E.2.1 Timer

The timer provides a periodic signal to the calculated channels at a fixed interval. The interval is set in milliseconds but is internally rounded to the nearest multiple of the sample interval. The first calculation period of the calculated channels starts at the first sample of the acquisition.

E.2.2 Cycle detector

The cycle detector provides a signal to the calculated channels at selected level crossings of an analog input signal. The cycle detector consists of a level crossing detector, followed by a counter/filter. The level crossing detector detects rising and falling level crossings. The counter/filter is used to select half cycle or (multiple) full cycle mode. In multiple cycle mode, the level crossing direction can be selected (rising or falling). The first calculation period of the calculated channels starts at the first selected level crossing after the start of acquisition.

2.2.1 Level crossing detector operation

The level crossing detector uses two thresholds: +Threshold (level + hysteresis) and -Threshold (level - hysteresis). The area between these two thresholds is called the hysteresis band.




Figure E.2: Level crossings

- A** Level crossing at rising edge
- B** Level crossing at falling edge
- C** Hysteresis band

- k1** Last sample below -Threshold
- k2** First sample above +Threshold
- k3** Last sample above +Threshold
- k4** First sample below -Threshold

A sample of the input signal can be in one of three states: above, within or below the hysteresis band. The timestamps for state changes and the sample values at a state change are used to determine the level crossing times using the following table:

State sequence	Level crossing	Level crossing timestamp
below → within → above OR below → above	rising level crossing	calculated using linear interpolation between timestamp/value of last sample below hysteresis band and first sample above hysteresis band (k1 and k2 in Figure E.2)

State sequence	Level crossing	Level crossing timestamp
above → within → below OR above → below	falling level crossing	calculated using linear interpolation between timestamp/value of last sample above hysteresis band and first sample below hysteresis band (k3 and k4 in Figure E.2)
above → within → above	none	
below → within → below	none	

Input signal slew rate limitation

The cycle detector always detects cycles too late for real-time calculations. Looking at Figure E.2 on page 811, the center amplitude crossing (**A**) is found at the time of **k2** and the center amplitude crossing (**B**) is found at the time of **k4**. To compensate for this, the cycle detector processes samples as they are taken, while the calculations on these samples are postponed for 10 ms. This means that the time difference between the real crossing (**A**) and the time of **k1** may not be more than 10 ms. In other words, the time between **k1** and **k2** may not be more than 20 ms.

Figure E.3 shows an analog input signal (blue) and the output of a calculated channel (green) using a “Maximum” formula. The lower graph shows the calculation periods (black) as detected by the cycle detector.




Figure E.3: Cycle detector input signal slew rate too low

- A** Input signal crosses the +threshold in downwards direction: the detector is waiting for the input signal to drop below the -threshold.
- B** Input signal drops below the -threshold: the detector calculates the time of zero crossing (using linear interpolation), but determines that the zero crossing occurred more than 10 ms in the past. An event bar marker I “Cycle signal amplitude too small” is generated when the input signal enters the hysteresis band.
- C** Input signal crosses -threshold in upwards direction: the zero crossing detector is waiting for the input signal to rise above the +threshold.
- D** Input signal rises above the +threshold: the detector calculates the time of zero crossing (using linear interpolation), but determines that the zero crossing occurred more than 10 ms in the past. Samples older than 10 ms have already been processed (i.e. the older samples are included in the current calculation period). This means that it is too late to stop the current calculation period at the correct time. The next rising edge (when detected correctly) will stop the current calculation period.
- E** Input signal enters the hysteresis band.
- F** Input signal leaves the hysteresis band: a valid zero crossing has been detected (less than 10 ms in the past). The detector was set to detect rising edges, so this zero crossing is not used to end/start a calculation period.

- G** Input signal crosses -threshold in upwards direction: the zero crossing detector is waiting for the input signal to rise above the +threshold.
- H** Input signal rises above the +threshold: a valid rising edge has been detected (less than 10 ms in the past). An event bar marker **J** “Cycle signal within range” is generated at the time after the last rejected zero crossing. The current calculation period ends, the calculated results become available and a new calculation period is started.
- I** The event bar marker **I** “Cycle signal amplitude too small” denotes the first time that the input signal stays within the hysteresis band for too long (low slew rate of the input signal around the detector level). If the input signal stays within the hysteresis band for too long on subsequent occasions, an event marker will not be generated.
- J** The event bar marker **J** “Cycle signal within range” indicates that the cycle detector is operating normally again.

The level crossing detector also detects whether the input signal stays within the hysteresis band for more than 20 ms. When the input signal stays within the hysteresis band for more than 20 ms, the following two things occur (see Figure E.4):

- No level crossing is reported to the counter/filter.
- An event bar marker (**C**) is generated at the position where the signal entered the hysteresis band.

To prevent numerous event bar markers from being generated, event bar markers are not generated on subsequent occasions when the level crossing detector detects this condition repeatedly. As soon as the level crossing detector has not detected this condition for at least 1 s, an event bar marker (D) is generated at the end of the last time period when this condition occurred.




Figure E.4: Temporary low signal amplitude

- A** Input signal enters the hysteresis band and stays there for longer than 20 ms. An event bar marker **C** is generated, indicating the start of a low slew rate/amplitude condition.
- B** Input signal leaves the hysteresis band. An event bar marker **D** is generated, indicating the end of the low signal amplitude condition.

Note *Setting lower threshold levels would result in cycles being detected even if the input signal had a low amplitude.*

Note *The time T between consecutive rising edges is shorter than the cycle detector timeout of 1 s. Therefore, the calculation period is still valid.*

State change limitation

The level crossing detector can handle up to 80,000 state changes per second. If the input signal causes more state changes, the detector will lose track of the input signal.




Figure E.5: Cycle detector input signal frequency too high

- A** Event bar marker “Cycle signal frequency too high” indicates that the calculation period(s) will be extended by an integral number of cycles to obtain a calculation period of $> 900 \mu\text{s}$.
- B** Event bar marker “Cycle detector overload” indicates that the input signal frequency of the cycle detector is so high that it cannot determine zero crossings anymore. The current calculation period is aborted (no results generated). The cycle detector will wait until the input signal is within normal operating range again for at least 1 second.
- C** Event bar marker “Cycle signal within range” indicates that the input signal is within normal operating range again. A new calculation period starts.

Figure E.5 and Figure E.6 show what happens when the detector loses track of the input signal: an event bar marker (**B**) is generated close to the position where it was detected. Repeatedly generating event bar markers to report such a condition is suppressed for 1 s. Calculated channels that depend on the output of the cycle detector abort their current calculation period.




Figure E.6: Cycle detector input signal frequency crossing threshold too often

- A** Event bar marker “Cycle signal frequency too high” indicates that the calculation period(s) will be extended by an integral number of cycles to obtain a calculation period of $> 900 \mu\text{s}$.
- B** Event bar marker “Cycle detector overload” indicates that the input signal of the cycle detector crosses the threshold too often. The detector does not determine zero crossings anymore. The current calculation period is aborted (no results generated). The cycle detector will wait until the input signal is within normal operating range again for at least 1 second. The cycle detector will then resume normal operation.
- C** Event bar marker “Cycle signal within range” indicates that the input signal is within normal operating range again. A new calculation period starts.

Counter/filter operation

The counter/filter receives rising and falling level crossings from the level crossing detector. The counter/filter then produces a signal at which the calculated channels produce a result and start a new calculation period. The counter/filter can be set to half cycle mode or full cycle mode. In half cycle mode, all rising and falling level crossings are passed to the calculated channels. In full cycle mode, the direction (rising or falling) and the number of full cycles can be selected where the calculated channels are signaled.

Cycle detector time out




Figure E.7: Cycle detector time out

- A** Valid rising edge detected: ends the current calculation period and starts a new calculation period.
- B** First falling edge with low slew rate detected: causes the event bar marker **J** “Cycle signal amplitude too small” to be generated.
- C** Signal leaves hysteresis band for long period. No valid rising edge detected within 1 s after previous valid rising edge (**A**): the cycle detector generates the event bar marker **I** “No cycles detected” at the time of the last valid rising edge. The current measurement period is aborted.
- D** The trace of a cycle-based calculation ends here because no result will become available.

- E** The rising edge is rejected due to a low slew rate. The calculation period does not start.
- F** A valid falling edge is detected, but the detector is set to start calculations at rising edges.
- G** A valid rising edge is detected: an event bar marker **K** “Cycle signal within range” signals the end of the “Cycle signal amplitude too small” condition. At the same time, the event bar marker **J** “Cycle signal within range” is generated to signal the end of the “No cycles detected” condition. A new calculation period starts here.
- H** The trace of a cycle-based calculation appears again.
- I** Event bar marker indicating “No cycles detected”: no calculation results will be available.
- J** Event bar marker indicating the start of a low cycle detector input signal slew rate.
- K** Event bar marker indicating the end of the low cycle detector input signal slew rate.
- L** Event bar marker indicating “Cycle signal within range”: calculations started again. The results will become available.

An event bar marker (**I**) is generated if no cycles are detected for a period longer than 1 s. Calculated channels that depend on the output of the cycle detector abort their current calculation period. When a cycle is detected again, another event bar marker (**L**) is generated and the calculated channels starts a new calculation period.




Figure E.8: Cycle detector high input signal frequency

- A** Start of a new calculation period.
- B** End of the previous calculation period (duration: 1000 μs), start of a new calculation period.
- C** Zero crossing too close (400 μs) to the start of the current calculation period: the zero crossing is ignored and the calculation continues.
- D** Zero crossing too close (800 μs) to the start of the current calculation period: the zero crossing is ignored and the calculation continues.
- E** Zero crossing accepted: the current calculation period ends (duration: 1200 μs) and a new calculation period starts.
- F** End of previous calculation period (duration: 1000 μs) and start of new calculation period.
- G** Event bar marker “Cycle signal frequency too high”.
- H** Event bar marker “Cycle signal within range”.

The cycle detector is rate-limited. It does not signal a new calculation period within 900 μs after the start of the current calculation period. If the cycle detector detects such a rate-limiting condition, an event bar marker (**G**) is generated and the current calculation period is extended by one half cycle or one full cycle (dependent on half/full cycle mode). The cycle detector keeps extending the calculation period until the calculation period lasts at least 900 μs . As soon as the rate-limiting condition has ceased to exist, another event bar marker (**H**) is generated to indicate that the cycle detector is operating normally again.

E.3 Calculated channels

E.3.1 Processing

A calculated channel processes input samples using a formula that can be selected. The calculation is performed during a calculation period. When the calculation period ends:

- A result is generated. This result is positioned at the *start* of the calculation period.
- The result is processed by the trigger detector.
- The calculator is reset.
- A new calculation period starts.

Calculated channels which depend on the cycle detector cannot produce calculation results in the following circumstances:

- The cycle detector reports that no cycles have detected for longer than 1 s.
- The cycle detector reports that a state change limitation condition exists.
- The span or offset of the input channel has changed: the input signal is temporarily invalid.
- The span or offset of the cycle detector input channel has changed: the cycle detector signal is temporarily treated as being invalid.

In all these cases, the current calculation period is aborted and a new period is started as soon as all conditions are back to normal.

All calculated channels provide technical units, multiplier and offset settings to provide user scaling of the calculated results.

E.3.2 Trigger detector

Every calculated channel has its own trigger detector that provides basic and dual trigger modes (see also “Trigger Modes” on page 505). Trigger levels are compared to the calculated (user scaled) results. An enabled trigger detector of a calculated channel can generate a *calculated trigger*. Calculated triggers will always result in a recorder trigger.

Due to the fact that calculated results become available at the end of a calculation period, but the timestamp is for the start of the calculation period, a calculated trigger is always generated too late. The system automatically compensates for this, but this time compensation is limited.

Calculated triggers are shown on the event bar with two timestamps: the first timestamp represents the trigger position on which the recorder(s) actually triggered, the second timestamp (in parenthesis) represents the intended calculated trigger position. Figure E.9 shows a calculated trigger which has been compensated for automatically: the calculated trigger position (**B**) is equal to the actual trigger position (**A**).




Figure E.9: Calculated trigger fully compensated

- A** Actual trigger position
- B** Calculated trigger position

Figure E.10 shows a calculated trigger which could not be fully compensated: the calculated trigger position (**C**) is not equal to the actual trigger position (**B**). An additional event bar marker (**A**) is placed at the intended calculated trigger position.




Figure E.10: Calculated trigger not fully compensated

- A** Marker at intended (calculated) trigger position
- B** Actual trigger position
- C** Calculated trigger position

In order to send the calculated triggers to other recorders within the same mainframe, the System trigger 3 mode must be set to 'Calculated' with transmit enabled, using the advanced settings of the sending recorder:




Figure E.11: Enabling sending calculated triggers to other recorders

A System trigger 3 mode (set to sending calculated triggers)

In order to receive calculated triggers from other recorders, the System trigger 3 mode must be set to 'Calculated' with receive enabled, using the advanced settings of the receiving recorder:




Figure E.12: Enabling receiving calculated triggers from other recorders

A System trigger 3 mode (set to receiving calculated triggers)

E.4 Analog calculated channels

All analog calculated channels require a cycle source to determine the calculation period and an analog input channel on which the calculation needs to be performed.

E.4.1 Area

Function

Calculates the area under the curve.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

Let Δt be the time between two consecutive samples.

$$\text{Area} = \left(\sum_{n=i}^j |y_n| \right) \cdot \Delta t$$

E.4.2 Energy

Function

Calculates the energy under the curve.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

Let Δt be the time between two consecutive samples.

$$\text{Energy} = \left(\sum_{n=i}^j (y_n)^2 \right) \cdot \Delta t$$

E.4.3 Maximum

Function

Determines the maximum value.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

$$\text{Maximum} = \max(y_i, \dots, y_j)$$

E.4.4 Mean

Function

Determines the mean value.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

Let N be the number of samples within the calculation period ($N = j - i + 1$).

$$\text{Mean} = \frac{\sum_{n=i}^j y_n}{N}$$

E.4.5 Minimum

Function

Determines the minimum value.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

$$\text{Minimum} = \min(y_i, \dots, y_j)$$

E.4.6 Peak to peak

Peak to peak

Function

Calculates the peak to peak value.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

$$\text{Peak to peak} = \max(y_i, \dots, y_j) - \min(y_i, \dots, y_j)$$

E.4.7 RMS

Function

Calculates the RMS (Root Mean Square) value.

Description

Let y_i be the value of the first sample of the calculation period.

Let y_j be the value of the last sample of the calculation period.

Let N be the number of samples within the calculation period ($N = j - i + 1$).

$$\text{RMS} = \sqrt{\frac{\sum_{n=i}^j (y_n)^2}{N}}$$

E.5 Cycle source calculated channels

The cycle source calculated channels perform calculations on the cycle source signal itself. Cycle source calculated channels do not need an input channel.

E.5.1 Cycles

Function

Visualizes the cycle source output as a square wave.

Description

Cycles can be used to visualize the calculation periods as they were determined by the cycle source and as they were used by other calculated channels. Having this visual aid may be helpful in determining the correct level/threshold settings for the cycle detector and in understanding the results when the cycle detector input signal is heavily disturbed or contains frequencies that exceed the specified cycle detector limitations.

Note *If the cycle source is a timer, the square wave will have a constant period.*

Output

A symmetrical square wave representing the output of the cycle source, the period is equal to the calculation period. The rising edge of the square wave indicates the start/end of a calculation period. The falling edge of the square is always positioned in the middle of two consecutive rising edges and has no direct relation to the rising/falling level crossings of the cycle detector input channel.




Figure E.13: Cycle detector set to detect half cycles

Figure E.13 shows the output of this calculated channel (green) and the input signal of the cycle detector (blue) with the cycle detector set to half cycle mode. The input signal is asymmetrical.




Figure E.14: Cycle detector set to detect full cycles

- A** The falling edge of the calculated channel is always positioned in the middle of two consecutive rising edges. Figure E.14 shows the output of this calculated channel (green) and the input signal of the cycle detector (blue) with the cycle detector set to rising edge full cycle mode. The input signal is asymmetrical.




Figure E.15: Cycle detector set to detect multiple full cycles

Figure E.15 shows the output of this calculated channel (green) and the input signal of the cycle detector (blue) with the cycle detector set to two rising edge cycles. The input signal is asymmetrical.

E.5.2 Cycle Frequency Function

Calculates the actual frequency of the input signal of the cycle detector.

Description

The cycle frequency calculator uses the cycle source information to calculate the frequency of the cycle detector input channel. The cycle detector provides not only the start/end of each calculation period, but also the actual number of (half-)cycles that have been detected during each calculation period.

Note *A trace of the cycle frequency calculator provides an excellent overview to detect missed or erroneously detected cycles. These show up as a spike in the cycle frequency trace.*

Note *If the cycle source is a timer, the output value of this calculator is very constant.*




Figure E.16: Cycle frequency calculator

Figure E.16 shows the output of this calculated channel (green) and the input signal of the cycle detector (blue) with the cycle detector set to rising edge full cycle mode.




Figure E.17: Cycle frequency calculator and high input frequencies

- A** Start of calculation period
- B** End of calculation period: duration 1000 μs , one cycle found, resulting in a calculated average frequency of 1 kHz during the past period
- C** Rising edge is too close to the start of the calculation period (400 μs)
- D** Rising edge is too close to the start of the calculation period (800 μs)
- E** Rising edge ends the current calculation period: duration 1200 μs , three cycles found, resulting in a calculated average frequency of 2.5 kHz during the past period. A new calculation period starts
- F** Rising edge ends the current calculation period: duration 1000 μs , one cycle found, resulting in a calculated average frequency of 1 kHz during the past period. A new calculation period starts

Figure E.17 shows the output of this calculated channel (green) and the input signal of the cycle detector (blue) with the cycle detector set to rising edge full cycle mode. Even though the calculation period that starts at **(B)** has been extended by two additional full cycles, the output of this calculated channel still represents the correct cycle detector input channel frequency.

E.6 Timer/Counter calculated channels

The formula of the calculation is selectable between Frequency, Frequency (gated) and RPM of Angle.

E.6.1 Frequency Function

Calculates the frequency of the input signal of the Timer/Counter channel which is set to frequency or RPM mode. The calculation period is determined by the selected cycle source.

Description

The calculated channel computes the (average) input frequency of the selected Timer/Counter input channel, taking the following input channel settings into account:

- Frequency prescaler
- Technical units multiplier and offset
- Timer/Counter mode

If no pulses are detected within the cycle period, a calculated result of 0 is produced.

Note *The measuring (gate) time of the input Timer/Counter channel must be set to its minimum value for this calculation function.*

If no input pulses are detected for a prolonged time period, the calculation period continues to be extended. This would mean that triggering on a low calculated output value would not be possible because no calculated result is produced as long as no input pulse is detected. To prevent this, the calculator has a fixed timeout of two gate times. If no pulses are detected within this period, a calculated result of 0 is produced. As soon as one or more pulses are detected, the calculated channel produces results again.

E.6.2 Frequency (gated) Function

Calculates the frequency of the input signal of the channel which is set to frequency or RPM mode. The calculation period is equal to the measuring (gate) time of the selected input channel.

Description

The calculated channel computes the (average) input frequency of the selected input channel, taking the following input channel settings into account:

- Frequency prescaler
- Technical units multiplier and offset
- Measuring time
- Measuring time

If one or more pulses have been detected during the previous measuring (gate) time, the calculated channel produces a result. If no pulses have detected during the previous measuring (gate) time, the calculation period is extended by an additional gate time and no calculated result is produced (yet).

If no input pulses are detected for a prolonged time period, the calculation period continues to be extended. This would mean that triggering on a low calculated output value would not be possible because no calculated result is produced as long as no input pulse is detected. To prevent this, the calculator has a fixed timeout of two gate times. If no pulses are detected within this period, a calculated result of 0 is produced. As soon as one or more pulses are detected, the calculated channel produces results again.

E.6.3 RPM of Angle Function

Calculates the RPM of the input signal of the channel which is set to Angle mode. The calculation period is determined by the selected cycle source.

Description

The calculated channel computes the (average) RPM of the selected input channel, taking the following input channel settings into account:

- Frequency prescaler
- Technical units multiplier and offset
- mode

If no angle change is detected within the cycle period, a calculated result of 0 is produced.

E.7 Settings and conflicts

Settings of calculated channels may conflict with other settings of the recorder. When such a conflict is detected, the 'Enabled' setting of a calculated channel will indicate a conflict. Before starting acquisition, the calculated channels with conflicts will be automatically disabled.

The following types of conflicts might arise:

- When the clock base of the mainframe is set to external, there is no guarantee that the samples are equidistant in time. In such a situation calculated channels cannot provide valid results.
- A calculated channel which is used for calculating the frequency of a Timer/Counter channel is in conflict when the measuring time of the Timer/Counter channel is below a certain limit.
- A calculated channel which is used for calculating the frequency of a Timer/Counter channel is in conflict when the mode of the Timer/Counter channel is set to something else than frequency or RPM (uni- and bidirectional).
- In the situation where the required calculation power of all enabled calculated channels exceeds the available calculation power of the recorder. The required calculation power depends on the sample rate and resolution, the number of enabled calculated channels and the selected calculation formula of each channel. The number of calculated channels that would exceed the available calculation power will have a conflict, starting from the bottom enabled calculated channel of the setting sheet towards the top of the sheet. The 'Multiplication' calculation formula needs more calculation power than the other formulas, the 'Cycle Frequency' and 'Cycles' formula needs less calculation power than the other formulas.

F Wake-on-LAN

F.1 Overview

F.1.1 Technology background

Purpose

Wake-on-LAN (WoL) is a widely supported networking standard that allows network connected devices to be remotely turned-on. This can be useful if the device is in a remote or hard to access location. The technology was originally introduced by the Advanced Manageability Alliance in April 1997. Turning the device on is accomplished by sending a wake-up frame to the device over the network. This frame is also called a “magic packet”. The Wake-on-LAN protocol utilizes the data link layer (OSI model layer 2) for sending the data. This means no IP-addresses are used, instead the device MAC-address is important. The magic packet is broadcasted over the network, so all devices connected to the network will receive it.

In order for Wake-on-LAN to work properly the device that is turned on needs to fulfill some requirements:

- It needs to contain a Wake-on-LAN capable network interface.
- This interface needs to be powered, even if the device is turned off.
- The **magic packet** needs to be sent from sender to receiver.

Note *If any of these requirements is not met, Wake-on-LAN will fail. The protocol does not include a confirmation message. This means there will be no error messages if Wake-on-LAN fails. The device will not be turned on.*

Magic packet

The magic packet is created as a broadcast frame that consists of 6 bytes with hexadecimal value FF (255), followed by sixteen repetitions of the MAC-address (48-bit) of the device that needs to be turned on. So the total size of the magic packet is 102 bytes.

Typically (Perception also does this) the packet is sent over Ethernet by using a UDP datagram, however alternative implementations are also used.

F.1.2 Wake-on-LAN in Perception

Connecting

GEN series hardware is automatically detected by Perception when it is turned on. Perception tracks this hardware and keeps a list of the mainframes it has once detected (see Figure F.2). When Perception starts and the mainframe which was detected before is no longer available the network, Perception will still show the hardware in the hardware navigator (see Figure F.1). The hardware will be indicated with a different icon:




Figure F.1: Hardware detected but not available

A Status icon: Detected but not available




Figure F.2: Hardware detected and available

A Status icon: Detected and available

When trying to connect a mainframe which is detected but not available (either manually **(1)** or through loading a workbench**(2)**) the mainframe will be turned on. In this case the connection or loading process will take longer than normal.

- 1 Manually connecting will give this feedback:




Figure F.3: Connection status when connected manually

- 2 When loading a workbench the internal connection process takes more time, during this process the progress window will be shown:




Figure F.4: Connection status when connected via workbench

Note *When loading a workbench there is no separate indication that the system was not active and turned on.*

Managing Wake-on-LAN mainframes

Retention

Mainframes will be remembered by Perception only for a specific time. When the specified time has passed, the mainframe is removed from the Wake-on-LAN list. This is called the **retention** time. By default this is 15 days, the following workflow illustrates how the retention policy works (see Figure F.5).




Figure F.5: Wake-on-LAN retention time

In short, mainframes that are in the Wake-on-LAN list will remain there until more than the number of retention days have passed between them being last detected and Perception is closed.

Change retention time in Perception

It is possible to change the retention time in the Perception **Preferences** (see Figure F.6). In this dialog, the Wake-on-LAN list can also be cleared.




Figure F.6: Wake-on-LAN preferences

- A** Wake-on-LAN option
- B** Set the number of days to keep the mainframe(s) in Wake-on-LAN list
- C** Clear Wake-on-LAN cache

Changing the retention time will only change the time between last detection and automatic removal from the Wake-on-LAN list. So mainframes that are detected will only be removed from that list after the new time period has exceeded. Mainframes that were already in the Wake-on-LAN list will be automatically removed upon closing Perception on the date of their last detection and the new retention time.

In the Wake-on-LAN preferences it is also possible to disable Wake-on-LAN. This can be done by selecting “Wake-on-LAN cache disabled” from the retention list (**B**).

Finally, the preferences allow removal of all currently stored Wake-on-LAN mainframes from the list with the **Clear Wake-on-LAN cache** button. Click **Apply** to confirm this action.

Hardware navigator

The hardware navigator also contains some Wake-on-LAN related features. The icons in the used/unused hardware indicate if a mainframe is either:




Figure F.7: Wake-on-LAN related features

A Detected

The mainframe is powered on and on the network.

- Some detected mainframes can report issues such as incorrect network settings. These mainframes are indicated with a yellow exclamation mark (D).

B Wake-on-LAN

The mainframe was previously detected on the network, supports Wake-on-LAN and was stored in the Perception Wake-on-LAN list.

- **Note** As the mainframe is currently not powered on it is unclear if the mainframe is still available after a Wake-on-LAN request.

C Manually added


It is possible to manually add a mainframe. This option is available for GEN series mainframes only and is used to connect to mainframes in an environment where the network does not allow the standard UDP broadcast messaging between Perception and the mainframe.

D Mainframe with issue


There are a number of things that can be wrong with the mainframe in case it is marked with this icon. Possible issues are incorrect network settings, but the mainframe could also be unsupported by Perception. Hover the mouse cursor over the item to get a tooltip with more detailed information on this specific reason(s).

Wake-on-LAN in the hardware navigator context menus


The following functionalities are also available in the hardware navigator through the context menus. These tasks can be done by right clicking one of the Wake-on-LAN mainframes in the unused hardware.



- A** Manually turn on a mainframe (**Wake Up**).
- B** Remove a single mainframe from the Wake-on-LAN list (**Forget Wake-on-LAN**).



- A** Shut down a mainframe (**Shut Down**).
- B** Restart the mainframe remotely (**Restart**).



- A** Clear all mainframes in the Wake-on-LAN list (**Clear all WakeOnLAN devices**).

F.2 Trouble-shooting (Wake-on-LAN)

F.2.1 Connection fails after Wake-on-LAN message

There are a number of potential causes why a mainframe will not wake up after Perception sends the Wake-on-LAN message.

Cause 1	Solution
Power down procedure	Wake-on-LAN is only available if the mainframe was powered down using Perception or through the normal power down procedure on the front panel. If the mainframe was shutdown through a power loss, or by pressing the power button for an extended period (forced power down), the Wake-on-LAN functionality will not be available and the mainframe needs to be manually powered on again.

Cause 2	Solution
Network settings	Wake-on-LAN technology broadcasts a special message over the network. The infrastructure might cause this message not to reach the mainframe. This can happen if the mainframe is in a different subnet or if a firewall or a network router blocks transmission of these messages completely. The router should be allowed to forward UDP message(s) from any source ports to destination port 9 and 7.

F.2.2 Perception try to connect to a not used mainframe

I have a new mainframe. When loading my workbench Perception keeps trying to connect to the old mainframe.

Cause	Solution
The old mainframe is still in the workbench and the Wake-on-LAN list.	To remedy this behavior, remove this mainframe from the Wake-on-LAN list. This can be done through the preferences or context menu in the hardware navigator. When the old mainframe is removed reload the workbench. Now the mainframe replacement dialog should be shown, allowing the new mainframe to be used instead of the old one. To complete this, save the workbench again when the new mainframe is connected and the workbench finishes loading.

G QuantumX – Unsupported features

G.1 Unsupported features

Some of the features in Perception and QuantumX are not supported when using the QuantumX in Perception; in some cases the feature is available but maybe limited. Below is a list of the most important features.

G.1.1 General limitations/remarks

Feature	QX module	Detailed information
No C-type thermocouple	MX809B	Currently Perception does not support using the MX809B with C-type thermocouples.
No sensor	MX1609TB/KB	When no sensor is connected to a MX1609TB/KB channel, a very high sample value will be recorded.
No sensor	MX471B	The signal behaviour when no CAN cable is connected to a MX471B depends on the signal repetition time setting. For more information, please refer to "Configuring CAN signal repetition time" on page 861.
No voltage measurements	MX809B	Within Perception the MX809B mainframe can only be used as a thermocouple data recorder.
Channel count	MX1609TB/KB	There are 16 Recorders per mainframe, with one Channel/Recorder.
Channel count	MX809B	There are eight Recorders per mainframe, with one Channel/Recorder.
Channel count	MX471B	There are four Recorders per mainframe, with max. 128 Channels/Recorder.
Firmware version	All	Perception will always attempt to enforce the firmware version distributed with Perception.
Number of connections	All	Detailed information: the amount of modules that can be connected and recorded simultaneously is only limited* by the total amount of RAM in the control PC. *Please note that the system was tested with a maximum of 16 QuantumX units, in a mixed setup.

G.1.2 Perception features

Feature	QX module	Detailed information
Spectral display	All	Not supported for QuantumX
XY display	All	Not supported for QuantumX
Slow-fast-slow & dual storage modes	All	QuantumX will use the same sample rate for high and low rate segments.
Triggering	All	QuantumX cannot be used as a trigger source within Perception.
StatStream™	All	There is no StatStream™ support for data recorded with a QuantumX. This may cause decreased performance in reviewing and calculating large datasets from the QuantumX.
Offline configuration	All	Offline configuration is not supported for the QuantumX.
Mainframe setup	MX1609TB/ KB	Use Perception or the MX assistant to configure the MX1609.
Mainframe setup	MX471B	Use the MX Assistant to configure the MX471B (CAN settings). Perception cannot be used to configure these.

G.1.3 QuantumX features

Feature	QX module	Detailed information
TEDS/RFID	All	Not supported in Perception for QuantumX.
Virtual math	All	Not supported in Perception. An alternative could be using the Perception formula database to do post processing.
CAN output channels	All	Perception will not send CAN out data via the MX471B. However, a MX471B, when properly configured using the MX Assistant, supports the transmission of CAN out data from input signals it receives via FireWire (i.e. coming from a MX1609KB/TB).

Feature	QX module	Detailed information
Analog output channels	All	Using the MX878 it is also possible to convert data from other QuantumX units that connected to it via FireWire as an analog output channel. Please note that the MX878 is currently not directly supported by Perception, so please use the MX Assistant to make the appropriate set-up. The analog outputs can be recorded using a GEN series acquisition system.
PTP Re-synchronization while recording	All	If QuantumX modules loose PTP synchronization during recording, they will stop acquiring data. Perception will show a warning that no more samples are being received but it will not automatically stop and close the recording in this case. Acquisition of data will only continue when stopping the recording and starting a new one.
IRIG synchronization	All	Perception currently does not support IRIG for QuantumX
Multiple users	All	The QuantumX platform allows multiple clients to connect to it simultaneously. Perception cannot detect if multiple users are using a QuantumX unit. It will not show information or protect against conflicts regarding multiple simultaneous users. When using Perception it is advised not to use the QuantumX module by multiple users at the same time. Doing so may cause a recording to be created with different settings than expected, or the system may even reboot during a recording.
Classic Data Rates	All	Perception supports only the Decimal data rates: (0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, 100, 200, 600 S/s). The Classic Data Rates (1200, ..., 9600, 19200, ..) are not supported. For the Decimal data rates, B type hardware is needed.
FireWire	All	Perception does not support a direct FireWire connection between a QuantumX unit and the PC running Perception. Although the QuantumX unit may be shown in Perception, no guarantees are given regarding proper operation of the either QuantumX or Perception in this set-up.

H Configuring MX471B – MX Assistant

H.1 Introduction

This appendix describes how to configure a MX471B using the MX Assistant tool.

It describes:

- How to change the network settings of a MX471B.
- How to change the MX471B module name.
- How to configure the general CAN bus settings
- How to configure the CAN signal settings.
- How to configure the CAN signal repetition time.

H.2 Configuring the MX471B using the MX Assistant

To configure the MX471B, use the MX Assistant tool. The tool can be found on the QuantumX/Somat^{XR} System CD or can be downloaded from the HBM site.

H.2.1 Ethernet network setting MX471

After connecting the MX471B to the Ethernet network, in the MX Assistant tool use: **File ► Find modules...** to scan the network for the QuantumX module:




Figure H.1: Find Modules

- A File menu
- B Find modules....

- 1 Select the MX471 device line and then **Edit network settings** to configure the network settings:




Figure H.2: Search for modules dialog

A MX471 checkbox

B Edit network settings

2 Configure the network settings and click **OK** to effectuate:




Figure H.3: Configure network settings

- A Network settings
- B OK button

3 Select the MX471 checkbox (A) and click **OK** to connect to it:




Figure H.4: Connect to MX471

A Check the MX471

B OK button

- When connected properly, the MX471 will be listed in the list of connected modules:




Figure H.5: List of connected modules

The default factory name of the MX471B module is “MX471”. To change the module name (which is advised), activate the context menu (RMB) on the connected MX471 and select **Rename...** and change the module name.




Figure H.6: Rename module

A Rename....

B Change module name

H.2.2 Configuring the CAN bus settings

Once you are able to connect to the MX471B via the MX Assistant, you can start configuring the CAN bus settings. These settings need to be set right for each MX471B CAN bus connector.

- The first connector is selected by selecting a CAN channel in the range 1.1 up to 1.128.
- The second connector is selected by selecting a CAN channel in the range 2.1 up to 2.128.
- The third connector is selected by selecting a CAN channel in the range 3.1 up to 3.128.
- The fourth connector is selected by selecting a CAN channel in the range 4.1 up to 4.128.

1 Select the first connector and then the CAN bus settings dialog:




Figure H.7: Select CAN bus settings

- A First connector
- B CAN Bus
- C Settings...

- 2 Set the Bit rate to the right value. The maximum value is 1000000 bits/s:




Figure H.8: CAN bus settings dialog

A Bit rate

B Termination on or off by checking or unchecking

Dependent on the CAN cabling used, the **Termination** can be switched off or on. When the used CAN cabling has a built-in physical termination resistance, there is no need to switch the **Termination** on.

Repeat this for all used MX471 CAN bus connectors (max. four).

H.2.3 Configuring the CAN signal settings

There are two ways to configure the CAN signal settings: Manually or using a CAN database file (DBC file). The latter is the most common practice.

H.2.4 Configuring CAN signal settings using a CAN database file

- 1 Add the CAN database file by selecting **Add** on the **Sensor database** menu:




Figure H.9: Add CAN database

- A** Sensor database menu
- B** Add tool

2 Select the CAN database file (.dbc) and then **Open**:




Figure H.10: Open CAN database file

A CAN database file

B Open button

3 The opened CAN database file will be added to the list of CAN databases:




Figure H.11: List of CAN databases

A Added file

- Now use the signals from the CAN database file to configure the CAN channels.

In the **Channels** menu (**A**), select the CAN channel (**B**) you want to configure and the signal you want to assign to it. By double clicking on the signal (**C**), or using drag and drop, the signal configuration is transferred to the CAN channel.




Figure H.12: Configure CAN channel

- A** Channels menu
- B** CAN channel
- C** Double click or drag and drop the signal

- To inspect the details of the CAN amplifier settings, select the button near the Amplifier setting column:

Path	Type	Signal name	Sensor description	Amplifier setting	Output unit
1.1 : MX471_TEST (004C05)	CAN Bus	DC_RBS_Temperatur	DC_RBS_Temperatur	CAN signal (469728032); Extended (29-bit ID)	Unit_DegreCelsi
1.2 : MX471_TEST (004C05)	CAN Bus			Disabled	
1.3 : MX471_TEST (004C05)	CAN Bus			Disabled	
1.4 : MX471_TEST (004C05)	CAN Bus			Disabled	

A

Figure H.13: Inspect details of CAN amplifier

A CAN Amplifier setting button

Path	Type	Signal name	Sensor description	Amplifier setting
1.1 : MX471_TEST (004C05)	CAN Bus	DC_RBS_Temperatur	DC_RBS_Temperatur	CAN signal (469728032); Extended (29-bit ID)
1.2 : MX471_TEST (004C05)	CAN Bus			Disabled
1.3 : MX471_TEST (004C05)	CAN Bus			Disabled
1.4 : MX471_TEST (004C05)	CAN Bus			Disabled
1.5 : MX471_TEST (004C05)	CAN Bus			Disabled
1.6 : MX471_TEST (004C05)	CAN Bus			Disabled
1.7 : MX471_TEST (004C05)	CAN Bus			Disabled
1.8 : MX471_TEST (004C05)	CAN Bus			Disabled
1.9 : MX471_TEST (004C05)	CAN Bus			Disabled
1.10 : MX471_TEST (004C05)	CAN Bus			Disabled
1.11 : MX471_TEST (004C05)	CAN Bus			Disabled
1.12 : MX471_TEST (004C05)	CAN Bus			Disabled
1.13 : MX471_TEST (004C05)	CAN Bus			Disabled
1.14 : MX471_TEST (004C05)	CAN Bus			Disabled
1.15 : MX471_TEST (004C05)	CAN Bus			Disabled
1.16 : MX471_TEST (004C05)	CAN Bus			Disabled
1.17 : MX471_TEST (004C05)	CAN Bus			Disabled
1.18 : MX471_TEST (004C05)	CAN Bus			Disabled
1.19 : MX471_TEST (004C05)	CAN Bus			Disabled
1.20 : MX471_TEST (004C05)	CAN Bus			Disabled
1.21 : MX471_TEST (004C05)	CAN Bus			Disabled
1.22 : MX471_TEST (004C05)	CAN Bus			Disabled
1.23 : MX471_TEST (004C05)	CAN Bus			Disabled
1.24 : MX471_TEST (004C05)	CAN Bus			Disabled
1.25 : MX471_TEST (004C05)	CAN Bus			Disabled
1.26 : MX471_TEST (004C05)	CAN Bus			Disabled
1.27 : MX471_TEST (004C05)	CAN Bus			Disabled
1.28 : MX471_TEST (004C05)	CAN Bus			Disabled
1.29 : MX471_TEST (004C05)	CAN Bus			Disabled
1.30 : MX471_TEST (004C05)	CAN Bus			Disabled

Sensor adaptation »004C05.1.1: CAN signal (469728032); Extended (29-bit ID)«

Edit sensor adaptation, e.g. the **scaling**, for this channel only.
Use the sensor database if you want to change the **scaling type** or other sensor parameters.
Electrical values may be **measured**.

Expand all Collapse all

CAN ID	469728032
Description	DC_RBS_Temperatur
Signal type	Standard signal
Frame format	Extended (29-bit ID)
Byte sequence	Intel
Data format	Unsigned 32-bit integer
Start bit	3
Number of bits	8
Scaling factor	1
Scaling offset	-40
Minimum value	-40
Maximum value	213
Physical unit	User defined
User defined output unit	Unit_DegreCelsi
Mode start bit	0
Number of bits for mode signal	2
Byte sequence of mode signal	Intel
Mode data format	Unsigned 32-bit integer
Mode value	3

CAN ID
CAN message identifier (decimal, for hex notation precede with 0x)

Help Update in database OK Cancel

Figure H.14: Details of CAN amplifier settings

Configure the remaining CAN channels in the same way.

Note The MX471B supports the following CAN message Data formats:
 Unsigned and Signed 32-bit integer, Unsigned and Signed 64-bit integer, 32-bit real and 64-bit real.

Note Multiple signals can share the same CAN message ID. The actual sample bits used for the signal are specified by means of the **Start bit** and **Number of bits** setting.

Note The MX471B converts the received CAN signal bits to 64-bit asynchronous sample values before passing them to Perception. Perception displays these asynchronous sample values as a continuous trace.

H.2.5 Configuring CAN signal settings manually

If there is no CAN database configuration file (.dbc) available, the CAN channels can be configured manually.

- 1 In the **Channels** menu, first activate the signal by using the context menu (RMB) in the **Amplifier setting** cell of the involved CAN channel.




Figure H.15: Activate signal

- A Channel menu
- B CAN channel and open context menu (RMB)
- C Activate signal signal

- Now configure the CAN amplifier settings by selecting the **...** button near the **Amplifier setting** column:

Path	Type	Signal name	Sensor description	Amplifier setting	Output unit
1.1: MX471_TEST (004C05)	CAN Bus	Sinus100	Sinus100	CAN signal (100); Standard (11-bit ID) ...	V
1.2: MX471_TEST (004C05)	CAN Bus			Disabled	
1.3: MX471_TEST (004C05)	CAN Bus			Disabled	

Figure H.16: Configure CAN amplifier settings

A Amplifier setting button.

- Fill in the CAN amplifier settings. Select **OK** to effectuate:

Edit sensor adaptation, e.g. the **scaling** for this channel only.
 Use the sensor database if you want to change the **scaling type** or other sensor parameters.
 Electrical values may be **measured**.

CAN ID	100
Description	Sinus 100
Signal type	Standard signal
Frame format	Standard (11-bit ID)
Byte sequence	Intel
Data format	Signed 32-bit integer
Start bit	0
Number of bits	16
Scaling factor	1
Scaling offset	0
Minimum value	-10
Maximum value	10
Physical unit	V
User defined output unit	V
Mode start bit	0
Number of bits for mode signal	2
Byte sequence of mode signal	Intel
Mode data format	Unsigned 32-bit integer
Mode value	3

Data format
Data format of this signal in the CAN message

Figure H.17: CAN amplifier settings

A CAN amplifier settings rows

B OK button

H.2.6 Configuring CAN signal repetition time

The repetition time can be configured for each CAN signal. The repetition time indicates when to assume an input signal loss.

- 1 To configure the CAN signal repetition time, select the  button in the **Signals** menu near the **CAN signal format** column.




Figure H.18: Configure CAN signal repetition time

- A Signals menu
- B Signal adaptation button

- In the Signal adaptation dialog, set the value of the **Time monitoring in sec.**




Figure H.19: Signal adaptation dialog

A Time monitoring in sec. value row

With the **Time monitoring in sec.** (or signal repetition time) you can define that a signal must be received within a certain time interval at the latest, otherwise the signal will be labeled with Overflow (OVR). The time specification is not followed exactly and the value may vary by some milliseconds. Enter 0 as the time monitoring value in order to deactivate the time monitoring.

Note *Perception has no special treatment for Overflow (OVR) samples. They are put on the display and added to the recording file like all other samples. The Overflow samples (OVR) have a very high sample value.*

Note *When the time monitoring is deactivated for a signal, a CAN cable disconnect does not cause the QuantumX unit to generate OVR samples. So in this case, no samples are shown on the display nor added to the recording file.*

Note *CAN channels that have no activated signal in the MX Assistant are not visible in Perception.*

Note Each MX471B CAN connector is mapped to a recorder in Perception. CAN connectors that do not contain any active signals are not shown in Perception.

H.2.7 Configuring CAN signal minimum/maximum value




Figure H.20: Sensor adaptation dialog

- A** Set Minimum value
- B** Set Maximum value

The **Minimum value** setting corresponds to “Range from” in the settings sheet. The **Maximum value** setting corresponds to “Range to” in the settings sheet.

I Creating a synchronized recording using Perception and PTP

I.1 Using PTP

This section explains how to create a synchronized recording within Perception. Unless otherwise stated, this section assumes Perception is used to setup a PTP synchronized recording in combination with GEN series DAQ hardware.

I.1.1 Why use a synchronization method

When working with multiple mainframes, the internal clocks of the mainframes may differ. Even if initially set accurately, real clocks will differ after some time due to clock drift, caused by clocks counting time at slightly different rates. To solve this issue in a multiple mainframe setup, it is possible to use synchronization sources like IRIG, GPS and PTP.

I.1.2 Why choose PTP

PTP is one of many methods to synchronize a network of heterogeneous devices. It is especially useful when confronted with the following challenges:

- More than one device are measuring data; the data from all devices must be correlated.
- Equipment from multiple vendors needs to be synchronized.
- Data acquisition equipment runs for a longer period of time.

When selecting PTP, the following requirements should be met by the test setup:

- When synchronization between equipment that runs on different type of buses (e.g. Ethernet and Profibus based devices). PTP must be available on all buses and buses can be interconnected.
- Data acquisition equipment is all connected through a Local Area Network. Multiple subnets are allowed but require dedicated hardware to interconnect the subnets.
- PTP typically works using existing Ethernet cabling, making it a cost effective method. However when switches are used to connect data acquisition hardware, these must be PTP aware switches, which are more expensive than normal switches.

In the above mentioned cases (but not limited to), using PTP is most likely the best choice for the experiment.

Note *PTP will only result in a synchronized recording if all equipment in the system uses PTP and is connected through a network.*

Note *For PTP to function properly in a larger network it is necessary to use PTP-aware network switches.*

I.2 Hardware setup

This section briefly discusses how to setup PTP. For more elaborate instructions, please refer to the hardware manuals of the equipment involved in the measurement.

However in general please be aware of the following items:

- 1 Use PTP aware network components if any are required.

Note *Not using PTP aware components will lead to unstable synchronization or no synchronization at all.*


- 2 Make sure all hardware involved supports hardware based PTP. Software based PTP is also available, but has a much lower accuracy (similar to NTP) than hardware based PTP.
- 3 When connect GEN series DAQ into a PTP network, use the PTP enabled network ports.

I.3 Software setup

How to setup PTP synchronization in Perception

To setup the data acquisition equipment controlled by Perception, use the following steps:

- 1 Connect to the mainframes.
- 2 Open the settings sheet, go to the **General ► Mainframe** section.



General Mainframe	Storage location	Sync source	Master/Slave mode
GEN3	PC Storage	PTP 1 (RJ45)	Stand Alone

Figure I.1: Mainframe - general settings

- 3 In the sync source setting, select the PTP source that is connected to the network:
 - **PTP 1** for PTP port 1
 - **PTP 2** for PTP port 2

Note *Depending on the type of mainframe, only one PTP selection could be available.*

- 4 Repeat this for all mainframes.

I.3.1 PTP Synchronization status monitoring

Once the sync source setting is set to PTP, the mainframe will start to look for the PTP Master Clock. This is done using the Best Master Clock (BMC) algorithm that is defined in the PTP standard. Once the best master clock is selected, a slave will synchronize to that clock. Within Perception there are three ways to monitor this process, and also the status of the PTP synchronization during the rest of the measurement (setup).

1 Advanced setting: Sheet settings

The advanced settings in the settings sheet allow for fine tuning of the PTP setup, but also show some information that can be used to check proper synchronization. There are four settings that can help in determining the status and configuration of the PTP network.

- **PTP Master MAC-address:** If no master can be found this is set to 00-00-00-00-00-00, otherwise it displays the MAC-address of the master clock. Especially when using a dedicated PTP Grandmaster Clock, this MAC-address can typically be found in the interface of the grandmaster.
- **PTP Role:** There are three possibilities here. In case the role is “None” no PTP synchronization can be established. The other options are “Slave” and “Master”, these both indicate that the mainframe is part of a PTP network.

Note *If a grandmaster clock is used, the mainframe role should always be slave, if it is not slave the grandmaster could not be found or is not properly operational.*

- **Clock class:** The clock class is not shown if it could not be determined, which is the case if Accurate Clock Status is "Unknown".
- **Accurate clock status:** Closely related to the clock class setting. Possibilities are:
 - Found: Clock class of master clock ≤ 7
 - Not found: Clock class of master clock > 7
 - Unknown: No master was found, or the clock class of the master could not be resolved.










 PTP Accuracy	 Use Accurate Master	 PTP Delay Method	 PTP Master MAC-address	 PTP Role	 Clock Class	 Accurate Clock Status
150 ns		End to end	00-00-00-00-00-00	None		Unknown

Figure I.2: Advanced PTP settings when no signal can be found

2 Status area

Perception also shows a system wide synchronization status. This is displayed in the status palette. The synchronization status shows the synchronization mechanism used, in a cascade of multiple methods are used in the system (e.g. a combination of PTP and master/slave). There is a priority mechanism in displaying the status.

If one of the synchronization mechanisms is reporting an error or warning, that mechanism is shown. The issue reported is displayed in the bottom of the status area. In case no problems are reported, the mechanism that was reported last is shown.

3 Network topology

In case of issues, or if a more detailed overview is desired the network topology can be used.



HINT/TIP

Clicking on the synchronization status will show the network topology.

The network topology gives an overview of all mainframes connected with Perception showing their synchronization mechanism, status and if available information on the source. If the mainframe is set to PTP, and is master in the PTP network, the source will be included in the mainframe, if another node in the PTP configuration is the master is will be outside the mainframe.




Figure I.3: Acquisition system that is a PTP master (left)/Acquisition system that is a PTP slave and uses an external PTP master (right)

This can be used to inspect if all mainframes are synchronized and if so, to which master. In case there is a problem prohibiting overall synchronization to succeed, this overview can be used to determine if one mainframe is not synchronizing, potentially indicating a wiring or network topology problem.

A typical setup with two mainframes will look like this:




Figure I.4: Two mainframes, one is master, the other one slave

It is clear that mainframe GEN7tA is now the master, both from the fact that it the PTP synchronization master information is encapsulated in a single block, also from the fact that the PTP 1 state is **(Master 1)**.

A more elaborate setup in which an external PTP source is used may look like this:




Figure I.5: Two mainframes both slaves with the same master PTP clock

From this image it is clear that the PTP master is not one of the connected mainframes, as none of the acquisition systems encapsulates a PTP master block. It is also visible that both acquisition systems use the same master, as both PTP master blocks contain the same MAC address. In this case the PTP master is typically connected to a primary time source such as IRIG or GPS.

Note *Some master clock devices allow you to check which slaves are present.*

The network topology can also be used to diagnose problems with time synchronization between acquisition systems.




Figure I.6: Two systems connected to the same network. One finds itself as master; the other system finds no master

For example see Figure I.3. This is a setup with two mainframes, both connected to the same local area network. A very simple PTP setup is intended, in which one of the mainframes should be the master, the other one a PTP slave to the first mainframe. One of the mainframes has resolved itself as a master. This indicates that it is connected to the LAN via a PTP enabled port. However the second mainframe is not able to find any master mainframe and it is reporting: "No Signal" indicating that it is connected to the local area network, but not via a PTP enabled port.

It is also possible that all mainframes are having problems synchronizing which could indicate an issue with the master clock.

Finally the overview can also be used to diagnose unexpected synchronization behaviour, for example in case two mainframes have synchronized to different master clocks. This might happen if a network is divided into several subnets and the master clock is only available on one of these subnets.

Note *The PTP synchronization status will not affect the ability to start a new recording. In case a recording is started while one or more mainframes are not synchronized this information can be added to the recording. If this actually happens depends on the specific hardware, GEN series mainframes will add this information.*

I.3.2 Advanced setup 1: Accurate master

The main focus of the PTP protocol is to keep a tight synchronization between all the nodes in the system. It is possible to have a master clock that is not related or synchronizing to the wall-clock or UTC time, that still keeps all data acquisition equipment measuring in a synchronous fashion.

However often it is also important to have measurement data synchronous to UTC or TAI time, when using PTP, this means the PTP Master clock should be synchronized with primary time source like GPS or IRIG. PTP Masters that have this capability and that are synchronized against such a time source can be identified by their clock class. The above mentioned scenario is only true if the clock class of the master is set to 6 (or lower). These master clocks may lose synchronization to their primary time source, if this occurs; the clock class is downgraded from class 6 to class 7 and continues synchronization against its internal clock.

When it is important to have the capability of synchronizing against a primary master, the **Use Accurate Master** setting can be enabled in the settings sheet.

PTP Master MAC-address	PTP Role	PTP Accuracy	Use Accurate Master	PTP Delay Method	Clock Class	Accurate Clock Status
00-09-E5-FF-00-54	Master	150 ns	<input checked="" type="checkbox"/>	End to end	0	Not found

A

A Use Accurate Master option

When there is a clock class 7 or lower master, Perception will continue to work as before, no difference will be noticed. However when a higher clock class (less accurate) is detected a number of things will occur in the system when using GEN series DAQ.

- 1 A notification will be shown, stating that “ the PTP master clock has no clock class 7 or better”.




Figure I.7: Mainframe alert notification

- 2 When a recording is started a marker will be inserted in the recording stating that the recording was started without an accurate master clock.

Typically all clock classes of 7 and better will be treated as accurate masters. Also if a master downgrades from class 6 to 7, this is typically not recorded by Perception, nor is it notified. The clock class will be updated in Perception, it can be found in the settings sheet mainframe – general advanced settings.

I.3.3 **Advanced setup 2: PTP tolerance**

The PTP source is used to control real clocks in mainframes. This is done through an adjustment process (PLL) that takes the PTP input, compares it to real clock and applies slight adjustments based on the difference between the two clocks.

When there is a difference between the clocks that exceeds acceptable tolerances, the mainframe reports that is no longer synchronized. It will continue to adjust to the PTP clock and after a period of time (maybe minutes to hours); it will have adjusted the real clock enough to reduce the difference below the given tolerance and will report the mainframe as synchronous to the PTP clock again.

Using the PTP tolerance setting, it is possible to adjust the tolerance that is used and thus control when the system reports it is not synchronized anymore. This can be used if there are constraints in the overall measurement system architecture that affect the accuracy of the master or slave clocks, or the communication between them. It may also be used in case a higher degree of accuracy is required for the measurement application, and a warning is desired when this accuracy is exceeded.



WARNING

Setting the tolerance to 0 will result in a system that is never synchronized. The difference between real clocks is caused by physical phenomena that cannot be avoided. Typically 0 will not be accepted or selectable.

Note *A thorough understanding of the measurement system, the PTP protocol and implementation and real clocks is required before changing this value.*

I.3.4 Advanced setup 3: Using separate network for data and synchronization
 In some cases it might be desired to have a separate network for data traffic and PTP synchronization traffic. Study has not shown any negative impact on synchronization accuracy or data throughput of combining both on a single network.

Note *Physical network layout or company (IT) policy might dictate a separation nonetheless. In case this requirement does exist, it is important to have a GEN series DAQ apparatus with at least two network ports. If this is available follow these steps to setup separate network streams.*

Tethered systems

- 1 Make sure the system is connected to the networks correctly.
- 2 Connect to the system.
- 3 Open the network sheet.
- 4 Select “Mainframe Network Setup...” from the “Settings” menu.

- Set the network port that should be used to store data as preferred.




Figure I.8: Mainframe Settings - Network Setup dialog

- A Preferred port** The currently preferred port is indicated with a green icon.
- B Network port** Select to show details and make it the preferred port.
- C Checkbox for preferred port** After selecting the port that should be preferred, check the box to make it preferred.

Note *If a separation of PTP and data network is to be achieved, make sure that the preferred port is not the same port as used for PTP.*

Integrated systems

When using an integrated system, the data is automatically separated from the PTP traffic as the data is stored through the internal PCI bus. In case the system is controlled remotely, setting up the network is done through as standard Windows configuration.

Note *In case the data is stored on an iSCSI network drive the setup might be a different. Please refer to the section on iSCSI storage in the GEN series hardware manual for more information.*

I.3.5 PTP synchronization lost during recording

It is possible to start a recording when the system is not yet synchronized. In this case a non-blocking notification will be shown to warn about this occurrence.




Figure I.9: Not synchronized warning notification

The recording will be created and data storage will commence. Mainframes that are not synchronized when started will add a marker to the recording that is visualized in the display.




Figure I.10: Recording started before synchronized.

A Marker A marker is added and the data between two channels of two mainframes is not synchronized.

There are several reasons a mainframe is not synchronized when set to PTP. Please refer to the trouble shooting section in the GEN series hardware manual for detailed information.

Once the mainframe is synchronized again a new notification is shown, stating that the synchronization is established again.

Also a marker is added to the recording indicating when the mainframe resynchronized to PTP.




Figure I.11: Recording - mainframe resynchronized to PTP

A Marker The mainframe is resynchronized to PTP.

Synchronization lost during recording

Another option is that the synchronization is lost during the measurement. This may happen for example when a power or other hardware failure on the grandmaster clock occurs, if a network problem between the master clock and the slave, or another reason. If this happens, PTP will initiate a search for a new master clock using the BMC algorithm. There are several potential outcomes: A new master clock will be found. That master was most likely synchronized to the old master clock (the old clock could even be back online) and will take over the master clock task. The new clock will typically be close to the old clock, and the mainframe will resynchronize to the master. The recording will contain two markers:

- 1 A marker indicating when the synchronization was lost.
- 2 A marker indicating when the synchronization was retrieved.

Note *Not all acquisition systems will handle finding a new PTP master the same. Some may immediately switch to the new time of the PTP, other hardware such as GEN series mainframes will use a synchronization process to align PTP Master and internal clocks. The time when the synchronization was retrieved will always after the new master clock was selected. The time difference between these occurrences depends on the time difference between the new and old clock and the time it took to select a new master. This may impact the time during which the system is not synchronized.*

In this case the new clock most likely is not a class 6 or 7 clock, but will be of a lower clock class, and as such the recording may drift away from the primary time source. If “Use accurate master” was enabled, another marker will now be added into the recording to indicate that synchronization from that point on was not done against an accurate master.

It is also possible that the new clock was not a slave of the old master clock; in that case its time may be unrelated to the previous clock. The system behaviour depends heavily on the acquisition hardware used. Some hardware may use the new time immediately, some hardware may use PLL alike processes to gradually resynchronize with the new clock and other hardware may not resynchronize at all. Refer to the hardware manual for more information on how the specific hardware handles this scenario.

New clock introduced in PTP network

When a new node is introduced into a PTP network, this will invoke a new BMC cycle. The result of this cycle will normally not change anything. However in case the new node turns out to be the best clock in the network, it will be made PTP master clock.

If this occurs during a recording, the master clock will typically be lost first, including a notification and marker in the recording. After a mainframe is resynchronized to the new PTP master clock a new notification will be shown and the event will be stored in the recording with a marker.

I.4 Using Perception to troubleshoot PTP synchronization

I.4.1 Unable to synchronize to PTP at all

Description:

After connecting to the mainframe and setting up PTP as synchronization source, the synchronization status never states synchronized.

Check:

- If the PTP enabled port of your hardware is connected to the network.
- If the correct PTP selection is made. PTP 1 in case PTP port 1 is used; PTP 2 in case PTP port 2 is used.

I.4.2 Synchronization keeps getting lost

Description:

After connecting to the mainframe and setting up PTP as synchronization source, the synchronization state synchronized is reached, but every now and then the synchronization state changes to not synchronized.

Check:

- Check if all network equipment is PTP aware.
- Check that PTP is enabled for connections used on PTP aware switches. This can typically be manipulated through the switches' configuration software.
- Check that the PTP Tolerance setting is not set too small. Try restoring default settings to ensure that the default setting is used.

I.4.3 Unexpected master is found or not all mainframes synchronize to the same master

Description:

The mainframe synchronizes when set to PTP; however the PTP-Master MAC address of one or more mainframes is not the expected address.

Check:
<ul style="list-style-type: none"> ● Check if the mainframes are not synchronizing to different boundary clocks which are in turn synchronized to the same grandmaster clock. In this case it may not be a problem that the Master MAC-addresses differs. This is only possible if mainframes are part of different subnets. ● Check if any network nodes (switches/routers) are in between the mainframe(s) and the master clock. If so check that all these network nodes support PTP, that this support is enabled, and that network addresses are correctly translated in case of several subnets. ● If the PTP master allows it, open its (web)interface and check if the mainframe is in the slave list. (see PTP master manual for details). ● Check if the mainframe(s) are physically connected to the correct network.

I.4.4 32 second offset

Description:
<p>Two signals from two mainframes that should be time synchronized show a difference of approximately 32 to 33 seconds. This difference is typically caused by use of two different timescales. TAI, short for Temps Atomique International (or International atomic time), uses a network of atomic clocks to determine an accurate time, and UTC, Coordinated Universal Time, the bases for times in different time zones.</p> <p>There is a slight difference in the time measured through TAI and the rotation speed of the earth. As time zones are based on UTC and are geographically fixed, a leap second is introduced every number of years to avoid the UTC time from slipping.</p>

Check:
<ul style="list-style-type: none"> ● Check that both mainframes are synchronized against the same master clock. If so, check the manual or contact the vendor of the hardware to enquire about TAI vs. UTC handling. ● If different physical sources are used. Check to see if all sources output the same time source (TAI, or UTC).

Note *This difference will increase as more leap seconds are introduced. Until 2012, 25 leap seconds were introduced in 41 years; this will increase as time progresses.*

I.4.5 19 second offset

Description:
<p>Same as before (see "32 second offset" on page 880), but now with a 19 second offset.</p>

<p>Check:</p> <ul style="list-style-type: none"> • Same as before (see "32 second offset" on page 880), but now look for GPS against TAI settings. <p>Note <i>This difference will not change over time.</i></p>

I.4.6 13 second offset

<p>Description:</p> <p>Same as before (see "32 second offset" on page 880), but now with a 13 second offset.</p>

<p>Check:</p> <ul style="list-style-type: none"> • Same as before (see "32 second offset" on page 880), but now look for GPS against UTC settings.
--

I.4.7 Accuracy not as expected

<p>Description:</p> <p>Two signals from different mainframes that are both PTP synchronized are not as closely synchronous as expected.</p>
--

<p>Check:</p> <ul style="list-style-type: none"> • If the PTP Tolerance is set to a very high number (thus being more inaccurate) there might be a synchronization issue that is not being reported because it never exceeds the PTP tolerance threshold. • The clock class of the master clock. If this is a very high clock class, the master clock might not be very accurate. If the two mainframes respond differently to an inaccurate clock, their signals might show some drift.

J Recordings

J.1 Merge Recordings explained

Introduction

If you make a recording using multiple mainframes and multiple storage locations (for example mainframe SCSI disk or compact flash card and PC), the end result is a distributed set of recordings that are actually one single recording.

Perception offers a way to integrate these multiple recording files into a single recording via the **Merge Files** command in the Automation menu. Read this appendix for a better understanding of the Merge Files command and its results.

J.1.1 Basic recording (PNRF) structure

A recording file consists of various parts of information that are all stored in the **Perception Native Recording File (PNRF)**. A normal recording made on a PC has the following structure:




Figure J.1: Structure of a recording

J.1.2 Basic recording merge process

A merge of two recordings (for example one mainframe SCSI storage and one PC storage) created using two mainframes (MF1 and MF2) will look like this:




Figure J.2: Basic recording merge process

As you may notice the merged recording contains a single start time information block. This means that all data and trigger information of mainframe 2 is now viewed relative to the start time of the original mainframe 1 recording. So the merge process already started when you created the original recordings in the hardware. The merge process does not check for availability of time synchronization or valid times. If you need time-synchronous accuracy, you must add time synchronization options to your hardware such as IRIG/GPS. This is outside the scope of this document.

A detail to consider is that the merged recording also contains the experiment information. This is not an arbitrary detail that comes automatically. When merging multiple recordings, one of the recordings is designated the master recording. The experiment information of this recording is added to the merged recording, and also the time information.

Consider the previous recording merge example, now with the SCSI recording as a master recording. The resulting merged recording will look different:



Note that the merged recording's time information is now the mainframe 2 start time info

Figure J.3: Basic recording merge process with SCSi recording

Note that the merged recording contains NO more experiment information

Although merging files from different locations is a powerful feature, you should consider the mentioned issues to make sure you get the desired results without undesirable side effects.

J.2 ASCII Recording Loader

Introduction

This chapter describes the Perception ASCII file loader:

- How to use the ASCII Recording Loader
- Supported file formats

The Perception ASCII file loader is part of the Perception software since version 6.22.

J.2.1 Opening an ASCII file with the Perception ASCII file loader

There are two ways to open an ASCII file containing recorded data:

- Using the "Recordings Navigator" on page 885.
- Using the "File menu" on page 886.

Opening an ASCII file with the Recordings Navigator

ASCII data files which have *.txt or *.asc as their filename extension are accessible through the Recordings Navigator. This navigator uses a tree view to display the various items as an indented outline based on their hierarchical relationship.

Figure J.4 below shows four ASCII files which are stored in the **ASCII Recording Files** folder.




Figure J.4: ASCII Recording Files

A ASCII Recording Files

For more information about Recordings navigation, please refer to "Recordings navigation" on page 94.

Opening an ASCII file with the File menu

To open an ASCII file from the File menu:

- 1 Point to **File** ► **Load Recording**




Figure J.5: File menu with Load Recording option

A Load Recording

- In the **Load Recording**, dialog select **ASCII Recording Files** in the **Files of type** drop down list.




Figure J.6: Load Recording dialog

- A Files of type
- B Load recording area

- In the **Load Recording** area, select how you want to open the ASCII file:
 - **As active**
 - **As reference**
 - **Using filename**

Note You can also use the formula `@ReadAsciiFile()` to load an ASCII recording file. However, the number of channels which can be read is restricted to only one. For more information, please refer to the Perception Analysis Option manual.

- Confirm your selection with the **Open** button.

J.2.2 Supported ASCII file formats

The ASCII file loader supports five different file formats. These formats will be described in this section:

- ASCII file format (I) for Perception export. Refer to "ASCII file format I" on page 888.
- ASCII file format (II) which supports Catman and ASCII export with channel information. Refer to "ASCII file format II" on page 891.
- ASCII file format (III) for short header. Refer to "ASCII file format III and IV" on page 893.
- ASCII file format (IV) for long header. Refer to "ASCII file format III and IV" on page 893.
- ASCII file format (V) when working with no header. Refer to "ASCII file format V" on page 896.

ASCII file format I

The first supported file format is used to export a file using the Perception ASCII export. For more information about export recording, please refer to "Export Recording..." on page 356.

You should enable at least the following options when you create an ASCII export file:

- Add x-axis
- Column titles
- File header

Figure J.7 below shows an example of an ASCII export setup which can be used to generate an ASCII file that can be read back by the ASCII file loader.




Figure J.7: Perception ASCII export setup

Note *The ASCII file must contain a header and a data part.*

Header:

Line	Description	Remark	Example
1	The file name	<i>Always has to start with "File:"</i>	File: C:\Export \AsciiDemo1.txt
2	Creation information	<i>Not used (1)</i>	Created: Wednesday, December 21 2011 11:38:47
3	Header time information	<i>Not used (1)</i>	Header time format: Absolute
4	Time of the first sample	<i>Used (2)</i>	Time of first sample: 067 11:44:38.054093300
5	Title	<i>Comes back in the Recording Information. Comment</i>	Title: This is a demo file
6	Empty line	<i>Not Used (1)</i>	

Line	Description	Remark	Example
7	Names of the scaled units (x; y ₁ ; y ₂ ; ... y _n)	<i>Required</i>	Time; Left_Wing; Right_Wing
8	Units for x and y (x; y ₁ ; y ₂ ; ... y _n)	<i>Required</i>	s; V; A

- (1) The lines with the remark **Not used** may be empty.
- (2) The information in this line is used to set the time of the first sample. The line should start with a text followed by a colon ':' and the date and time in the following format:

[<Year>] <Day of Year> <Time>

Where the field *Year* is optional:

If the field *Year* is not available, the year of the ASCII file's date/time entry will be used.

Examples:

2011 067 11:44:38.054093300
067 11:44:38

The time/date is handled as the UTC time/date of the first sample. This means that the time in the example above can be shown as 12:44:38 in the Perception display if you are in the Amsterdam time zone +1 UTC.

Data:

The samples of the imported data are interpreted as being equidistant.

The data comes after the header and always starts at line 9.

Each data line contains sample information from one or more different channels:

x, y₁, y₂, ... y_n


The x (time) value should be the first value in a line, followed by at least one Y value. The separator between the x and y values can be:

- Semicolon ';'
- TAB '\t'
- Comma ','
- Space ' '

Example of a data line:

0.00015; -0.754458; -0.757576

Example of an ASCII of format type I:



```

AsciiDemo1.txt - Notepad
File Edit Format View Help
File: C:\Ascii Recording Files\AsciiDemo1.txt
Created: woensdag 21 december 2011 11:38:47
Header time format: Absolute
Time of first sample: 067 11:44:38.054093300
Title: This is a demo file

Time;Left_wing;Right_wing
s;g;g
0;-0.411523;-0.360751
5E-005;-0.800183;-0.703464
0.00015;-1.14312;-0.883839
0.00015;-0.754458;-0.757576
0.0002;-0.137174;-0.252525
0.00025;-0.594422;-0.162338
0.0003;-1.37174;-0.270563
0.00035;-1.18884;-0.162338
0.0004;-0.548697;0
0.00045;-0.274348;0.234488
0.0005;-0.502972;0.0360751
0.00055;-0.640146;-0.414863
0.0006;-0.205761;-0.432901
0.00065;-0.0685871;-0.252525
0.0007;-0.38866;-0.288601
0.00075;-0.663009;-0.595239
0.0008;-0.708733;-0.955989
    
```

Figure J.8: Example of an ASCII file for Perception export

ASCII file format II

This format supports the Catman ASCII export format with channel information

Note *The ASCII file must contain a header and a data part.*

Header:

Line	Description	Remark	Example
1	First line	<i>Always has to contain the string: CATMAN</i>	HBM_CATMAN_DATA FILE_40
2	Empty line	<i>Not used (1)</i>	
3	Date	<i>Used (2)</i>	1/16/2012
4	Time	<i>Used (2)</i>	11:29
5	Number of channels	<i>Required</i>	CHANNELS: 17
6	Separator	<i>Required</i>	SEPARATOR: 59
7	Number of data points	<i>Required</i>	MAXLINES: 103
8	Empty line	<i>Not used (1)</i>	

Line	Description	Remark	Example
9	Names of the scaled units (x; y ₁ ;y ₂ ;...y _n)	<i>Required</i>	Time;Left_Wing;Right_Wing
10	Units for x and y (x; y ₁ ;y ₂ ;...y _n)	<i>Required</i>	s;V;A
11	Information	<i>Not used (1)</i>	
12	
...	
x	Empty line	<i>Required</i>	

- (1) The lines with the remark **Not used** may be empty.
After line 10, there can be an arbitrary number of header lines. The end of the header lines will be marked by an empty line. After this line, the data lines will start.
- (2) The information in lines 3 and 4 is used to set the time of the first sample. You may extend the time string with seconds and with a decimal part of a second.

Examples:

11:29

11:29:38

11:29:38.054093300

The date/time is handled as the local date/time.

If the date/time information is not available, the ASCII file's date/time entry will be used.

Data:

The samples of the imported data are interpreted as being equidistant. The data comes after the header and always starts after an empty line. Each data line contains sample information from one or more different channels:

x, y₁, y₂,...y_n

The x (time) value should be the first value in a line, followed by at least one Y value. The separator between the x and y values is defined in the header.

Example of a data line:

0.00015;-0.754458;-0.757576

Example of an ASCII of format type II:




Figure J.9: ASCII file format which supports Catman

Note *When the Catman export ASCII file contains multiple sample rates only the channels recorded at the primary sample rate are read.*

ASCII file format III and IV

The third (Short header) and fourth (Long header) supported file formats have almost the same header. However, the header of the fourth ASCII file is larger and contains more information.

The format is also described in the Perception Analysis Option manual. For more information please, refer to [@ReadAsciiFile](#) function. The only difference is that the ASCII recording loader supports multiple channels.

Note *The ASCII file must contain a header and a data part.*

ASCII file format III (Short header)

Line	Description	Remark	Example
1	Number of header rows	<i>Always 5 for a short header</i>	5
2	Data delimiter (dot, comma, tab or semicolon)	<i>Required</i>	;
3	Number of data pairs	<i>Optional, if empty the loader reads until the last data line</i>	2400
4	Scale factor for x and y (X; Y ₁ ;Y ₂ ;...Y _n)	<i>Optional, if empty scale factors of 1 will be used</i>	1,000E-4;7,570637E-1;4000
5	Units for x and y (X; Y ₁ ;Y ₂ ;...Y _n)	<i>Required Recording Information. Comment</i>	s;V;A

ASCII file format IV (Long header)

Line	Description	Remark	Example
1	Number of header rows	<i>Always 12 for a long header</i>	12
2	Data delimiter (dot, comma, tab or semicolon)	<i>Required</i>	;
3	Number of data pairs	<i>Optional, if empty the loader reads until the last data line</i>	2400
4	Date of data generation	<i>Used (2)</i>	17.03.00
5	Time of data generation	<i>Used (2)</i>	23:59
6	Extra information about producer of the data	<i>Not used (1)</i>	TDG 1.1
7	Comment	<i>Comes back in the Recording Information. Comment</i>	First example: Test 1;
8	Scale factor for x and y (X; Y ₁ ;Y ₂ ;...Y _n)	<i>Optional, if empty scale factors of 1 will be used</i>	1,000E-4;7,570637E-1;4000
9	Units for x and y (X; Y ₁ ;Y ₂ ;...Y _n)	<i>Required Recording Information. Comment</i>	s;V;A
10	Names of the scaled units (X; Y ₁ ;Y ₂ ;...Y _n)	<i>Required</i>	Time;Voltage;Current

Line	Description	Remark	Example
11	Resolution of y-data in bit	<i>Not used</i> ⁽¹⁾	12
12	Use if dynamic range in %	<i>Not used</i> ⁽¹⁾	80

(1) The lines with the remark **Not used** may be empty.

(2) The information for the long header in lines 4 and 5 is used to set the time of the first sample. You may extend the time string with seconds and with a decimal part of a second.

Examples:

11:29

11:29:38

11:29:38.054093300

The date/time is handled as the local date/time.

If the date/time information is not available, the ASCII file's date/time entry will be used.

Data

The samples of the imported data are interpreted as being equidistant.

The data comes after the header and always starts at line 6 or 13.

Each data line contains sample information from one or more different channels:

x, y_1, y_2, \dots, y_n


The x (time) value should be the first value in a line, followed by at least one Y value. The separator between the x and y values can be:

- Semicolon ‘;’
- TAB ‘\t’
- Space ‘ ’
- Dot ‘.’
- Comma ‘,’

Example of a data line:

0.00015;-0.754458;-0.757576

Example of an ASCII of format type III:



```

12
;
2400
10.05.2004
14:24
TDG 1.1
Curve #2 , DC-component = 120ms and increasing RMS , delta(f) = 2,5Hz
1,000E-4;7,570637E-1;4000
S;A;g
Time;Current;Force
12
90
0;0;1
1;0;1
2;0;2
3;0;3
4;0;2
5;0;3
6;0;4
7;0;2
8;0;1
9;0;5
10;0;1
11;0;1
12;0;7
13;0;8
14;0;2
15;0;3
16;0;4
17;0;2
18;0;1
19;0;5
20;0;1
21;0;1
22;0;9.5

```

Figure J.10: ASCII file format (short header)

ASCII file format V

This file format works without a header, it contains only data lines.

Data:

The samples of the imported data are interpreted as being equidistant. The data starts at the first line of the file, the file should contain at least 10 lines. Each data line contains sample information of 1 or more different channels:

$$x, y_1, y_2, \dots, y_n$$


The x (time) value should be the first value in a line, followed by at least one Y value. The separator between the x and y values can be:

- Semicolon ';'
- TAB '\t'
- Space ' '

Example of a data line:

0.00015;-0.754458;-0.757576

Example of an ASCII of format type V:



```

AsciiDemo NoHeader.txt - Notepad
File Edit Format View Help
0.0000;-0.411523;-0.360751
0.00005;-0.800183;-0.703464
0.0001;-1.14312;-0.883839
0.00015;-0.754458;-0.757576
0.0002;-0.137174;-0.252525
0.00025;-0.594422;-0.162338
0.0003;-1.37174;-0.270563
0.00035;-1.18884;-0.162338
0.0004;-0.548697;0
0.00045;-0.274348;0.234488
0.0005;-0.502972;0.0360751
0.00055;-0.640146;-0.414863
0.0006;-0.205761;-0.432901
0.00065;-0.0685871;-0.252525
0.0007;-0.38866;-0.288601
0.00075;-0.663009;-0.595239
0.0008;-0.708733;-0.955989
0.00085;-0.137174;-0.974027
0.0009;-0.0228624;-0.685426
0.00095;-0.48011;-0.306638
0.001;-0.114312;-0.0541126
0.00105;-0.114312;0
0.0011;-0.845908;0.0180375
0.00115;-0.38866;-0.126263
0.0012;0.297211;-0.108225
  
```

Figure J.11: ASCII file format (Without header)

J.3 CSV Recording Loader

Introduction

This chapter describes the Perception CSV file loader:

- How to use the Perception CSV file loader.
- Supported file format

The Perception CSV file loader is part of the Perception software since version 6.22.

J.3.1 Opening a CSV file with the Perception CSV file loader

There are two ways to open a CSV file containing recorded data:

- Using the "Recordings navigator" on page 898.
- Using the "File menu" on page 899.

Opening a CSV file with the Recordings Navigator

CSV data files which have *.csv as their filename extension are accessible through the Recordings Navigator. This navigator uses a tree view to display the various items as an indented outline based on their hierarchical relationship.

Figure J.12 below shows four CSV files which are stored in the **CSV Recording Files** folder.




Figure J.12: CSV Recording Files

A CSV Recording files

For more information about Recordings navigation, please refer to "Recordings navigation" on page 94.

Opening a CSV file with the File menu

To open a CSV file from the File menu:

- 1 Point to **File** ► **Load Recording**




Figure J.13: File menu with Load Recording option

A Load Recording

- In the **Load Recording** dialog, select **CSV Recording Files** in the **Files of type** drop down list.




Figure J.14: Load Recording dialog

- A** Files of type
- B** Load recording area

- In the **Load Recording** area, select how you want to open the CSV file:
 - **As active**
 - **As reference**
 - **Using filename**
- Confirm your selection with the **Open** button.

J.3.2 Supported CSV file format

The Perception CSV loader does not support all possible CSV formats. The limitations of the format are described in this section. Although CSV means 'Comma Separated Variables', the loader also accepts other separator characters, such as a semicolon ';', comma ',', or space ' '. A dot '.' cannot be used as a separator!

Note The ASCII file must contain a header and a data part.
The first line of the header should always start with: **Recording title**

Header:

Line	Description	Remark	Example
1	The file name	Always has to start with "Recording title:"	Recording title: ;TestCSV;
2	Title	Comes back in the Recording Information. Comment	Export title: ;This is a CSV demo file;
3	Header time information	Not used (1)	Header time format is: ;Absolute;
4	Time of the first sample	Used (2)	Time of first sample: 067 11:44:38.054093300
5	Names of the scaled units (x; y ₁ ;y ₂ ;...y _n)	Required	Time;Left_Wing;Right_Wing
6	Units for x and y (x; y ₁ ;y ₂ ;...y _n)	Required	s;V;A

(1) The lines with the remark **Not used** may be empty.

(2) The information in this line is used to set the time of the first sample. The line should start with a text followed by a colon ':' and the date and time in the following format:

[<Year>] <Day of Year> <Time>

Where the field *Year* is optional:

If the field *Year* is not available, the year of the ASCII file's date/time entry will be used.

Examples:

2011 067 11:44:38.054093300

067 11:44:38

The time/date is handled as the UTC time/date of the first sample. This means that the time in the example above can be shown as 12:44:38 in the Perception display if you are in the Amsterdam time zone +1 UTC.

Data:

The samples of the imported data are interpreted as being equidistant. The data comes after the header and always starts at line 7.

Each data line contains sample information from one or more different channels:

x, y₁, y₂,...y_n

The x (time) value should be the first value in a line, followed by at least one Y value. The separator between the x and y values can be:

- Semicolon ';'
- TAB '\t'
- Comma ','
- Space ' '

Example of a data line:

0.00015;-0.754458;-0.757576

Example of a CSV format:




Figure J.15: CSV file format

K File Information

K.1 UFF58 File Format

General information

The **Universal File Formats** (UFF58) and (UFF58b) are standard in experimental dynamics. There are several universal file formats. UFF58 and UFF58b are the most widely used file formats.

One application area which is often used is the modal and structural analysis.

UFF58 Storage mode:

- Header information in ACSII format
- Data information in ASCII format

UFF58b Storage mode of:

- Header information in ACSII format
- Data information in binary format

Ways to import UFF58 and UFF58B files:

- NI Diadem
- NI Sound and Vibration Measurement suite
- Several third-party sound and vibration software packages

K.1.1 Configuration of UFF58 and UFF58b files

UFF58 and UFF58b files are configured in the following way:

- One or more functions
- One or more datasets

The **function** is:

- Delimited by -1 and contains 12 records

Each **record** contains:

- One or more fields

- Records 1 to 11 contain header information
- Record 12 contains the data

If you view an UFF58 or UFF58b file in a text editor:

- The first line is a function delimiter (-1)
- The second line defines whether the file meet the UFF58 or UFF58b standard.
- The subsequent lines contain records 1 to 12

The UFF58 standard allows any information to be in records 1 to 5 but allows only specific information to be in records 6 to 12.

Record	Description
1	Typically contains the function description
3	Typically contains the time and date information about when the file was created
6	Contains the degree of freedom identification
7	Contains the data form, including fields that define the ordinate data type and abscissa spacing
8	Contains the abscissa data characteristics
9	Contains the ordinate or ordinate numerator data characteristics
10	Contains the ordinate denominator characteristics if needed
11	Contains z-axis data characteristics if needed
12	Contains the data

K.2 File extensions in Perception 6.0 or later

In Perception 6.0 and above various file extensions of Perception-related files were modified. Refer to the following table for details.

File extension conversion table

Legacy extension	New extension	Description
LDSesw	pEsw	Embedded software / firmware
LDSFormulas	pFormulas	Formula sheet (Analysis option)
LDSReportData	pReportData	Report saved as compound (Windows) MetaFile
LDSReportLayout	pReportLayout	Report sheet layout
LDSLinkList	pLinkList	Link list for advanced Word reporting
LDSInfo	pInfo	Info sheet data
LDSHPHV	pHPHV	HPHV sheet information
LDSSequence	pSequence	Sequencer sheet (BE3200) data
pSet	pSet	Hardware settings
LDSKey	pKey	HASP key update file
VWB	pVWB	Virtual WorkBench information
PNRF	pnrp	Perception Native Recording File
OfflineConfig	pOfflineConfig	Offline Configuration file

Various file formats for storage and settings are expanded over the years to include more information. HBM, however, always strives for backwards compatibility as much as possible. Therefore reading older files should always be possible although they may not contain all the latest settings. In these situations warnings are generated, but you can always use these older files and save them for upwards compatibility.

L Product Cycle

L.1 End-of-life products

Product supported by Perception

The following products are no longer supported by Perception:

Product	Since
IM1 – Interface Module	Perception V7.30
MultiPro	Perception V7.00.16336
BE256	Perception V7.00.16336
Liberty	Perception V6.70.15224

IM1 – Interface Module

Perception V7.20 is the last version that supports **IM1** Interface Modules.

Interface Modules of type IM1 can be recognized by their serial numbers. Mainframes equipped with the IM1 Interface Module have a serial number starting with **IDJ**. This serial number can be found in Perception by navigating to the **Properties** page of the mainframe (see Figure L.1).




Figure L.1: Properties window of a mainframe with an IM1.

A IM1 Interface Module serial number

Note *The IM1 Interface Module type can also be distinguished from IM2 Interface Module type in the communication area (see Figure L.2).*




Figure L.2: IM1 Interface Module




Figure L.3: End-of-life warning shown in Perception 7.20

M Glossary

M.1 Abbreviations

Abbreviations	Description
AC	Alternating Current
ADC	Analog-to-Digital Converter
ALU	Arithmetic (and) Logic Unit
BER	Bit Error Ratio
BMC	Best Master Clock Algorithm
CAN	Controller Area Network
CANopen	Controller Area Network, a communication protocol and device profile specification for embedded systems used in automation and developed by CiA.
CCP	CAN Calibration Protocol
CD	Compact Disc
CiA	CAN in Automation, an international users and manufacturers organization that develops and supports CAN based higher layer protocols.
CoE	CANopen over EtherCAT®, a CANopen compatible application protocol layer on top of EtherCAT®.
CSI	Custom Software Interface
DC	Direct Current
DHCP	Dynamic Host Configuration Protocol
DPI	Dots per Inch
DTP	Desktop Publishing
DVD	Digital Versatile Disc
ECU	Electronic Control Unit
ETG	EtherCAT® Technology Group, an industrial Ethernet user organization, developing and supporting the EtherCAT® specifications.
FFT	Fast Fourier Transform
FIR	Finite Impulse Response
GND	Ground
GPS	Global Positioning System
HASP	Hardware Against Software Piracy
HPHV	High Power High Voltage

Abbreviations	Description
IEC	International Electrotechnical Commission, a non-profit, non-governmental international standards organization that prepares and publishes International Standards for all electrical, electronic and related technologies.
IP	Internet Protocol
IRIG	Inter Range Instruments Group
iSCSI	Internet Small Computer System Interface
LAN	Local Area Network
MAC address	Media Access Control address
NZR	Non Return to Zero
PC	Personal Computer
PCI	Peripheral Component Interconnect
PDO	Process Data Object, a CANopen specified data object that is updated cyclically.
PLL	Phase Locked Loop
PTP	Precision Time Protocol
RAID	Redundant Array of Independent Disks
RAM	Random Access Memory
ROM	Read Only Memory
RPC	Remote Procedure Call
RPM	Revolutions per Minute
RTC	Real-Time Clock
RTD	Resistance Temperature Detector
SCSI	Small Computer System Interface
SDO	Service Data Object, a CANopen specified data object that is accessible on-demand by means of an SDO request message.
SOAP	Simple Object Access Protocol
TAI	Temps Atomique International (or International atomic time)
TDC	Top Dead Center
TTL	Transistor-Transistor Logic
USB	Universal Serial Bus
UT	Universal Time
UTC	Universal Time Coordinated
VWB	Virtual Work Bench

Index

A	
Absolute time	139, 140, 197
Acquisition	
status	127
Acquisition control	113, 114
Continuous	123
Fast Sweeps	122
Groups	121
Name	117
Slow Sweep	121
Status	120
Acquisition	118
Active cursor	134
Alarm	
Detector	521
Output	521
Aliasing	498
Alt zoom	157
Analog calculated channels	825
Area	825
Energy	825
Maximum	825
Mean	826
Minimum	826
Peak to peak	826
RMS	826
Annotation	135, 197
per tick	140
ASCII file format	
ASCII export with channel information	891
Catman	891
Long header	893
Perception export	888
Short header	893
Without header	896
ASCII Recording Loader	
Introduction	885
Auto placement, cursor	167
Automation Actions	416
Automation menu	404
Actions configuration dialogs	416
Add to Logfile	407
Automated Recording Processing	414
Automation Actions	411
Automation Progress	423
Clear Logfile	407
Configure Logfile	405
Data source	414
Interval selection	413, 415
Logfile	404
Manual logging	405
Merge Files	424
Open Logfile in Excel	407
Quick Report to Word	426
Recordings	414
Recordings Batch Processing	412
Setup Process Display	409
Automation status	127
B	
Basic qualifier	510
Bin size	496
Binary clock base	495
C	
Calculated channels	822
Processing	822
Trigger detector	822
Calculations	183, 184
Area	184
Cycle	184
Pulse	184
Statistics	184
Channels	483
Circular recording	489, 493
Clipboard	245
Clock base	
Binary	495
Decimal	495
Color	62
Color (Trace)	205
Commands	61
Comment	294
Configuration Manager	522, 525
Miscellaneous configuration commands	529
Moving mainframes	527

Open a setup file	525	Cycle source	810
Using mainframes	528	Counter/filter operation	818
Configuring MX471B – MX Assistant	847	Cycle detector	810
Configuring the MX471B		Cycle detector time out	818
CAN bus settings	853	Input signal slew rate limitation	812
CAN signal settings	854	Rate limitation	820
CAN signal settings using a CAN database		State change limitation	816
file	855	Timer	810
Configuring CAN signal minimum/maximum		Cycle source calculated channels	828
value	863	Cycle Frequency	830
Configuring CAN signal repetition time	861	Cycles	828
Configuring CAN signal settings manually ..	859		
Ethernet network setting MX471	848	D	
Configuring the MX471B using the MX Assistant ..	848	Data sources	
Control area	142, 193	Data source naming	51
Control menu	393	Data source types	48
Basic acquisition control	393	Introduction	47
Conditional Start Stop	400	Where are data sources used	49
How to use Perception Voicemark	395	Data Sources Navigator	108
Manual Trigger	394	Data storage	
Pause	393	Circular	124, 493
Reboot System(s)	401	Continuous	487, 493
Single Shot	393	Dual	488
Start	393	Fast sweep stretch storage	492
Stop	393	Individual storage of settings	38
Voicemark	394	Lead-out	493
Zero Balancing	398	Normal	124
Coordinated Universal Time	140	Pre-trigger sweeps	490
Copy	392	Slow-Fast Sweep	488
CSI sheet	72	Specified time	124, 494
CSV Recording Loader		Standard	493
Introduction	898	Stop on trigger	124, 493
Cursor measurements		Sweeps	487, 488
Menu bar	285	Trigger	490
Cursor navigation	178	Decimal clock base	495
Properties	182	Definer Mode menu	366
Cursor values	134, 137, 144	Change a restricted Workbench	368
Table	171	Create a restricted Workbench	368
Cursors		Detailed description	369
Active	134	Introduction	366
Horizontal	132, 163, 169	Password lost	389
Passive	135	Restrictions on toolbars and docking panes	385
Sample snap	166	Use case examples	390
Slope	132, 163, 170	Diagnostic Viewer sheet	327
Vertical	132, 163, 165	Commands	328
Cursors and basic measurements	163	Filter Diagnostics	329
Cut	392	Open diagnostics file	327
Cycle parameters	184		

Operation	327	Slope cursor marker	214
Digital Trigger Modes	499	Slope marker	213
Basic Trigger	505	Time marker	213
Channel Alarm	521	Trace marker	211
Dual Trigger	506	X-range marker	212
Dual-Window Trigger	508	Y-range marker	212
Sequential Trigger	509	Display name	192
Trigger Qualifier	510	Display Setup	191
Window Trigger	507	Control area	193
Digital triggering		Display name	192
Digital Trigger Detector	501	Font	197
Valid Trigger	503	Grid	198
Digitizing	495	Overrange	195
Display		Pages	194
Alt zoom	157	Panels	199
Cursor values	134, 144	Traces	201
Event bar	147	X-annotation	197
Event traces	145	Y-annotation	197
Font	197	Dual-level qualifier	510
Grid	198		
Name	192	E	
Page	130, 187, 194	Edit menu	392
Page control	134	Delete an object	392
Pane	130, 156, 187	Transfer an object	392
Panels	199	End-of-life products	906
Replay control	134, 144	Engineering Format	174
Sweep index	134	Event bar	147
Time control	134, 144, 159	Event counter (trigger)	511
Trace	130, 186, 201	Event traces	145
View	130, 154	Excel	407
View types	131	Exit	366
Views	130	Experiment	40
Y-annotation	135	Explorer	96
Zoom	157, 195	External clock support	221
Display concepts and components		External trigger	499
Pages	267		
Traces	267	F	
Views	267	FFT	496
Display markers		Bin size	496
Automatic markers	217	Frequency resolution	496
Free float marker	215	Fiber status	126
Full display marker	214	Fiber Status sheet	320
Hide	209	Additional commands	326
Marker properties	215	Status information	320
Marker terminology	207	File extensions	905
Place	209	File menu	332
Remove	210		
Show	209		

Archives	347	H	
Auto-configured Experiment	334	Hardware	
Close	344	Connect	83
Continuous data rate	348	Disconnect	86
Continuous data rate gauge	351	Scan for	86
Definer Mode menu	366	Unused	81
Exit	366	Used	80
Export Recording...	356	Hardware navigation	
Hardware not found	336	Add a data acquisition system	82
Load Recording...	354	Add an unlisted system	87
Load settings	338	Add/remove a data acquisition system	82
New blank Experiment	334	Data source selection for display	92
New Sheet	346	Firmware upgrade	89
New...	332	Network conflict	84
Open	335	Recorders and viewing options	91
Open Existing Workbench	339	Remove a data acquisition system	86
Open Experiment	339	Hardware Navigator	80
Open Virtual Workbench...	344	HASP	533
Preferences	365	Help menu	436
Print	363	About Perception	443
Revert to Last Opened Setup.	345	Check for Software Updates	436
Save	339	Diagnostics Folder	437
Save a Copy As...	340	Network Load	438
Save Configuration for Offline Use... ..	346	Performance Tests...	437
Save Virtual Workbench	344	Update Key...	436
Save Virtual Workbench As...	345	Hold off (trigger)	511
Set and Test current storage location	348	Horizontal cursors, see Cursors	169
User Interface Mode	366	Hysteresis (trigger)	502
Workbook	347		
File types	97	I	
Find	168	Image	225, 249
Firmware upgrade	89	Fitting	250
Fitting	250	Information sheet	294
Font (Display)	197	Comment	294
Format		Load Information	296
Engineering	174	Print	298
Scientific	174	Refresh	297
Time	174	Save Information	297
G		Installation	31
GEN2i Instrument Panel mode	366	Installing the software	
Glossary		Install Perception	31
Abbreviations	908	Interval timer (trigger)	511, 514
Grid (Display)	198	Introduction	
Group (of recorders)	483	Cycle Math	807

K		N	
Key, via HASP	533	Navigator	
L		Data Sources	108
Lead-out	493	Navigators	
Legend	303	Archives	95
License	4	Data Sources	79, 431
Load Recording		Hardware	79, 80, 430
File Formats	355	Mainframes	95
Load recording		Properties window	79, 112, 431
as Active	106, 355	Recordings	79, 94, 430
as Reference	106, 355	Visions	95
using Filename	106, 355	Network setup	315
Local disk	487	Rreview/update mainframe network settings ..	316
Logfile	404	Nyquist	498
M		O	
Mainframe	81, 483	Objects for sheets	225
Connect	83	Offline setup	522, 530
Disconnect	86	Creating a setup file	524
Navigator	95, 101	Key	533
Password	86	Offline Setup & Configuration Manager	522
Scan for	86	Open a CSV file	
Manual trigger	499	File menu	899
Master/Sync		Perception CSV file loader	898
Trigger transfer	520	Recordings Navigator	898
Menus	526	Open an ASCII file	
Merge Recordings	882	File menu	886
Basic recording (PNRF) structure	882	Perception ASCII file loader	885
Basic recording merge process	882	Recordings Navigator	885
Meter object	229	Open experiment	105
Add	231	Options	444
Data source	230	Overrange	195
Insert, delete and move	234	P	
Modify	234	Page (Display)	130, 187, 194
Page	246	Control	134, 143
Properties	235	Page (Meters)	246
Replace	233	Page control	143
Type	238	Palettes	66
Update rate	238	Grouping	69
Mouse wheel	160	Moving, docking and sizing palettes	67
		Showing and hiding palettes	66
		Pan zoom area (Display)	157
		Pane (Display)	130, 156, 187, 199
		Passive cursor	135

Password	86	QuantumX in Perception	
Paste	392	Background network details	458
Perception Start-up	42	CAN bus	450
Perception with a QuantumX via a CX27B	480	Combining QuantumX and GEN series	474
Hardware setup	480	Concepts and terminology	449
Synchronization and network setup	481	Configuring a MX1609KB/TB	460
Performance	30, 437	Configuring a MX471B	460
Post	418, 426	Configuring a QuantumX module	460
Precision Time Protocol (PTP)	450	Configuring the hardware via the Settings Sheet	466
Preferences	365	Connection basics	456
Primary trigger level	502	Filters	450
Print		First time connecting	461
Display	190	Identify the hardware	464
Meters	247	Introduction	445
Properties window	112	MX471B specific settings	471
PTP		PTP (Precision Time Protocol)	450
Advanced setup 1: Accurate master	872	Recorders & time base	449
Advanced setup 2: PTP tolerance	873	References	448
Advanced setup 3: Using separate network for data and synchronization	874	Supported QuantumX modules	446
Hardware setup	865	Unsupported features	844
PTP synchronization lost during recording ..	876	QuantumX module in Perception	454
PTP Synchronization status monitoring	866	Multiple QuantumX modules	455
Software setup	866	MX471-B	454
Tethered systems	874		
PTP (Precision Time Protocol)	450	R	
PTP troubleshooting		Real-Time Calculations Explained	
13 second offset	881	Cycle source	810
19 second offset	880	Settings and conflicts	835
32 second offset	880	Real-time calculators - Functions	706
Accuracy not as expected	881	Real-Time Clock	127
Not all mainframes synchronize to the same master	879	Real-time Formula Database/RT-FDB	697
Synchronization keeps getting lost	879	Basic arithmetic operations	702
Unable to synchronize to PTP at all	879	Reboot a mainframe/system	402
Unexpected master is found	879	Reboot System(s)	401
Pulse detector (trigger)	511	Recorder	88, 483
Pulse parameters	184	Recording	
Pulse reject (trigger)	512	Close	107
Pulse width (pulse detector)	513	Load as Active	106, 355
		Load as Reference	106, 355
Q		Load Using Filename	106
Qualifier (trigger)	519	Load using Filename	355
Qualifier modes		Open in new User Sheet	106
basic	510	Recording (noun)	121, 487
dual-level	510	Recording (verb)	483
		Recordings	
		Open	97

Recordings navigation			
Archives	95	Input group/Charge	618
Current acquisition folder	96	Input group/Current loop	637
Data source selection for display	104	Input group/IEPE	629
Externally stored recordings	101	Input group/Marker (Events)	645
Remote access	98	Input group/Resistance thermometers	650
Recordings Navigator	94	Input group/Resistor	665
Archives	95	Input group/Thermocouple	647
Mainframes	95	Input group/Timer-Counter	654
Visions	95	Memory and Time base group	574
Recycle Bin	226	Memory and Time base group/Mainframe ..	574
Reference Recording	106, 355	Real-time calculators - Functions	706
Relative time	140, 197	Real-time calculators group	687
Replay control	161	Real-time calculators group/ RT-FDB Boo-	
Replay waveform	134, 145, 161	lean formulas	699
Requirements	29	Real-time calculators group/Cycle based cal-	
Software	29	culator	687
Resample for Export	360	Real-time calculators group/Cycle Source ..	693
Resolve conflicts	309	Real-time calculators group/Formula Data-	
RTC status	127	base	697
S		Real-time calculators group/RT-FDB Pub-	
Sample snap	166	lishing	781
Scan for mainframes	86	Sensors group	672
Scan for Visions	103	Sensors group/Shunt verification	672
Scientific Format	174	Time base groups	581
Scroll zoom area (Display)	160	Trigger group	786
Search Similar	110	Trigger group/Analog channel	790
Secondary trigger level	502	Trigger group/Calculated Channel	800
Settings Sheet		Trigger group/CAN-Bus channel	797
Alarm group	803	Trigger group/Marker channel	797
Alarm group/Channel	803	Trigger group/Recorder	786
Alarm group/Marker	805	Zero Balance and Calibration	678
Alarm group/Timer-Counter	806	Settings sheet	
Conventions	535	Additional commands	307
General group	536	Block diagram	299, 305
General group/Analog channel	557	Bridge Wizard	309
General group/CAN-Bus	570	Conflicts	309
General group/Mainframe	536	Layout	299
General group/Marker (Events)	563	Layout modes	46
General group/Recorder	552	Load settings	308
General group/Timer/Counter	567	Modifying settings	303
Input group	589	Network and External storage setup	315
Input group/Basic-sensor	599	Power on Setup	317
Input group/Basic-voltage	589	Print Report	313
Input group/Bridge	608	Save settings	308
Input group/CAN-Bus	625	Selection bar	300
		Settings Sheet Reference	534
		Setup external storage	316
		Connection to an external storage device ...	317

Sheet Objects			
Adding and deleting objects	225		
Introduction	225		
Recycle Bin	226		
Sheets	72		
Active	75		
Active sheet	76		
Add objects	226		
Delete objects	226		
Splitters	76		
User sheet	75		
Shortcut keys	119, 143, 159, 167, 186, 187, 189		
Signal trigger	499		
Slope cursors, see Cursors	170		
Slope Trigger	502		
Start dialog options	55		
Start dialog options summary	57		
Start Perception in GEN2i Instrument Panel mode	46		
Starting Perception	33		
Statistics	184		
Status	125		
Acquisition	127		
Automation	127		
Fiber	126		
RTC (Real-Time Clock)	127		
Timer	127		
Trigger	127		
Stop on trigger	493		
Storage	487		
Supported ASCII file formats	888		
Supported CSV file format	900		
Sweep index	134		
System trigger	519		
T			
Time			
Absolute	140, 197		
absolute	197		
Annotation	141		
Linear	140		
Relative	140		
relative	197		
Rotational, 360 degrees per cycle	140		
Rotational, 720 degrees per cycle	140		
UTC	140		
Time base	495		
Binary	495		
Decimal	495		
External	495		
Internal	495		
Real-time sampling	495		
Time Format	174		
Time scale	139, 159		
Timer for Conditional Start Stop	400		
Timer status	127		
Timer/Counter calculated channels	833		
Frequency	833		
Frequency (gated)	833		
RPM of Angle	834		
Title bar (Display)	192		
Title bar (Meter)	229		
Toolbar			
Dynamic	59, 70		
Moving	71		
Showing and hiding	70		
Trace	130, 186, 201		
Color	205		
Trigger			
External	499		
Manual	499		
Signal	499		
Status	127		
Trigger add-ons	511		
Event Counter	518		
Event counter	511		
Hold off	511		
Holdoff	513		
Interval Timer	514		
Interval timer	511		
Interval timer/Between	514, 516		
Interval timer/Less	514		
Interval timer/More	514		
Interval timer/NotBetween	514		
Pulse Detector	512		
Pulse detector	511		
Pulse detector/Pulse detect	512		
Pulse detector/Pulse reject	512		
Slope detector (trigger)	511		
Trigger detector			
Dual-level	502		
Hysteresis	502		
Single-level	501		
Slope	502		

U		W	
UFF58 file format		Wake-on-LAN	836
Configuration	903	Hardware navigator	841
General information	903	Managing mainframes	839
Universal time	140	Perception	837
Update		Technology background	836
Key	436	Trouble shooting	843
Software	436	Warranty	4
Update rate (Meters)	238	Waveform display operation	149
USB	533	Adding traces to a display	149
User interface modes	41	Drag and drop traces	150
Quick start	44	Keyboard and time control to zoom	159
Start Perception in a specific mode	45	Modifying the display layout	153
User modes	41	Modifying the pane size	156
User tables	252	Mouse wheel support	160
Creating	253	Move a trace to a different or new page	153
Data Sources Navigator	254	Replay continuous data	161
Editing data	257	Replay data	161
Insert data	257	Scrolling waveforms on the X-axis	160
Inserting data	253	Separate combined traces	151
Layout	258	Using Display Setup	150
Post to Word	264	Using the Data Source Navigator	149
Posting to Excel	263	Using the Hardware Navigator	149
Properties	255, 262	Using the Recordings Navigator	149
Toolbar	263	Zooming and panning	157
Using Perception to troubleshoot PTP synchro- nization	879	What's new in Perception	34
Using PTP	864	Window menu	430
Why choose PTP	864	Acquisition Controls	432
Why use a synchronization method	864	Automation Progress	432
UTC	140	Battery Status	433
		Cursor Navigation	434
		Data Sources	431
V		Hardware	430
Vertical cursors, see Cursors	165	Properties	431
Video	225	Recording	430
View (Display)	130, 154	Status	433
View types (Display)	131	Toolbars	434
Virtual WorkBench		Windows Explorer	96
Active display	36	Work area	58
User sheet	36	Insert and format a data source	64
Virtual Workbench	36	Notifications	59
Open	344	Workbench	339
Save	344	Workbook	36, 77, 347
Save As	345	Delete	347
Visions		Duplicate	347
Navigator	103	New	347

X

X-annotation	139
X-scale (Display)	141
X-scale (frequency)	498
XY-display	
Add traces to a XY-display	276
Control area	273
Cursor measurements	283
Cursors and basic measurements	282
Dynamic menu	291
Dynamic toolbar	292
Frame cursor control	274
Interaction XY-display/Time display	279
Introduction	266
Link with submenu	291
Linked display	275
Linking	281
Modifying the display layout	276
Remove traces from a XY-display	276
Replay data	279
Shortcut menu	290
Show or hide cursors	283
Split submenu	291
X-annotation area	273
XY-display properties	287
XY-display settings	288
Y-annotation area	272
Zooming and panning	277
XY-display concepts and components	267
XY-display operations	274
XY-display view area in detail	269

Y

Y-annotation	135
Y-annotation per tick	138

Z

Zoom (Display)	157
Zoom style	195

Head Office
Hottinger Brüel & Kjaer GmbH
Im Tiefen See 45
64293 Darmstadt
Germany
Tel: +49 6151 8030
Email: info@hbm.com

France
HBM France SAS
46 rue du Champoreux
BP76
91542 Mennecy Cedex
Tél: +33 (0)1 69 90 63 70
Fax: +33 (0) 1 69 90 63 80
Email: info@fr.hbm.com

UK
Hottinger Bruel & Kjaer UK Ltd.
1 Churchill Court, 58 Station Road
North Harrow, Middlesex, HA2 7SA
Tel: +44 (0) 208 515 6100
Email: info@uk.hbm.com

USA
HBM, Inc.
19 Bartlett Street
Marlborough, MA 01752, USA
Tel : +1 (800) 578-4260
Email: info@usa.hbm.com

PR China
Hottinger Bruel & Kjaer Co. Ltd.
106 Heng Shan Road
Suzhou 215009
Jiangsu
Tel: +86 512 682 47776
Email: hbmchina@hbm.com.cn
Support Email: atsc@hbm.com.cn

© Hottinger Brüel & Kjaer GmbH. All rights reserved.
All details describe our products in general form only.
They are not to be understood as express warranty and do
not constitute any liability whatsoever.

measure and predict with confidence

